

ROV Tools

Torque Tool CI.1-4

Client: FMC Kongsberg Subsea as

Client DR-Code:

Client P/N: 100035992

Oceaneering P/N: 0287700

A	06.03.09	Issued for Project Acceptance	DHD	EW
Rev.	Date	Reason for Issue	Made by	Approved by

Client Doc. No.:

100035992-OMM

Client Logo :

FMC Technologies

Oceaneering AS
P.O.Box 8024
4068 Stavanger, Norway
Phone: 51 82 51 00 - Telefax: 51 82 52 90

Oceaneering Doc. No.

101753-DTS-OPR-008

Rev.

02

Document Title:


Operation & Maintenance Manual

"This document is the property of Oceaneering International Inc., and may not be used for any purpose unless authorized in writing by Oceaneering and which, upon demand, shall be returned to Oceaneering. The document contains Oceaneering confidential, proprietary information and shall not be copied, reproduced, used, transferred to other documents or disclosed to others for any purpose unless specifically authorized in writing by Oceaneering."



Operation and Maintenance Manual

2700Nm Torque Tool ISO 13628-8 Cl.1-4





Operation and Maintenance Manual

Rev.02

Page 2 of 41

Tool Description

101753-DTS-OPR-008

Document No.:	101753-DTS-OPR-008
Title:	2700 NM TORQUE TOOL ISO 13628-8 CL.1-4
Project:	
Oceaneering P/N:	<u>0287700</u>
Oceaneering S/N:	

Client:	
Client P.O:	
Client P/N:	
Client S/N:	

"This document is the property of Oceaneering International Inc., and may not be used for any purpose unless authorized in writing by Oceaneering and which, upon demand, shall be returned to Oceaneering. The document contains Oceaneering confidential, proprietary information and shall not be copied, reproduced, used, transferred to other documents or disclosed to others for any purpose unless specifically authorized in writing by Oceaneering."

02	Issued for Use	20.11.08	EW	TAB	EW
01	Issued for Use	21.02.08	EW	KKA	EW
Rev.	Reason for Issue	Date	By	Check	Approval

Table of content

1	INTRODUCTION.....	5
1.1	PURPOSE AND SCOPE	5
1.2	ABBREVIATIONS	5
1.3	SAFETY NOTES.....	6
1.3.1	<i>Handling and Transportation.....</i>	6
1.3.2	<i>Testing.....</i>	6
1.3.3	<i>Installation/Retrieval.....</i>	6
1.3.4	<i>Operation.....</i>	6
1.3.5	<i>Maintenance.....</i>	6
1.4	CONTACT ADDRESSES	6
2	TECHNICAL INFORMATION AND DATA	7
2.1	TECHNICAL DESCRIPTION.....	7
2.1.1	<i>Interface Description</i>	8
2.2	TECHNICAL DATA	9
3	AUXILIARY EQUIPMENT.....	10
3.1	EQUIPMENT MATRIX	10
4	HANDLING AND TRANSPORTATION.....	11
4.1	HANDLING AND LIFTING	11
4.1.1	<i>Onshore.....</i>	11
4.1.2	<i>Offshore.....</i>	11
4.2	TRANSPORTATION.....	11
4.2.1	<i>Onshore.....</i>	11
4.2.2	<i>Offshore.....</i>	11
5	PRESERVATION.....	12
5.1	PRESERVATION MATRIX	12
6	STORAGE.....	13
6.1	STORAGE MATRIX	13
7	INSTALLATION AND RETRIEVAL.....	14
7.1	PRE-OPERATIONAL/PRE INSTALLATION TEST	14
7.1.1	<i>Function Test.....</i>	14
7.1.2	<i>Pressure Test</i>	15
7.1.3	<i>Flushing.....</i>	16
7.2	INSTALLATION	17
7.3	RETRIEVAL	17
8	OPERATION	18
8.1	DISTURBANCE OF OPERATION	18
8.1.1	<i>Emergency Stop.....</i>	18
8.1.2	<i>Start after Emergency Stop.....</i>	18
8.2	CORRECTIVE MEASURES.....	19
8.2.1	<i>Troubleshooting/Faultfinding.....</i>	19
8.3	HAZARDS AND PROTECTION	20
8.4	QUALIFICATIONS AND TRAINING	20
9	INSPECTION, MAINTENANCE & REPAIR	21
9.1	INSPECTION MATRIX.....	21
9.2	PREVENTIVE MAINTENANCE.....	21
9.2.1	<i>Pre/post Operational Preventive Maintenance Matrix.....</i>	21



Tool Description

101753-DTS-OPR-008

9.3	CORRECTIVE MAINTENANCE	23
9.3.1	Assembly/Disassembly	23
9.3.1.1	Hydraulic Motors	23
9.3.1.2	Shaft assy	25
9.3.1.3	Mechanical rotation indicator	26
9.3.1.4	Latch assy	27
9.3.1.5	Tool nose	28
9.3.1.6	Torque bucket and gear	29
9.3.1.7	Motor flange and motor	31
9.3.1.8	Turn counter	33
9.3.1.9	Fittings	34
9.3.1.10	Rov handle	35
9.3.1.11	Low torque assy	36
9.3.1.12	Changing from OMSS motor w/ turn counter to the OMM Motor w/ turn counter	37
9.3.1.13	Hydraulics	38
9.3.2	Repair	39
10	SPARE PARTS	40
10.1	SPARE PARTS LISTS INDEX	40
11	REFERENCED DRAWINGS, DOCUMENTS AND DATA SHEETS	41
11.1	DRAWING INDEX	41
11.2	DOCUMENT INDEX	41
11.3	TECHNICAL DATA SHEETS INDEX	41

1 Introduction

This User Manual contains operation and maintenance instructions for the 2700 Nm Torque Tool ISO 13628-8 Cl.1-4. The Torque Tool is intended for operation directly from an ROV or via an Oceaneering provided Remote Control Unit (RCU).

For operation of the RCU, please refer to the RCU User Manual.

It is suggested that the ROV operators read this manual thoroughly prior to mobilization for offshore work in order to familiarize them selves with the tooling package and to allow time for fabrication of any mounting hardware required to adapt the tooling to the specific ROV being utilized.

1.1 Purpose and Scope

The purpose of this manual is to give instructions to install, operate and maintain the following equipment as supplied by Oceaneering AS:

OAS P/N	Title
0287700	2700 Nm TORQUE TOOL ISO 13628-8 Cl.1-4

The manual is to be used by trained and competent personnel only.

1.2 Abbreviations

The following abbreviations are used in this manual:

Abbreviation	Title
TT	Torque Tool
CW	Clockwise
CCW	Counter Clockwise
OMM	Operation and Maintenance Manual
P/N	Part Number
S/N	Serial Number
SJA	Safe Job Analysis
ROV	Remote Operated Vehicle
RCU	Remote Control Unit
HPU	High Pressure Unit
TJ	Test Jig
BOM	Bill Of Material

1.3 Safety Notes

1.3.1 Handling and Transportation

- Visually inspect condition and certification on lifting/ handling equipment.
- Always wear steel toed-shoes when handling the Torque Tool or Transportation Box.
- Always secure Transportation Box with straps to transportation basket/deck when transporting

1.3.2 Testing

- Always wear safety glasses when testing and operating pressurized equipment.
- Secure area around tools when operating Torque Tool in Test Jig.

1.3.3 Installation/Retrieval

- Visually inspect the Torque Tool for mechanical damage.

1.3.4 Operation

- Verify that the Torque Tool is secured to ROV before each dive.
- During handling of MQC plates with the Torque Tool, pressure applied to the latch mechanism should not be lower than 100 bar.

1.3.5 Maintenance

- Always wear safety gloves when performing maintenance on oilfilled equipment.
- WARNING: Special attention has to be taken during handling off the OMSS hydraulic motors. The splined shaft can drop out if motor is turned with the splined shaft down. A small washer will then fall off the taco shaft. This will prevent the splined shaft to engage with the valve drive and the taco shaft. See also "Danfoss Service Manual" in the appendix.

1.4 Contact Addresses

Oceaneering Norway:
Jåttåvågen, Hinna
P.O. Box 8024
4068 STAVANGER
NORWAY

Switch Board: +47 51 82 51 00
Duty Phone: +47 90 64 44 77

2 Technical information and data

2.1 Technical Description

The 2700 Nm Torque Tool ISO 13628-8 Class 1-4 is able to operate rotational Valves from 35 Nm up to 2700 Nm, Latch and handle MQC plates, SCM Override Tool etc. according to the modified Intervention Fixture, ISO 13628-8 App. C, Docking/rotary, Latch Class 1, 2, 3 and 4.

The tool is equipped with the following instruments:

- A turn counter giving the actual number of turns in 0,1 resolution (readable by the ROV camera).
- Mechanical Turn Counter Indicator (readable by the ROV camera).
- Hydraulic Latch System.
- Torque Feedback (based on strain gauge).

The 2700 Nm Torque Tool ISO 13628-8 Class 1-4 transmits torque from a hydraulic motor, through a gearbox and a socket to the valve stem. Reaction forces are transferred to the docking receptacle.

The tool can be mounted onto flying lead orientation tool, tool elevator or be deployed by ROV manipulator.

The 2700 Nm Torque Tool ISO 13628-8 Class 1-4 will maintain its position in the receptacle by gravity (vertical valve stems) or by use of horizontal ROV thruster capacity or latch mechanism (horizontal valve stems).

The latch system is designed to interface with the ISO 13628-8 Class 1-4 docking receptacle internal profile. It consists of two hydraulic mini-cylinders with a spring return. When hydraulic pressure is applied, the cylinders will push two latch dogs into the docking receptacle profile. The springs ensure return of the dogs.

The latch dogs are mounted in such a way that the axial forces between the tool and the receptacle are transferred through the dogs, but not through the hydraulic mini cylinders. The only force taken up by the cylinders is the push/pull force to extend/retract the dogs. The latch dogs have a rounded profile which, combined with the spring return force, will force the dogs back into the tool body if a pull force is applied on the tool, in event of loss of hydraulic power.

The turn counter consists of an electronics canister and a magnet wheel. The canister contains the counter electronics, display and sensors as well as batteries and is equipped with a MCBHRA8MSS bulkhead connector, providing power/ battery charging input. The turn counter is powered from a battery when not connected to the RCU. It is equipped with a power saving feature providing temporary shut down if no rotation is detected within 3 minutes. When powered from the battery, the turn counter is turned ON by connecting a supplied linked connector or the RCU to the MCBHRA8FSS bulkhead connector on the counter. Removing the linked connector or the RCU turns the counter OFF. The linked connector has a yellow marking. There is also a low battery warning "Lob" displayed on the display when the battery is near to be discharged. The turn counter is powered from the RCU when the RCU is connected.

The turn counter batteries are charged using the provided battery charger and cable. Charging is done by removing the plug connector on the turn counter, connecting the battery charger cable to the turn counter, and connecting the charger to a 220/110VAC 50/60Hz outlet

Tool Description

101753-DTS-OPR-008

2.1.1 Interface Description

MECHANICAL INTERFACE

Interface to	Interface Type
ROV	ROV Handle
Valves, MQC plates, SCM override Tool, etc	ISO 13628-8 Class 1-4

HYDRAULIC INTERFACE

Interface to	Interface Type
RCU or ROV	Hydraulic Hoses

ELECTRICAL INTERFACE

Interface to	Interface Type
RCU	Electrical Cable

Tool Description

101753-DTS-OPR-008

2.2 Technical Data

Size:	Ø =300 mm x L= 600 mm (11 ¾" x 23 ½")
Weight in air:	40.0 kg (88 lbs)
Submerged in water:	30.0 kg (66 lbs)
Depth rating:	2500 m (8200 ft)
Operating Temperature:	-10 to +60°C
Hydraulic Motor type:	Danfoss OMSS 200 and OMM 32
Pressure max:	210 bar (3045 psi)
Test pressure (hoses):	310 bar (4495 psi)
Hydraulic connections:	
-Motor:	Parker fluid connector JIC No 8
-Tool Drain:	Parker fluid connector JIC No 4
-Latches:	¼" Swagelok
Hydraulic hoses:	2-off 4-meter (13 ft) 3/8" with JIC 8 swivel and JIC 8 90° swivel 1-off 4-meter (13 ft) 1/4" with JIC 4 swivel in both ends 1-off 4-meter (13 ft) 1/4" with ¼" Swagelok and JIC No 4 swivel
Torque output:	
OMSS 200	250 – 2700 Nm (185 - 2000 lb.ft)
OMM 32	26 – 300 Nm (19 - 222 lb.ft)
Torque multiplier:	HT-5 1/5 ratio
Turns Counter:	
Mechanical:	2-off, indication of 0.5 revolution
Electronic:	Indication of 1/10 revolution and up to 99.9 revolution
Battery Type:	5 x YUASA HRY2300A Nickel-Metal Hybrid Rechargeable 6 VDC nominal (1.2 VDC x 5) @ + 20° Celsius (68°F) 2300 mAh @ + 20° Celsius (68°F)
Battery Charger:	Battery Charger - NiCd. for turn counter Spec.: charge current 2.0 A Connector type MCIL8F (PIN 1-Pos., PIN 3-Neg.)
Charging current:	2.0 A
Charging time:	ca. 1.5 hrs full charge
Battery time:	ca. 100 hrs at 20mA average load.
Electrical connection:	Subconn MCBHRA8FSS
Battery charger:	Friwo FW 7304/10
Valve interface:	ISO 13628-8 Class 1-4
ROV manipulator interface:	Vertical- and Horizontal interface
Transport box size LBH:	800 mm x 600 mm x 400 mm (32 x 24 x 16 in)

3 AUXILIARY EQUIPMENT

3.1 Equipment Matrix

Item	Handling / Transport	Testing	Installation / retrieval	Operation	Maintenance
RCU/ HPU		X	X	X	
Testjig CI.4		X	X		
Typical Tools. Allen Keys, Wrench and sockets		X			
ROV			X	X	

4 Handling and Transportation

Item Weights

Item	Weight in Air (kg)	Weight in water (kg)
Torque Tool ISO 13628-8 Class 1-4	40	30
Transport Box with inventory	95	N/A

Item Measurements

Item	Length (mm)	Width (mm)	Height (mm)
Torque Tool ISO 13628-8 Class 1-4	740	Ø300	N/A
Transport box Size	800	600	400

4.1 Handling and Lifting

4.1.1 Onshore

Storage box includes interface to pallet jack for handling. Lifting of Torque Tool itself performed with crane to lift eye, or ROV handle if mounted.

4.1.2 Offshore

For topside handling, see section [4.1.1 Onshore](#). For subsea handling use ROV.

4.2 Transportation

4.2.1 Onshore

The Torque Tool shall be transported in Aluminium transportation box. Secure box with straps.

4.2.2 Offshore

See section [4.2.1 Onshore](#)

5 Preservation

Place the tool and spare parts into the storage/shipping container. Verify that the tool and spare parts are secured properly to prevent damage during transportation.

5.1 Preservation Matrix

Action	Prior to Shipment	Mobilization	Demob / Prior to Storage	Before / After Use
Fresh water rinsing of the tool			X	X
Repair damages (paint; hydraulic fittings and pipes etc.)			X	X
Perform flushing of tool as per 7.2.1 Flushing			X	X
Perform calibration of TT				X
Spray the complete TT with protective oil WD-40 or equivalent			X	X
Disassembly of the tool to subassembly level, rinsing and relubricating each component (Repetition for stored tool every 6. month)			X	
Complete disassembly of tool and replace all seals, every 2. year	X	X	X	X
Charge the turn counter battery pack		X	X	X
Preservation performed as described above	Date:		Signature:	

6 Storage

- High storage temperature can cause damage to seals
- The equipment should be stored and transported in a non-corrosive environment.
- Location: Indoor, in its transportation box
- Sunlight: Minimal.

6.1 Storage Matrix

Action	Onshore Storage	Offshore Storage
Store the tool in its dedicated transportation box indoor.	X	X
Make sure that the Transport Box is complete according to the inventory list	X	X
Preservation performed as described above	Date:	Signature:

7 INSTALLATION AND RETRIEVAL

7.1 Pre-operational/Pre Installation Test

7.1.1 Function Test

Item/Step	Task Description	Date	Sign
1	<p>Connect the hoses directly to the ROV or to the RCU. In order to prevent Motor damage caused by overpressure, ensure that Motor drain is properly connected and unrestricted.</p> <p>Verify Tool Socket rotation and latch mechanism.</p>		
2	<p>Turn the turns counter ON by connecting the Linked Dummy connector to the 8-pin connector. Check counter function and that the socket rotates freely.</p> <p>NOTE: The turn counter will enter sleep mode, i.e the display will become dark, after 3 min. This function is implemented for power saving when powering from the battery. The Turn Counter will light up immediately with the same value that it had before entering sleep mode when the TT is rotated. To reset the Counter, disconnect the "special switch" and reconnect it.</p>		
3	<p>Insert the TT in a TJ and apply specified operation Torque/ Pressure to the tool by adjusting the Pressure Relief valve setting. Read the torque applied to the Test Jig on the Readout Unit</p>		
4	<p>Install the TT onto ROV manipulator with hoses "up". Ensure that the hydraulic hoses leave enough slack for manipulator operation.</p>		
5	<p>When TT is deployed from ROV manipulator, secure the TT to the manipulator and use an extra wire attached between TT and the ROV.</p>		

Tool Description

101753-DTS-OPR-008

7.1.2 Pressure Test

This test applies to the hydraulic Latches circuit only. The Motor shall not be pressure tested.

- ANY HYDRAULIC FITTING/PORT, WHEN LEFT DISCONNECTED, MUST BE CAPPED OFF WITH A CLEAN, PURPOSE MADE BLANKING CAP OR OTHER TEMPORARY CAPPING DEVICE. THE CAPPING DEVICE MUST BE INSPECTED VISUALLY FOR SIGNS OF CONTAMINATION PRIOR TO FITTING.
- PRIOR TO CONNECTION OF ANY TEST EQUIPMENT, VERIFY THAT SUCH EQUIPMENT IS COMPATIBLE WITH THE HYDRAULIC FLUID TO BE USED FOR TESTING.

WARNING:

- ENSURE THAT THE TEST AREA IS PROPERLY MARKED, RESTRICTED AND SECURED PRIOR TO START – UP OF TEST.
- NEVER ATTEMPT TO CONNECT, DISCONNECT OR TIGHTEN A LEAKING HYDRAULIC FITTING WHILE PRESSURISED.
- ALWAYS WEAR SUITABLE PROTECTIVE CLOTHING AND SAFETY GLASSES WHEN THERE IS A POSSIBILITY FOR CONTACT WITH HYDRAULIC FLUIDS.
- DO NOT CHECK PRESSURE LEAKS WITH BARE HANDS. HIGH PRESSURE FLUID CAN PIERCE YOUR SKIN.

Item/Step	Task Description	Date	Sign
1	Connect an external hydraulic power source (Enerpac) to the hydraulic line for the latches.		
2	Connect an isolation valve and a test manometer in the circuit.		
3	Pressure up to 210 bar and isolate with the valve.		
4	Let the pressure stabilize		
5	Check for pressure drop according to holding time		

Pressure test acceptance criteria:

- 2% Pressure variation and no visible leaks
- 5min. Hold Period.

Tool Description

101753-DTS-OPR-008

7.1.3 Flushing

WARNING:

- ENSURE THAT THE TEST AREA IS PROPERLY MARKED, RESTRICTED AND SECURED PRIOR TO START – UP OF FLUSHING.
- NEVER ATTEMPT TO CONNECT, DISCONNECT OR TIGHTEN A LEAKING HYDRAULIC FITTING WHILE PRESSURISED.
- ALWAYS WEAR SUITABLE PROTECTIVE CLOTHING AND SAFETY GLASSES WHEN THERE IS A POSSIBILITY FOR CONTACT WITH HYDRAULIC FLUIDS.
- DO NOT CHECK PRESSURE LEAKS WITH BARE HANDS. HIGH PRESSURE FLUID CAN PIERCE YOUR SKIN.
- DURING ALL FUNCTIONAL TESTING AND ON-DECK OPERATION OF THE TT, SUFFICIENT COOLING OF THE HYDRAULIC OIL MUST BE ENSURED TO AVOID TOO HIGH TEMPERATURE IN THE MOTOR. OIL TEMPERATURE TO BE HELD BELOW 50 DEG. C.

Item/Step	Task Description	Date	Sign
1	Connect the TT to a test HPU or similar with clean oil		
2	Run the TT for 10 min.		

Flushing acceptance criteria, on site:

- NAS1630/SAE AS4860 class 8
- Water content less than 500 ppm

Flushing acceptance criteria, after maintenance:

- NAS 6
- Water content less than 250 ppm

Cleanliness chart

Cleanliness chart with date/sign and KOP Part/Serial number must be attached

Cleanliness	Comments	Date	Sign

Tool assembled after flushing	Date	Sign

7.2 Installation

Installation to seabed

The following is a description of the installation of the Torque Tool, from vessel deck to landing on the sea bed. Status prior to start of installation is:

- The subsea operation programme has been prepared
- The subsea operation area is inspected and prepared.
- The Torque Tool is on deck and fitted to the ROV, ready for installation

Normal installation

Initial Requirements: Pre survey completed, any marine growth covers or debris removed.

- Perform post survey of the area, and find a stable position for the ROV to operate the Torque Tool (Grabber Bar or Landing platform).
- Check valve position indicator. Write down the valve position.
- Insert the Torque Tool in the receptacle. Rotate the tool opposite of operation direction until the valve stops against end stop. Confirm proper docking. This will be observed when the turn counter stops. Note the turn counter number.
- Latch on to the receptacle

7.3 Retrieval

- Retract latches
- Disengage the Torque Tool from receptacle
- Visually observe valve indicator and confirm that the valve is in correct position.

8 Operation

After successful installation:

- Activate tool in operation direction and observe the Turn Counter in the rear end of the Torque Tool.
- Release torque when the required number of rotations has been performed, or valve stem has reached end position.

NOTE: DURING HANDLING OF MQC PLATES WITH THE 2700 Nm Torque Tool ISO 13628-8 Class 1-4, PRESSURE APPLIED TO THE LATCH MECHANISM SHOULD NOT BE LOWER THAN 100 BAR

8.1 Disturbance of Operation

8.1.1 Emergency Stop

The latch mechanism is fail-safe, i.e. the spring return in combination with the shape of the Latches ensures TT release in the case of ROV power loss.

The following is a procedure for emergency retrieval of the TT from its installed position in the subsea Bucket, if hydraulic control to unlock the Latches is lost. It is dependent on the hydraulic valves controlling the TT are connected to "Open centre" valves.

Item/Step	Task Description	Date	Sign
1	Centralize the hydraulic control valve, thereby opening hydraulic flow to drain from both ports of the TT		
2	Now depressurised, the hydraulic Latches will move to "Open" position when the TT is pulled out of the Bucket by the ROV.		
3	Bring to surface to locate source of malfunction, and repair. A power/ hydraulic failure of the ROV/RCU would result in a "dead" vehicle recovery and would be accomplished as per the ROV operations instructions.		

8.1.2 Start after Emergency Stop

Verify that hydraulic control valves on RCU are in mid position to prevent unexpected activation of TT.

8.2 Corrective Measures

8.2.1 Troubleshooting/Faultfinding

- Hydraulic leakage:**

Item/Step	Task Description	Date	Sign
1	Check Torque Tool Body, motor, fittings and hydraulic connections.		
2	Check for water ingress in Torque Tool body and ROV reservoir. Locate and repair the leakage, drain water and flush with clean oil.		

- Torque not available / tool socket will not turn:**

Item/Step	Task Description	Date	Sign
1	Check hydraulic supply / return from ROV		
2	Check weak link (Gear Spline) See section 9.3.1 Assembly/Disassembly for disassembly of tool		
3	Check motor for internal wear / leakage: Insert the Torque Tool into the Test Jig. Disconnect the drain line from the ROV, apply 120 Bar on the supply line and measure the leakage over the motor through the drain line with a flowmeter. Specification to be found in the Danfoss service manual		
4	Check oil temperature. Not to exceed 30°C		

- Turn counter not responding**

Item/Step	Task Description	Date	Sign
1	Check that turn counter is ON.		
2	The batteries may be discharged. Recharge the batteries.		
3	Check for water ingress in turn counter housing. If electronic components are damaged, return for repair.		

Tool Description

101753-DTS-OPR-008

- **No torque feedback:**

Item/Step	Task Description	Date	Sign
1	Check conductivity on torque feedback cable and connectors		
2	Check condition of torque bucket, see section 9.3.1 Assembly/Disassembly for disassembly of tool		

Other critical problems caused by external systems are:

- **Loss of ROV power**

The tool latches on to the subsea equipment. However, the latch mechanism is fail-safe, i.e. the spring return in combination with the shape of the latches ensures tool release in the case of ROV power loss. Any emergency or failure condition of the tool should result in returning the ROV to the surface. A power / hydraulic failure on the ROV would result in a "dead" vehicle recovery and would be accomplished as per the ROV operations instructions.

- **Incorrect calibration of instruments**

8.3 Hazards and Protection

Ref. section [1.3 Safety Notes](#)

8.4 Qualifications and Training

Equipment must be operated by qualified personnel only.

9 Inspection, Maintenance & repair

9.1 Inspection Matrix

1. Daily/After every dive	2. Weekly	3. Monthly
Inspect Latch Cylinder for hydraulic leakage.	Inspect movable parts for mechanical damage and lubrication	Inspect welded joints for mechanical damage. (Handle)
Inspect bolts on TT for loosening. Tighten if necessary.		
Inspect hydraulic hoses / fittings for leakage and mechanical damage.		
Inspect electrical connector on turn count and torque feedback for mechanical damage.		Inspect surface coating on hydraulic motor.
Preservation performed as described above	Date:	Signature:

9.2 Preventive Maintenance

9.2.1 Pre/post Operational Preventive Maintenance Matrix

Action	Prior to / after use	Prior to / after shipm.	Mob.	Demob	During Storage (every 12 months)
Clean the TT with fresh water to remove all traces of salt. Remove excess water using compressed air.	X			X	
Inspect markings and refresh the paint as required according to manufacturer instructions	X		X	X	X

Tool Description

101753-DTS-OPR-008

Action (Cont.)	Prior to / after use	Prior to / after shipm.	Mob.	Demob	During Storage (every 12 months)
Check the hydraulic fluid for water intrusion. If present, thoroughly flush the unit with clean hydraulic oil.	X			X	
Check for loose hydraulic fasteners and fittings. Tighten fittings as required.	X		X	X	X
Perform flushing of TT as per 8.1.2. Pre-Installation Testing				X	X
Perform leak/ function test of TT as per 8.1.2. Pre-Installation Testing	X		X	X	
Perform pressure test of TT as per 8.1.2. Pre-Installation Testing	X		X	X	
Perform calibration of TT	X		X		
Charge battery of turns counter	X		X		
Spray all parts of TT with protective oil such as WD-40 or similar					X
Inspect Hubs and fit Protection Caps	X		X	X	X
Report observations and correct (repair or replace with new) all divergences.	X	X	X	X	X
Preventive Maintenance performed as described above	Date:		Signature:		


9.3 Corrective Maintenance

9.3.1 Assembly/Disassembly

This section provides assembly instructions for the 2700 Nm Torque Tool ISO 13628-8 Class 1-4. The tool uses metric components except for the Norbar Hand torque gearbox and hydraulic fittings. No special tools are required to assemble the tool. The item name in the assembly instruction refers to the item names in the BOM of the tool drawings.

9.3.1.1 Hydraulic Motors

Oceaneering modifies the OMM 32 and OMSS 200 Motor before install in the 2700 Nm Torque Tool ISO 13628-8 Class 1-4.




The illustration above shows the motor, Turn Counter Bracket and it's bolts. The bracket is fastened to the motor with the 4-off M5x10 DIN7991 Bolts. The 4-off M10x20 DIN933 Bolts holds the Turns Counter assembly. The Turn Counter assembly is described later in this manual.

Tool Description

101753-DTS-OPR-008


NOTE:

SPECIAL ATTENTION HAS TO BE TAKEN DURING HANDLING OFF THE OMSS 200 HYDRAULIC MOTOR. THE SPLINED SHAFT CAN DROP OUT IF MOTOR IS TURNED WITH THE SPLINED SHAFT DOWN. A SMALL WASHER WILL THEN FALL OFF THE TACO SHAFT. THIS WILL PREVENT THE SPLINED SHAFT TO ENGAGE WITH THE VALVE DRIVE AND THE TACO SHAFT. SEE ALSO "DANFOSS SERVICE MANUAL IN THE APPENDIX.



- Place the Motor Adapter with the spring into the Motor Adapter Bearing.
- Mount 3-off M5x35 DIN912 through Motor Adapter Plate, Motor Adapter Bearings and Motor Adapter Spacers into the OMSS Motor as shown above.

9.3.1.2 Shaft assy




- Clamp the bronze alloy Glide Ring onto the Shaft. The Glide Ring shall be mounted so that its two M5 holes are farthest away from the largest diameter shaft flange.
- Insert the Cam Bolt in the Glide Ring and into the cam track on the Shaft. Make sure the Glide Ring is free to whirl around about the Shaft
- Mount Parker Seal into the Seal Housing after lubricating it with silicone grease
- Mount the Seal Housing (Pack Box) with Parker seal and Bearing onto the Shaft and secure with the Seeger Ring. **NOTE: The Parker Seal is to be mounted with the U-lip in position like shown in figure above, so that the inside oil pressure forces the lip to seal.**
- Prior to installing Seal Housing (Pack Box), lubricate the O-ring 2-238 with silicon grease and place it into the O-ring groove on the Seal Housing as shown above.
- Install the Shaft, large flange end first into the Tool Body. Direction of installation is from top of the Tool Body and through

Tool Description

101753-DTS-OPR-008

9.3.1.3 Mechanical rotation indicator




- Insert a M5 bolt through the Link as shown on above.
- Screw the M5 bolt into the Glide Ring, which now should be located inside the Tool Body. After no more turns are possible rewind two revolutions.
- Insert the Indicator Flag into slot on Tool body.
- Insert Rod into Tool body and through the Link.

Tool Description

101753-DTS-OPR-008


- Screw the Rod into Indicator Flag before Rod head is screwed into the Link. Repeat on other side.
- Make sure that mechanical indicators run freely up and down when Shaft is rotated.

9.3.1.4 Latch assy

- Place the spring onto the Piston
- Place a O-ring 13,1x1,6 into the O-ring groove on the Piston
- Place a O-ring 18,77x1,78 onto the Latch Cylinder
- Mount the Piston into the Latch Cylinder
- Mount the Latch Cylinder into the Tool Body
- Mount the Latch Dog into the Tool Body and lock it to the Cylinder by turning the Piston counter clockwise.
- Repeat on other side.

Tool Description

101753-DTS-OPR-008


9.3.1.5 Tool nose

- Mount the 4-off Pom guides to the Tool Body with M6 Bolts.
- Mount the Tool Nose to the Tool Body with 6-off M6 Bolts.
- Mount the Socket and fasten with the M6 Bolt.


Tool Description

101753-DTS-OPR-008

9.3.1.6 Torque bucket and gear



- Insert the connector into tool body, fasten with the washer and nut
- Lubricate the o-ring with silicon grease and insert to o-ring groove.
- Insert the 4-off parallel pins into the tool body




- Solder the blue wire on the Torque Bucket to pin 1 on the pre-mounted MCBHRA4MSS connector on the Tool Body. (Wires on connector are marked with pin no.) Leave sufficient wire length for Torque bucket to be mounted correct.
- Solder the red wire on the Torque Bucket to pin 2
- Isolate the soldered area on each wire with a shrink tube.


Tool Description

101753-DTS-OPR-008

- If available, the shield from the Torque Bucket is to be solder to pin 3 (Ground)
- Cut wire on pin 4 as close to the connector as possible.
- Handle the wires carefully when mounting the Torque Bucket.




- Insert the Gear spline into the square on top of the shaft in the tool body
- Insert the Support ring over the shaft bearing
- Insert the HT5 Gear into the Torque Bucket, fasten with the 4-off 2BA x 25 bolts.
- Insert the bucket carefully into the tool body, without pinching the wires.

9.3.1.7 Motor flange and motor

- Lubricate the O-rings with silicone grease.
- Place the O-ring 2-255 into the groove in the Motor Mounting Flange
- Use 8-off M10 bolts to mount the Mounting Flange.
- Place the O-ring 2-242 on top of the Mounting Flange in the O-ring groove.

Tool Description

101753-DTS-OPR-008



- Place the OMSS Motor with Motor Adaptor onto the Motor Mounting Flange.
- Turn the Motor adaptor and motor until the Adaptor fits into the Gear Box.
- Mount the Motor to the Motor Flange with 4-off M10x30 with Washers.
- Mount the Magnet Wheel to the motor with the opening for the magnets facing down.
- Lock the Magnet Wheel to the Motor Shaft with 2-off M5x16 DIN912 bolts.


9.3.1.8 Turn counter

- Place the Turn Counter onto the M10x20 DIN933 on the Turn Counter Bracket. .
- Rotate the Turn Counter Body Clockwise and tighten the M10x20 DIN933 Bolts to lock the Turn Counter in Position

Tool Description

101753-DTS-OPR-008

9.3.1.9 Fittings




- Fittings to be fastened to tool body like shown above

9.3.1.10 Rov handle

- Fasten the handle of choice with the 2-off M12 bolts from underneath


Tool Description

101753-DTS-OPR-008

9.3.1.11 Low torque assy


- Lubricate the O-ring 2-036 with Silicone grease and install it on top of the Motor Mounting Flange
- Place OMM32 Motor onto the Motor Mounting Flange and fasten with M6 Washers and Bolts
- Screw the Distance Piece and the Threaded Rods into the Motor Mounting Flange.
- Install the Subconn Connector MCBH4MSS to the Motor Mounting Flange.
- Mount the turn counter on top of the Distance Pieces and fasten with Washers and Nuts.
- Connect up the Cable between the turn counter and the Motor Mounting Flange and secure with locking Sleeves
- Install the Sensor Card on the Motor Mounting Flange and secure with M3 Washers and Screws.
- Insert the Motor Adapter with Magnets.
- Lubricate O-ring 2-255 with Silicone grease and install it on the bottom of the Motor Mounting Flange.


9.3.1.12 Changing from OMSS motor w/ turn counter to the OMM Motor w/ turn counter



- Remove the M10 bolts and carefully pull the OMSS 200 Motor Assy w/ turn counter off the tool body as shown above.
- Place the O-ring 2-255 into the O-ring groove in the Motor Mounting Flange of the OMM Motor Assembly as shown below to the left
- Mount and secure the OMM 32 Motor Assy to the Tool Body with the M10 bolts.
- Reverse the process to change back to the OMSS 200 Motor Assy.

The torque ranges for the motors are described in the specifications in section [2.2 Technical Data](#)

9.3.1.13 Hydraulics




Hoses with fittings are listed in the [2.2 Technical Data](#)

- Connect the 2-off 4 m (13 ft) long 3/8" hoses from the Torque Tool Motor directly to the ROV tool outlet or to the RCU. Verify tool socket rotation direction.
- Connect the 4 m (13 ft) long 1/4" hose from Motor drain located on the Tool body directly to the ROV reservoir or to the RCU drain / tank line.
- Connect the 4 m (13 ft) long 1/4" hose from the latch system on the Tool Body directly to a spare directional valve on the ROV or to the RCU.


NOTE:

- The latch system must be connected to an open centre directional valve (A and B Connected to the tank)
- The drain hose must be connected to the tool before operation. If the tool is operated without the drain function the tool will most probable be damaged due to high internal pressure.

	Operation and Maintenance Manual		Rev.02	Page 39 of 41
	Tool Description		101753-DTS-OPR-008	

9.3.2 Repair

For repair of Torque Tool it is recommended to locate the faulty/damaged part and change it with a new spare part.

	Operation and Maintenance Manual	Rev.02	Page 40 of 41
	Tool Description	101753-DTS-OPR-008	

10 Spare Parts

10.1 Spare Parts Lists Index

OAS Doc. No	Client Doc. No.	Title
101753-DTS-LST-006	N/A	Sparekit Torque Tool Body Latch

11 Referenced drawings, documents and Data Sheets

11.1 Drawing Index

OAS Doc. No	Client Doc. No.	Title
0287700	100035992	GA-drawing Torque Tool ISO 13628-8 Cl.1-4
0312890	N/A	GA-drawing Low Torque Assy
0299487	N/A	GA-drawing Torque Feedback Cable

11.2 Document Index

OAS Doc. No	Client Doc. No.	Title
N/A	N/A	Danfoss service manual OMSS/OMM

11.3 Technical Data Sheets Index

OAS Doc. No	Client Doc. No.	Title
General Torque Diagram OMSS 200 Motor	N/A	101753-DTS-CAL-001
General Torque Diagram OMM 32 Motor	N/A	101753-DTS-CAL-002

8

7

6

5

4

3

2

1

REVISIONS			
REV	DESCRIPTION	INCORP BY	DATE
B	INITIAL RELEASE	WT	02 APR 08

F

E

D

C

B

A

F





E

D

C

B

A



ITEM NO.	QTY.	PART NO.	DESCRIPTION	MATERIAL
1	1	0312891	MOTOR MOUNTING FLANGE	ALU 6082 T6
2	4	0289483	DISTANSE PIECE	ALU 6082 T6
3	1	0314090	DANFOSS OMM32 WITHOUT SEAL	N/A
4	1	0281829	8 PIN LOW TORQUE	VARIOUS
5	1	0320257	MOTOR ADAPTER ASSY	VARIOUS
6	1	0289485	SENSOR CARD	N/A
7	1	0289487	PARKER O-RING 2-036	NITRIL SHORE 70
8	1	0289488	MCBH4MSS SUB. CONN	N/A
9	1	0287661	PARKER O-RING 2-255	NITRIL 70
10	3	M6X16 DIN912	M6X16 DIN912	A4
11	1	0289479	MCIL4M//0.35M//MCIL4F CABLE	N/A
12	4	M3X6 DIN7991	M3X6 DIN7991	A4
13	2	0289481	3/8" BSP - JIC8	316 L
14	2	0027692	FEMALE LOCKRING RETROFIT	
15	4	0289489	M3 HEX SPACER	316L
16	1	0292607	O-RING 6-129	NITRIL 70
17	8	M10x50 DIN916	M10X50 DIN916	A4
18	4	M10 DIN125	M10 DIN125 WASHER	A4
19	4	M10 DIN985	M10 DIN985 NUT	A4
20	3	M6 DIN125	M6 DIN125 WASHER	A4

UNLESS OTHERWISE SPECIFIED:
ALL DIMENSIONS ARE IN MILLIMETERS

DECIMALS: NO DEC. ±0.4
.X ±0.2
.XX ±0.05

ANGLES: ±0.5°

BREAK ALL SHARP EDGES

SURFACE TEXTURE: 3.2 US0



OCEANEERING INTERNATIONAL, INC.
WWW.OCEANEERING.COM

THIS DOCUMENT CONTAINS INFORMATION WHICH IS
PROPRIETARY TO OCEANEERING INTERNATIONAL INC.
THE INFORMATION CONTAINED HEREIN SHALL NOT
BE DISCLOSED, DUPLICATED, USED IN WHOLE OR IN
PART FOR ANY PURPOSE OTHER THAN TO EVALUATE
THIS DOCUMENT WITHOUT WRITTEN CONSENT OF
OCEANEERING INTERNATIONAL, INC.

TITLE
**LOW TORQUE ASSY W/BODY LATCH
2,7 KNM TORQUE TOOL CLASS 1-4
GENERAL ARRANGEMENT**

DRAWN: WTJOELSEN DATE: 02 APR 08
ENGR: KALBREKTSSEN DATE: 02 APR 08
PR MGR: EWALBERG DATE: 02 APR 08

1ST ANGLE PROJECTION DO NOT SCALE
SIZE DWG. NO. REV
A2 0312890 B

eSIGNATURES ON FILE SCALE: NTS WEIGHT: KG SHEET 1 OF 1

NOTES:

FORM F1362, REV. A

8

7

6

5

4

3

2

1


TORQUE VS. PRESSURE CURVE

TOOL : 2.7 KNm Torque Tool Class 4
 TAG NO :
 RCU TAG :
 FMC TT SI :
 FMC RCU :
 BY :

Pressure			CCW Torque		
(PSI)	(bar)	(ft.lb)	Average (Nm)	Peak (Nm)	
145	10	156	210	330	
290	20	307	415	531	
435	30	444	600	744	
580	40	564	761	908	
725	50	690	931	1104	
870	60	777	1049	1236	
1015	70	890	1202	1420	
1160	80	1021	1378	1670	
1305	90	1171	1581	1944	
1450	100	1273	1718	2110	
1595	110	1358	1832	2230	
1740	120	1431	1931	2245	
1885	130	1500	2025	2337	
2030	140	1615	2179	2500	
2175	150	1713	2312	2696	
2320	160	1790	2415	2840	
2465	170	1873	2528	3000	
2610	180	1930	2605	3060	
2755	190	2063	2784	3080	
2900	200	2131	2876	3085	

NOTE: The Transducer calibrated counter clock wise.
 The plot shows the average value of three measurings.

This Sheet is for information only. It is based on tests with different Torque tools to different RCUs. The Torque vs. pressure for the actual Torque Tool have to be verified before used in operation.




MAX OUTPUT TORQUE:	3085	Nm
MAX OUTPUT PRESSURE:	200	Bar

OCEANEERING®

TORQUE VS. PRESSURE CURVE

TOOL : 2.7 KNm Torque Tool Class 4
 TAG NO :
 RCU TAG NO :
 FMC TT SN: :
 FMC RCU SN: :
 BY :

Pressure		CCW Torque		
(PSI)	(bar)	(ft.lb)	Average (Nm)	Peak (Nm)
145	10	24	32	52
290	20	49	66	93
435	30	72	97	124
580	40	93	125	163
725	50	111	149	184
870	60	133	179	222
1015	70	143	194	237
1160	80	164	221	275
1305	90	181	245	305
1450	100	191	258	325
1595	110	201	271	341
1740	120	213	287	349
1885	130	217	293	366
2030	140	237	320	403
2175	150	247	334	419
2320	160	252	340	434
2465	170	268	361	457
2610	180	279	377	470
2755	190	287	387	480
2900	200	302	408	493



NOTE: The Transducer calibrated counter clock wise.
 The plot shows the average value of three measurements.

This Sheet is for information only. It is based on tests with different Torque tools to different RCUs. The Torque vs. pressure for the actual Torque Tool have to be verified before used in operation.


MAX OUTPUT TORQUE:	493	Nm
MAX OUTPUT PRESSURE:	200	Bar

OCEANEERING

Hydraulic motors OMS series 2 and series 3

Metric version

DKMH.PS.130.AG.52 replaces HN.13.AF.52




Contents

	<u>Page</u>
Special versions	2
Cost-free repairs.....	2
Service shops.....	2
Serial marking	3
Exploded view OMS series 2	4
Exploded view OMS series 3	5
Spare parts list	6
Tools	10
Dismantling.....	11
Tacho cennction	13
Assembling	14

Specialudførelse	Reservedelslisten kan ikke anvendes til bestilling af reservedele til OMS i specialudførelser. Kontakt venligst salgsorganisationen for Danfoss Hydraulik vedrørende dette spørgsmål.	
Special versions	The list of spare parts cannot be used when ordering parts for special OMS versions. In this respect, please contact the sales organisation for Danfoss Hydraulics.	
Sonderausführung	Die Ersatzteilliste kann nicht für Bestellung von Ersatzteilen für OMS in Sonderausführungen benutzt werden. Wenden Sie sich diesbezüglich bitte an die Verkaufsorganisation für Danfoss Hydraulik.	
Version spéciale	La liste de pièces de rechange ne peut pas être utilisée pour commander pièces de rechange pour OMS en versions spéciales. A ce sujet, vous êtes priés de vous adresser à l'organisation de vente de composants hydrauliques Danfoss.	
Vederlagsfri reparation	Vi gør opmærksom på at den vederlagsfrie reparation som er omtalt i Danfoss Almindelige Leveringsbetingelser kun udføres hos Danfoss Nordborg eller hos Danfoss autoriserede service shops.	
Cost-free repairs	We would point out that cost-free repairs as mentioned in Danfoss General Conditions of Sale, are carried out only at Danfoss Nordborg or at service shops authorised by Danfoss.	
Kostenlose Reparatur	Wir machen darauf aufmerksam, daß die in den "Allgemeinen Lieferbedingungen" von Danfoss erwähnte kostenlose Reparatur nur bei Danfoss Nordborg oder bei den autorisierten Danfoss Kundendienstwerkstätten ausgeführt wird.	
Réparation gratuite	Nous faisons observer que la réparation gratuite mentionnée dans les Conditions générales de Vente de Danfoss ne devra être effectuée que dans les ateliers Danfoss à Nordborg ou dans les ateliers de dépannage agréés par Danfoss.	
Authorized Service Shops	Australia : Danfoss (Australia) Pty. Ltd., Melbourne Austria : Hainzl Industriesysteme, GmbH., Linz Belgium : N.V. Danfoss S.A., Bruxelles Brazil : Danfoss do Brasil Ind.e Com. Ltda., São Paulo Canada : Danfoss Mfg. Ltd., Mississauga Denmark : Danfoss Hydraulik A/S, Ganløse Finland : OY Danfoss AB, Espoo France : Danfoss S.a.r.l., Trappes (Paris) Germany : Danfoss GmbH., Offenbach/Main Great Britain : Danfoss Limited, Greenford (London) Iceland : Hedinn Verslun HF, Reykjavik India : Dantal Hydraulics PVT Ltd., New Delhi Italy : Danfoss s.r.l. Division Sordella, Torino Japan : Danfoss K.K., Gotemba Korea : Unitek Corporation, Seoul Netherlands : Itho B.V., Schiedam New Zealand : Danfoss (New Zealand) Limited, Auckland Norway : Danfoss A/S, Skui Republic of South Africa : Danfoss (Pty) Ltd., Johannesburg Singapore : Danfoss Industries Pte. Ltd., Singapore Spain : Danfoss S.A., San Sebastian de los Reyes, (Madrid) Sweden : Danfoss AB, Mjölby Switzerland : Danfoss Werner Kuster AG, Frenkendorf Turkey : Mert Teknik A.S., Istanbul U.S.A. : Danfoss Fluid Power Div. Racine, Wisconsin	
Service Shops	Australia : Danfoss (Australia) Pty. Ltd., Adelaide Australia : Danfoss (Australia) Pty. Ltd., Brisbane Australia : Danfoss (Australia) Pty. Ltd., Perth Australia : Danfoss (Australia) Pty. Ltd., Sydney Czech Rep. : Techno Trade, Olomouc Greece : A. Skoura & Co. E.E., Athens New Zealand : Danfoss (New Zealand) Limited, Christchurch Taiwan : Symbbridge Machinery Co. Ltd., Taipei	

Seriemærkning	Serienummer ændres, når der foretages ændringer af dele i motorene. OMS er mærket med seriebetegnelse efter datomærkningen xxx-3
Series marking	The series number is altered when parts in the motor are changed. The OMS series marking follows its date marking: xxx-3
Serienkennzeichnung	Bei Teileänderungen im Motor wird die Seriennummer geändert. Die Kennzeichnung von OMS erfolgt mit einer Serienbezeichnung nach der Datumszeichnung: xxx-3
Marquage de série	A toute modification d'une ou de plusieurs pièces des moteurs correspond un changement de numéro de série. Les moteurs OMS portent leur numéro de série à la suite de la date, par exemple: xxx-3
Kommentarer	a) Kun OMS serie 2: Efter uge 41.97 er spændestift flyttet. Ved reparation af motor fremstillet før 41.97 skal ende-dæksel, balanceplade, spændestift og fjederskive skiftes.
Comments	a) Only OMS series 2: After week 41.97 the guide pin has a new location. When repairing motors manufactured before week 41.97 it will therefore be necessary to replace end cover, balace plate, tightening pin and spring washer.
Kommentare	a) Nur OMS Serie 2: Der Spannstift hat nach Woche 41.97 eine neue Plazierung. Bei Reparaturen von Motoren die vor Woche 41.97 gefertigt wurden, müssen deswegen Enddeckel, Ausgleichplatte, Spannstift und Federscheibe ausgewechselt werden.
Commentaires	a) Seulement OMS série 2: À partir de la semaine 41.97, la pièce de serrage occupe une nouvelle position. Lors d'une réparation sur un moteur fabriqué avant la semaine 41.97, le couvercle d'extrémité, la plaque de compensation, la pièce de serrage et la rondelle à ressort devront être changées.


Exploded view OMS series 2



Tilspændingsmoment / Tightening torque
Anzugsmoment / Couple de serrage

Item	15, with item 16:	3.0 - 6.0 daNm (270 - 530 lbf in)
Item	36:	7.5 - 8.0 daNm (660 - 705 lbf in)
Item	40:	1.0 - 1.5 daNm (90 - 130 lbf in)
Item	51:	0.4 - 0.6 daNm (35 - 55 lbf in)

Exploded view OMS series 3



DANFOSS
A151-1819.10.10

Tilspændingsmoment / Tightening torque
Anzugsmoment / Couple de serrage

Item 15, with item 16:	3.0 - 6.0 daNm (270 - 530 lbf in)
Item 36:	7.5 - 8.0 daNm (660 - 705 lbf in)
Item 40:	1.0 - 1.5 daNm (90 - 130 lbf in)
Item 51:	0.4 - 0.6 daNm (35 - 55 lbf in)

Spare parts list

Item	Spare parts	Stock per 100 motors**			
		Number per motor		OMS Series 2 3	
		Code No.			
1	Dust seal ring 35 x 42 x 3.5 mm	633B3198	1	1	*
2	Dust seal ring (p.t.o.) 40 x 47 x 4.0 mm	633B3356	1	1	*
3	<u>Bearing housing</u>				
3	OMS	151F1534	1	1	2
3a	OMS with special flange	151F1536	1	1	2
3b	OMSW	151F1535	1	1	2
4	OMS (p.t.o.)	151F1549	1	1	2
5	<u>Shaft seal</u> ISO R 1629 35 x 52 x 5.9 mm NBR	633B3197	1	1	*
	35 x 52 x 5.9 mm FPM	633B3196	1	1	*
6	Shaft seal (p.t.o.) ISO R 1629 40 x 60 x 6.0 mm NBR	633B3355	1	1	*
7	Parallel key A 10 x 8 x 45 mm	682L8019	1	1	5
8	Cylindrical shaft ø32 mm with bearings incl. item 7;	151F0112	1	1	2
8a	Splined shaft 1 1/4 in with bearings;	151F0113	1	1	2
8b	Tapered shaft 35 mm with bearings; incl. item 10, 11 and 12	151F0114	1	1	2
9	P.t.o. shaft incl. bearing, DIN9611	151F0116	1	1	2
10	Castellated nut M20 x 1.5 mm	681X8235	1	1	5
11	Washer 20.5 x 44 x 4 mm	684X2530	1	1	5
12	Parallel key B6 x 6 x 20 mm	682L8021	1	1	5
13	Seal ring	633B9023	1	1	*
14	O-ring 70 x 2 mm NBR ISO 1629	633B1379	1	1	*
15	Drain plug G1/4 (ISO228/1)	151-1524	1	1	10
16	Washer 13.5 x 17.5 x 1.5 mm	684X2120	1	1	5
17	Intermediate plate	151F1811 151F1538	1	1	5 5
18	O-ring for OMSS 100 x 3 mm NBR ISO 1629	151F1033	1	1	10
19	Mounting flange for OMSS	151F1817 151F1486	1	1	5 5
20	<u>Cardan shaft</u>				
	OMS/OMSW/OMSS 80 l = 70 mm	151F1461	1	1	3
	OMS/OMSW/OMSS 100 l = 73 mm	151F1462	1	1	3
	OMS/OMSW/OMSS 125 l = 78 mm	151F1463	1	1	3
	OMS/OMSW/OMSS 160 l = 84 mm	151F1464	1	1	3
	OMS/OMSW/OMSS 200 l = 91 mm	151F1769	1	1	3
	OMS/OMSW/OMSS 250 l = 99.5 mm	151F1770	1	1	3
	OMS/OMSW/OMSS 315 l = 111 mm	151F1829	1	1	3
	OMS/OMSW/OMSS 400 l = 124.5 mm	151F1830	1	1	3
21	O-ring 82.5 x 2 mm NBR ISO R 1629	633B1431	2	3	*

NBR: (Buna N, Perbunan); FPM (Viton)

Spare parts list

Item	Spare parts	Stock per 100 motors**			
		Number per motor			
		Code No.	OMS Series 2	3	
22	<u>Gearwheel set Series 3</u>				
	OMS/OMSW/OMSS 80 w = 14 mm	151F1081		1	5
	OMS/OMSW/OMSS 100 w = 17 mm	151F1082		1	5
	OMS/OMSW/OMSS 125 w = 22 mm	151F1083		1	5
	OMS/OMSW/OMSS 160 w = 28 mm	151F1084		1	5
	OMS/OMSW/OMSS 200 w = 35 mm	151F1085		1	5
	OMS/OMSW/OMSS 250 w = 44 mm	151F1086		1	5
	OMS/OMSW/OMSS 315 w = 55 mm	151F1087		1	5
	OMS/OMSW/OMSS 400 w = 68.4 mm	151F1088		1	5
	<u>Gearwheel set Series 2</u>				
	OMS/OMSW/OMSS 80 w = 14 mm	151F1036	1		5
	OMS/OMSW/OMSS 100 w = 17 mm	151F1037	1		5
	OMS/OMSW/OMSS 125 w = 22 mm	151F1038	1		5
	OMS/OMSW/OMSS 160 w = 28 mm	151F1039	1		5
	OMS/OMSW/OMSS 200 w = 35 mm	151F1040	1		5
	OMS/OMSW/OMSS 250 w = 44 mm	151F1041	1		5
	OMS/OMSW/OMSS 315 w = 55 mm	151F1042	1		5
	OMS/OMSW/OMSS 400 w = 68.4 mm	151F1059	1		5
23	Guide pin \varnothing 4 mm, l = 6 mm DIN 6325	682L2006	1		5
24	Valve drive	151F1448	1	1	5
25	Channel plate	151F1821		1	5
		151F1023	1		3
26	Stop ring (only OMSS 200, 250, 315 and 400)	151F1542	1	1	3
27	Disc valve	151F1022	1	1	3
28	Balance plate a)	151F1738	1	1	3
29	Guide pin \varnothing 4 mm, l = 20 mm DIN 1481 a)	682L9105	1	1	5
30	<u>O-ring 45 x 2 mm</u>				
	NBR, ISO R 1629	633B1429	1	1	*
	FPM, ISO R 1629	633B1455	1	1	*
31	<u>O-ring 24 x 2 mm</u>				
	NBR, ISO R 1629	633B1428	1	1	*
	FPM, ISO R 1629	633B1453	1	1	*
32	Spacer	151F1449	1	1	2
33	Spring washer a)	684X0097	1	1	5
34	Seal plug G 1/2	633X0074	2	2	20
35	Valve housing a)	151F1801		1	2
		151F1445	1		2

NBR: (Buna N, Perbunan); FPM (Viton)

Spare parts list

Item	Spare parts	Stock per 100 motors**				
		Number per motor				
		Code No.	OMS Series 2	3		
36	<u>Screw M10</u>					
	OMS/OMSW 80 l = 120 mm	681X1349	4	4	12	
	OMS/OMSW 100, 125 l = 130 mm	681X1350	4	4	12	
	OMS/OMSW 160, 200 l = 140 mm	681X1352	4	4	12	
	OMS/OMSW 250 l = 150 mm	681X1353	4	4	12	
	OMS/OMSW 315 l = 160 mm	681X1356	4	4	12	
	OMS/OMSW 400 l = 180 mm	681X0038	4	4	12	
	OMSS 80, 100 l = 100 mm	681X1347	4	4	12	
	OMSS 125, 160 l = 110 mm	681X1348	4	4	12	
	OMSS 200 l = 120 mm	681X1349	4	4	12	
	OMSS 250 l = 130 mm	681X1350	4	4	12	
	OMSS 315 l = 140 mm	681X1352	4	4	12	
	OMSS 400 l = 150 mm	681X1353	4	4	12	
37	Check valve ball	ø3/16 in	689X1005		2	10
		ø1/4 in	689X1015	2		10
38	Check valve spring		013-0662	2		10
39	Washer 10.2 x 13.5 x 1 mm		684X2564	2		10
40	Check valve plug G 1/8 (ISO228/1)		631X2053	2		10
41	Name plate (adhesiv)					
	Aluminium OMS/OMSW/OMSS	151A0407	1	1	15	
	Brass OMS/OMSW/OMSS	151A0408	1	1	15	
43	Tacho valve housing, complete	a) 151F0137		1	2	
		151F0100	1		2	
44	Tacho connection, complete	151F1031	1	1	3	
45	Tacho valve drive + guide pin	151F1032	1	1	2	
46	Spacer ring	151F1502	1	1	2	
47	Tacho valve housing	151F1802		1	1	
		a) 151F1498	1		1	
48	O-ring 40 x 2 mm	633B1378	1	1	4	
49	Bearing housing	151F1499	1	1	1	
50	Washer 5.6 x 8.5 x 1 mm	684X2012	4	4	20	
51	Screw M5; l = 15 mm	681X1880	4	4	16	
52	Tacho drive shaft	151F1500	1	1	1	
53	Locking ring UR 6 x 0.7 mm DIN6799	682L4922	2	2	4	
54	Bearing 8 x 22 x 7 mm	981X1020	1	1	2	
55	Shaft seal	633B3175	1	1	2	
56	Locking ring N 22 x 1 mm DIN427	682L4008	1	1	2	
57	Name plate (Tacho)	151A0410	1	1	4	

NBR: (Buna N, Perbunan); FPM (Viton)

a, Se kommentarer side 3

a, See comments page 3

a, Siehe Kommentare Seite 3

a, Voir commentaire à la page 3

Spare parts list

Item	Spare parts	Stock per 100 motors**			
		Number per motor			
		Code No.	OMS Series 2	3	
A	Set of seals NBR, ISO R 1629, OMS/OMSW Item 1, 5, 13, 14, 21, 30 and 31	151F0111	1	1	10
	OMS (p.t.o) Item 2, 6, 13, 14, 21, 30 and 31	151F0117	1	1	10
B	Set of seals NBR, ISO R 1629, OMSS Item 13, 18, 21, 30 and 31	151F0103	1	1	10
C	Set of seals NBR, ISO R 1629 OMSS Item 13 and 18	151F1033	1	1	10
D	Set of seals FPM, ISO R 1629 OMS/OMSW/OMSS Item 1, 5, 30 and 31	151F0109	1	1	10

NBR: (Buna N, Perbunan); FPM (Viton)

a, Se kommentarer side 3

a, See comments page 3

a, Siehe Kommentare Seite 3

a, Voir commentaire à la page 3

* Indeholdt i reservedelsposen A eller D

* Contained in spare parts bag A or D

* Im Ersatzteilbeutel A oder D enthalten

* Contenu dans le sachet de pièces de rechange A ou D








** Antallet af reservedele som Debør have på lager for hver 100 motorer der er i brug i Deres område.

** The number of spare parts to be held in stock for each 100 motors being in service in your district.

** Die Anzahl von Ersatzteilen, die Sie für je 100 Motoren, die in Ihrem Gebiet verwendet werden, auf Lager haben sollten.

** Les Quantités de pièce de rechange que vous devez prévoir en stock pour 100 moteurs actuellement en service dans votre secteur.

Special tools

<p>A</p> 	<p>B</p> 	<p>C</p> 
<p>D</p> <div></div> <div></div> <p>p.t.o.</p>		
<p>E</p> 	<p>F</p> 	

- A Main holding tool. Code no.: SJ 151-9000-1
- B Holding tool for OMSS. Code no.: SJ 151F9000-1
- C Holding tool for OMSW. Code no.: SJ 151B9000-1
- D Mandrel for fitting shaft seal.
- E Two guide bolts.
- F Mandrel to remove balance plate.

Note: D, E, and F cannot be bought from Danfoss.

Dismantling

Item	Part to remove	Comments
7 or 12	Parallel key	Cylindriske eller koniske aksler. Cylindrical or tapered shafts. Zylindrischen oder konischen Wellen. Les arbres cylindriques ou coniques.
*) 13	Conical seal ring	
15, 16	Drain plug and washer	
34	Seal plugs (2 off)	Anbring motor i holdeværktøj. Place the motor in holding tool. Den Motor im Haltewerkzeug anbringen. Placer le moteur dans un appareil de fixation.
40	Plugs (2 off) Series 2 only	Benyt 5 mm unbrakoskruenøgle. Use 5 mm Allen head spanner. 5 mm Innensechskantschlüssel benutzen. Utiliser une clé Allen de 5 mm.
39	Washer (2 off) Series 2 only	
38	Springs (2 off) Series 2 only	Tip motor, hvorefter fjedre og kugler falder ud. Tilt motor, springs and balls come out.
37	Ball (2 off) Series 2 only	Motor neigen; Federn und Kugeln fallen heraus Les ressorts et les billes sortent d'eux-mêmes en inclinant le moteur.
36	Srew (4 off)	Benyt 17 mm topnøgle. Use 17 mm socket spanner. Einen 17 mm Steckschlüssel verwenden. Utiliser clé à douille 17 mm.
35	Valve housing	Placer fingrene under kanalpladen (pos. 25) og løft forsigtigt hele enheden ud. Lift off carefully as a unit, holding your fingers under the channel plate (Item no.25). Vorsichtig als Einheit abheben, indem Sie die Finger unter die Kanalplatte (Pos. 25) halten. Soulever l'ensemble avec précaution en plaçant vos doigts sous la plaque profilée (pièce n° 25).
25	Channel plate	
21	O-ring	Series 2 (1 off), Series 3 (2 off)
37	Ball (2 off) Series 3 only	
26	Stop ring	Kun på OMSS 200, 250, 315 og 400 Only on OMSS 200, 250, 315 and 400 Nur an OMSS 200, 250, 315 und 400 Uniquement sur les OMSS 200, 250, 315 et 400.
27	Disc valve	
32	Spacer	
28	Balance plate	Fyld olie i hul for afstandsstykke, og skub balance plade op ved at bruge en ø14.25 mm dorn som stempel. Fill in oil into the spacer hole and use the ø14.25 mm mandrel as a piston to press up the balance plate. Öl in das Loch für das Distanzstück füllen und den Ø14.25 mm-Dorn als Kolben benutzen um die Ausgleichsplatte hochzudrücken. Verser de l'huile par le trou de l'entretoise et utiliser le mandrin ø14.25 mm comme piston pour enfoncer la plaque de compensation.

* OMSS only

Dismantling

Item	Part to remove	Comments
29	Guide pin	
30	O-ring	
31	O-ring	
33	Spring washer	
24	Valve drive	
23	Guide pin Series 2 only	
22	Gearweel set	<p>Hold fingrene under tandhjulsæt for at forhindre delene i at falde ud.</p> <p>Hold fingers under the gearweel set to prevent the parts from dropping out.</p> <p>Halten Sie die Finger unter das Zahnradsatz, um ein Herausfallen der Teile zu vermeiden.</p> <p>Tenir le jeu d'engrenage par le dessous pour éviter de perdre des pièces.</p>
21	O-ring	
20	Cardan shaft	
17	Intermediate plate	
13	Conical seal ring	<p>Ikke på OMSS; er allerede fjernet.</p> <p>Not on OMSS, is already removed.</p> <p>Nicht bei OMSS; ist bereits entfernt.</p> <p>Pas sur l'OMSS ; est déjà enlevé.</p>
14	O-ring	
*)8 8a 8b 9	Shaft incl. bearings	<p>Vend lejehuset.</p> <p>Pres aksel/lejeenhed ud ved hjælp af en hydraulisk presse (trykkraft max. 250 daN).</p> <p>Bemærk: aksel/lejeenhed må ikke demonteres!</p> <p>Turn the bearing housing.</p> <p>Press out the shaft/bearing assembly using a hydraulic press (pressing force max. 250 daN)</p> <p>Note: Shaft/bearing assembly should not be dismantled!</p> <p>Das Lagergehäuse wenden.</p> <p>Die Wellen/Lager-Kombination mit Hilfe einer hydraulischen Presse (Preßdruck max. 250 daN) herauspressen.</p> <p>Anmerkung: Die Wellen/Lager-Kombination darf nicht demontiert werden!</p> <p>Tourner le logement de palier.</p> <p>Extraire l'assemblage arbre-palier en utilisant une presse hydraulique (force maximale à exercer : 250 daN)</p> <p>Attention : l'assemblage arbre-palier ne doit pas être démonté !</p>

* Except OMSS

Dismantling

Item	Part to remove	Comments
*) 1, 2	Dust seal ring	Slå pos. nr. 1 og 5 ud ved hjælp af specialdorn. ("D" på side 7) Item nos. 1 and 5 to be knocked out by means of the special mandrel. ("D" on page 7)
*) 5, 6	Shaft seal	Pos. 1 und 5 sind mit Hilfe des Spezialdorns herauszuschlagen. ("D" auf Seite 7) Les pièces n°1 et 5 doivent être extraites à l'aide d'un mandrin spécial. ("D" en page 7)

Tacho connection

Item	Part to remove	Comments
51	Screw (4 off)	
44	Tacho connection	Fjern den fra tachoventilhuset. Remove from tacho valve housing. Vom Tachoventilgehäuse entfernen. Extraire du logement de valve du tachymètre.
48	O-ring	
46	Spacer ring	
56	Retaining ring	Løsn tachoakselenhed (ved at banke let på akselenden) og tag den ud af tachohuset. Loosen tacho shaft package (by tapping lightly at the end of the shaft) and extract the package from tacho housing. Die Tachowelleneinheit lösen (durch leichtes Schlagen am Wellenende) und die Einheit aus dem Tachogehäuse herausziehen. Débloquer l'ensemble arbre du tachymètre (en tapant légèrement sur l'extrémité de l'arbre) et l'extraire du logement du tachymètre.
55	Shaft seal	
53	Retaining ring (2 off)	
54	Bearing	

* Except OMSS

After dismantling, clean all parts in low aromatic kerosene.

Examine the parts and exchange them if necessary.

Immediately before assembly, lubricate each part with hydraulic oil and grease rubber parts with vaseline.


Assembly

Item	Part to mount	Comments
*) 5, 6	Shaft seal	<p>Slå den på plads i lejehuset ved hjælp af monteringsdorn. Smør læbe med vaseline.</p> <p>Knock into position in the bearing housing, using the assembly mandrel. Grease lip with vaseline.</p> <p>Mit Montagedorn in das Lagergehäuse hineinschlagen. Lippe mit Vaseline einschmieren.</p> <p>À enfoncer dans le logement de palier à l'aide du mandrin d'assemblage. Graisser la lèvre du joint à la vaseline.</p>
*) 1, 2	Dust seal ring	<p>Benyt monteringsdorn og plasthammer. Smør læbe med vaseline.</p> <p>Use assembly mandrel and plastic hammer. Grease lip with vaseline.</p> <p>Montagedorn und Kunststoffhammer benutzen. Lippe mit Vaseline einschmieren.</p> <p>Utiliser le mandrin d'assemblage, et le maillet en plastique. Graisser la lèvre du joint à la vaseline.</p>
*) 8, 8a 8b, 9	Shaft incl. bearings	<p>Benyt den hydrauliske presse. (max. 250 daN). Bemærk: pres altid på lejets yderring.</p> <p>Use the hydraulic press. (max. 250 daN). Note: Always press on the bearing outer ring.</p> <p>Hydraulische Presse benutzen. (max. 250 daN). Anmerkung: Immer auf den Lageraußenring pressen.</p> <p>Utiliser la presse hydraulique. (max. 250 daN). Attention : la pression doit toujours être exercée sur la bague extérieure du palier.</p>
17, 14 13	Intermediate plate, O-ring, conical seal ring	<p>Skrue de to styrebolte i lejehuset. Monter O-ring i lejehus. Monter den koniske tætningsring i mellemladens reces. Ringens største diameter skal vende mod mellemladen. Monter mellemlade på lejehuset med konisk tætningsring pejende nedad.</p> <p>Screw the guide bolts into the bearing housing. Fit the O-ring into the bearing housing. Fit the conical seal ring (biggest diameter facing the intermediate plate) into the recess in the intermediate plate. Place the intermediate plate in position on the bearing housing with the conical seal ring downwards.</p> <p>Die beiden Führungsbolzen in das Lagergehäuse einschrauben. Den O-Ring in Lagergehäuse montieren. Den kegeligen Dichtungsring in die Aussparung in der Zwischenplatte montieren. Der größte Durchmesser des Rings muß gegen die Zwischenplatte gekehrt sein. Die Zwischenplatte mit dem kegeligen Dichtungsring zuerst auf das Lagergehäuse montieren.</p> <p>Visser dans le carter de roulement les deux boulons de guidage. Monter le joint torique dans le carter de roulement. Monter la bague d'étanchéité conique dans l'évidement de la plaque intermédiaire. Le diamètre le plus grand doit être orienté vers la plaque intermédiaire.</p> <p>Monter la plaque intermédiaire dans le carter de roulement avec la bague d'étanchéité conique orientée vers le bas.</p>

* Except OMSS

Assembly

Item	Part to mount	Comments
20	Cardan shaft	<p>Før kardanakslen ned i udgangsakslen så splines kommer i indgreb.</p> <p>Guide the cardan shaft down into the output shaft so that the splines engage.</p> <p>Kardanwelle in die Abtriebswelle hinabführen, so daß die Vielkeile in Eingriff kommen.</p> <p>Descendre l'arbre à cardan dans l'arbre de sortie engageant les cannelures.</p>
21	O-ring	<p>Smør med vaseline.</p> <p>Grease with vaseline.</p> <p>Mit Vaseline einschmieren.</p> <p>Graisser à la vaseline.</p>
22, 23	Gearwheel set	<p>Hold fingrene under tandhjulsættet for at forhindre delene i at falde ud. Læg forsigtig tandhjulsættet på mellemladen således at o-ringsrillen (OMS serie 3) eller hul til styrestift (OMS serie 2) peger opad. Gennemgående hul (6 mm) skal flugte med hul i mellemladen. Monter styrestiften (kun OMS serie 2) i tandkransen.</p> <p>Mærk tandhjulsættets hjul på det sted, hvor bunden af en indvendig tand befinder sig over for bunden af en udvendig placeret tand (se tegning).</p> <p>Hold fingers under the gearwheel set to prevent parts falling out. Carefully lay the gearwheel set on the intermediate plate so that the O-ring groove (OMS series 3) or guide pin hole (OMS series 2) is upwards. The through-hole (6 mm) must line up with the hole in the intermediate plate. Fit the guide pin (OMS series 2 only) in the gear rim.</p> <p>Mark the wheel of the gearwheel set at the point where the bottom of an internal tooth is opposite the bottom of an external tooth (see drawing).</p> <p>Die Finger unter den Zahnradsatz halten, um ein Herausfallen der Teile zu verhindern. Den Zahnradsatz vorsichtig auf die Zwischenplatte legen, so daß die O-Ringrille (OMS Serie 3) oder das Loch im Führungsstift (OMS Serie 2) nach oben zeigen. Das durchgehende Loch (6 mm) muß mit dem Loch in der Zwischenplatte fluchten. Den Führungsstift im Zahnkranz montieren (nur OMS Serie 2).</p> <p>Den Zahnradsatz an der Stelle kennzeichnen, an der sich der Boden eines Innenzahns gegenüber dem Boden eines Außenzahns befindet (siehe Zeichnung).</p> <p>Glisser les doigts sous le jeu d'engrenages afin d'éviter la chute de pièces. Placer avec précaution le jeu d'engrenages sur la plaque intermédiaire de façon que la cannelure du joint torique (OMS série 3) ou l'orifice de la goupille-guide (OMS série 2) soit dirigé vers le haut. L'orifice traversant (6 mm) doit être aligné avec l'orifice de la plaque intermédiaire.</p> <p>Monter la goupille-guide (OMS série 2 uniquement) dans la couronne de l'engrenage.</p> <p>Marquer la roue du jeu d'engrenage à l'endroit où le creux de la dent intérieure se trouve en face du creux d'une dent placée à l'extérieur (voir croquis).</p>
24	Valve drive	<p>Mærk toppen af en tand på enden af ventildrevet med den bredeste fortanding. Sørg for at mærke på tandhjul og ventildrev flugter. Enden med bredeste fortanding skal pege opad.</p> <p>(Bemærk: På motorer med tachoforbindelse skal stift på ventildrev pege opad).</p> <p>Mark the tip of a spline tooth on the end of the valve drive with the widest splines. Line up mark on rotor and valve drive. The end with the widest splines must point upwards.</p>



Assembly

Item	Part to mount	Comments
24	Valve drive	<p>(Note: Applies to motors with tacho connection: Pin on valve drive must point upwards).</p> <p>Markieren Sie die Spitze eines Zahns am Ende des Ventiltriebs mit der breitesten Verzahnung. Die Markierungen am Zahnrad und Ventiltrieb miteinander fluchten. Das Ende mit der breitesten Verzahnung muß nach oben zeigen.</p> <p>(Anmerkung: Gilt für Motoren mit Tachoanschluß: Der Stift am Ventiltrieb muß nach oben zeigen).</p> <p>Marquer le point d'une dent de cannelure sur le bout de la commande de soupape avec la cannelure la plus large. Aligner la marque du rotor avec celle de la commande de soupape. L'extrémité avec la cannelure la plus large doit tourner vers le haut.</p> <p>(Attention : S'applique aux moteurs avec jonction de tachymètre ; la fiche placée sur la commande de soupape doit pointer vers le haut).</p>
21	O-ring (OMS series 3: 2 off) (OMS series 2: 1 off)	<p>Smøres i vaseline og lægges i tandhjulsættets (kun OMS serie 3) og kanalpladens rille .</p> <p>Grease with vaseline. Mount in the gearwheel (only OMS serie 3) and channel plate groove.</p> <p>Mit Vaseline einschmieren. In die Rille des Zahnradatzes (Nur OMS serie 3) und Kanalplatte einlegen.</p> <p>Placer un joint torique (enduit de vaseline) dans le jeu d'engrenages (Uniquement OMS Serie 3) et la rainure de la plaque à canaux.</p>
25	Channel plate (OMS series 3)	<p>Monter kanalpladen sådan at o-ringsrillen vender opad og huller til kontraventil flugter med gennemgående hul i tandhjulsættet.</p> <p>Fit the channel plate so that the O-ring groove is upwards and the check valve holes line up with the through-hole in the gearwheel set.</p> <p>Die Kanalplatte so montieren, dass die O-Ringrille nach oben zeigt und die Löcher für das Rückschlagventil mit dem durchgehenden Loch im Zahnradatz fluchten.</p> <p>Monter la plaque à conduits de façon que la cannelure du joint torique soit orientée vers le haut et que les orifices du clapet anti-retour soient alignés avec l'orifice traversant du jeu d'engrenages.</p>
	Channel plate (OMS series 2)	<p>Monter kanalpladen sådan at styrestiften kommer i indgreb med hullet i kanalpladen.</p> <p>Fit the channel plate so that the guide pin engages with the hole in the channel plate.</p> <p>Kanalplatte so montieren, daß der Führungsstift mit dem Loch in der Kanalplatte in Eingriff kommt.</p> <p>Monter la plaque à canaux de telle sorte que la goupille de guidage s'engrène avec le trou de la plaque à canaux.</p>
37	Ball (2 off) OMS series 3 only	
27	Disc valve	<p>Sørg for, at mærke på ventildrev flugter med et hul i yderkrans. (A på tegning). Drej skiveventil mod uret, indtil splines i de to dele går i indgreb.</p> <p>Align mark on valve drive with a hole in the outer rim. (A on drawing). Turn disc valve counter clockwise until splines in the two parts engage.</p> <p>Die Markierung am Ventiltrieb mit einer Bohrung im Außenkranz fluchten. (A auf der Skitse). Das Scheibventil gegen den Uhrzeigersinn drehen bis die zwei Teile ineinandergreifen.</p>

Assembly

Item	Part to mount	Comments
27	Disc valve	Aligner la marque de la commande de soupape avec un des trous du bord extérieur (A sur le plan). Tourner la soupape à disque dans le sens des aiguilles d'une montre jusqu'à ce que les cannelures des deux pièces s'enclenchent.
33	Spring washer	Placer dem i ventilhuset. Place into valve housing. Im Ventilgehäuse plazieren. Positionner dans le logement de soupape.
30, 31	O-ring	Monter de to O-ringe (indfedtet i vaseline) i balancepladens riller. Fit the two O-rings (greased with vaseline) in the balance plate grooves. Die beiden O-Ringe (mit Vaseline eingefettet) in die Rillen der Ausgleichsplatte montieren. Monter les deux joints toriques (enduits de vaseline) dans les rainures de la plaque d'équilibrage.
29	Guide pin	Monter i ventilhuset Mount in valve housing Im Ventilgehäuse montieren Monter dans le carter de la glace à disque.
28	Balance plate	Monter i ventilhuset Mount in valve housing Im Ventilgehäuse montieren Monter dans le carter de la glace à disque.
32	Spacer	Smør med vaseline for at forhindre afstandsstykke i at falde ud. Grease with vaseline to prevent the spacer from dropping out. Mit Vaseline einschmieren, um ein Herausfallen des Distanzstückes zu vermeiden. Graisser à la vaseline pour empêcher l'entretoise de tomber.
35	Valve housing	Monter enheden på den resterende del af motoren. Portene skal pege i den samme retning som drænporten. Mount unit on the rest of the motor. Ports should face in the same direction as the drain port. Die Einheit am übrigen Teil des Motors montieren. Die Anschlüsse sollten in die gleiche Richtung zeigen wie der Leckölanschluß. Monter l'unité sur le reste du moteur. Les orifices doivent être dirigés dans la même direction que l'orifice de drainage.
36	Screw (4 off)	Smør gevindene og spænd skruerne krydsvis med 7.5 - 8.0 daNm. Lubricate threads and cross tighten screws to 7.5 - 8.0 daNm. Die Gewinde schmieren und die Schrauben kreuzweise mit 7.5 - 8.0 daNm anziehen. Lubrifier les filetages et serrer les vis en croix au couple de 7.5 - 8.0 daNm.

Assembly

Item	Part to mount	Comments
37	Ball (2 off) Series 2 only	
38	Spring (2 off) Series 2 only	
39	Washer (2 off) Series 2 only	
40	Plug (2 off) Series 2 only	Spænd dem med 1.0 - 1.5 daNm. Tighten to 1.0 - 1.5 daNm. Mit 1.0 - 1.5 daNm anziehen Serrer au couple de 1.0 - 1.5 daNm.
7 or 12	Parallel key	Sikres med plastring eller tape. Secure with plastic ring or tape. Mit Kunststoffring oder Klebeband sichern. Fixer au moyen d'une bague en plastique ou du scotch.
15, 16	Drain plug and washer	Fyld olie på motoren før tilpropning. Spændes med 3.0 - 6.0 daNm. Fill motor with oil before plugging. Tighten to 3.0 - 6.0 daNm. Vor dem Zustopfen den Motor mit Öl füllen. Mit 3.0 - 6.0 daNm anziehen. Remplir le moteur d'huile avant de vidanger. Serrer au couple de 3,0 – 6,0 daNm.
*) 13	Conical seal ring	Smør med vaseline for at holde den på plads. Grease with vaseline to keep in place. Mit Vaseline einfetten um ihn am Platz zu halten. Coller à la vaseline pour les maintenir en place.
34	Seal plug (2 off)	


* OMSS only

Assembling of tachometer connection

The tachometer connection must be reassembled in reverse order in relation to the procedure described under "disassembling the tachometer connection".

4 screws (pos. 51) to be tightened to 0.4 - 0.6 daNm.

OMS series 3



Danfoss Hydraulics Organization

Danfoss is an international concern with factories in 10 countries and subsidiaries in 32 countries. In addition to the hydraulic components, the Danfoss range of products includes refrigeration controls, industrial automatics, precision step systems, industrial instrumentations, electrical drives and controls, controls for heating plant, system controls, components for burners and boilers, compressors and thermostats for refrigerators and freezers.

Argentina	Danfoss S.A. San Lorenzo 4310 1605 Munro Buenos Aires Tel. : +54 1 756 4200 Fax : +54 1 756 4100 E-mail: danfoss@interserver.com.ar Ing. Lahusen S.R.L. Av. Belgrano, 615 - 8° I 1092 - Buenos Aires Tel. : +54 1 342 1083/1835 Fax : +54 1 331 7314	Colombia	Fiza Ltda. Carrera 40 N° 163-A-55 (Toberin) Santafé de Bogotá D.C. Colombia S.A. Tel. : +57 1 677 6346/677 6440 Tel. : +57 1 677 5142 Fax : +57 677 7025 E-mail : fisaza@anditel.andinet.lat.net	Greece	A. Skoura A.E. Spirou Patsi 105 GR-118 55 Athens Tel. : +30 1 345 3906 Tel. : +30 1 346 3967 Fax : +30 1 347 4106 (Skouras) E-mail : skoura@otenet.gr. Service Shops
Australia	Danfoss (Australia) Pty. Ltd. P.O. Box 6484, Silverwater New South Wales 2128 199 Paramatta Road, Auburn New South Wales, 2144 Tel. : +61 02 9648 4982 Fax : +61 02 9748 0573 E-mail: inter@danfoss.com.au	Cyprus	Tektron Ltd. 25, Heroes Street P.O. Box 2123 Strovolos-Nicosia Tel. : +357 2 49 7907 Fax : +357 2 31 4844 E-mail : TEKTRON@cytanet.com.cy	Hong Kong	Nicko International RM. 1203, Chevalier Commercial Centre 8 Wang Hoi Road Kowloon Bay, Hong Kong Tel. : +852 2755 2783 Fax : +852 2798 8656 E-mail : sales@nicko.com.hk
Austria	Hainzl Industriesysteme Gesellschaft m.b.H. & Co KG Industriezeile 56 P.O. Box 100 A-4040 Linz Tel. : +43 732 7892 Fax : +43 732 7892 150 E-mail: info@hainzl.at Danfoss authorized service shop	Czech Republic Slovak Republic	Techno Trade GmbH Dipl. Ing. Petr Kejduš Tovární ul. 41 CZ 772 00 Olomouc Tel. : +420 68 52 22 004 Fax : +420 68 52 32 055 E-mail : Technotrade@traveller.cz Service Shops	Hungary	Kite RT. 4181 Nadudvar, Bem. J.U.2. Tel. : +36 54 48 0401 Fax : +36 54 48 0331
Belgium	N.V. Danfoss S.A. Erasmus Business Park Av. Joseph Wybran 45 B-1070 Bruxelles Tel. : +32 02 525 0711 Fax : +32 02 525 0757 E-mail: "name"@danfoss.be (ex: Daniel_Titeka@danfoss.be) Danfoss authorized service shop	Denmark	Danfoss Fluid Power A/S DK-6430 Nordborg International tel.: +45 74 88 22 22 National tel.: +74 88 22 22 Telex : 50599 Fax : +45 74 49 09 49 +45 74 49 16 13 (Hydr.) +45 74 88 55 95 (Overseas) +45 74 49 04 90 (Logistic) E-mail : danfoss@danfoss.com	Iceland	Hedinn Verslun HF Seljavegi 2 P.O. Box 512 IS-121 Reykjavik Tel. : +354 562 4260 Fax : +354 562 4315 E-mail : "name"@hedinn-verslun.is (ex: gisli@hedinn-verslun.is) Danfoss authorized service shop
Brazil	Danfoss do Brasil Ind. e Com. Ltda. Rua Nelson Francisco 26, Casa Verde CEP 02712-100 São Paulo - SP Tel. : +55 11 855 5400 Fax : +55 11 855 5455 E-mail: danfoss@danfoss.com.br Danfoss authorized service shop	Finland	OY Danfoss AB Kivenlahdentie 7 SF-02360 Espoo Tel. : +358 9 802 81 Fax : Hydraulics dept. +358 9 802 85 61 E-mail : f14w9qs9@ibmmail.com Danfoss authorized service shop	India	Dantal Hydraulics PVT Ltd. 805-806 Chiranjeev Tower Nehru Place New Delhi 110019 Tel. : +91 646 01 55 + 642 5036 + 645 3806 Fax : +91 11 647 6089 E-mail : dantal@giasd101.vsnl.net.in Danfoss authorized service shop
Canada	Danfoss Fluid Power 7880 Transmere Drive Mississauga Ontario L5S 1L9 Tel. : +1 905 673 0559 Fax : +1 905 673 5039 E-mail: "no."@danfoss.com Danfoss authorized service shop	France	Danfoss S.a.r.l. Z.A. de Trappes-Elancourt 7, Av. Roger Hennequin P.O. Box 58 F-78193 Trappes-Cedex Tel. : +33 1 30 62 5000 Fax : +33 1 30 62 5009 E-mail : "name"@danfoss.com Danfoss authorized service shop	Iran	Dancool Iran Co. Ltd. Piche Shemiran Kh. Tonekabon No. 15 Teheran 11488 Tel. : +98 21 7532 026 +98 21 7523 835 Fax : +98 21 7530 565
Chile	Talleres Lucas Ltda. Av. Blanco Encalada 1737 Santiago Tel. : +56 2 695 4233 Fax : +56 2 698 2515 E-mail: tlucas@emnet.net	Germany	Danfoss Antriebs- und Regeltechnik GmbH <u>Geschäftsbereich Hydraulik</u> Carl-Legien-Str. 8 D-63073 Offenbach/Main P.O. Box 10 04 53, D-63004 Offenbach/Main Tel. : +49 069 8902 0 Fax : +49 69 8902 319 +49 69 8902 316 E-mail : "name"@danfoss.com Danfoss authorized service shop	Israel	Radion Engineering Company Ltd. 11 Ha'sivim St. P.O.B. 7111 Petah-Tikvah 49250 Tel. : +972 3 922 6688 Fax : +972 3 922 6655 E-mail : main@radion.co.il
China	Danfoss (Tianjin) Ltd. Wuging Development Area Road 3 Tianjin 301 700 Peoples Republic of China Tel. : +86 22 8212 6400 Fax : +86 22 8212 6407 E-mail: danfoss@public.tpt.tj.cn Symbridge International Room E 12F GaoJia Building No. 1 Chungfeng Road Shenzhen 518 005 P.R. China Tel. : +86 755 218 6843 Fax : +86 755 217 0147	Great Britain	Danfoss Limited Perivale Industrial Park Horsenden Lane South Greenford, Middx. UB6 7QE Tel. : +44 081 991 7000 Fax : +44 181 991 7053 E-mail : "name"@danfoss.com Danfoss authorized service shop	Italy	Danfoss s.r.l. Division Sordella Strada Carignano 48 I-10024 Moncalieri / Torino Tel. : +39 11 682 7111 Fax : +39 11 682 7199 Danfoss authorized service shop
				Japan	Danfoss K.K. Head Office Shinyokohama Mineta Bldg. 3-19, Shinyokohama 2-chome Kohoku-ku Yokohama, 222-0033 Japan Tel. : +81 45 476 5001 Fax : +81 45 476 5010 E-mail : info@danfoss.co.jp Danfoss authorized service shop
				Jordan	Nicola M. Nassar & Sons 7th Circle - Royal Jordanian City Terminal (I) Bld. P.O. Box 808 Amman 11118, Jordan Tel. : +2 962 65 859 472 Fax : +2 962 65 859 473 E-mail : nicolaco@go.com.jo

Danfoss Hydraulics Organization

Korea	Unitex Corporation Korea World Trade Center P.O. Box 181 Room 201 Seokyeong Bldg. 1000-3 Daichi-Dong, Kang Nam-Ku Seoul, Korea Tel. : +82 2 567 0090 Fax : +82 2 569 2894 E-mail : unitex@ktnet.co.kr. Danfoss authorized service shop	Poland	Danfoss Sp. z o.o. ul. Obozowa 20, 01-161 Warszawa Tel. : +48 632 00 75, 632 39 81, 632 43 84 Fax : +48 632 69 32 E-mail : info@danfoss.com.pl Danfoss Sp. z o.o. ul. Chrzanowska 5 PL 05-825 Grodzisk Mazowiecki Poland	Sweden	Danfoss AB Brita Sahlgrens Gata 8C Box 9143 S-400 93 Göteborg Tel. : +46 031 709 27 00 Fax : +46 031 709 27 49 E-mail: H"initial"@danfoss.com (B. Oberg ex: Hboe@danfoss.com) Danfoss authorized service shop
Malaysia	Danfoss Industries Sdn. Bhd. No: 12B, Jalan Penyelenggara U1/77 Taman Perindustrian Batu Tiga 40150 Shah Alam, Selangor Tel. : +60 3 550 1685 Fax : +60 3 550 2805 E-mail : danfoss@po.jaring.my	Portugal	Danfoss (Portugal), Lda. Av.do Forte, 8-1º P Edificio Pujol P-2795 Carnaxide Tel. : +351 1 424 8930 Fax : +351 1 417 2466	Switzerland	Danfoss Werner Kuster AG Parkstrasse 6 CH-4402 Frenkendorf Tel. : +41 061 906 1111 Fax : +41 061 906 1121 E-mail: e-mail@danfoss.ch Danfoss authorized service shop
Mexico	Danfoss Compressors, S.A. Mr. Jesus Campos, Hydraulics Department Carr.a Cd. Miguel Alemán 162 Apodaca, N.L. C.P. 66600 Tel. : +52 8 156 56 14 (or) 15 Fax : +52 8 156 56 25 E-mail: danfoss@infosel.net.mx	Republic of South Africa	Danfoss (Pty) Ltd. Cambridge Commercial Park 23 Trinity Close Paulshof Ext. 45 Johannesburg Tel. : +27 11 803 8390 Fax : +27 11 803 8244 Danfoss authorized service shop	Taiwan	Symbridge Machinery Co. Ltd. 28 Lane 205, Sec. 3 Chung Ching North Road P.O. Box 47-132 Taipei/Taiwan R.O.C. Tel. : +886 2 259 10816 8 (three lines) Fax : +886 2 259 14190 E-mail: symbgtap@ms15.hinet.net Service Shops
Netherlands	ltho bv Adm. de Ruyterstraat 2 3115 HB Schiedam P.O. Box 21 3100 AA Schiedam Tel. : +31 10 427 8500 Fax : +31 10 427 1534 E-mail : "name"@danfoss.nl (ex: Jacques.van.der.Windt@danfoss.nl) E-mail : hyd@danfoss.nl (general group) Danfoss authorized service shop	Rumania	Michail Petrache S.C. LYRA PRODIMPX LTD. B-dul Timisoara 41 Bl. P14, Sc. B. Ap. 24 77309 BUCURESTI Tel./fax : 401 725 6677 Mobil : 092 269 844 Internet: http://www.lyra.ro E-mail : lyra@fx.ro	Thailand	Danfoss (Thailand) Co., Ltd. 47/11 Soi Mongkol Nives Ngam Wong Warn Road, Ladyao Jatujak, Bangkok 10900 Tel. : +66 2 561 1130 Fax : +66 2 561 1446
New Zealand	Danfoss (New Zealand) Limited 15 Byron Street P.O. Box 4435 Sydenham, Christchurch Tel. : +64 03 36 56 123 Fax : +64 03 37 94 365 E-mail : "name"@danfoss.com (ex: Broderick@danfoss.com) Danfoss authorized service shop	Russia	Zao Danfoss Marksistskaya ul. 34 109147 Moscow Tel.: +7 095 792 5757 +7 501 792 5757 (Satellite) Fax: +7 095 792 5760 +7 501 792 5760 (Satellite)	Turkey	Mert Teknik Fabr. Alzemetleri Ticaret ve Sanayi A.S. Tersane Cad. No. 43 80000 Karaköy - Istanbul Tel. : +90 0 212 252 8435 Fax : +90 0 212 245 6369 E-mail: info@mert.com Danfoss authorized service shop
Norway	Danfoss A/S Arenga 2 N-1314 Skui Tel. : 47 67 17 7200 Fax : 47 67 13 6850 E-mail : danfoss@online.no Danfoss authorized service shop	Singapore	Danfoss Industries Pte. Ltd. 6 Jalan Pesawat Singapore 619364 Tel. : +65 261 4088 Fax : +65 261 0488 Danfoss authorized service shop	U.S.A.	Danfoss Fluid Power (Head office) Racine operations 8635 Washington Avenue Racine, Wisconsin 53406 Tel. : +1 414 884 7400 Fax : +1 414 884 7440 E-mail: "Name"@danfoss.com (Ole Sigvardt: Osigvardt@danfoss.com) Danfoss authorized service shop
Pakistan	Khan Brothers Engineers 684, Central Commercial Area Allama Iqbal Road P.E.C.H.S., Karachi-75400 Tel. : +92 21 452 6002/6003/6004 or 6005 Fax : +92 21 454 5995	Slovenia	Technical Office Klun Ul. Bratov Martinec 16 SI-1000 Ljubljana Slovenija Tel. : +386 61 127 3718 Fax : +386 61 127 1624		Danfoss Fluid Power, Easley Operations 1201 Pelzer Highway P.O. Box 2189 Easley, South Carolina 29640 Tel. : +1 864 855 2884 Fax : +1 864 855 5885 (general) +1 864 855 6010 (executive office)
		Spain	Danfoss S.A. Avda. Tenerife No. 22 Pol. Ind. Norte 28700 San Sebastian de los Reyes (Madrid) Tel. : +34 91 663 8051 Fax : +34 91 663 7570 E-mail : "NO."@danfoss.com (Luis Baque: SPOO16@danfoss.com) Danfoss authorized service shop		

Sauer-Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed or electronic material. Sauer-Danfoss reserves the right to alter its products without prior notice. This also applies to products already ordered provided that such alterations can be made without subsequent changes being necessary in specifications already agreed. All trademarks in this material are properties of the respective companies. Sauer-Danfoss and the Sauer-Danfoss logotype are trademarks of the Sauer-Danfoss Group. All rights reserved.

Hydraulic motor OMM
All standard versions and OMM
with integrated pressure relief valve

DKHM.PS.170.A1.93 replaces HN.17.X2.93




Contents

	<u>Page</u>
Special versions	2
Cost-free repairs.....	2
Series marking	2
Service shops.....	3
Exploded view OMM series 3.....	4
Spare parts list	5
Tools	6
Dismantling.....	7
Assembling	9

Specialudførelse	Reservedelslisten kan ikke anvendes til bestilling af reservedele til OMM i specialudførelser. Kontakt venligst salgsorganisationen for Danfoss Hydraulik vedrørende dette spørgsmål.
Special versions	The list of spare parts cannot be used for ordering parts for special OMM versions. In this respect, please contact the sales organisation for Danfoss Hydraulics.
Sonderausführung	Die Ersatzteilliste kann nicht für Bestellung von Ersatzteilen für OMM in Sonderausführungen benutzt werden. Wenden Sie sich diesbezüglich bitte an die Verkaufsorganisation für Danfoss Hydraulik.
Version spéciale	La liste de pièces de rechange ne peut pas être utilisée pour commander pièces de rechange pour OMM en versions spéciales. A ce sujet, vous êtes priés de vous adresser à l'organisation de vente de composants hydrauliques Danfoss.
Vederlagsfri reparation	Vi gør opmærksom på, at den vederlagsfrie reparation som er omtalt i Danfoss' Almindelige Leveringsbetingelser kun udføres hos Danfoss Nordborg eller hos Danfoss autoriserede service shops.
Cost-free repairs	Please note that cost-free repairs as mentioned in Danfoss' General Conditions of Sale, are carried out only at Danfoss Nordborg or at service shops authorised by Danfoss.
Kostenlose Reparatur	Beachten Sie bitte, daß die in den "Allgemeinen Lieferbedingungen" von Danfoss erwähnte kostenlose Reparatur nur bei Danfoss Nordborg oder bei den autorisierten Danfoss Kundendienstwerkstätten ausgeführt wird.
Réparation gratuite	Nous faisons observer que la réparation gratuite mentionnée dans les Conditions générales de Vente de Danfoss ne devra être effectuée que dans les ateliers Danfoss à Nordborg ou dans les ateliers de dépannage agréés par Danfoss.
Seriemærkning	Serienummer ændres, når der foretages ændringer af dele i motorerne. OMM er mærket med seriebetegnelse efter datomærkningen xxx-3
Series marking	The series number is altered when parts in the motor are changed. The OMM series marking follows its date marking: xxx-3
Serienkennzeichnung	Bei Teileänderungen im Motor wird die Seriennummer geändert. Die Kennzeichnung von OMM erfolgt mit einer Serienbezeichnung nach dem Datumstempel: xxx-3
Marquage de série	A toute modification d'une ou de plusieurs pièces des moteurs correspond un changement de numéro de série. Les moteurs OMM portent leur numéro de série à la suite de la date, par exemple: xxx-3

Authorized Service Shops	Australia	: Danfoss (Australia) Pty. Ltd., Melbourne
	Austria	: Hainzl Industriesysteme, GmbH., Linz
	Belgium	: N.V. Danfoss S.A., Bruxelles
	Brazil	: Danfoss do Brasil Ind.e Com. Ltda., São Paulo
	Canada	: Danfoss Mfg. Ltd., Mississauga
	Denmark	: Danfoss Hydraulik A/S, Gamløse
	Finland	: OY Danfoss AB, Espoo
	France	: Danfoss S.a.r.l., Trappes (Paris)
	Germany	: Danfoss GmbH., Offenbach/Main
	Great Britain	: Danfoss Limited, Greenford (London)
	Iceland	: Hedinn Verslun HF, Reykjavik
	India	: Dantal Hydraulics PVT Ltd., New Delhi
	Italy	: Danfoss s.r.l. Division Sordella, Torino
	Japan	: Danfoss K.K., Gotemba
	Korea	: Unitek Corporation, Seoul
	Netherlands	: Itho B.V., Schiedam
	New Zealand	: Danfoss (New Zealand) Limited, Auckland
	Norway	: Danfoss A/S, Skui
	Republic of South Africa	: Danfoss (Pty) Ltd., Johannesburg
	Singapore	: Danfoss Industries Pte. Ltd., Singapore
	Spain	: Danfoss S.A., San Sebastian de los Reyes, (Madrid)
Service Shops	Sweden	: Danfoss AB, Mjölby
	Switzerland	: Danfoss Werner Kuster AG, Frenkendorf
	Turkey	: Mert Teknik A.S., Istanbul
	U.S.A.	: Danfoss Fluid Power Div. Racine, Wisconsin
	Australia	: Danfoss (Australia) Pty. Ltd., Adelaide
	Australia	: Danfoss (Australia) Pty. Ltd., Brisbane
	Australia	: Danfoss (Australia) Pty. Ltd., Perth
	Australia	: Danfoss (Australia) Pty. Ltd., Sydney
	Czech Rep.	: Techno Trade, Olomouc
	Greece	: A. Skoura & Co. E.E., Athens
	New Zealand	: Danfoss (New Zealand) Limited, Christchurch
	Taiwan	: Symbridge Machinery Co. Ltd., Taipei

Exploded view OMM series 3



DANFOSS
A131-1007.18.17

Tilspændingsmoment / Tightening torque			
Anzugsmoment / Couple de serrage			
Item	18:	Drain plug	0.5 - 1.0 daNm (45 - 90 lbf in)
Item	20:	Screw M8 x 1.25	2.2 - 2.8 daNm (200 - 250 lbf in)

Spare parts list

Item	Spare parts	Stock per 100 motors**		
		Number per motor		
		Code No.		
1	Drive screw	681Z1011	2	100
2	<u>Name plate</u> Aluminium Brass	151A0237 151A0239	1 1	10 10
3	Housing + output shaft	Not sold separately		
4	Dust seal ring 17 x 23 x 5 mm NBR	633B3373	1	*
5	<u>Shaft seal</u> BAKHD ring 17 x 28,2 x 5.5 mm NBR BAHD ring 17 x 28,2 x 5.5 mm FPM	633B3208 633B3390	1 1	* *
6	Bearing race	151G0307	1	15
7	Axial needle bearing	981X3172	1	50
8	<u>Parallel key</u> 5 x 5 x 16 DIN 6885 3/16 x 3/16 x 3/4 B.S. 46	682L8026 682L8031	1 1	50 50
10	Distributor plate	151G0314	1	10
11	<u>Cardan shaft</u> OMM 8 l = 54 mm OMM 12.5 l = 56 mm OMM 20 l = 59 mm OMM 32/50 l = 64 mm	151G0369 151G0101 151G0310 151G0311	1 1 1 1	10 10 10 10
12	<u>Gearwheel set</u> OMM 8 w = 3.5 mm OMM 12.5 w = 5.5 mm OMM 20 w = 8.5 mm OMM 32 w = 13.5 mm OMM 50 w = 21.5 mm	151G0119 151G0101 151G0102 151G0103 151G0117	1 1 1 1 1	10 10 10 10 10
13	O-ring 54 x 1.5 mm NBR	633B1487	4	*
14	Intermediate plate	151G0332	1	10
15	Check valve ball	689X1005	2	10
16	<u>End cover</u> G 3/8 in end ports 9/16 - 18 UNF end ports	151G0113 151G0110	1 1	5 5
16a	<u>End cover</u> G 3/8 in side ports 9/16 - 18 UNF side ports	151G0109 151G0110	1 1	5 5
17	<u>Seal plugs</u> G 3/8 in ports 9/16 - 18 UNF ports	633X7009 633X7023	2 2	20 20
18	<u>Drain plug</u> G 1/8 thread 3/8 - 24 UNF ports	631X2053 151G0111	1 1	5 5
19	Washer 8.2 x 11.9 x 1 mm	684X2481	3	*
20	<u>Screw M8 x 1.25; for end port motor</u> OMM 8 l = 40 mm OMM 12.5 l = 40 mm OMM 20 l = 45 mm OMM 32 l = 50 mm OMM 50 l = 55 mm	681X0358 681X0358 681X0359 681X0360 681X0324	3 3 3 3 3	18 18 18 18 18
20a	<u>Screw M8 x 1.25; for side port motor</u> OMM 8 l = 45 mm OMM 12.5 l = 45 mm OMM 20 l = 50 mm OMM 32 l = 55 mm OMM 50 l = 60 mm	681X0359 681X0359 681X0360 681X0324 681X0098	3 3 3 3 3	18 18 18 18 18
21	Mounting flange; for metric version only	151G0336	1	5

Spare parts list

Item	Spare parts	Stock per 100 motors**		
		Number per motor		
		Code No.		
22	Screw M6 x 1.25 for mounting flange l = 12 mm	681X2260	3	15
23	Mounting flange and screws (Item 21 + 22) for metric version only.	151G0211		
	<u>Spare parts bag</u>	151G0202	1	5
4	Dust seal ring 1 pcs. 633B3373			
5	Shaft seal NBR 1 pcs. 633B3208			
13	O-ring 4 pcs. 633B1487			
19	Washer 3 pcs 684X2481			

NBR: (Buna N, Perbunan)

* Indeholdt i reservedelsposen.

* Contained in spare parts bag.

* Im Ersatzteilbeutel enthalten.

* Contenu dans le sachet de pièces de rechange.


** Antall reservedele som De bør have på lager for hver 1000 motorer der er i brug i Deres område.

** The number of spare parts to be held in stock for each 1000 motors in operation in your district.


** Die Anzahl von Ersatzteilen, die Sie für je 1000 Motoren, die in Ihrem Gebiet verwendet werden, auf Lager haben sollten.

** Les quantités de pièce de rechange que vous devez prévoir en stock pour 1000 moteurs actuellement en service dans votre secteur.


Special tools




Main holding tool:
Code no.: SJ 150-9000-2



Fork. For use when fitting OMM cardan shaft.
Code no.: SJ 151G9000-1



Bush for use with main holding tool.
Code no.: SJ 151G9000-2



Mandrel for fitting shaft seal:
Code no.: SJ 151G9000-5

Dismantling

Item	Part to remove	Comments
8	Key	Fjern feder fra udgangsaksel (kun cylindrisk aksel). Remove key from output shaft. (Cylindrical shafts only). Feder von der Abtriebswelle entfernen (nur zylindrische Welle). Enlever la clavette de l'arbre de sortie (arbres cylindriques seulement).
17	Seal plugs	Placer motor i holdeværktøj med udgangsaksel nederst. Place the motor in holding tool with the output shaft down wards. Den Motor mit der Abtriebswelle nach unten im Haltewerkzeug anbringen. Placer le moteur dans l'outil avec l'arbre de sortie en bas.
18	Drain plug	Benyt 5 mm unbrakonøgle. Use 5 mm Allen key. 5 mm Inbusschlüssel benutzen. Utiliser une clé Allen de 5 mm.
19, 20	Screws washers (3 off)	Benyt 6 mm unbrakonøgle. Use 6 mm Allen key. 6 mm Inbusschlüssel benutzen. Utiliser une clé Allen de 6 mm.
15, 16	End cover Check valves balls	Fjern endedæksel sideværts. Pas på kontraventilkugler. Remove end cover sideways. Mind the check valve balls. Den Enddeckel seitwärts entfernen. Auf Rückschlagventilkugeln achten. Enlever le couvercle latéralement. Attention aux billes du clapet antiretour.
13, 14	O-ring Intermediate plate	Fjern O-ring og mellemlade. Remove O-ring and intermediate plate. O-Ring und Zwischenplatte entfernen. Enlever le joint torique et la plaque intermédiaire.
12, 13	Gearweel set O-rings (2 off)	Hold fingrene under tandhjulsættet for at forhindre delene i at falde ud. Hold fingers under the gearweel set to prevent the parts from dropping out. Halten Sie die Finger unter dem Zahnradsatz, damit die Teile nicht herausfallen.. Tenir le jeu d'engrenage par le dessous pour éviter de perdre des pièces.
11	Cardan shaft	Fjern kardanakslen. Remove cardan shaft. Kardanwelle entfernen. Enlever l'arbre à cardan
13, 12	Distributor plate	Fjern fordelerplade og O-ring. Remove distributor plate and O-ring. Verteilerplatte und O-Ring entfernen. Enlever la plaque de distribution et le joint torique.
3	Output shaft	Tag udgangsakslen ud af huset. Take output shaft out of housing. Abtriebswelle aus dem Gehäuse heraus nehmen. Sortir l'arbre de sortie du carter.
6, 7	Bearing race Axial needle bearing	Ryst nåleleje og løbeskinne ud af huset. Shake needle bearing and bearing race out of housing. Nadellager und Laufscheibe aus dem Gehäuse herausschütteln. Secouer le carter pour le roulement à aiguilles et la baque de roulement.

Dismantling

Item	Part to remove	Comments
4	Dust seal ring	Fjern støvtætningsring med skruetrækker. Remove dust seal ring with screwdriver. Staubdichtungsring mit Schraubenzieher entfernen. Enlever la bague anti-poussière avec un tournevis.
5	Shaft seal	Fjern akselpakning med skruetrækker. Remove shaft seal with screwdriver. Wellendichtung mit Schraubenzieher entfernen. Enlever le joint d'arbre avec un tournevis.

**Rensning, kontrol,
udskiftning og smøring**

Rensning
Alle dele rengøres omhyggeligt.

Kontrol og udskiftning
Kontroller omhyggeligt alle dele og skift dem ud om nødvendigt.
Alle pakningsdele udskiftes i forbindelse med reparation.

Smøring
Smør alle enkeltdele ind i hydraulikolie og indfedt gummideler med vaseline før samling.

**Cleaning, inspection,
replacement and
lubrication**

Cleaning
Clean all parts carefully.

Inspection and replacement
Check all parts carefully and replace, if necessary.
All sealing parts must always be replaced during a repair.

Lubrication
Before assembly, lubricate all parts with hydraulic oil, and grease rubber parts with vaseline.

**Reinigung, Kontrolle,
Austausch und
Schmierung**

Reinigung
Alle Teile sorgfältig reinigen.

Kontrolle und Auswechselung
Alle Teile sorgfältig kontrollieren und - wenn nötig - auswechseln.
Alle Dichtungsteile müssen in Verbindung mit einer Reparatur ausgewechselt werden.

Schmierung
Vor dem Zusammenbau alle Einzelteile mit Hydrauliköl und Gummiteile mit Vaseline einfetten.


**Nettoyage, contrôle,
remplacement et
graissage**

Nettoyage
Nettoyer soigneusement toutes les pièces.



Contrôle et remplacement
Contrôler minutieusement toutes les pièces et les remplacer au besoin.
Lors d'une réparation, remplacer tous les joints.

Graissage
Avant de procéder à leur rassemblement, enduire toutes les pièces détachées d'huile hydraulique et tous les joints de vaseline.

Assembly

Item	Part to mount	Comments
5	Shaft seal	<p>Monter akselpakning i motorhus ved hjælp af dorn og plastic hammer.</p> <p>Fit shaft seal into motor housing by means of mandrel and plastic hammer.</p> <p>Wellendichtung anhand Dorn und Kunststoffhammer ins Motorgehäuse montieren.</p> <p>Monter le joint d'arbre dans le carter au moyen de mandrin et de marteau plastique.</p>
4	Dust seal ring	<p>Benyt monteringsdorn og plashammer.</p> <p>Use assembly mandrel and plastic hammer.</p> <p>Montagedorn und Kunststoffhammer benutzen.</p> <p>Utiliser le mandrin d'assemblage, et le maillet en plastique.</p>
6, 7	Bearing race Axial needle bearing	<p>Monter nåleleje og løbeskive på aksel.</p> <p>Fit needle bearing and bearing race on to shaft.</p> <p>Nadellager und Laufscheibe auf die Welle montieren.</p> <p>Remonter le roulement à aiguilles et la baque de roulement sur l'arbre.</p>
3	Output shaft 	<p>Akselsølerne smøres med hydraulikolie.</p> <p>Mærk udgangsakslen mellem to kommuteringsriller.</p> <p>Før akslen på plads i motorhuset.</p> <p>Grease the axle journals with hydraulic oil.</p> <p>Mark output shaft in the middle between two commutation grooves. Install shaft in motor housing.</p> <p>Die Gleitlager der Welle mit Hydrauliköl einsmieren.</p> <p>Abtriebswelle zwischen zwei Kommutierungsritzen kennzeichnen. Welle ins Motorgehäuse montieren.</p> <p>Enduire les paliers glissants d'huile hydraulique.</p> <p>Avec un crayon à feutre, marquer la partie vanne de l'arbre de sortie en face du milieu de deux rainures de commutation.</p> <p>Monter l'arbre dans le carter.</p>
8	Parallel key	<p>Monter feder i udgangsaksel. (Kun cylindrisk aksel).</p> <p>Placer motorhus med aksel i holdeværktøj.</p> <p>Fit key in to output shaft. (Cylindrical shafts only).</p> <p>Place motor housing with shaft in holding tool.</p> <p>Feder in Abtriebswelle montieren. (Nur zylindrische Welle).</p> <p>Motorgehäuse mit Welle ins Haltewerkzeug anbringen.</p> <p>Monter la clavette dans l'arbre de sortie. (arbres cylindriques seulement). Placer le carter avec l'arbre dans l'outil de montage.</p>
13	O-ring	<p>Indfedt O-ringen og læg den i husets O-ringsrille.</p> <p>Grease the O-ring and put into the O-ring groove in the housing.</p> <p>Den O-Ring einfetten und in die O-Ring-Rille des Gehäuses legen.</p> <p>Graisser le joint et le placer dans sa rainure dans le carter.</p>

Assembly

Item	Part to mount	Comments
11	Cardan shaft 	<p>Før kardanakslen ned i udgangsaksel. Overfør markering fra udgangsaksel til kardanaksel.</p> <p>Hold kardanakslen oppe ved brug af gaffel.</p> <p>Guide the cardan shaft down into the output shaft. Transfer the mark from output shaft to cardan shaft.</p> <p>Support cardan shaft with the fork.</p> <p>Kardanwelle in die Abtriebswelle einführen. Markierung von der Abtriebswelle auf die Kardanwelle übertragen.</p> <p>Kardanwelle mit der Gabel angehoben halten.</p> <p>Glisser l'arbre à cardan dans l'arbre de sortie. Transposer le marquage de l'arbre de sortie à l'arbre à cardan.</p> <p>Maintenir l'arbre à cardan soulevé dans la fourche.</p>
10	Distributor plate	<p>Placer fordelerplade på huset. Drej fordelerplade så huller flugter.</p> <p>Place the distributor plate on the housing. Turn the distributor plate so that the holes line up.</p> <p>Verteilerplatte an das Gehäuse anbringen. Die Verteilerplatte so drehen, daß die Löcher fluchten.</p> <p>Placer la plaque distribution sur le carter. Ajuster la plaque de distribution pour aligner les trous.</p>
13	O-rings	<p>Indfædt O-ringe og monter dem i riller i tandsæt.</p> <p>Lubricate the O-rings and fit them into the recesses in the gearwheel set.</p> <p>O-Ringe einfetten und in die Rillen im Zahnradsatz montieren.</p> <p>Graisser les joints toriques et les remonter dans les encoches de jeu d'engrenages.</p>
12	Gearwheel set 	<p>Monter tandsæt på fordelerplade (og gaffel). For at sikre korrekt omløbsretning skal markeringen på kardanakslen være midt imellem 2 tandtoppe på tandhjulets udvendige fortanding.</p> <p>Fit the gearwheel set onto the distributor plate (and fork). To ensure correct direction of rotation the mark of the cardan shaft must be in the middle of two tooth peaks on the external toothing of the gearwheel.</p> <p>Zahnradsatz auf Verteilerplatte (und Gabel) montieren. Um die richtige Drehrichtung sicherzustellen, muß sich die Markierung der Kardanwelle zwischen zwei Zahnköpfen der äußeren Verzahnung befinden.</p> <p>Remonter le jeu d'engrenages sur la plaque de distribution (et la fourche). Pour obtenir le sens de rotation correct, s'assurer que la marque sur l'arbre se trouve au milieu des deux pointes d'une dent extérieure du jeu d'engrenage.</p>
13	O-ring	<p>Indfædt O-ringen og monter den i rillen i mellemladen.</p> <p>Lubricate the O-ring and fit it into the recess in the intermediate plate.</p> <p>O-Ring einfetten und in die Rille der Zwischenplatte montieren.</p> <p>Graisser le joint torique et le remonter dans l'encoche de la plaque intermédiaire.</p>

Assembly

Item	Part to mount	Comments
14	Intermediate plate	<p>Placer mellemlade på tandsæt så huller for sammen-spændingsskruer flugter.</p> <p>Place the intermediate plate on the gearwheel set so that the holes for tightening screws line up.</p> <p>Zwischenplatte auf den Zahnradsatz so anbringen, daß die Löcher für die Befestigungsschrauben fluchten.</p> <p>Placer la plaque intermédiaire sur le jeu d'engrenages pour aligner les trous des vis de fixation.</p>
15	Check valves balls	<p>Indfedt kuglerne og placer dem i hullerne i mellemladen.</p> <p>Lubricate the check valve balls and place them in the holes in the intermediate plate.</p> <p>Kugeln einfetten und in die Löcher in der Zwischenplatte anbringen.</p> <p>Graisser les billes et les placer dans les trous de la plaque intermédiaire.</p>
16	End cover	<p>Monter endedæksel på mellemlade.</p> <p>Fit the end cover onto the intermediate plate.</p> <p>Enddeckel auf die Zwischenplatte montieren.</p> <p>Remonter le couvercle sur la plaque intermédiaire.</p>
20	Screws (3 off)	<p>Skrue de tre sammenspændingsskruer løst i huset og fjern gaffelen. Spænd herefter skruerne med momentnøgle. Tilspændingsmoment: 2.2 - 2.8 daNm.</p> <p>Loosely screw the three retaining screws into the housing and remove the fork. Then tighten the screws with a torque wrench. Tightening torque: 2.2 - 2.8 daNm.</p> <p>Die drei Verbindungsschrauben locker in das Gehäuse einschrauben und Gabel entfernen. Dann die Schrauben mit Drehmomentschlüssel anziehen.</p> <p>Anzugsmoment: 2.2 - 2.8 daNm.</p> <p>Visser sans resserrer les trois vis d'assemblage dans le carter et enlever la fourche. En utilisant une clé dynamométrique, resserrer ensuite les trois vis; couple 2.2 - 2.8 daNm.</p>
17, 18	Seal plugs Drain plug	<p>Skrue plastpropper i tilslutningsporte. Skru drænprop i dræntilslutning med momentnøgle.</p> <p>Tilspændingsmoment: 0.5 - 1.0 daNm.</p> <p>Screw plastic plugs into connection ports.</p> <p>Screw drain plug into the drain port with a torque wrench.</p> <p>Tightening torque: 0.5 - 1.0 daNm.</p> <p>Kunststoffstopfen in die Anschlußöffnungen einschrauben.</p> <p>Leckölstopfen mit Drehmomentschlüssel in den Leckölanschluß montieren.</p> <p>Anzugsmoment: 0.5 - 1.0 daNm.</p> <p>Visser les bouchons synthétiques dans les orifices de raccordement.</p> <p>Visser le bouchon de drainage dans le raccord de drainage avec une clé dynamométrique;</p> <p>couple: 0.5 - 1.0 daNm.</p>

Danfoss Hydraulics Organization

Danfoss is an international concern with factories in 10 countries and subsidiaries in 32 countries. In addition to the hydraulic components, the Danfoss range of products includes refrigeration controls, industrial automatics, precision step systems, industrial instrumentations, electrical drives and controls, controls for heating plant, system controls, components for burners and boilers, compressors and thermostats for refrigerators and freezers.

Argentina	Danfoss S.A. San Lorenzo 4310 1605 Munro Buenos Aires Tel. : +54 1 756 4200 Fax : +54 1 756 4100 E-mail: danfoss@interserver.com.ar Ing. Lahusen S.R.L. Av. Belgrano, 615 - 8° I 1092 - Buenos Aires Tel. : +54 1 342 1083/1835 Fax : +54 1 331 7314	Colombia	Fiza Ltda. Carrera 40 N° 163-A-55 (Toberin) Santafé de Bogotá D.C. Colombia S.A. Tel. : +57 1 677 6346/677 6440 Tel. : +57 1 677 5142 Fax : +57 677 7025 E-mail : fisaza@anditel.andinet.lat.net	Greece	A. Skoura A.E. Spirou Patsi 105 GR-118 55 Athens Tel. : +30 1 345 3906 Tel. : +30 1 346 3967 Fax : +30 1 347 4106 (Skouras) E-mail : skoura@otenet.gr Service Shops
Australia	Danfoss (Australia) Pty. Ltd. P.O. Box 6484, Silverwater New South Wales 2128 199 Parramatta Road, Auburn New South Wales, 2144 Tel. : +61 02 9648 4982 Fax : +61 02 9748 0573 E-mail: inter@danfoss.com.au	Cyprus	Tektron Ltd. 25, Heroes Street P.O. Box 2123 Strovolos-Nicosia Tel. : +357 2 49 7907 Fax : +357 2 31 4844 E-mail : TEKTRON@cytanet.com.cy	Hong Kong	Nicko International RM. 1203, Chevalier Commercial Centre 8 Wang Hoi Road Kowloon Bay, Hong Kong Tel. : +852 2755 2783 Fax : +852 2798 8656 E-mail : sales@nicko.com.hk
Austria	Hainzl Industriesysteme Gesellschaft m.b.H. & Co KG Industriezeile 56 P.O. Box 100 A-4040 Linz Tel. : +43 732 7892 Fax : +43 732 7892 150 E-mail: info@hainzl.at Danfoss authorized service shop	Czech Republic Slovak Republic	Techno Trade GmbH Dipl. Ing. Petr Kejduš Tovární ul. 41 CZ 772 00 Olomouc Tel. : +420 68 52 22 004 Fax : +420 68 52 32 055 E-mail : Technotrade@traveller.cz Service Shops	Hungary	Kite RT. 4181 Nadudvar, Bem. J.U.2. Tel. : +36 54 48 0401 Fax : +36 54 48 0331
Belgium	N.V. Danfoss S.A. Erasmus Business Park Av. Joseph Wybran 45 B-1070 Bruxelles Tel. : +32 02 525 0711 Fax : +32 02 525 0757 E-mail: "name"@danfoss.be (ex: Daniel_Titeka@danfoss.be) Danfoss authorized service shop	Denmark	Danfoss Fluid Power A/S DK-6430 Nordborg International tel.: +45 74 88 22 22 National tel.: +74 88 22 22 Telex : 50599 Fax : +45 74 49 09 49 Tel. : +45 74 49 16 13 (Hydr.) Tel. : +45 74 88 55 95 (Overseas) Tel. : +45 74 49 04 90 (Logistic) E-mail : danfoss@danfoss.com	Iceland	Hedinn Verslun HF Seljavegi 2 P.O. Box 512 IS-121 Reykjavik Tel. : +354 562 4260 Fax : +354 562 4315 E-mail : "name"@hedinn-verslun.is (ex: gisli@hedinn-verslun.is) Danfoss authorized service shop
Brazil	Danfoss do Brasil Ind. e Com. Ltda. Rua Nelson Francisco 26, Casa Verde CEP 02712-100 São Paulo - SP Tel. : +55 11 855 5400 Fax : +55 11 855 5455 E-mail: danfoss@danfoss.com.br Danfoss authorized service shop	Finland	OY Danfoss AB Kivenlaudentie 7 SF-02360 Espoo Tel. : +358 9 802 81 Fax : Hydraulics dept. +358 9 802 85 61 E-mail : f14w9qs9@ibmmail.com Danfoss authorized service shop	India	Dantal Hydraulics PVT Ltd. 805-806 Chiranjeev Tower Nehru Place New Delhi 110019 Tel. : +91 646 01 55 + 642 5036 + 645 3806 Fax : +91 11 647 6089 E-mail : dantal@giastd101.vsnl.net.in Danfoss authorized service shop
Canada	Danfoss Fluid Power 7880 Transmere Drive Mississauga Ontario L5S 1L9 Tel. : +1 905 673 0559 Fax : +1 905 673 5039 E-mail: "no."@danfoss.com Danfoss authorized service shop	France	Danfoss S.a.r.l. Z.A. de Trappes-Elancourt 7, Av. Roger Hennequin P.O. Box 58 F-78193 Trappes-Cedex Tel. : +33 1 30 62 5000 Fax : +33 1 30 62 5009 E-mail : "name"@danfoss.com Danfoss authorized service shop	Iran	Dancool Iran Co. Ltd. Piche Shemiran Kh. Tonekabon No. 15 Teheran 11488 Tel. : +98 21 7532 026 Tel. : +98 21 7523 835 Fax : +98 21 7530 565
Chile	Talleres Lucas Ltda. Av. Blanco Encalada 1737 Santiago Tel. : +56 2 695 4233 Fax : +56 2 698 2515 E-mail: tlucas@emnet.net	Germany	Danfoss Antriebs- und Regeltechnik GmbH <u>Geschäftsbereich Hydraulik</u> Carl-Legien-Str. 8 D-63073 Offenbach/Main P.O. Box 10 04 53, D-63004 Offenbach/Main Tel. : +49 069 8902 0 Fax : +49 69 8902 319 Tel. : +49 69 8902 316 E-mail : "name"@danfoss.com Danfoss authorized service shop	Israel	Radion Engineering Company Ltd. 11 Ha'sivim St. P.O.B. 7111 Petah-Tikvah 49250 Tel. : +972 3 922 6688 Fax : +972 3 922 6655 E-mail : main@radion.co.il
China	Danfoss (Tianjin) Ltd. Wuging Development Area Road 3 Tianjin 301 700 Peoples Republic of China Tel. : +86 22 8212 6400 Fax : +86 22 8212 6407 E-mail: danfoss@public.tpt.tj.cn Symbridge International Room E 12F GaoJia Building No. 1 Chungfeng Road Shenzhen 518 005 P.R. China Tel. : +86 755 218 6843 Fax : +86 755 217 0147	Great Britain	Danfoss Limited Perivale Industrial Park Horsenden Lane South Greenford, Midx. UB6 7QE Tel. : +44 081 991 7000 Fax : +44 181 991 7053 E-mail : "name"@danfoss.com Danfoss authorized service shop	Italy	Danfoss s.r.l. Division Sordella Strada Carignano 48 I-10024 Moncalieri / Torino Tel. : +39 11 682 7111 Fax : +39 11 682 7199 Danfoss authorized service shop
				Japan	Danfoss K.K. Head Office Shinyokohama Mineta Bldg. 3-19, Shinyokohama 2-chome Kohoku-ku Yokohama, 222-0033 Japan Tel. : +81 45 476 5001 Fax : +81 45 476 5010 E-mail : info@danfoss.co.jp Danfoss authorized service shop
				Jordan	Nicola M. Nassar & Sons 7th Circle - Royal Jordanian City Terminal (I) Bld. P.O. Box 808 Amman 11118, Jordan Tel. : +2 962 65 859 472 Fax : +2 962 65 859 473 E-mail : nicolaco@go.com.jo

Danfoss Hydraulics Organization

Korea	Unitex Corporation Korea World Trade Center P.O. Box 181 Room 201 Seokyoung Bldg. 1000-3 Daichi-Dong, Kang Nam-Ku Seoul, Korea Tel. : +82 2 567 0090 Fax : +82 2 569 2894 E-mail : unitex@ktnet.co.kr. Danfoss authorized service shop	Poland	Danfoss Sp. z o.o. ul. Obozowa 20, 01-161 Warszawa Tel. : +48 632 00 75, 632 39 81, 632 43 84 Fax : +48 632 69 32 E-mail : info@danfoss.com.pl Danfoss Sp. z o.o. ul. Chrzanowska 5 PL 05-825 Grodzisk Mazowiecki Poland	Sweden	Danfoss AB Brita Sahlgrens Gata 8C Box 9143 S-400 93 Göteborg Tel. : +46 031 709 27 00 Fax : +46 031 709 27 49 E-mail: H"initial"@danfoss.com (B.Öberg ex: Hboe@danfoss.com) Danfoss authorized service shop
Malaysia	Danfoss Industries Sdn. Bhd. No: 12B, Jalan Penyelenggara U1/77 Taman Perindustrian Batu Tiga 40150 Shah Alam, Selangor Tel. : +60 3 550 1685 Fax : +60 3 550 2805 E-mail : danfoss@po.jaring.my	Portugal	Danfoss (Portugal), Lda. Av.do Forte, 8-1º P Edificio Pujol P-2795 Carnaxide Tel. : +351 1 424 8930 Fax : +351 1 417 2466	Switzerland	Danfoss Werner Kuster AG Parkstrasse 6 CH-4402 Frenkendorf Tel. : +41 061 906 1111 Fax : +41 061 906 1121 E-mail: e-mail@danfoss.ch Danfoss authorized service shop
Mexico	Danfoss Compressors, S.A. Mr. Jesus Campos, Hydraulics Department Carr.a Cd. Miguel Alemán 162 Apodaca, N.L. C.P. 66600 Tel. : +52 8 156 56 14 (or) 15 Fax : +52 8 156 56 25 E-mail: danfoss@infosel.net.mx	Republic of South Africa	Danfoss (Pty) Ltd. Cambridge Commercial Park 23 Trinity Close Paulshof Ext. 45 Johannesburg Tel. : +27 11 803 8390 Fax : +27 11 803 8244 Danfoss authorized service shop	Taiwan	Symbridge Machinery Co. Ltd. 28 Lane 205, Sec. 3 Chung Ching North Road P.O. Box 47-132 Taipei/Taiwan R.O.C. Tel. : +886 2 259 10816 8 (three lines) Fax : +886 2 259 14190 E-mail: symbgatap@ms15.hinet.net Service Shops
Netherlands	Itho bv Adm. de Ruyterstraat 2 3115 HB Schiedam P.O. Box 21 3100 AA Schiedam Tel. : +31 10 427 8500 Fax : +31 10 427 1534 E-mail : "name"@danfoss.nl (ex: Jacques.van.der.Windt@danfoss.nl) E-mail : hyd@danfoss.nl (general group) Danfoss authorized service shop	Rumania	Michail Petrache S.C. LYRA PRODIMPEx Ltd. B-dul Timisoara 41 Bl. P14, Sc. B. Ap. 24 77309 BUCURESTI Tel./fax : 401 725 6677 Mobil : 092 269 844 Internet: http://www.lyra.ro E-mail : lyra@fx.ro	Thailand	Danfoss (Thailand) Co., Ltd. 47/11 Soi Mongkol Nives Ngam Wong Worn Road, Ladyao Jatujak, Bangkok 10900 Tel. : +66 2 561 1130 Fax : +66 2 561 1446
New Zealand	Danfoss (New Zealand) Limited 15 Byron Street P.O. Box 4435 Sydenham, Christchurch Tel. : +64 03 36 56 123 Fax : +64 03 37 94 365 E-mail : "name"@danfoss.com (ex: Broderick@danfoss.com) Danfoss authorized service shop	Russia	Zao Danfoss Marksistskaya ul. 34 109147 Moscow Tel.: +7 095 792 5757 +7 501 792 5757 (Satellite) Fax: +7 095 792 5760 +7 501 792 5760 (Satellite)	Turkey	Mert Teknik Fabr. Malzemeleri Ticaret ve Sanayi A.S. Tersane Cad. No. 43 80000 Karaköy - Istanbul Tel. : +90 0 212 252 8435 Fax : +90 0 212 245 6369 E-mail: info@mert.com Danfoss authorized service shop
Norway	Danfoss A/S Årenga 2 N-1314 Skui Tel. : 47 67 17 7200 Fax : 47 67 13 6850 E-mail : danfoss@online.no Danfoss authorized service shop	Singapore	Danfoss Industries Pte. Ltd. 6 Jalan Pesawat Singapore 619364 Tel. : +65 261 4088 Fax : +65 261 0488 Danfoss authorized service shop	U.S.A.	Danfoss Fluid Power (Head office) Racine operations 8635 Washington Avenue Racine, Wisconsin 53406 Tel. : +1 414 884 7400 Fax : +1 414 884 7440 E-mail: "Name"@danfoss.com (Ole Sigvardt: Olsigvardt@danfoss.com) Danfoss authorized service shop
Pakistan	Khan Brothers Engineers 684, Central Commercial Area Allama Iqbal Road P.E.C.H.S., Karachi-75400 Tel. : +92 21 452 6002/6003/6004 or 6005 Fax : +92 21 454 5995	Slovenia	Technical Office Klun Ul. Bratov Martinec 16 SI-1000 Ljubljana Slovenija Tel. : +386 61 127 3718 Fax : +386 61 127 1624		Danfoss Fluid Power, Easley Operations 1201 Pelzer Highway P.O. Box 2189 Easley, South Carolina 29640 Tel. : +1 864 855 2884 Fax : +1 864 855 5885 (general) +1 864 850 6010 (executive office)
		Spain	Danfoss S.A. Avda. Tenerife No. 22 Pol. Ind. Norte 28700 San Sebastian de los Reyes (Madrid) Tel. : +34 91 663 8051 Fax : +34 91 663 7570 E-mail : "NO."@danfoss.com (Luis Baque: SPOO16@danfoss.com) Danfoss authorized service shop		

Comments

Comments

Comments

Danfoss can accept no responsibility for possible errors in catalogues, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without subsequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

**DK-6430 Nordborg
Denmark**