

# ANSYS CFX-Solver Modeling Guide

---



ANSYS, Inc.  
Southpointe  
275 Technology Drive  
Canonsburg, PA 15317  
ansysinfo@ansys.com  
<http://www.ansys.com>  
(T) 724-746-3304  
(F) 724-514-9494

Release 14.0  
November 2011

ANSYS, Inc. is  
certified to ISO  
9001:2008.

---

## Copyright and Trademark Information

© 2011 SAS IP, Inc. All rights reserved. Unauthorized use, distribution or duplication is prohibited.

ANSYS, ANSYS Workbench, Ansoft, AUTODYN, EKM, Engineering Knowledge Manager, CFX, FLUENT, HFSS and any and all ANSYS, Inc. brand, product, service and feature names, logos and slogans are registered trademarks or trademarks of ANSYS, Inc. or its subsidiaries in the United States or other countries. ICEM CFD is a trademark used by ANSYS, Inc. under license. CFX is a trademark of Sony Corporation in Japan. All other brand, product, service and feature names or trademarks are the property of their respective owners.

## Disclaimer Notice

THIS ANSYS SOFTWARE PRODUCT AND PROGRAM DOCUMENTATION INCLUDE TRADE SECRETS AND ARE CONFIDENTIAL AND PROPRIETARY PRODUCTS OF ANSYS, INC., ITS SUBSIDIARIES, OR LICENSORS. The software products and documentation are furnished by ANSYS, Inc., its subsidiaries, or affiliates under a software license agreement that contains provisions concerning non-disclosure, copying, length and nature of use, compliance with exporting laws, warranties, disclaimers, limitations of liability, and remedies, and other provisions. The software products and documentation may be used, disclosed, transferred, or copied only in accordance with the terms and conditions of that software license agreement.

ANSYS, Inc. is certified to ISO 9001:2008.

## U.S. Government Rights

For U.S. Government users, except as specifically granted by the ANSYS, Inc. software license agreement, the use, duplication, or disclosure by the United States Government is subject to restrictions stated in the ANSYS, Inc. software license agreement and FAR 12.212 (for non-DOD licenses).

## Third-Party Software

See the [legal information](#) in the product help files for the complete Legal Notice for ANSYS proprietary software and third-party software. If you are unable to access the Legal Notice, please contact ANSYS, Inc.

Published in the U.S.A.

---

# Table of Contents

<b>1. Basic Capabilities Modeling</b> .....	1
1.1. Domains .....	2
1.2. Physical Models .....	2
1.2.1. Steady State and Transient Flows .....	3
1.2.2. Mesh Deformation .....	3
1.2.2.1. None .....	4
1.2.2.2. Regions of Motion Specified .....	4
1.2.2.2.1. Mesh Stiffness .....	4
1.2.2.2.1.1. Increase Near Small Volumes .....	4
1.2.2.2.1.2. Increase Near Boundaries .....	5
1.2.2.2.1.3. Value (Specified Stiffness) .....	5
1.2.2.2.2. Mesh Motion Options .....	5
1.2.2.2.2.1. Conservative Interface Flux .....	6
1.2.2.2.2.2. Unspecified .....	7
1.2.2.2.2.3. Stationary .....	7
1.2.2.2.2.4. Specified Displacement .....	7
1.2.2.2.2.5. Specified Location .....	7
1.2.2.2.2.6. ANSYS MultiField .....	8
1.2.2.2.2.7. Rigid Body Solution .....	8
1.2.2.3. Junction Box Routine .....	8
1.2.3. Laminar Flow .....	9
1.2.4. Turbulence and Turbulence Models .....	9
1.2.5. Heat Transfer .....	9
1.2.5.1. None .....	9
1.2.5.2. Isothermal .....	9
1.2.5.3. Thermal Energy .....	9
1.2.5.4. Total Energy .....	9
1.2.5.5. Turbulent Flux Closure .....	10
1.2.6. Conjugate Heat Transfer .....	10
1.2.7. Compressible Flow .....	10
1.2.7.1. Mixed Subsonic/Supersonic Boundaries .....	11
1.2.8. Setting a Reference Pressure .....	11
1.2.9. Buoyancy .....	12
1.2.9.1. Full Buoyancy Model (Density Difference) .....	13
1.2.9.2. Boussinesq Model .....	13
1.2.9.3. Buoyancy and Pressure .....	14
1.2.9.4. Buoyancy In Rotating Domains .....	14
1.2.10. Immersed Solids .....	14
1.2.10.1. Immersed Boundary Tracking .....	16
1.2.10.2. Limitations to using Immersed Solids .....	16
1.2.11. Multicomponent Flow .....	18
1.2.11.1. Assumptions About Multicomponent Flow .....	18
1.2.11.2. Multicomponent Flow Terminology .....	18
1.2.11.2.1. Pure Substance .....	18
1.2.11.2.2. Component .....	18
1.2.11.2.3. Multicomponent Fluid .....	18
1.2.11.2.4. Fluid .....	19
1.2.11.2.5. Additional Variable .....	19
1.2.11.2.6. Ideal Mixture .....	19
1.2.11.2.7. Transport Equation .....	19

1.2.11.2.8. Constraint Equation .....	19
1.2.11.2.9. Algebraic Equation .....	19
1.2.11.3. Multicomponent Flow Examples .....	19
1.2.11.3.1. Example 1: Multicomponent Multiphase .....	19
1.2.11.3.2. Example 2: Smoke in Air .....	20
1.2.11.4. Component Domain Settings .....	21
1.2.11.4.1. Algebraic Slip .....	21
1.2.11.4.2. Kinematic Diffusivity and Bulk Viscosity .....	22
1.2.11.4.3. Turbulent Flux Closure .....	22
1.2.11.5. Boundary Conditions .....	22
1.2.11.6. Multicomponent Energy Diffusion .....	22
1.2.12. Additional Variables .....	23
1.2.12.1. Kinematic Diffusivity .....	23
1.2.12.2. Turbulent Flux Closure .....	24
1.2.12.3. Volumetric and Specific Additional Variable .....	24
1.2.12.4. Additional Variables In Units Other Than Mass .....	25
1.2.12.5. Unspecified Additional Variables .....	25
1.2.12.6. Tensor Type .....	26
1.2.13. Non-Newtonian Flow .....	26
1.2.14. Coordinate Frames .....	29
1.2.14.1. Global Coordinate Frame (Coord 0) .....	29
1.2.14.2. Local Coordinate Frames .....	29
1.2.14.3. Cartesian Coordinate Frames .....	30
1.2.15. Rotating Frames of Reference (RFR) .....	30
1.2.15.1. Alternate Rotation Model .....	31
1.3. Sources .....	31
1.3.1. Locators for Sources .....	31
1.3.1.1. Subdomains .....	31
1.3.1.2. Boundary Sources .....	32
1.3.1.3. Point Sources .....	32
1.3.2. Types of Sources .....	32
1.3.2.1. General Sources .....	32
1.3.2.1.1. Source Coefficient / Total Source Coefficient .....	33
1.3.2.2. Momentum Sources .....	33
1.3.2.2.1. Isotropic and Directional Loss Models .....	33
1.3.2.2.2. General Momentum Source .....	34
1.3.2.2.2.1. Post-Processing the Momentum Sources .....	35
1.3.2.2.3. Immersed Solids Sources .....	35
1.3.2.3. Mass (Continuity) Sources .....	35
1.3.2.3.1. Mass (Continuity) Source Coefficients .....	37
1.3.2.4. Bulk Sources .....	37
1.3.2.5. Solid Sources .....	37
1.3.2.6. Radiation Sources .....	37
1.3.2.7. Particle User Sources .....	38
1.3.3. Multiplying Sources by Porosity .....	38
1.4. Material Properties .....	38
1.4.1. CEL Expressions .....	38
1.4.2. Coord Frame .....	38
1.4.3. Equation of State .....	38
1.4.3.1. Option .....	39
1.4.3.1.1. Value .....	39
1.4.3.1.2. Ideal Gas .....	39

1.4.3.1.3. Real Gas .....	39
1.4.3.1.4. IAPWS Library .....	40
1.4.3.2. Molar Mass .....	40
1.4.4. Specific Heat Capacity .....	40
1.4.4.1. Value .....	41
1.4.4.2. NASA Format .....	41
1.4.4.3. Zero Pressure Polynomial .....	42
1.4.4.4. Real Gas .....	42
1.4.4.5. Reference State Properties .....	42
1.4.4.5.1. Reference Temperature and Reference Pressure .....	42
1.4.4.5.2. Reference Specific Enthalpy and Entropy .....	42
1.4.5. Density and Specific Heat Dependencies .....	43
1.4.6. Table Generation Pressure and Temperature Limits .....	43
1.4.7. Transport Properties .....	44
1.4.7.1. Dynamic Viscosity .....	44
1.4.7.1.1. Value .....	44
1.4.7.1.2. Rigid Non Interacting Sphere and Interacting Sphere Models .....	44
1.4.7.1.3. Non-Newtonian Model .....	45
1.4.7.1.4. Ideal Mixture .....	45
1.4.7.1.5. Sutherland's Formula .....	45
1.4.7.2. Thermal Conductivity .....	45
1.4.7.2.1. Sutherland's Formula .....	46
1.4.7.2.2. Modified Eucken Model .....	46
1.4.8. Radiation Properties .....	46
1.4.9. Buoyancy Properties .....	47
1.4.9.1. Thermal Expansivity .....	47
1.4.10. Electromagnetic Properties .....	47
1.4.10.1. Electrical Conductivity .....	47
1.4.10.2. Magnetic Permeability .....	47
1.4.11. Library Materials .....	47
1.4.11.1. Adding to the MATERIALS file .....	48
1.5. Mixture Properties (Fixed and Variable) .....	48
1.5.1. Density .....	48
1.5.2. Molar Mass .....	49
1.5.3. Electromagnetic Properties .....	49
1.6. Efficiency Calculation .....	49
1.6.1. Isentropic Efficiency and Total Enthalpy .....	49
1.6.2. Polytropic Efficiency .....	51
1.6.3. Activating Efficiency Output .....	53
1.6.3.1. CFX-Solver Manager Output Variables .....	53
1.6.3.2. Results File Output Variables .....	54
1.6.4. Restrictions .....	54
1.7. Wall Condensation Model .....	55
1.7.1. CFX-Pre Setup .....	55
1.7.1.1. Domain Fluid Model Specification .....	55
1.7.1.2. Boundary Condition Specification .....	55
1.7.1.3. Restrictions .....	56
1.7.2. Condensation Mass Flux in CFD-Post .....	56
<b>2. Boundary Condition Modeling .....</b>	<b>57</b>
2.1. The Purpose of Boundary Conditions .....	57
2.2. Available Boundary Conditions .....	58
2.2.1. Fluid Boundaries .....	58

2.2.2. Solid Boundaries .....	59
2.3. Using Boundary Conditions .....	59
2.3.1. Specifying Well-Posed Boundary Conditions .....	59
2.3.2. Recommended Configurations of Boundary Conditions .....	60
2.3.3. Using Inlets, Outlets and Openings .....	60
2.3.3.1. Inlets .....	60
2.3.3.2. Outlets .....	61
2.3.3.3. Openings .....	61
2.3.3.4. Using Pressure Specified Boundaries with Buoyant Flows .....	63
2.3.4. Using CEL Expressions With Boundary Conditions .....	63
2.4. Inlet .....	64
2.4.1. Mesh Motion .....	64
2.4.2. Inlet (Subsonic) .....	64
2.4.2.1. Mass and Momentum .....	64
2.4.2.1.1. Normal Speed .....	64
2.4.2.1.2. Cartesian Velocity Components .....	64
2.4.2.1.3. Cylindrical Velocity Components .....	65
2.4.2.1.4. Mass Flow Rate .....	65
2.4.2.1.5. Total Pressure (Stable) .....	65
2.4.2.1.6. Stationary Frame Total Pressure (Stable) .....	66
2.4.2.1.7. Static Pressure .....	66
2.4.2.1.8. Fluid Velocity .....	66
2.4.2.2. Flow Direction .....	66
2.4.2.3. Turbulence .....	66
2.4.2.3.1. Default Intensity and Autocompute Length Scale .....	67
2.4.2.3.2. Intensity and Autocompute Length Scale .....	67
2.4.2.3.3. Intensity and Length Scale .....	67
2.4.2.3.4. Low (Intensity = 1%) .....	68
2.4.2.3.5. Medium (Intensity = 5%) .....	68
2.4.2.3.6. High (Intensity = 10%) .....	68
2.4.2.3.7. Specified Intensity and Eddy Viscosity Ratio .....	68
2.4.2.3.8. k and Epsilon .....	68
2.4.2.3.9. Zero Gradient .....	68
2.4.2.4. Heat Transfer .....	68
2.4.2.4.1. Static Temperature .....	68
2.4.2.4.2. Total Temperature .....	68
2.4.2.4.3. Stat. Frame Total Temperature .....	68
2.4.2.4.4. Total Enthalpy .....	68
2.4.2.4.5. Stationary Frame Total Enthalpy .....	68
2.4.2.5. Thermal Radiation .....	69
2.4.2.5.1. Radiative Heat Flux (P1 Model) .....	69
2.4.2.5.2. Radiation Intensity (P1 Model) .....	69
2.4.2.5.3. External Blackbody Temperature .....	69
2.4.2.5.4. Local Temperature .....	69
2.4.2.5.5. Sources (Discrete Transfer and Monte Carlo models) .....	69
2.4.2.6. Transported Additional Variables at an Inlet .....	69
2.4.3. Inlet (Supersonic) .....	70
2.4.3.1. Mass and Momentum .....	70
2.4.4. Inlet (Mixed Subsonic-Supersonic) .....	71
2.4.4.1. Supported Material Types .....	72
2.4.4.2. Mass and Momentum .....	72
2.4.4.2.1. Cartesian Velocity Components and (Total) Pressure .....	72

2.4.4.2.2. Cylindrical Velocity Components and (Total) Pressure .....	72
2.4.4.2.3. Normal Speed and (Total) Pressure .....	72
2.4.4.3. Heat Transfer .....	72
2.4.4.3.1. Static Temperature .....	72
2.4.4.3.2. Total Temperature .....	72
2.4.4.3.3. Total Enthalpy .....	73
2.4.4.4. Initial Guess Recommendation .....	73
2.5. Outlet .....	73
2.5.1. Mass and Momentum .....	73
2.5.1.1. Static Pressure .....	73
2.5.1.2. Normal Speed .....	74
2.5.1.3. Cartesian Velocity Components .....	74
2.5.1.4. Cylindrical Velocity Components .....	74
2.5.1.5. Average Static Pressure .....	74
2.5.1.5.1. Average Over Whole Outlet .....	74
2.5.1.5.2. Average Above Specified Radius .....	74
2.5.1.5.3. Average Below Specified Radius .....	75
2.5.1.5.4. Circumferential .....	75
2.5.1.5.5. Radial Equilibrium .....	75
2.5.1.6. Mass Flow Rate (Bulk Mass Flow Rate for Multiphase) .....	75
2.5.1.6.1. Scale Mass Flows .....	76
2.5.1.6.2. Constant Flux .....	76
2.5.1.6.3. Shift Pressure with or without Pressure Profile .....	76
2.5.1.6.4. Shift Pressure with Circumferential Pressure Averaging .....	77
2.5.1.7. Degassing Condition (Multiphase only) .....	77
2.5.1.8. Fluid Velocity (Multiphase only) .....	77
2.5.1.9. Supercritical (Multiphase only) .....	77
2.5.2. Turbulence, Heat Transfer, and Additional Variables .....	78
2.5.3. Thermal Radiation .....	78
2.5.4. Mesh Motion .....	78
2.5.5. Outlet (Supersonic) .....	78
2.6. Opening .....	78
2.6.1. Mass and Momentum .....	78
2.6.1.1. Cartesian Velocity Components .....	78
2.6.1.2. Cylindrical Velocity Components .....	79
2.6.1.3. Opening Pressure and Direction .....	79
2.6.1.4. Static Pressure and Direction .....	79
2.6.1.5. Entrainment .....	79
2.6.1.6. Fluid Velocity .....	80
2.6.2. Loss Coefficient .....	80
2.6.2.1. For a Pressure-Specified Opening .....	80
2.6.2.2. For a Static-Pressure-Specified Opening .....	80
2.6.3. Heat Transfer .....	80
2.6.4. Turbulence .....	80
2.6.5. Thermal Radiation .....	81
2.6.6. Additional Variables .....	81
2.6.7. Mesh Motion .....	81
2.7. Wall .....	81
2.7.1. Mass and Momentum .....	81
2.7.1.1. No Slip Wall .....	82
2.7.1.2. Free Slip Wall .....	83
2.7.1.3. Finite Slip Wall .....	83

2.7.1.4. Specified Shear .....	83
2.7.1.5. Counter-rotating Wall .....	83
2.7.1.6. Rotating Wall .....	83
2.7.2. Wall Roughness .....	84
2.7.3. Wall Contact Model .....	84
2.7.4. Wall Adhesion .....	84
2.7.5. Heat Transfer .....	84
2.7.5.1. Adiabatic .....	84
2.7.5.2. Fixed Temperature .....	84
2.7.5.3. Heat Flux and Wall Heat Flux .....	84
2.7.5.4. Heat Transfer Coefficient and Wall Heat Transfer Coefficient .....	85
2.7.5.5. ANSYS Multi-field .....	85
2.7.5.6. Results File Variables for Post-Processing .....	85
2.7.5.7. Wall Temperature ( $T_w$ ) .....	86
2.7.5.8. Wall Heat Flux and Heat Flux ( $q_w$ ) .....	86
2.7.5.9. Wall Heat Transfer Coefficient ( $h_c$ ) and Wall Adjacent Temperature ( $T_{nw}$ ) .....	87
2.7.5.10. Wall External Heat Transfer Coefficient and Wall External Temperature .....	87
2.7.6. Mesh Motion .....	87
2.7.7. Thermal Radiation .....	88
2.7.7.1. Opaque .....	88
2.7.7.2. Sources .....	88
2.7.8. Equations Governing Additional Variables .....	88
2.7.9. Additional Coupling Sent Data .....	88
2.8. Symmetry Plane .....	88
2.8.1. Mesh Motion .....	89
2.9. Profile Boundary Conditions .....	89
2.9.1. Using a Profile From One Location at Another Location .....	90
2.9.2. Standard Variable Names .....	91
2.9.3. Non-Standard Variable Names .....	92
2.9.4. Custom Variables .....	92
2.9.5. Using r-Theta Profiles .....	92
2.9.6. Data Interpolation Method .....	93
2.9.7. Extracting Profile Data from Results Files .....	93
<b>3. Initial Condition Modeling .....</b>	<b>95</b>
3.1. Setting the Initial Conditions in CFX-Pre .....	96
3.1.1. Automatic .....	96
3.1.2. Automatic with Value .....	97
3.1.3. Using Expressions with Initial Conditions .....	97
3.2. Initialization Parameters .....	97
3.2.1. Coord Frame .....	98
3.2.2. Frame Type .....	98
3.2.2.1. Considerations for Multiple Domains and Global Initialization .....	98
3.2.3. Velocity Type .....	99
3.2.3.1. Cartesian Coordinate Frame, Cartesian Velocity Components .....	99
3.2.3.2. Cartesian Coordinate Frame, Cylindrical Velocity Components .....	99
3.2.3.3. Cylindrical Coordinate Frame, Cartesian Velocity Components .....	99
3.2.3.4. Cylindrical Coordinate Frame, Cylindrical Velocity Components .....	99
3.2.4. Cartesian Velocity Components .....	99
3.2.4.1. Automatic Values .....	99
3.2.4.2. Recommended Values .....	101
3.2.5. Cylindrical Velocity Components .....	101
3.2.5.1. Automatic Values .....	101

3.2.5.2. Recommended Values .....	101
3.2.6. Velocity Scale .....	102
3.2.7. Velocity Fluctuation .....	102
3.2.8. Static Pressure .....	102
3.2.8.1. Automatic Values .....	102
3.2.8.2. Recommended Values .....	102
3.2.9. Temperature .....	103
3.2.9.1. Automatic Values .....	103
3.2.9.2. Recommended Values .....	103
3.2.10. K (Turbulent Kinetic Energy) .....	103
3.2.10.1. Automatic Values .....	103
3.2.10.2. Recommended Values .....	103
3.2.11. Epsilon (Turbulence Eddy Dissipation) .....	103
3.2.11.1. Automatic Values .....	103
3.2.11.2. Recommended Values .....	104
3.2.11.3. Manual Specification .....	104
3.2.12. Omega (Turbulence Eddy Frequency) .....	104
3.2.12.1. Automatic Values .....	104
3.2.12.2. Recommended Values .....	105
3.2.12.3. Manual Specification .....	105
3.2.13. Reynolds Stress Components .....	105
3.2.14. Initialization of Additional Variables .....	105
3.2.15. Component .....	106
3.2.16. Volume Fraction .....	106
3.2.17. Radiation Intensity .....	106
3.2.18. Initialization of Solid Domains .....	106
3.2.19. Initial Conditions for a Multiphase Simulation .....	106
3.2.19.1. Volume Fraction .....	106
3.2.19.2. Velocity .....	107
3.2.20. Initialization Advice .....	107
3.3. Reading the Initial Conditions from a File .....	107
3.3.1. Using Configuration Results to Provide Initial Values .....	108
3.3.2. Continuing the History .....	109
3.3.3. Using Multiple Files to Provide Initial Conditions .....	111
3.3.4. Using the Mesh from the Initial Values File .....	112
3.3.5. Using an Initial Values File Which Contains Particles .....	112
3.4. Using the CFX-Interpolator .....	114
3.4.1. Interpolating from a Single File .....	115
3.4.1.1. Mapping Data from the Source File to the Target File .....	117
3.4.2. Interpolating from Multiple Files .....	120
3.4.3. Adjusting the Bounding Box Tolerance .....	121
3.4.4. Interpolating Onto a Solver Input File with Results Fields .....	123
3.4.5. Miscellaneous Limitations of the CFX-Interpolator .....	123
3.4.6. Using the CFX-Interpolator to Calculate Difference Variables .....	124
<b>4. Turbulence and Near-Wall Modeling .....</b>	<b>125</b>
4.1. Turbulence Models .....	126
4.1.1. The Laminar Model .....	126
4.1.2. The Zero Equation Model .....	126
4.1.3. The k-epsilon Model .....	127
4.1.4. The RNG k-epsilon Model .....	127
4.1.5. The k-omega and SST Models .....	127
4.1.6. Curvature Correction for Two-Equation Models .....	128

4.1.7. The Reynolds Stress Model .....	128
4.1.8. Omega-Based Reynolds Stress Models .....	130
4.1.9. Explicit Algebraic Reynolds Stress Model .....	130
4.1.10. CFX Transition Model .....	130
4.1.10.1. Estimating when the Transition Model Should be Used .....	131
4.1.10.2. Grid Requirements .....	132
4.1.10.3. Specifying Inlet Turbulence Levels .....	135
4.1.10.4. Summary .....	137
4.1.11. The Large Eddy Simulation Model (LES) .....	137
4.1.11.1. Using the LES model in CFX .....	137
4.1.11.2. Introduction to LES .....	138
4.1.11.3. When to use LES .....	138
4.1.11.4. Setting up an LES Simulation .....	138
4.1.11.4.1. Geometry for LES .....	138
4.1.11.4.2. Meshing .....	139
4.1.11.4.3. Boundary Layers .....	139
4.1.11.4.4. Analysis Type .....	139
4.1.11.4.5. Domains .....	139
4.1.11.4.6. LES Boundary Conditions: Inlet .....	139
4.1.11.4.7. LES Boundary Conditions: Outlets and Openings .....	140
4.1.11.4.8. LES Initialization .....	140
4.1.11.4.9. LES Solver Control .....	140
4.1.11.4.10. LES Timestep Considerations .....	140
4.1.11.5. Solver Memory .....	141
4.1.11.6. Useful Values For LES Runs .....	141
4.1.11.6.1. Statistical Reynolds Stresses .....	141
4.1.11.6.2. Delaying the Start of Reynolds Stress Calculations .....	141
4.1.12. The Detached Eddy Simulation Model (DES) .....	142
4.1.12.1. Using the Detached Eddy Simulation Model in CFX .....	142
4.1.12.1.1. When to use DES .....	142
4.1.12.2. Setting up a DES Simulation .....	143
4.1.12.2.1. Geometry for DES .....	143
4.1.12.2.2. Meshing Requirements for DES .....	143
4.1.12.2.3. DES Timestep Considerations .....	143
4.1.12.2.4. Boundary Conditions .....	143
4.1.12.2.5. DES Initialization .....	144
4.1.12.2.6. Monitoring a DES Simulation .....	144
4.1.12.3. Limitations/Concerns of the DES Model .....	145
4.1.13. The Scale-Adaptive Simulation (SAS) .....	146
4.1.13.1. Using the Scale Adaptive Simulation model in CFX .....	148
4.1.14. Buoyancy Turbulence .....	148
4.2. Modeling Flow Near the Wall .....	148
4.2.1. Standard Wall Functions .....	150
4.2.2. Scalable Wall Functions .....	150
4.2.3. Automatic Near-Wall Treatment for Omega-Based Models .....	150
4.2.4. User Defined Wall Functions .....	150
4.2.4.1. Heat Flux .....	151
4.2.4.2. Additional Variable Flux .....	151
4.2.4.3. Example of User-Defined Wall Function for Heat Flux .....	151
4.2.4.4. Example of User-Defined Wall Function for an Additional Variable .....	152
4.2.5. Treatment of Rough Walls .....	152
4.2.6. Solver Yplus and Yplus .....	152

4.2.7. Guidelines for Mesh Generation .....	153
4.2.7.1. Minimum Node Spacing .....	153
4.2.7.1.1. Determination of the Near Wall Spacing .....	153
4.2.7.2. Minimum Number of Nodes .....	154
4.2.7.2.1. Goal .....	154
4.2.7.2.2. Formulation .....	154
<b>5. Domain Interface Modeling .....</b>	<b>157</b>
5.1. Overview of Domain Interfaces .....	157
5.2. Interface Type .....	158
5.3. Interface Models .....	158
5.3.1. Translational Periodicity .....	159
5.3.2. Rotational Periodicity .....	159
5.3.3. General Connection .....	160
5.3.3.1. Frame Change/Mixing Model .....	161
5.3.3.1.1. None .....	161
5.3.3.1.2. Frozen Rotor .....	161
5.3.3.1.2.1. Rotational Offset .....	161
5.3.3.1.3. Stage .....	162
5.3.3.1.3.1. Pressure Profile Decay .....	163
5.3.3.1.3.2. Downstream Velocity Constraint .....	163
5.3.3.1.4. Transient Rotor-Stator .....	163
5.3.3.2. Pitch Change .....	164
5.3.3.2.1. None .....	165
5.3.3.2.2. Automatic .....	165
5.3.3.2.3. Value .....	166
5.3.3.2.4. Specified Pitch Angles .....	166
5.3.4. Mass and Momentum Models .....	166
5.3.4.1. Translational Periodicity .....	166
5.3.4.2. General Connection .....	167
5.3.4.2.1. Specified Pressure Change .....	167
5.3.4.2.2. Specified Mass Flow Rate .....	167
5.3.4.3. Further Comments .....	168
5.4. Mesh Connection Options .....	168
5.4.1. Automatic Connections .....	169
5.4.2. Direct (One-to-One) Connections .....	169
5.4.3. GGI (General Grid Interface) Connections .....	170
5.4.3.1. Non-overlap Boundary Conditions .....	170
5.4.3.2. Conditional Connections .....	171
5.4.4. Mesh Connection Recommendations .....	171
5.5. Defining Domain Interfaces as Thin Surfaces .....	172
5.5.1. Modeling Thin Surfaces: Overview .....	172
5.6. Recommendations For Using Domain Interfaces .....	173
5.6.1. Using Domain Interfaces .....	173
5.6.2. Using Multiple Domain Interfaces .....	173
5.6.3. Using Domain Interfaces in Turbomachinery Applications .....	174
5.6.3.1. Case 1: Impeller/Volute .....	174
5.6.3.2. Case 2: Step change between rotor and stator .....	175
5.6.3.3. Case 3: Blade Passage at or close to the edge of a domain .....	175
5.6.3.4. Case 4: Blade Passage at or close to the edge of a domain .....	176
5.6.3.5. Case 5: Blade with thick trailing edge .....	177
5.7. Automatic Creation and Treatment of Domain Interfaces .....	177
<b>6. Transient Blade Row Modeling .....</b>	<b>179</b>

6.1. Transient Blade Row Modeling Terminology .....	179
6.2. Setting up a Transient Blade Row Model .....	180
6.2.1. Setting up Monitors to Check Results .....	181
6.3. Running and Postprocessing a Simulation that uses a Transient Blade Row Model .....	182
6.4. Profile Transformation .....	182
6.5. Time Transformation .....	182
6.5.1. Time Transformation: Workflow Requirements .....	183
6.6. Fourier Transformation .....	183
6.6.1. Fourier Transformation: Workflow Requirements .....	183
6.7. Guidelines for Using Transient Blade Row Features .....	184
6.7.1. General Setup Guidelines .....	184
6.7.2. Guidelines for using the Time Transformation Feature .....	185
6.7.3. Guidelines for using the Fourier Transformation Feature .....	185
6.7.4. General Postprocessing Guidelines .....	185
6.8. Use Cases .....	186
6.8.1. Case 1: Transient Rotor Stator Single Stage .....	186
6.8.2. Case 2: Flow Boundary Disturbance .....	187
<b>7. Multiphase Flow Modeling .....</b>	<b>189</b>
7.1. Multiphase Terminology .....	190
7.1.1. Multiphase Flow .....	190
7.1.2. Eulerian-Eulerian .....	190
7.1.3. Inhomogeneous Multiphase Flow .....	191
7.1.4. Homogeneous Multiphase Flow .....	191
7.1.5. Multicomponent Multiphase Flow .....	191
7.1.6. Volume Fraction .....	191
7.1.7. Free Surface Flow .....	191
7.1.8. Surface Tension .....	191
7.2. Multiphase Examples .....	191
7.2.1. Water Droplets in Air .....	192
7.2.2. Air Bubbles in Water .....	192
7.2.3. Gas-Solid and Liquid-Solid Flow .....	192
7.2.4. Three-Phase Flow .....	192
7.2.5. Polydispersed Flow .....	192
7.3. Eulerian-Eulerian Multiphase Versus Particle Transport .....	193
7.4. Specifying Fluids for Multiphase Flow .....	193
7.4.1. Morphology .....	194
7.4.1.1. Continuous Fluid .....	194
7.4.1.2. Dispersed Fluid .....	194
7.4.1.3. Dispersed Solid .....	194
7.4.1.4. Polydispersed Fluid .....	194
7.4.2. Mean Diameter .....	194
7.4.3. Minimum Volume Fraction .....	195
7.4.4. Maximum Packing .....	195
7.5. The Homogeneous and Inhomogeneous Models .....	195
7.5.1. The Inhomogeneous (Interfluid Transfer) Model .....	195
7.5.1.1. The Particle Model .....	195
7.5.1.2. The Mixture Model .....	195
7.5.1.3. The Free Surface Model .....	196
7.5.2. The Homogeneous Model .....	196
7.6. Buoyancy in Multiphase Flow .....	197
7.6.1. Fluid Buoyancy Model .....	197
7.6.1.1. Density Difference .....	197

7.6.1.2. Boussinesq .....	197
7.7. Multicomponent Multiphase Flow .....	198
7.8. Interphase Momentum Transfer Models .....	198
7.8.1. Interphase Drag .....	198
7.8.1.1. Interphase Drag for the Particle Model .....	198
7.8.1.1.1. Specifying a Drag Coefficient .....	198
7.8.1.1.2. Sparsely Distributed Solid Particles .....	199
7.8.1.1.2.1. Sparsely Distributed Solid Particles: Schiller Naumann Drag Model .....	199
7.8.1.1.3. Densely Distributed Solid Particles .....	199
7.8.1.1.3.1. Densely Distributed Solid Particles: Wen Yu Drag Model .....	199
7.8.1.1.3.2. Densely Distributed Solid Particles: Gidaspow Drag Model .....	199
7.8.1.1.4. Sparsely Distributed Fluid Particles (drops and bubbles) .....	199
7.8.1.1.4.1. Sparsely Distributed Fluid Particles: Ishii-Zuber Drag Model .....	199
7.8.1.1.4.2. Sparsely Distributed Fluid Particles: Grace Drag Model .....	200
7.8.1.1.4.3. Sparsely Distributed Fluid Particles: Availability .....	200
7.8.1.1.5. Densely Distributed Fluid Particles .....	200
7.8.1.1.5.1. Densely Distributed Fluid Particles: Ishii-Zuber Drag Model .....	200
7.8.1.1.5.2. Densely Distributed Fluid Particles: Grace Drag Model .....	200
7.8.1.2. Interphase Drag for the Mixture Model .....	201
7.8.2. Lift Force .....	201
7.8.3. Virtual Mass Force .....	201
7.8.4. Wall Lubrication Force .....	202
7.8.5. Interphase Turbulent Dispersion Force .....	202
7.8.5.1. Favre Averaged Drag Model .....	202
7.8.5.2. Lopez de Bertodano Model .....	203
7.9. Solid Particle Collision Models .....	203
7.9.1. Solid Pressure Force Model .....	203
7.9.2. Maximum Packing .....	204
7.9.3. Kinetic Theory Models .....	204
7.10. Interphase Heat Transfer .....	204
7.10.1. Inhomogeneous Interphase Heat Transfer Models .....	204
7.10.1.1. Particle Model Correlations for Overall Heat Transfer Coefficient .....	205
7.10.1.2. Mixture Model Correlations for Overall Heat Transfer Coefficient .....	206
7.10.1.3. Two Resistance Model for Fluid Specific Heat Transfer Coefficients .....	206
7.10.2. Homogeneous Heat Transfer in Multiphase Flow .....	207
7.11. Polydispersed, Multiple Size Group (MUSIG) Model .....	207
7.11.1. Setting up a Polydispersed (MUSIG) Simulation .....	207
7.11.1.1. Creating a Polydispersed (MUSIG) Fluid .....	207
7.11.1.2. Boundary Conditions .....	208
7.11.1.3. Initial Conditions .....	208
7.11.1.4. Sources .....	208
7.11.1.5. Post Processing Variables .....	208
7.11.2. MUSIG Model Advice .....	208
7.12. Turbulence Modeling in Multiphase Flow .....	209
7.12.1. Phase-Dependent Turbulence Models .....	209
7.12.1.1. Algebraic Models .....	209
7.12.1.2. Two Equation Models .....	210
7.12.1.3. Reynolds Stress Models .....	210
7.12.2. Homogeneous Turbulence in Inhomogeneous Flow .....	210
7.12.3. Turbulence Enhancement .....	210
7.12.4. Turbulence in Homogeneous Multiphase Flow .....	210
7.13. Additional Variables in Multiphase Flow .....	210

7.13.1. Additional Variable Interphase Transfer Models .....	210
7.13.1.1. Particle Model Correlations .....	211
7.13.1.1.1. Ranz-Marshall Correlation .....	211
7.13.1.1.2. Hughmark Correlation .....	211
7.13.1.1.3. Sherwood Number .....	211
7.13.1.1.4. Additional Variable Transfer Coefficient .....	211
7.13.1.1.5. Interface Flux .....	211
7.13.1.2. Mixture Model Correlations .....	212
7.13.2. Homogeneous Additional Variables in Multiphase Flow .....	212
7.14. Sources in Multiphase Flow .....	212
7.14.1. Fluid-Specific Sources .....	212
7.14.2. Bulk Sources .....	212
7.15. Interphase Mass Transfer .....	212
7.15.1. Double Precision Solver .....	213
7.15.2. User Specified Mass Transfer .....	213
7.15.3. Thermal Phase Change Model .....	213
7.15.3.1. Saturation Temperature .....	213
7.15.3.2. Wall Boiling Model .....	214
7.15.3.2.1. RPI Model .....	214
7.15.3.2.2. Using the Wall Boiling Model .....	215
7.15.3.3. Latent Heat .....	215
7.15.3.4. Heat Transfer Models .....	216
7.15.3.5. Interphase Heat Transfer Correlations .....	216
7.15.3.6. Modeling Advice .....	217
7.15.3.6.1. Saturated Vapor Bubbles in Subcooled or Superheated Liquid .....	217
7.15.3.6.2. Subcooled or Superheated Droplets in Saturated Vapor .....	217
7.15.3.6.3. Superheated Vapor Bubbles in Liquid .....	217
7.15.3.6.4. Thermal Energy and Total Energy Models .....	217
7.15.4. Cavitation Model .....	218
7.15.4.1. Rayleigh Plesset Model .....	219
7.15.4.2. User Defined Cavitation Models .....	219
7.15.5. Interphase Species Mass Transfer .....	220
7.15.5.1. Component Pairs .....	220
7.15.5.2. Two Resistance Model .....	221
7.15.5.3. Single Resistance Model .....	221
7.15.5.4. Interfacial Equilibrium Models .....	221
7.15.5.4.1. Liquid Evaporation (Raoult's Law) .....	221
7.15.5.4.2. Gas Absorption / Dissolution (Henry's Law) .....	222
7.15.5.4.3. Other Situations .....	222
7.15.5.5. Species Mass Transfer Coefficients .....	222
7.15.5.6. Modeling Advice .....	223
7.15.5.6.1. Liquid Evaporation .....	223
7.15.5.6.2. Gas Dissolution .....	223
7.15.5.6.3. Mixture Properties .....	224
7.15.5.6.4. Current Limitations .....	224
7.15.6. Droplet Condensation Model .....	224
7.16. Boundary Conditions in Multiphase Flow .....	225
7.16.1. Wall Boundaries in Multiphase .....	225
7.16.1.1. Bulk Wall Boundary Conditions .....	226
7.16.1.1.1. Area Contact Model .....	226
7.16.1.2. Fluid Dependent Wall Boundary Conditions .....	227
7.16.1.3. Wall Deposition .....	228

7.16.2. Mass Flow Inlet .....	228
7.16.3. Mass Flow Outlet .....	228
7.17. Modeling Advice for Multiphase Flow .....	229
7.17.1. Turbulence Models .....	229
7.17.2. Minimum Volume Fraction Setting .....	229
7.17.3. Buoyancy .....	229
7.17.4. Initial Conditions .....	229
7.17.5. Timestepping .....	230
7.17.6. Convergence .....	230
7.17.7. Transient Simulations .....	230
7.18. Free Surface Flow .....	230
7.18.1. Interface Compression Level .....	230
7.18.2. Supercritical and Subcritical Flow .....	231
7.18.3. Multiphase Model Selection .....	231
7.18.4. Surface Tension .....	231
7.18.4.1. Background .....	231
7.18.4.2. Discretization Options .....	232
7.18.4.2.1. Volume Fraction Smoothing Type .....	232
7.18.4.2.2. Curvature Under Relaxation Factor .....	232
7.18.4.3. Initial Conditions .....	232
7.18.4.4. Wall Adhesion .....	233
7.18.5. Modeling Advice for Free Surface Flow .....	233
7.18.5.1. Domains .....	233
7.18.5.2. Turbulence Model .....	233
7.18.5.3. Boundary Conditions .....	233
7.18.5.3.1. Pressure Reference .....	233
7.18.5.3.2. Outlets .....	233
7.18.5.4. Initial Conditions .....	234
7.18.5.5. Timestep .....	234
7.18.5.6. Mesh Adaption .....	235
7.18.5.7. Body Forces .....	235
7.18.5.8. Convergence .....	235
7.18.5.9. Parallel .....	235
7.19. Algebraic Slip Model (ASM) .....	235
7.19.1. Algebraic Slip Model Specification .....	235
7.19.1.1. Fluid Models .....	236
7.19.1.2. Wall Deposition .....	236
7.19.1.3. Limitations .....	236
7.20. Multiphase Flow Restrictions .....	236
<b>8. Particle Transport Modeling .....</b>	<b>237</b>
8.1. Model Validity .....	238
8.2. Particle Transport Versus Eulerian-Eulerian Multiphase .....	238
8.3. Forces Acting on the Particles .....	239
8.3.1. Drag Force .....	239
8.3.2. Reference Frame Rotational Forces .....	239
8.3.3. Buoyancy Force .....	239
8.4. Creating Particle Materials .....	239
8.5. Particle Domain Options .....	239
8.5.1. Basic Settings .....	240
8.5.1.1. Particle Morphology Options .....	240
8.5.2. Fluid Models .....	240
8.5.2.1. Multiphase Reactions .....	240

8.5.2.2. Buoyancy for Particles .....	240
8.5.2.3. Turbulence for Particles .....	240
8.5.2.4. Heat Transfer for Particles .....	240
8.5.2.5. Radiation for Particles .....	240
8.5.3. Fluid Specific Models .....	241
8.5.3.1. Particle Diameter Distribution .....	241
8.5.3.1.1. Specified Diameter .....	241
8.5.3.1.2. Uniform in Diameter by Number .....	241
8.5.3.1.3. Uniform in Diameter by Mass .....	241
8.5.3.1.4. Normal in Diameter by Number .....	241
8.5.3.1.5. Normal in Diameter by Mass .....	241
8.5.3.1.6. Rosin Rammler .....	241
8.5.3.1.7. Nukiyama Tanasawa .....	242
8.5.3.1.8. Discrete Diameter Distribution .....	243
8.5.3.2. Particle Shape Factors .....	245
8.5.3.3. Particle Diameter Change Due to Swelling .....	245
8.5.3.4. Heat Transfer .....	245
8.5.3.5. Erosion .....	245
8.5.3.5.1. Finnie .....	245
8.5.3.5.2. Tabakoff .....	246
8.5.3.5.3. User Defined .....	247
8.5.3.6. Particle-Rough Wall Model (Virtual Wall Model) .....	247
8.5.3.6.1. Sommerfeld-Frank Model .....	247
8.5.3.7. Particle Breakup Model .....	247
8.5.3.8. Particle Collision Model .....	248
8.5.3.8.1. Requirements for the Applicability of Particle-Particle Collision Model .....	249
8.5.3.9. Fluid Buoyancy Model .....	249
8.5.4. Fluid Pairs .....	249
8.5.4.1. Particle Fluid Pair Coupling Options .....	249
8.5.4.2. Drag Force for Particles .....	250
8.5.4.2.1. Particle User Source Example .....	250
8.5.4.2.2. Linearization Blend Factor .....	253
8.5.4.3. Particle User Source .....	253
8.5.4.4. Non-Drag Forces .....	253
8.5.4.4.1. Virtual Mass Force .....	253
8.5.4.4.2. Turbulent Dispersion Force .....	253
8.5.4.4.3. Pressure Gradient Force .....	253
8.5.4.5. Interphase Heat Transfer .....	253
8.5.4.5.1. Particle User Source .....	254
8.5.4.6. Interphase Radiation Transfer .....	254
8.5.4.6.1. Opaque .....	254
8.5.4.6.2. Blended Particle Emissivity .....	254
8.5.4.7. Mass Transfer .....	254
8.5.4.7.1. Ranz Marshall .....	254
8.5.4.7.2. Liquid Evaporation Model .....	254
8.5.4.7.3. Liquid Evaporation Model: Spray Dryer with Droplets Containing a Solid Substrate .....	255
8.5.4.7.4. Liquid Evaporation Model: Oil Evaporation/Combustion .....	256
8.5.4.7.5. Latent Heat .....	256
8.5.4.8. Particle User Sources .....	256
8.5.4.8.1. Particle User Source example .....	257
8.5.5. Particle Injection Regions .....	260

8.6. Particle Boundary Options and Behavior .....	260
8.6.1. Inlet/Opening Boundaries .....	260
8.6.1.1. Mass and Momentum .....	260
8.6.1.2. Particle Position .....	260
8.6.1.2.1. Uniform Injection .....	260
8.6.1.2.2. Uniform Injection within Annulus .....	260
8.6.1.2.3. Injection With Line Weighting .....	261
8.6.1.2.4. Injection With Point Weighting .....	261
8.6.1.2.5. Injection With Circular Weighting .....	261
8.6.1.2.6. Injection With User Defined Weighting .....	262
8.6.1.2.7. Injection at Face Centers .....	262
8.6.1.2.8. Injection at IP Face Centers .....	262
8.6.1.2.9. Number of Positions .....	262
8.6.1.2.10. Point Data Format .....	263
8.6.1.3. Particle Locations .....	263
8.6.1.4. Particle Diameter Distribution .....	263
8.6.1.5. Particle Mass Flow Rate .....	263
8.6.1.6. Heat Transfer .....	263
8.6.1.7. Component Details .....	263
8.6.1.8. Particle Actions at Inlets and Openings .....	263
8.6.2. Outlet Boundaries .....	263
8.6.2.1. Particle Actions at Outlets .....	263
8.6.3. Wall Boundaries .....	264
8.6.3.1. Wall Interaction .....	264
8.6.3.1.1. Standard Particle-Wall Interaction .....	264
8.6.3.1.1.1. Restitution Coefficients for Particles .....	264
8.6.3.1.2. Advanced Particle-Wall Interaction .....	265
8.6.3.1.3. User Defined Particle-Wall Interaction .....	265
8.6.3.2. Erosion Model .....	265
8.6.3.3. Particle-Rough Wall Model (Virtual Wall Model) .....	266
8.6.3.4. Particle Breakup .....	266
8.6.3.5. Mass Flow Absorption .....	266
8.6.3.6. Mass and Momentum .....	266
8.6.3.7. Particle Impact Angle .....	266
8.6.3.8. Particle Position .....	266
8.6.3.9. Particle Diameter Distribution .....	266
8.6.3.10. Particle Mass Flow Rate .....	266
8.6.4. Symmetry Plane Boundaries .....	267
8.6.5. Interface Boundaries .....	267
8.6.6. Domain Interfaces .....	267
8.6.6.1. Fluid-Fluid .....	267
8.6.6.1.1. Frame Change Option = None .....	267
8.6.6.1.2. Frame Change Option = Frozen Rotor .....	267
8.6.6.1.3. Frame Change Option = Stage .....	267
8.6.6.1.4. Frame Change Option = Transient Rotor Stator .....	268
8.6.6.2. Periodic Connections .....	268
8.7. Subdomains .....	268
8.8. Particle Injection Regions .....	268
8.8.1. Sphere .....	269
8.8.2. Cone .....	269
8.8.2.1. Injection Velocity .....	270
8.8.2.2. An Example of a Point Cone .....	270

8.8.2.3. An Example of a Point Cone Using the Dispersion Angle .....	270
8.8.2.4. An Example of a Hollow Cone using the Dispersion Angle .....	271
8.8.3. Cone with Primary Breakup .....	272
8.8.4. User Defined .....	272
8.9. Particle Output Control .....	273
8.9.1. Transient Particle Diagnostics .....	273
8.9.1.1. User Diagnostics Routine .....	274
8.9.1.1.1. Example User Routine: CCL .....	275
8.9.1.1.2. Example User Routine: Mainline Routine .....	276
8.9.1.1.3. Example User Routine: Subroutine .....	276
8.9.1.1.4. Example: Complete CCL .....	276
8.9.2. List of Particle Variables .....	279
8.10. Particle Solver Control .....	279
8.10.1. Particle Coupling Control .....	279
8.10.1.1. First Iteration for Particle Calculation .....	279
8.10.1.2. Iteration Frequency .....	279
8.10.1.3. Particle Source Change Target .....	280
8.10.2. Particle Under Relaxation Factors .....	280
8.10.2.1. Under Relaxation Factor for Velocity, Energy, and Mass .....	281
8.10.2.2. Under Relaxation Factor for First Particle Integration .....	281
8.10.2.3. Under Relaxation at Time Step Start .....	281
8.10.3. Particle Integration .....	281
8.10.3.1. Number of Integration Steps Per Element .....	281
8.10.3.2. Maximum Particle Integration Time Step .....	281
8.10.3.3. Chemistry Time Step Multiplier .....	281
8.10.4. Particle Termination Control .....	281
8.10.4.1. Maximum Tracking Time .....	281
8.10.4.2. Maximum Tracking Distance .....	282
8.10.4.3. Maximum Number of Integration Steps .....	282
8.10.4.4. Minimum Diameter .....	282
8.10.4.5. Minimum Total Mass .....	282
8.10.4.6. Mass Fraction Limits .....	282
8.10.5. Particle Ignition .....	282
8.10.6. Particle Source Smoothing .....	283
8.10.7. Vertex Variable Smoothing .....	283
8.10.8. Particle Source Control .....	283
8.10.8.1. Particle Heat Source Bounding .....	284
8.10.8.2. Particle Momentum Source Bounding .....	285
8.10.8.3. Linearization of Particle Mass Sources .....	286
8.10.8.3.1. Simple Mass Transfer Model .....	287
8.10.8.3.2. Liquid Evaporation Model .....	287
8.10.8.3.2.1. Droplet Temperature Below Boiling Point .....	287
8.10.8.3.2.2. Droplet Temperature Above Boiling Point .....	288
8.10.8.4. Particle Source Control Usage Notes .....	288
8.11. Multiphase Reactions and Combustion .....	289
8.11.1. Specification of a Binary Mixture .....	289
8.11.2. Reactants/Products .....	289
8.11.2.1. Example .....	289
8.11.3. Multiphase Reactions .....	290
8.11.3.1. Mass Arrhenius .....	290
8.11.3.2. Field Char Oxidation Model .....	290
8.11.3.3. Gibb Char Oxidation Model .....	290

8.11.3.4. Particle User Routine .....	290
8.11.3.5. Heat Release/Heat Release Distribution .....	291
8.11.4. Hydrocarbon Fuel Model Setup .....	291
8.11.4.1. Setup using Library Template (Recommended) .....	292
8.11.4.2. Setup from Scratch (Experts) .....	294
8.11.4.3. Using Generic Multiphase Reactions Setup .....	294
8.12. Restrictions for Particle Transport .....	295
8.13. Restrictions for Particle Materials .....	295
8.14. Convergence Control for Particle Transport .....	295
8.15. Expert Parameters for Particle Tracking .....	296
8.16. Particle Diagnostics .....	296
8.17. Integrated Particle Sources for the Coupled Continuous Phase .....	296
8.18. Transient Simulations: What is Different for Particles? .....	296
<b>9. Combustion Modeling .....</b>	<b>299</b>
9.1. Reaction Models .....	300
9.1.1. Naming Convention for Reaction Schemes .....	300
9.1.2. Reaction Rate Types .....	300
9.1.2.1. Arrhenius .....	301
9.1.2.2. Arrhenius with Temperature PDF .....	301
9.1.2.3. Expression .....	301
9.1.2.4. Equilibrium .....	302
9.2. Using Combustion Models .....	302
9.2.1. Which Model is the Most Appropriate? .....	303
9.3. Eddy Dissipation Model .....	304
9.3.1. Fluid Models .....	304
9.3.1.1. Chemical Time Scale .....	304
9.3.1.2. Extinction Temperature .....	305
9.3.1.3. Maximum Flame Temperature .....	305
9.3.1.4. Mixing Rate Limit .....	305
9.3.1.5. Eddy Dissipation Model Coefficient A/B .....	305
9.3.1.6. Component Details .....	306
9.3.2. Initialization .....	306
9.3.3. Solver Parameters .....	306
9.4. Finite Rate Chemistry Model .....	306
9.4.1. Fluid Models .....	306
9.4.1.1. Chemical Time Scale .....	307
9.4.1.2. Extinction Temperature .....	307
9.4.1.3. Component Details .....	307
9.4.2. Initialization .....	307
9.4.3. Solver Parameters .....	307
9.5. Combined EDM/Finite Rate Chemistry Model .....	308
9.5.1. Fluid Models .....	308
9.5.1.1. Chemical Time Scale .....	308
9.5.1.2. Extinction Temperature .....	308
9.5.1.3. Component Details .....	309
9.5.2. Initialization .....	309
9.5.3. Solver Parameters .....	309
9.6. Reaction-Step Specific Combustion Model Control .....	309
9.7. Laminar Flamelet with PDF Model .....	309
9.7.1. Fluid Models .....	310
9.7.1.1. Component Details .....	310
9.7.2. Boundary Settings .....	310

9.7.2.1. Fuel .....	310
9.7.2.2. Oxidizer .....	310
9.7.2.3. Mixture Fraction .....	311
9.7.2.4. Mixture Fraction Mean and Variance .....	311
9.7.3. Initialization .....	311
9.7.4. Solver Parameters .....	311
9.8. Burning Velocity Model (Premixed or Partially Premixed) .....	311
9.8.1. Fluid Models .....	312
9.8.1.1. Component Details .....	312
9.8.2. Turbulent Burning Velocity .....	312
9.8.2.1. Value .....	312
9.8.2.2. Zimont Correlation .....	312
9.8.2.3. Peters Correlation .....	312
9.8.2.4. Mueller Correlation .....	312
9.8.3. Spark Ignition Model .....	313
9.8.3.1. Spark Kernel .....	313
9.8.3.2. Ignition Time .....	313
9.8.3.3. Spark Energy .....	313
9.8.4. Boundary Settings .....	313
9.8.4.1. Fuel .....	313
9.8.4.2. Oxidizer .....	313
9.8.4.3. Mixture Fraction .....	313
9.8.4.4. Mixture Fraction Mean and Variance .....	313
9.8.4.5. Reaction Progress .....	314
9.8.5. Initialization .....	314
9.8.5.1. Reaction Progress .....	314
9.8.6. Solver Parameters .....	314
9.8.7. Other Parameters .....	314
9.9. Extended Coherent Flame Model (ECFM) .....	314
9.9.1. Fluid Models .....	315
9.9.1.1. Laminar Flame Thickness .....	315
9.9.1.2. Component Details .....	315
9.9.2. Spark Ignition Model .....	315
9.9.2.1. Spark Kernel .....	315
9.9.2.2. Ignition Time .....	315
9.9.2.3. Spark Energy .....	315
9.9.3. Boundary Settings .....	316
9.9.3.1. Mixture .....	316
9.9.3.2. Reaction Progress .....	316
9.9.3.3. Flame Surface Density .....	316
9.9.4. Initialization .....	317
9.9.4.1. Mixture .....	317
9.9.4.2. Reaction Progress .....	317
9.9.4.3. Flame Surface Density .....	317
9.9.5. Solver Parameters .....	317
9.9.6. Other Parameters .....	317
9.10. Residual Material Model .....	317
9.10.1. Fluid Models .....	318
9.10.1.1. Reinitialization .....	318
9.10.2. Laminar Burning Velocity .....	318
9.10.3. Boundary Settings .....	318
9.10.4. Initialization .....	319

9.10.5. Other Parameters .....	319
9.11. Flamelet Libraries .....	319
9.11.1. CFX-RIF .....	319
9.11.1.1. Defining a CFX-RIF Object .....	320
9.11.1.2. Basic Settings Tab .....	320
9.11.1.3. Boundary Conditions Tab .....	321
9.11.1.4. Table Size Tab .....	321
9.11.1.5. Flamelet Library Calculation .....	322
9.11.2. Flamelet Library Import Filter .....	322
9.11.2.1. Loading Flamelet Libraries .....	323
9.11.3. Flamelet Library (FLL) File Format .....	323
9.11.3.1. Flamelet Library (FLL) File Contents .....	323
9.11.3.2. Flamelet Library (FLL) File Format .....	324
9.11.3.2.1. Detailed FLL File Format .....	324
9.11.3.2.1.1. Comment Section .....	324
9.11.3.2.1.2. Header .....	324
9.11.3.2.1.3. Unburnt Flamelet .....	325
9.11.3.2.1.4. Burnt Flamelet Solution .....	325
9.11.3.2.2. Example FLL File .....	325
9.11.4. Stoichiometric Mixture Fraction .....	328
9.11.4.1. Value .....	328
9.11.4.2. Reactants .....	328
9.11.4.3. Automatic .....	328
9.11.5. Laminar Burning Velocity .....	328
9.11.5.1. Value .....	328
9.11.5.2. Metghalchi and Keck .....	328
9.11.5.3. Equivalence Ratio Correlation .....	329
9.11.5.3.1. Reference Burning Velocity .....	329
9.11.5.3.2. Flammability Limits .....	329
9.11.5.3.3. Preheat Temperature Dependency .....	329
9.11.5.3.4. Pressure Dependency .....	329
9.11.5.3.5. Residual Material Dependency .....	329
9.12. Autoignition Model .....	329
9.12.1. Ignition Delay Time .....	330
9.12.2. Customize Knock Reaction Rate .....	330
9.13. NO Model .....	330
9.13.1. Introduction to the NO Model .....	331
9.13.1.1. NO Model with Eddy Dissipation / Finite Rate Chemistry / Combined Model .....	331
9.13.1.2. NO Model with Flamelet Model .....	331
9.13.1.3. NO Model for Coal Combustion / Hydrocarbon Fuel Model .....	332
9.13.2. Fluid Models .....	332
9.13.2.1. Component Details .....	332
9.13.2.2. Boundary Conditions .....	332
9.13.3. Initialization .....	332
9.13.4. Solver Parameters .....	333
9.14. Chemistry Post-Processing .....	333
9.14.1. Fluid Models .....	333
9.14.1.1. Chemistry Post-Processing .....	333
9.14.1.2. Materials List .....	333
9.14.1.3. Reactions List .....	333
9.14.2. Boundary and Initial Conditions .....	334
9.14.3. Solver Parameters .....	334

9.15. Soot Model .....	334
9.15.1. Fluid Models .....	334
9.15.1.1. Soot Model .....	334
9.15.1.2. Fuel Material .....	334
9.15.1.3. Soot Material .....	334
9.15.1.4. Fuel Consumption Reaction .....	335
9.15.1.5. Fuel Carbon Mass Fraction .....	335
9.15.1.6. Soot Particle Mean Diameter .....	336
9.15.2. Boundary Settings .....	336
9.15.2.1. Mass Concentration and Nuclei Concentration .....	336
9.15.2.2. Mass Fraction and Specific Nuclei Specific Concentration .....	336
9.15.3. Initialization .....	336
9.16. Phasic Combustion .....	336
9.17. General Advice for Modeling Combusting Flows in CFX .....	336
9.17.1. General Procedure for Running Simulations .....	336
9.17.2. Advantages and Disadvantages of Multistep Reaction Mechanisms .....	337
9.17.3. Tips for Improving Convergence .....	337
9.17.4. Advanced Combustion Controls .....	338
<b>10. Radiation Modeling .....</b>	<b>339</b>
10.1. Comparison of the Radiation Models .....	340
10.2. Terminology .....	341
10.2.1. Absorptivity .....	341
10.2.2. Diffuse .....	341
10.2.3. Gray .....	341
10.2.4. Opaque .....	341
10.2.5. Reflectivity .....	341
10.2.6. Spectral .....	341
10.2.7. Transmissivity .....	341
10.3. Material Properties for Radiation .....	342
10.4. Rosseland Model .....	342
10.4.1. Fluid Models .....	342
10.4.1.1. Include Boundary Temperature Slip .....	342
10.4.1.2. Spectral Model .....	342
10.4.1.3. Scattering Model .....	342
10.4.2. Initial Conditions .....	342
10.4.3. Solver Control .....	343
10.5. The P1 Model .....	343
10.5.1. Fluid Models .....	343
10.5.1.1. Spectral Model .....	343
10.5.1.2. Scattering Model .....	343
10.5.2. Initial Conditions .....	343
10.5.3. Solver Control .....	344
10.6. The Discrete Transfer Model .....	344
10.6.1. Fluid Models .....	344
10.6.1.1. Number of Rays .....	345
10.6.1.2. Transfer Mode .....	345
10.6.1.3. Spectral Model .....	345
10.6.1.4. Scattering Model .....	345
10.6.2. Initial Conditions .....	345
10.6.3. Solver Control .....	345
10.7. The Monte Carlo Model .....	345
10.7.1. Fluid Models .....	346

10.7.1.1. Number of Histories .....	346
10.7.1.2. Transfer Mode .....	346
10.7.1.3. Spectral Model .....	346
10.7.1.4. Scattering Model .....	346
10.7.2. Initial Conditions .....	346
10.7.3. Solver Control .....	346
10.8. General Radiation Considerations .....	346
10.8.1. Domain Considerations .....	346
10.8.2. Domain Interface Considerations .....	347
10.8.3. Boundary Details .....	347
10.8.3.1. External Blackbody Temperature .....	347
10.8.3.2. Local Temperature .....	347
10.8.3.3. Radiation Intensity .....	347
10.8.3.4. Radiative Heat Flux .....	347
10.8.3.5. Emissivity .....	347
10.8.3.6. Diffuse Fraction .....	348
10.8.4. Sources .....	348
10.8.4.1. Directional Radiation Source .....	348
10.8.4.2. Isotropic Radiation Source .....	348
10.8.4.3. Directional Radiation Flux .....	348
10.8.4.4. Combining Radiation Sources .....	348
10.8.4.5. Isotropic Radiation Flux .....	348
10.8.5. Thermal Radiation Control .....	349
10.8.5.1. Iteration Interval .....	349
10.8.5.2. Diagnostic Output Level .....	349
10.8.5.3. Ray Reflection Control .....	349
10.8.5.4. Coarsening Control .....	349
10.8.5.4.1. Target Coarsening Rate .....	349
10.8.5.4.2. Minimum Blocking Factor .....	350
10.8.5.4.3. Maximum Blocking Factor .....	350
10.8.5.4.4. Small Coarse Grid Size .....	350
10.8.5.4.5. Diagnostic Output Level .....	350
10.8.5.5. Ray Tracing Control .....	350
10.8.5.5.1. Iteration Interval .....	350
10.8.5.5.2. Maximum Buffer Size .....	350
10.8.5.5.3. Maximum Number of Tracks .....	350
10.8.5.5.4. Maximum Number of Iterations .....	350
10.8.5.5.5. Ray Reflection Threshold .....	350
10.8.5.5.6. File Path .....	350
10.8.6. Spectral Model .....	351
10.8.6.1. Gray .....	351
10.8.6.2. Multiband .....	351
10.8.6.3. Multigray/Weighted Sum of Gray Gases .....	351
10.8.6.4. When is a Non-Gray Spectral Model Appropriate? .....	351
10.8.7. Scattering Model .....	352
10.8.7.1. Option = None .....	352
10.8.7.2. Option = Isotropic .....	353
10.8.7.3. Option = Linear Anisotropy .....	353
<b>11. Rigid Body Modeling .....</b>	<b>355</b>
11.1. Introduction to Rigid Body Modeling .....	355
11.2. Rigid Body Motion .....	355
11.3. Modeling a Rigid Body .....	357

11.3.1. Modeling a Rigid Body as a Collection of 2D Regions .....	357
11.3.2. Modeling a Rigid Body using an Immersed Solid .....	358
11.4. CEL Access of the Rigid Body State Variables .....	358
11.5. Monitor Plots related to Rigid Bodies .....	359
11.6. Solver Control of Rigid Bodies .....	359
11.7. Limitations to using Rigid Bodies .....	360
<b>12. Real Fluid Properties .....</b>	<b>361</b>
12.1. Setting up a Dry Real Gas Simulation .....	362
12.1.1. Using a Real Gas Equation of State .....	362
12.1.1.1. Redlich Kwong Dry Steam .....	362
12.1.1.2. Redlich Kwong Dry Refrigerants .....	362
12.1.1.3. Redlich Kwong Dry Hydrocarbons .....	363
12.1.1.4. Dry Redlich Kwong .....	363
12.1.2. Metastable States and Saturation Curve Clipping .....	363
12.1.3. Additional Comments .....	365
12.1.4. Using the IAPWS Equation of State .....	365
12.1.5. Using Real Gas Property (RGP) Tables .....	366
12.1.5.1. Loading .rgp files .....	366
12.1.5.2. Comments on Pressure and Temperature Ranges .....	366
12.1.5.3. Saturation Curve Clipping .....	366
12.1.6. Using a General Setup (CEL or User Fortran) .....	366
12.1.6.1. Saturation Curve Clipping .....	367
12.2. Table Interpolation and Saturation Curve Clipping .....	367
12.2.1. Table Interpolation .....	368
12.2.2. Table Inversion .....	369
12.3. Equilibrium Phase Change Model .....	369
12.4. Setting up an Equilibrium Phase Change Simulation .....	371
12.4.1. Using a Real Gas Equation of State .....	372
12.4.1.1. Redlich Kwong Wet Steam .....	372
12.4.1.2. Redlich Kwong Wet Refrigerants .....	372
12.4.1.3. Redlich Kwong Wet Hydrocarbons .....	372
12.4.1.4. Wet Redlich Kwong .....	372
12.4.1.5. Creating a Liquid Phase Material .....	373
12.4.1.6. Creating the Homogeneous Binary Mixture .....	373
12.4.2. Using Real Gas Property (.rgp) table files .....	373
12.4.2.1. Loading an .rgp file .....	373
12.4.2.2. Creating the Homogeneous Binary Mixture .....	373
12.4.3. Using a General Setup .....	373
12.4.3.1. Constants or Expressions .....	373
12.4.3.2. Antoine Equation .....	374
12.4.4. CFX-Pre Domain Models Setup .....	374
12.5. Important Considerations .....	374
12.5.1. Properties .....	375
12.5.2. Inlet Boundary Conditions .....	375
12.6. Real Gas Property (RGP) File Contents .....	375
12.6.1. Superheat Region .....	375
12.6.2. Saturated Region .....	377
12.7. Real Gas Property (RGP) File Format .....	378
12.7.1. Organization of an .rgp File .....	379
12.7.1.1. Detailed .rgp File Format .....	379
12.7.1.2. Example .rgp File .....	382
12.8. Parameters in the .rgp File Controlling the Real Gas Model .....	386

12.8.1. REAL_GAS_MODEL .....	387
12.8.2. P_CRITICAL, T_CRITICAL .....	387
12.8.3. UNITS .....	387
12.8.4. MIN_PROPERTY_T, MAX_PROPERTY_T, MIN_PROPERTY_P and MAX_PROPERTY_P .....	387
12.8.5. MOLECULAR_VISCOSITY, MOLECULAR_CONDUCTIVITY .....	388
12.8.6. GAS_CONSTANT .....	388
12.8.7. TMIN_SATURATION, TMAX_SATURATION .....	388
12.8.8. P_TRIPLE, T_TRIPLE .....	388
12.8.9. SUPERCOOLING .....	388
<b>13. Coupling CFX to an External Solver: ANSYS Multi-field Simulations .....</b>	<b>389</b>
13.1. Pre-Processing .....	389
13.1.1. Overview of Pre-Processing for ANSYS Multi-field Simulations .....	390
13.1.2. Pre-Processing in ANSYS Workbench Using the Mechanical Application and CFX .....	390
13.1.3. Pre-Processing in ANSYS Workbench Using the Mechanical APDL Application .....	391
13.1.4. Using CFX-Pre in ANSYS Multi-field Mode .....	392
13.1.4.1. Input File Specification for the Mechanical Application .....	392
13.1.4.2. Coupling Time Control .....	393
13.1.4.3. Boundary Conditions in ANSYS Multi-field Mode .....	394
13.1.4.3.1. Mesh Motion Setting .....	394
13.1.4.3.2. Heat Transfer Setting .....	394
13.1.4.3.3. Additional Coupling Sent Data .....	395
13.1.4.3.4. Boundary Conditions for ANSYS Multi-field CFX Multiphase Cases .....	395
13.1.4.3.5. Solver Controls, External Coupling Tab .....	396
13.1.5. Using CFX-Pre in ANSYS MultiField via Prep7 (Mechanical APDL) Mode .....	397
13.1.5.1. Boundary Conditions in ANSYS MultiField via Prep7 (Mechanical APDL) Mode .....	397
13.1.5.1.1. Mesh Motion Setting .....	397
13.1.5.1.2. Heat Transfer Setting .....	397
13.2. Running an MFX Simulation .....	398
13.3. Post-Processing .....	398
13.4. General Information .....	398
13.4.1. Solver Technology .....	398
13.4.2. Interpolation .....	399
13.4.3. Two-Way and One-Way Data Transfer .....	400
13.4.4. Transient and Steady-state MFX Simulations .....	401
13.4.5. Multiple Load Steps .....	402
13.4.6. Units .....	403
13.4.7. ANSYS Multi-field Simulations with Lagrangian Particle Tracking .....	403
13.4.8. Best Practices for ANSYS Multi-field Simulations .....	403
13.4.8.1. Avoiding Mesh Alignment Errors .....	403
13.4.8.2. Checking Convergence .....	404
13.4.8.3. Running the Mechanical Application and CFX Solvers Separately .....	405
13.4.8.4. Miscellaneous .....	405
<b>14. Aerodynamic Noise Analysis .....</b>	<b>407</b>
14.1. Overview of Aerodynamic Noise Analysis .....	407
14.1.1. Near Field Noise Prediction .....	408
14.1.2. Far Field Noise Prediction .....	408
14.2. Types of Noise Sources .....	409
14.2.1. Monopole Sources .....	410
14.2.2. Dipole and Rotating Dipole Sources .....	410
14.2.3. Quadrupole Sources .....	410
14.3. Noise Source Strength Estimation in CFX .....	410
14.3.1. Monopole Sources .....	411

14.3.1.1. Monopole Data in the CFX-Solver Manager .....	411
14.3.1.2. Exporting Surface Monopole Data .....	411
14.3.2. Dipole or Rotating Dipole Sources .....	411
14.3.2.1. Dipole Data in the CFX-Solver Manager .....	411
14.3.2.2. Exporting Surface Dipole Data .....	411
14.3.3. Important Boundary Results Export Notes .....	412
14.3.4. Quadrupole Sources .....	412
14.3.4.1. Exporting Acoustic Quadrupole Data .....	412
14.4. The CGNS Export Data Format .....	412
14.4.1. File Naming Conventions .....	412
14.4.1.1. Important Notes .....	413
14.4.2. CGNS File Structure .....	413
14.4.2.1. Common Nodes for Mesh and Solution Files .....	415
14.4.2.2. Mesh File Specific Nodes .....	416
14.4.2.3. Solution File Specific Nodes .....	417
<b>15. Advice on Flow Modeling .....</b>	<b>419</b>
15.1. Solving Problems with ANSYS CFX .....	419
15.2. Modeling 2D Problems .....	419
15.3. Mesh Issues .....	420
15.3.1. Physical Modeling Errors: YPLUS and Mesh Resolution Near the Wall .....	420
15.3.2. Measures of Mesh Quality .....	420
15.3.2.1. Mesh Orthogonality .....	420
15.3.2.2. Mesh Expansion .....	422
15.3.2.3. Mesh Aspect Ratio .....	423
15.4. Timestep Selection .....	423
15.4.1. Steady State Time Scale Control .....	424
15.4.1.1. Max. Iterations .....	424
15.4.1.2. Minimum Number of Iterations .....	424
15.4.1.3. Time Scale Control .....	425
15.4.1.3.1. Auto Timescale .....	425
15.4.1.3.1.1. Length Scale Option .....	425
15.4.1.3.1.2. Timescale Factor .....	425
15.4.1.3.1.3. Maximum Timescale .....	426
15.4.1.3.1.4. Controlling the Time Scale with the CFX-Solver File Editor .....	426
15.4.1.3.2. Local Time Scale Factor .....	426
15.4.1.3.3. Physical Time Scale .....	426
15.4.1.4. Solid Time Scale Control .....	428
15.4.1.4.1. Solid Timescale Factor .....	428
15.4.1.5. Controlling the Timescale for Each Equation .....	428
15.4.2. Transient Timestep Control .....	429
15.4.2.1. Time Duration .....	429
15.4.2.2. Timesteps: Timesteps List .....	430
15.4.2.3. Timesteps: Timesteps for the Run List .....	431
15.4.2.4. Timesteps: Adaptive .....	431
15.4.2.5. Timesteps: Coupling Timesteps .....	432
15.4.2.6. Initial Time .....	432
15.4.2.7. Max. Iter. Per Step .....	432
15.4.2.8. Transient Scheme .....	433
15.4.2.8.1. First Order Backward Euler .....	433
15.4.2.8.2. Second Order Backward Euler .....	433
15.4.2.8.2.1. Timestep Initialization .....	434
15.4.2.8.3. High Resolution .....	434

15.5. Advection Scheme Selection .....	434
15.5.1. Upwind .....	434
15.5.2. High Resolution .....	434
15.5.3. Specified Blend Factor .....	435
15.5.4. Central Difference .....	435
15.5.5. Advection Scheme for Turbulence Equations .....	435
15.5.6. Advection Schemes for Multiphase Volume Fractions .....	435
15.5.7. Comparisons to CFX-TASCflow .....	435
15.6. Advanced Options: Dynamic Model Control .....	436
15.6.1. Global Dynamic Model Control .....	436
15.6.2. Turbulence Control .....	436
15.6.3. Combustion Control .....	436
15.6.4. Hydro Control .....	437
15.7. Pressure Level Information .....	437
15.8. Interpolation Scheme .....	437
15.8.1. Pressure Interpolation Type .....	437
15.8.2. Velocity Interpolation Type .....	437
15.8.3. Shape Function Option .....	438
15.9. Temperature Damping .....	438
15.9.1. Option .....	438
15.9.2. Temperature Damping Limit .....	438
15.9.3. Under Relaxation Factor .....	438
15.10. Monitoring and Obtaining Convergence .....	438
15.10.1. The Residual .....	439
15.10.2. Residual Type and Target .....	439
15.10.3. Judging Convergence .....	439
15.10.3.1. RMS Residual Level .....	440
15.10.3.2. MAX Residual Level .....	440
15.10.4. Global Balances and Integrated Quantities .....	440
15.10.4.1. Positive and Negative Domain Source Totals .....	440
15.10.4.2. Conservation Target .....	441
15.10.5. Convergence Rate .....	441
15.10.6. Problems with Convergence .....	441
15.10.6.1. Start-up Problems .....	441
15.10.6.2. Later Problems .....	442
15.11. Solver Issues .....	445
15.11.1. Robustness and Accuracy .....	445
15.11.2. Linear Solver Failure .....	445
15.12. How CEL Interacts with the CFX-Solver .....	446
15.13. Best Practice Guides .....	446
<b>16. Using the Solver in Parallel .....</b>	<b>449</b>
16.1. Partitioning .....	449
16.1.1. Node-based and Element-based Partitioning .....	450
16.1.2. Multilevel Graph Partitioning Software - MeTiS .....	451
16.1.3. Recursive Coordinate Bisection .....	451
16.1.4. Optimized Recursive Coordinate Bisection .....	452
16.1.5. Simple Assignment .....	452
16.1.6. User Specified Direction .....	452
16.1.7. Directional Recursive Coordinate Bisection .....	453
16.1.8. Radial .....	453
16.1.9. Circumferential .....	454
16.2. Setup for Parallel Runs .....	454

16.3. Message Passing Interface (MPI) for Parallel .....	454
16.3.1. How to Use MPI Run Modes .....	455
16.3.2. When to Use MPI or PVM .....	455
16.3.3. Common MPICH Errors .....	455
16.3.4. Common Problems Encountered While Running MPICH .....	456
16.3.4.1. Semaphores and Shared Memory Segments .....	456
16.3.4.2. Typical Problems When You Run Out of Semaphores .....	456
16.3.4.3. Checking How Many Semaphores Are in Use, and by Whom .....	456
16.3.4.4. Deleting the Semaphores You Are Using .....	457
16.3.4.5. Shared Memory Segment Size Problems .....	457
16.3.4.6. Checking Semaphore ID and Shared Memory Segment Limits .....	457
16.3.4.6.1. Linux .....	457
16.3.4.7. Increasing the Maximum Number of Semaphores for Your System .....	457
16.4. Advice on Using ANSYS CFX in Parallel .....	458
16.4.1. Optimizing Mesh Partitioning .....	458
16.4.1.1. Do Not Run Small Jobs in Parallel .....	458
16.4.1.2. Always Try to Use the MeTiS Partitioning Method .....	458
16.4.1.3. Try to Use a Sensible Number of Partitions .....	458
16.4.1.4. If Necessary, Store the Partition File .....	458
16.4.1.5. Selection of the Partitioning Mode for Multi-Domain Cases .....	459
16.4.2. Optimizing the Parallel Run .....	459
16.4.3. Error Handling .....	459
16.4.3.1. Problems with PVM .....	460
16.4.3.2. Problems with the ANSYS CFX Executables .....	460
16.4.3.3. Problems with ANSYS CFX Licenses .....	461
16.4.3.4. Windows Problems .....	461
16.4.3.5. Linux Problems .....	461
16.4.3.6. Convergence Problems .....	461
16.4.4. Measuring Parallel Performance .....	461
16.4.4.1. Wall Clock Performance .....	461
16.4.4.2. Memory Efficiency .....	462
16.4.4.3. Visualizing Mesh Partitions .....	463
<b>17. Expert Control Parameters .....</b>	<b>465</b>
17.1. When to Use Expert Control Parameters .....	465
17.2. Modifying Expert Control Parameters .....	465
17.3. CFX-Solver Expert Control Parameters .....	465
17.3.1. Discretization Parameters .....	465
17.3.2. Linear-Solver Parameters .....	470
17.3.3. I/O Control Parameters .....	472
17.3.4. Convergence-Control Parameters .....	474
17.3.5. Physical Models Parameters .....	476
17.3.6. Particle-Tracking Parameters .....	478
17.3.7. Override Parameters .....	480
<b>18. User Fortran .....</b>	<b>483</b>
18.1. User CEL Functions and Routines .....	484
18.1.1. Structure of User CEL Functions .....	485
18.1.2. User CEL Function Units .....	486
18.2. User Junction Box Routines .....	486
18.2.1. Junction Box Routine Options and Parameters .....	487
18.2.2. Calling Junction Box Routines .....	489
18.2.3. Reading Data with the User Input Option .....	490
18.2.4. Writing Data with the User Output Option .....	490

18.2.5. Other Junction Box Location Options .....	490
18.2.6. Structure of the User Junction Box Routines .....	490
18.2.7. Which Call .....	491
18.3. Shared Libraries .....	491
18.3.1. Creating the Shared Libraries .....	491
18.3.2. Compiling User Fortran for ANSYS CFX 14.0 on Windows .....	492
18.3.3. Compiling User Fortran for use on Linux Machines Without a Compiler Installation .....	492
18.3.4. Default Fortran Compilers .....	492
18.4. User Parameters .....	493
18.4.1. Adding and Modifying User Parameters .....	493
18.4.2. Parameter Names .....	493
18.4.3. Parameter Values .....	493
18.4.4. Example of CCL File User Parameters .....	494
18.4.5. Looking up a String Value .....	494
18.4.6. String Value Example .....	494
18.4.7. Looking Up List Values .....	495
18.4.8. Real Value Example .....	495
18.4.9. Looking up Sizes of Lists and Strings .....	496
18.4.10. Real List Example .....	496
18.4.11. Printing Parameters .....	497
18.5. Utility Routines for User Functions .....	497
18.5.1. Introduction to Utility Routines for User Functions .....	497
18.5.2. Data Acquisition Routines .....	498
18.5.2.1. USER_GETVAR .....	498
18.5.2.1.1. Boundcon Operator .....	500
18.5.2.1.2. Variable Shape and Dimensions .....	500
18.5.2.2. USER_GET_GVAR .....	501
18.5.2.2.1. USER_GET_GVAR with Multiphase Flow .....	505
18.5.2.3. USER_CALC_INFO .....	506
18.5.2.4. USER_GET_MESH_INFO .....	507
18.5.2.4.1. Global Mesh Information: CZONE = '', LOCALE = '' .....	508
18.5.2.4.2. Zonal Information: CZONE = 'ZNm', LOCALE = '' .....	509
18.5.2.5. Boundary Condition Patch Information: CZONE = 'ZNm', LOCALE = 'BCPn' .....	509
18.5.2.5.1. Face Set Information: CZONE = 'ZNm', LOCALE = 'FCSn' .....	510
18.5.2.5.2. Element Set or Element Group Information: CZONE = 'ZNm', LOCALE = 'ELSn' or 'IELGn' or 'BELGn' .....	510
18.5.2.6. USER_GET_MESHDATA .....	511
18.5.2.7. USER_GET_PHYS_INFO .....	513
18.5.2.7.1. Zonal Information: CZONE = 'ZNm', CPHASE = '' .....	514
18.5.2.7.2. Phase Information: CZONE = 'ZNm', CPHASE = 'FLm' or 'SLm' .....	514
18.5.2.8. USER_GET_TRANS_INFO .....	515
18.5.2.9. USER_ASSEMBLE_INFO .....	516
18.5.2.10. GET_PARALLEL_INFO .....	517
18.5.2.11. CAL_MESHMAP .....	518
18.5.3. Name Conversions .....	518
18.5.3.1. CONVERT_NAME_U2S .....	518
18.5.3.2. CONVERT_NAME_S2U .....	520
18.5.3.3. VAR_ALIAS .....	520
18.5.3.4. LOCALE_ALIAS .....	521
18.5.3.5. CONVERT_USER_NAMES .....	521
18.5.3.6. GET_PHASE_FROM_VAR .....	521
18.5.3.7. PARSMP .....	521

18.5.4. Character Handling .....	522
18.5.4.1. CFROMD .....	522
18.5.4.2. CFROMI .....	522
18.5.4.3. CFROMR .....	522
18.5.4.4. DFROMC .....	523
18.5.4.5. IFROMC .....	523
18.5.4.6. RFROMC .....	523
18.5.4.7. LENA CT .....	523
18.5.4.8. EDIT .....	523
18.5.4.9. IOPNAM .....	524
18.5.4.10. CCATI .....	524
18.5.5. Output Routines .....	525
18.5.5.1. MESSAGE .....	525
18.5.5.2. ERRMSG .....	526
18.6. CFX Memory Management System (MMS) .....	526
18.6.1. Introduction to the Memory Management System .....	526
18.6.2. Error Conventions .....	527
18.6.3. Stack Pointers .....	529
18.6.4. Subroutines .....	529
18.6.4.1. Directories .....	529
18.6.4.1.1. MAKDIR .....	529
18.6.4.1.2. DELDIR .....	530
18.6.4.1.3. CHGDIR .....	530
18.6.4.1.4. CHMDIR .....	530
18.6.4.1.5. PSHDIR .....	530
18.6.4.1.6. PSHDRH .....	530
18.6.4.1.7. POPDIR .....	531
18.6.4.1.8. LISDAT .....	531
18.6.4.1.9. PUTDIR .....	531
18.6.4.1.10. FNDFIL .....	531
18.6.4.2. Data Areas .....	533
18.6.4.2.1. MAKDAT .....	533
18.6.4.2.2. MAKVEC .....	534
18.6.4.2.3. GRBSTK .....	534
18.6.4.2.4. SQZDAT .....	534
18.6.4.2.5. RESIZE .....	535
18.6.4.2.6. DELDAT .....	535
18.6.4.2.7. LOCDAT .....	535
18.6.4.2.8. INFDAT .....	535
18.6.4.3. Renaming And Linking .....	536
18.6.4.3.1. RENAM .....	536
18.6.4.3.2. MAKLNK .....	536
18.6.4.3.3. DELLNK .....	536
18.6.4.4. Copying .....	536
18.6.4.4.1. COPDAT .....	536
18.6.4.4.2. COPDIR .....	537
18.6.4.5. Setting and Reading Individual Values .....	537
18.6.4.5.1. POKECA .....	537
18.6.4.5.2. POKECS .....	537
18.6.4.5.3. POKED .....	537
18.6.4.5.4. POKEI .....	537
18.6.4.5.5. POKEL .....	537

18.6.4.5.6. POKER .....	537
18.6.4.5.7. PEEKCA .....	538
18.6.4.5.8. PEEKCS .....	538
18.6.4.5.9. PEEKD .....	538
18.6.4.5.10. PEEKI .....	538
18.6.4.5.11. PEEKL .....	538
18.6.4.5.12. PEEKR .....	538
18.6.4.6. Name lists .....	539
18.6.4.6.1. NAMLST .....	539
18.6.4.7. Memory Management Statistics .....	540
18.6.4.7.1. GETMMS .....	540
18.6.4.7.2. WSTAT .....	542
18.7. User CEL Examples .....	542
18.7.1. User CEL Example 1: User Defined Momentum Source .....	543
18.7.1.1. Problem Setup .....	543
18.7.1.2. Creating the User CEL Function .....	543
18.7.1.3. User Fortran Routine .....	544
18.7.2. User CEL Example 2: Using Gradients for an Additional Variable Source .....	545
18.7.2.1. Problem Setup .....	546
18.7.2.1.1. Creating the Additional Variables .....	546
18.7.2.1.2. Creating the Domain .....	546
18.7.2.1.3. Creating the User CEL Routine and Function .....	546
18.7.2.1.4. Defining the Source Term .....	547
18.7.2.2. User Fortran Routine .....	547
18.7.3. User CEL Example 3: Integrated Quantity Boundary Conditions .....	549
18.7.3.1. Problem Setup .....	549
18.7.3.1.1. Creating the User Function .....	549
18.7.3.2. User Fortran Routine .....	550
18.8. User Junction Box Examples .....	550
18.8.1. Junction Box Example 1: Profile Boundary Conditions .....	550
18.8.1.1. Problem Setup .....	550
18.8.1.1.1. Creating the Junction Box Routine and User CEL Function .....	551
18.8.1.1.2. Setting the Boundary Condition .....	552
18.8.1.1.3. Enabling the Junction Box Routine .....	552
18.8.1.2. User Fortran Junction Box Routines .....	552
18.8.2. Junction Box Example 2: Integrated Residence Time Distribution .....	558
18.8.2.1. Problem Setup .....	559
18.8.2.1.1. Creating the Additional Variables .....	559
18.8.2.1.2. Creating the Domains .....	559
18.8.2.1.3. Creating the Subdomains and Additional Variable Sources .....	559
18.8.2.1.4. Creating the Junction Box Routine .....	559
18.8.2.1.5. Enabling the Junction Box Routine .....	559
18.8.2.2. User Fortran Junction Box Routine .....	560
18.8.3. Junction Box Example 3: Timestep Control .....	562
18.8.4. Junction Box Example 4: Solver Control .....	567
18.8.5. Junction Box Example 5: Transient Information .....	568
18.9. Using CFX-4 Routines in CFX .....	570
18.10. State Point Evaluation .....	572
18.10.1. General Usage Notes .....	573
18.10.2. Supported Independent Thermodynamic Input Properties .....	573
18.10.3. Supported Thermodynamic Output Properties .....	574
18.10.4. Input and Output Property Name Format .....	574

18.10.4.1. Pure Substance Example .....	574
18.10.4.2. Mixture Example .....	575
18.10.5. Supported Material Types .....	576
18.10.6. Error Checks .....	576
18.10.7. USER_STATEPT Example 1 .....	576
18.10.8. USER_STATEPT Example 2 .....	580
18.11. Calculating the Particle Drag Coefficient .....	583
Index .....	585

---

# Chapter 1: Basic Capabilities Modeling

---

This chapter describes the basic physical models and some other basic capabilities found in ANSYS CFX:

- 1.1. Domains
- 1.2. Physical Models
- 1.3. Sources
- 1.4. Material Properties
- 1.5. Mixture Properties (Fixed and Variable)
- 1.6. Efficiency Calculation
- 1.7. Wall Condensation Model

Additional information on using boundary and initial conditions is available:

- *Boundary Condition Modeling* (p. 57)
- *Initial Condition Modeling* (p. 95).

Descriptions of more advanced physical models and how the basic models extend to more complex cases are provided in:

- *Turbulence and Near-Wall Modeling* (p. 125)
- *Domain Interface Modeling* (p. 157)
- *Transient Blade Row Modeling* (p. 179)
- *Multiphase Flow Modeling* (p. 189)
- *Particle Transport Modeling* (p. 237)
- *Combustion Modeling* (p. 299)
- *Radiation Modeling* (p. 339)
- *Rigid Body Modeling* (p. 355)
- *Real Fluid Properties* (p. 361)
- *Coupling CFX to an External Solver: ANSYS Multi-field Simulations* (p. 389)
- *Aerodynamic Noise Analysis* (p. 407)
- *Wall Condensation Model* (p. 55)

Additional information is available:

- For general solver and convergence advice, see *Advice on Flow Modeling* (p. 419).
- For information on parallel processing and its implementation, see *Using the Solver in Parallel* (p. 449).
- For information on expert parameters, see *Expert Control Parameters* (p. 465).
- For information on extending the capabilities of CFX through Fortran subroutines, see *User Fortran* (p. 483).
- For a description of the mathematics used in the implementation of these models, see *Basic Solver Capability Theory in the CFX-Solver Theory Guide*.

## 1.1. Domains

Regions of fluid flow and/or heat transfer in CFX are called domains. Fluid domains define a region of fluid flow, while solid domains are regions occupied by conducting solids in which volumetric sources of energy can be specified. The domain requires three specifications:

- The region defining the flow or conducting solid. A domain is formed from one or more 3D primitives that constrain the region occupied by the fluid and/or conducting solids. For details, see [Mesh Topology in CFX-Pre in the CFX-Pre User's Guide](#).
- The physical nature of the flow. This determines the modeling of specific features such as heat transfer or buoyancy.
- The properties of the materials in the region.

There can be many domains per model, with each domain defined by separate 3D primitives. Multidomain problems may be created from a single mesh if it contains multiple 3D primitives or is from multiple meshes. For details, see [Importing and Transforming Meshes in the CFX-Pre User's Guide](#).

## 1.2. Physical Models

When you set up a simulation, you must select which physical models to include. The physical models define the type of simulation you want to perform.

Currently in CFX, the following models are available:

- [Steady State and Transient Flows](#) (p. 3)
- [Mesh Deformation](#) (p. 3)
- [Laminar Flow](#) (p. 9)
- [Turbulence and Turbulence Models](#) (p. 9)
- [Heat Transfer](#) (p. 9)
- [Conjugate Heat Transfer](#) (p. 10)
- [Compressible Flow](#) (p. 10)
- [Setting a Reference Pressure](#) (p. 11)
- [Buoyancy](#) (p. 12)
- [Immersed Solids](#) (p. 14)
- [Multicomponent Flow](#) (p. 18)
- [Equilibrium Phase Change Model](#) (p. 369)
- [Additional Variables](#) (p. 23)
- [Non-Newtonian Flow](#) (p. 26)
- [Coordinate Frames](#) (p. 29)
- [Rotating Frames of Reference \(RFR\)](#) (p. 30)
- [Sources](#) (p. 31)

In addition to these models, you can also introduce volumetric sources of mass, momentum energy, resistance, and Additional Variables using fluid subdomains. Point sources can also be applied to a single control volume. For details, see [Point Sources](#) (p. 32).

Descriptions of more advanced physical models and how the basic models extend to more complex cases are provided in:

- *Boundary Condition Modeling* (p. 57)
- *Initial Condition Modeling* (p. 95)
- *Turbulence and Near-Wall Modeling* (p. 125)
- *Domain Interface Modeling* (p. 157)
- *Multiphase Flow Modeling* (p. 189)
- *Particle Transport Modeling* (p. 237)
- *Combustion Modeling* (p. 299)
- *Radiation Modeling* (p. 339)
- *Real Fluid Properties* (p. 361)
- *Coupling CFX to an External Solver: ANSYS Multi-field Simulations* (p. 389)

### 1.2.1. Steady State and Transient Flows

The time dependence of the flow characteristics can be specified as either steady state or transient. Steady state simulations, by definition, are those whose characteristics do not change with time and whose steady conditions are assumed to have been reached after a relatively long time interval. They therefore require no real time information to describe them. Many practical flows can be assumed to be steady after initial unsteady flow development, for example, after the start up of a rotating machine.

Transient simulations require real time information to determine the time intervals at which the CFX-Solver calculates the flow field. Transient behavior can be caused by the initially changing boundary conditions of the flow, as in start up, or it can be inherently related to the flow characteristics, so that a steady state condition is never reached, even when all other aspects of the flow conditions are unchanging. Many flows, particularly those driven by buoyancy, do not have a steady state solution, and may exhibit cyclic behavior.

Sometimes simulations that are run in steady state mode will have difficulty converging, and no matter what action you take regarding mesh quality and time step size, the solution does not converge. This could be an indication of transient behavior. If you have run a steady state calculation and you see oscillatory behavior of the residual plots, you can test to see if you are observing a transient effect by reducing/increasing the time step size by known factors:

- If the period of oscillation of the residual plot changes by changing the time step size, then the phenomenon is most likely a numerical effect.
- If the period stays the same, then it is probably a transient effect.

In transient mode, you must set both physical time steps and the maximum number of coefficient iterations per time step.

### 1.2.2. Mesh Deformation

Mesh deformation is an important component for solving problems with moving boundaries or moving subdomains. The motion might be imposed, or might be an implicit part of a coupled fluid-structure simulation. Mesh deformation is available only for fluid domains. Three mesh deformation options are available for a domain:

- *None* (p. 4)

- [Regions of Motion Specified](#) (p. 4)
- [Junction Box Routine](#) (p. 8)

### 1.2.2.1. None

Select this option if no mesh deformation is desired.

### 1.2.2.2. Regions of Motion Specified

This mesh deformation option enables the specification of the motion of nodes on boundary or subdomain regions of the mesh using CEL. The motion of all remaining nodes is determined by the mesh motion model, which is currently limited to `Displacement Diffusion`. With this model, the displacements applied on domain boundaries or in subdomains are diffused to other mesh points by solving the equation:

$$\nabla \cdot \left( \Gamma_{\text{disp}} \nabla \delta \right) = 0 \quad (1-1)$$

In this equation,  $\delta$  is the displacement relative to the previous mesh locations and  $\Gamma_{\text{disp}}$  is the mesh stiffness, which determines the degree to which regions of nodes move together. This equation is solved at the start of each outer iteration or time step for steady state or transient simulations, respectively.

It is worth noting that the displacement diffusion model for mesh motion is designed to preserve the relative mesh distribution of the initial mesh. For example, if the initial mesh is relatively fine in certain regions of the domain (for example, in boundary layers), then it will remain relatively fine after solving the displacement diffusion equation.

#### 1.2.2.2.1. Mesh Stiffness

When any constant value of mesh stiffness is applied, specified displacements are homogeneously diffused throughout the mesh. When the mesh stiffness is specified as varying throughout the domain, nodes in regions of high stiffness move together (that is, there is little relative motion). Variable mesh stiffness is particularly useful to preserve the mesh distribution (and quality) near fine geometrical features (such as sharp corners) or in boundary layers.

The available **Mesh Stiffness** options are:

- `Increase Near Small Volumes`  
For details, see [Increase Near Small Volumes](#) (p. 4).
- `Increase Near Boundaries`  
For details, see [Increase Near Boundaries](#) (p. 5).
- `Value`  
For details, see [Value \(Specified Stiffness\)](#) (p. 5).

##### 1.2.2.2.1.1. Increase Near Small Volumes

The premise of increasing the stiffness near small mesh volumes is that mesh quality will benefit from having larger control volumes absorb more mesh motion. This option is desirable because it does not require the solution of additional equations (as for boundary dependent options). However, its behavior

does depend on the initial mesh distribution (for example, having a fine mesh in regions where the motion is likely to be most significant).

The following relationship is used to determine the mesh stiffness,  $\Gamma_{\text{disp}}$ , applied in the displacement diffusion equation:

$$\Gamma_{\text{disp}} = \left( \frac{1}{\nabla} \right)^{C_{\text{stiff}}} \quad (1-2)$$

This relationship provides an exponential increase in the mesh stiffness as the control volume size,  $\nabla$ , decreases. The stiffness model exponent,  $C_{\text{stiff}}$ , determines how quickly this increase occurs. For example, large values will yield a much more abrupt stiffness variation. Stiffness values are clipped between minimum and maximum values that are defaulted to 1e-15 and 1e15, respectively.

#### 1.2.2.2.1.2. Increase Near Boundaries

The premise of increasing the stiffness near certain boundaries (wall, inlet, outlet, and opening) is that mesh quality will benefit from having the mesh interior (that is, away from wall, inlet, outlet, and opening boundaries) absorb more mesh motion. Although this option requires the solution of an additional boundary scale equation, it is useful because it does not depend upon the original mesh distribution (that is, control volume size distribution) and it treats regions near all wall, interface, inlet, outlet, and opening boundaries identically. However, the mesh stiffness is unaffected near symmetry and one-to-one periodic interfaces.

The following relationship is used to determine the mesh stiffness,  $\Gamma_{\text{disp}}$ , applied in the displacement diffusion equation:

$$\Gamma_{\text{disp}} = \left( \frac{1}{d} \right)^{C_{\text{stiff}}} \quad (1-3)$$

This relationship provides an exponential increase in the mesh stiffness as the distance from the nearest boundary,  $d$ , decreases. The stiffness model exponent,  $C_{\text{stiff}}$ , determines how quickly this increase occurs.

Detailed information on the boundary scale equation is available at [Wall and Boundary Distance Formulation in the CFX-Solver Theory Guide](#).

#### 1.2.2.2.1.3. Value (Specified Stiffness)

The mesh stiffness can also be specified directly using the CEL. As suggested above, the mesh stiffness should increase in regions where mesh folding is most likely to occur. For example, the mesh stiffness could be made to increase with total mesh displacement.

#### 1.2.2.2.2. Mesh Motion Options

The mesh motion options that are available on subdomain and boundary regions are nearly identical. The options listed in [Table 1.1: Mesh Motion Options \(p. 6\)](#) are accessible on the **Mesh Motion** and **Boundary Details** tabs for the subdomain and boundary regions, respectively.

**Note**

**Mesh Motion = ANSYS Multifield** is not supported for boundaries in solid domains.

**Table 1.1 Mesh Motion Options**

Option	Inlet, Outlet, Opening	Wall	Symmetry	Interface	Subdomain
<i>Conservative Interface Flux</i>				X	
<i>Unspecified</i>	X	X	X	X	X
<i>Stationary</i>	X	X	X	X	X
<i>Specified Displacement</i>	X	X		X	X
<i>Specified Location</i>	X	X		X	X
<i>ANSYS MultiField</i>		X			
<i>Rigid Body Solution</i>	X	X		X	X

**Note**

When using *Unspecified* or *Conservative Interface Flux* conditions, there is no constraint that attempts to keep the meshes on either side of the interface together. One can expect that the mesh surfaces on either side of the interface will float apart or even cross over each other slightly. This will not generally affect solution accuracy because all interface values and transport flows are evaluated on control surfaces that represent an average of the surfaces on either side of the interface. However, if the mesh surfaces are too far apart (due to floating apart or due to crossover) then the solver may fail while trying to generate the average surface. Although very uncommon, this failure is fatal. GGI control expert parameters exist to relax the tolerances used while intersecting the meshes on either side of the interface. For details, see *CFX-Solver Expert Control Parameters* (p. 465).

The motion of all remaining nodes is implicitly unspecified, and is determined by solving a mesh displacement diffusion equation at the start of each time step for transient runs, or outer loop iteration for steady-state runs.

**1.2.2.2.1. Conservative Interface Flux**

This option is similar to *Unspecified* (p. 7) because no constraints on mesh motion are applied to nodes. The important difference is that motion of nodes in all domains adjacent to the interface influence, and are influenced by, the motion of the nodes on the interface.

**Important**

Applying *Conservative Interface Flux* implies that the quantity in question will “flow” between the current boundary and the boundary on the other side of the interface. This means that *Conservative Interface Flux* must also be used on the boundary on the other side of the interface. Accordingly, the CFX-Solver will not be able to handle cases where *Conservative Interface Flux* is set on just one side of the interface, or where the quantity being transferred does not exist on the other side. CFX-Pre will issue a warning if either of these cases exist.

#### 1.2.2.2.2. Unspecified

No constraints on mesh motion are applied to nodes. Their motion is determined by the motion set on other regions of the mesh. When this option is used on a domain interface boundary condition, only motion from other nodes in the current domain is “felt”. It is worth noting that this motion will enable the mesh on one side of a domain interface to pull away from the mesh on the other side of the interface.

#### 1.2.2.2.3. Stationary

Nodes are not permitted to move relative to the local boundary frame.

#### 1.2.2.2.4. Specified Displacement

Nodes are displaced according to the specified CEL expression or User CEL. This displacement is always relative to the initial mesh and the local coordinate frame, if defined.

The following displacement options exist:

- **Cartesian Components**

Provide X, Y, and Z components of the displacement.

- **Cylindrical Components**

Provide axial, radial, and theta components of the displacement. The theta (circumferential) component is an arc length rather than an angle. The displacement in **Cylindrical Components** also requires the specification of **Axis Definition** either as a `Coordinate Axis` of an existing coordinate frame (for details, see [Coordinate Frames \(p. 29\)](#)) or `Two Points`.

---

#### Note

When specifying mesh displacements using CEL, the variable `Initial Cartesian Coordinates` (with components `Initial X`, `Initial Y`, and `Initial Z`) may be useful. This variable represents the position of each node as it was at the start of the simulation (that is, the current position with `Total Mesh Displacement` subtracted).

#### 1.2.2.2.5. Specified Location

All nodes are located according to the specified CEL expression or User CEL.

---

#### Note

- Care should be taken when using this option because it is easy to get unexpected results. In particular, if a constant location (such as 0, 0, 0) is set for an entire region, all the mesh points will collapse to that point location.
- When specifying mesh locations using CEL, the variable `Initial Cartesian Coordinates` (with components `Initial X`, `Initial Y`, and `Initial Z`) may be useful. This variable represents the position of each node as it was at the start of the simulation (that is, the current position with `Total Mesh Displacement` subtracted).

### 1.2.2.2.6. ANSYS MultiField

In regions that match the ANSYS side, nodes are displaced according to the data received from the ANSYS Multi-field solver; in regions that do not match ANSYS side, the unspecified condition is imposed. This displacement is always relative to the initial mesh. For more information about simulations involving Fluid Structure Interaction (FSI) and the ANSYS Multi-field solver, refer to [Coupling CFX to an External Solver: ANSYS Multi-field Simulations](#) (p. 389) and the [Mechanical APDL Coupled-Field Analysis Guide](#).

### 1.2.2.2.7. Rigid Body Solution

Set **Rigid Body** to the name of the rigid body object that will govern the motion of the boundary/sub-domain.

You can restrict which aspects of the rigid body motion are applied to the boundary/subdomain by selecting **Motion Constraints** and choosing one of the following options:

- None

No constraints are applied to the boundary/subdomain. The motion of the rigid body object is applied to the boundary/subdomain.

- Ignore Translations

Any translational motion of the rigid body object is ignored when applying the motion of the rigid body object to the boundary/subdomain.

- Ignore Rotations

Any rotational motion of the rigid body object is ignored when applying the motion of the rigid body object to the boundary/subdomain.

[Modeling a Buoy using the CFX Rigid Body Solver in the CFX Tutorials](#) demonstrates the use of the **Motion Constraints** setting.

For additional information on modeling rigid bodies, see [Rigid Body Modeling in the CFX-Solver Modeling Guide](#).

### 1.2.2.3. Junction Box Routine

When this option is chosen, a User Fortran routine that explicitly sets the coordinates of all nodes in a given domain is specified and called. The Junction Box Routine that is called is specified with this mesh deformation option rather than with other Junction Box Routines on the **Solver Control** dialog box. The specified routine is always called at the start of each time step, and all mesh coordinate dependent quantities (for example, the volumes of control volumes) are automatically updated.

---

#### Note

This option becomes available only once one or more Junction Box Routines have been created; only one Junction Box Routine can be selected.

---

#### Important

Only the coordinates of mesh nodes may change; the topology (that is, the connectivity) of the mesh must remain fixed.

### 1.2.3. Laminar Flow

For details, see *The Laminar Model* (p. 126).

### 1.2.4. Turbulence and Turbulence Models

Information on turbulent flow, turbulence models and wall functions is available in *Turbulence and Near-Wall Modeling* (p. 125). A description of how turbulence modeling can be extended to multiphase flow is available in *Turbulence Modeling in Multiphase Flow* (p. 209).

The mathematical details of the turbulence models used in CFX is available in *Turbulence and Wall Function Theory in the CFX-Solver Theory Guide*.

### 1.2.5. Heat Transfer

A heat transfer model is used to predict the temperature throughout the flow. Heat transfer by conduction, convection, and (where appropriate) turbulent mixing and viscous work are included.

The following options for heat transfer available in CFX:

#### 1.2.5.1. None

Select this option if your simulation does not involve the modeling of heat transfer. It eliminates the heat transfer calculation from the governing equations. This option reduces the number of calculations performed, and subsequently the time required, by the CFX-Solver.

#### 1.2.5.2. Isothermal

This model requires you to enter a uniform temperature for the fluid in absolute temperature terms. This can be used for the purpose of evaluating fluid properties that are temperature dependent, for example, the density of an ideal gas. For general fluids, a constant temperature can be used as the basis for a series of isothermal simulations using temperature-dependent fluid properties. You may also use this option to create an initial results file for a more complex model. Heat transfer is not modeled.

#### 1.2.5.3. Thermal Energy

This models the transport of enthalpy through the fluid domain. It differs from the `Total Energy` model in that the effects of mean flow kinetic energy are not included. It consequently reproduces the same results as the `Total Energy` model when kinetic energy effects vanish, and is therefore adequate for low speed flows where kinetic effects are negligible.

For cases where viscous heating and the effects of turbulence on it are important, it is recommended that you use the `Total Energy` model.

#### 1.2.5.4. Total Energy

This models the transport of enthalpy and includes kinetic energy effects. It should be used where kinetic energy effects become significant, for example gas flows where the Mach number exceeds 0.3. The selection of the `Total Energy` model has implications for whether the fluid is modeled as compressible or incompressible (see *Compressible Flow* (p. 10)) and for which buoyancy model (see *Buoyancy* (p. 12)) is employed by the CFX-Solver.

The mathematical model for heat transfer is available in [Transport Equations in the CFX-Solver Theory Guide](#).

### 1.2.5.5. Turbulent Flux Closure

When the heat transfer model is set to either **Thermal Energy** or **Total Energy**, the **Turbulent Flux Closure for Heat Transfer** may be optionally selected in the **Turbulence** settings. When **Turbulent Flux Closure for Heat Transfer** is not selected, the default is the **Eddy Diffusivity** model with the turbulent Prandtl number of 0.9. The turbulent Prandtl number may be non-constant using by expressions (CEL), for example, as a function of physical space or solution variables.

By default the turbulent Prandtl number specified for heat transfer will also be applied as the turbulent Schmidt number for component mass fractions and combustion scalars.

### 1.2.6. Conjugate Heat Transfer

CFX enables you to specify regions that are occupied by conducting solids. You can specify such a region as a solid domain using the domains form.

To specify a source of energy in a solid domain, you should create a subdomain for the solid region (which may include the entire region) and apply the source term to the subdomain. Energy sources can be specified in terms of a source value and a linear source coefficient.

Information on the mathematical implementation of subdomain sources is available in [Sources in the CFX-Solver Theory Guide](#).

The mathematical equations solved in a solid domain are available in the Solver Theory documentation in [Conjugate Heat Transfer in the CFX-Solver Theory Guide](#).

### 1.2.7. Compressible Flow

CFX can solve for subsonic (less than the speed of sound), transonic (close to the speed of sound), and supersonic (greater than the speed of sound) flows when compressible fluid models are used. Compressible flow is activated in CFX-Pre by using an ideal gas or real fluid or a general fluid whose density is a function of pressure.

When modeling high-speed compressible flow (transonic or supersonic), you may want to use supersonic inlet and/or supersonic outlet boundaries. In this case, you must use the total energy heat transfer model.

If the local Mach number exceeds 2 during the solution of a supersonic flow problem, the CFX-Solver will take action to stabilize the solution with an inner iteration that re-linearizes the continuity equation. Your output file will show this loop as an extra continuity equation (P-Mass) line in the convergence history:

```

TIME STEP = 3 SIMULATION TIME = 3.00E-02 CPU SECONDS = 1.59E+02
-----
| Equation | Rate | RMS Res | Max Res | Location | Linear Solution |
+-----+
| U - Mom | 0.31 | 2.6E-04 | 2.7E-03 | 2757 | 2.0E-02 OK |
| V - Mom | 0.35 | 3.2E-04 | 3.8E-03 | 1660 | 4.3E-02 OK |
| W - Mom | 0.41 | 6.7E-05 | 8.6E-04 | 54 | 5.4E-02 OK |
| P - Mass | 0.22 | 3.7E-04 | 3.9E-03 | 114 | 8.6 1.6E-02 OK |
+-----+
| H-Energy | 0.24 | 2.1E-05 | 1.5E-04 | 49 | 9.7 2.8E-03 OK |
+-----+
| K-TurbKE | 0.28 | 1.0E-02 | 8.9E-02 | 882 | 5.3 1.3E-03 OK |

```

E-Diss.K	0.39	3.9E-03	6.0E-02	4	5.3	1.1E-04	OK
P-Mass	0.45	1.7E-04	1.7E-03	49	8.6	1.3E-02	OK

Supersonic flow problems are, in general, more difficult to solve than subsonic or incompressible flow problems. This is due to the highly nonlinear nature of supersonic flows, especially when shocks are present.

A large source of convergence problems arise due to non-physical problem specification, not only in supersonic flows. When you are setting up a problem make sure that the boundary conditions, material properties and geometry are all physically consistent. For instance, for certain internal geometries, there is a maximum achievable mass flow rate. The solver will not produce a converged solution with mass flow boundary conditions specified with a higher value than this limit. Another potentially problematic situation is when an oblique shock wave impinges on a boundary. To begin with, you should try using a slip wall to represent this boundary. Once convergence is achieved, you can switch the boundary to a supersonic Outlet. This may or may not converge, as a domain boundary/shock wave interaction is difficult to model at an Outlet. It may be necessary to move the side boundary in such cases.

For compressible flows, the pressure level should always be set. The pressure can be specified:

- By one of the boundaries in the simulation in the form of a pressure specified inlet, outlet or opening (in transient compressible flows, the initial conditions can set the pressure level).
- If the pressure level is not set at any boundary, it can be set at a particular location using the **Pressure Level Information** section on the **Advanced** tab of the **Solver Control** dialog box.

If the pressure level is not set, the CFX-Solver will set zero relative pressure at node 1. During the course of solution, this may yield negative relative pressures, and if the reference pressure is also small, this may lead to negative absolute pressure values, which is physically inconsistent. The CFX-Solver will then attempt to calculate the density with a negative value of absolute pressure, and will fail. For details, see [Setting a Reference Pressure](#) (p. 11).

### 1.2.7.1. Mixed Subsonic/Supersonic Boundaries

If you expect the conditions at an Inlet to be mixed subsonic/supersonic, you should use the Mixed flow regime option.

If you expect the conditions at an Outlet to be mixed subsonic/supersonic, there is no way to currently deal with this in CFX. Usually, the way to resolve such a situation is similar to the Outlet boundary problem where inflow occurs (that is, to move the boundary to a position where the conditions are known to be either fully subsonic or fully supersonic).

### 1.2.8. Setting a Reference Pressure

In CFX, you must specify a **Reference Pressure** for your simulation. The **Reference Pressure** is specified on the **Basic Settings** tab of the Domains form, but is a property of the entire simulation so all domains must use the same value. Each time you create a new domain or apply a change to an existing domain, the Reference Pressure in that domain is applied to all domains.

All relative pressure specifications set in CFX are measured relative to this **Reference Pressure** value. The **Reference Pressure** will affect the value of every other pressure set in the simulation.

The reference pressure is used to avoid problems with round-off errors. These can occur when the dynamic pressure change in a fluid, which is what drives the flow, are small compared to the absolute pressure level.

For example, low speed atmospheric air flow may have dynamic pressure changes of only a few Pascals or less, but the changes are relative to the atmospheric pressure of around 100,000 Pa. If you are dealing only in absolute pressure terms, these small pressure changes can get lost in round-off errors when performing calculations (for example, a change of 1 Pa is a change to the sixth significant digit). To rectify the situation, you should set a sensible **Reference Pressure** level. In this case, the local atmospheric pressure of 100,000 Pa is suitable. This value will be used as the new datum (instead of 0 Pa) about which all pressures are calculated. A change of 1 Pa will now be a change to the first significant digit.

As a counterexample, a reference pressure of 0 Pa can be used without any problems when the dynamic pressure changes are significant compared to the absolute pressure level. When modeling a liquid flow where nothing depends on the pressure level, there is no need to specify an atmospheric reference pressure.

When boundary and initial conditions are specified, they are set relative to the reference pressure. If you require a boundary to have an absolute pressure level of 100,000 Pa, you could:

- Set a relative pressure value of 0 Pa for the boundary if the reference pressure is 100,000 Pa or,
- Set a relative pressure value of 100,000 Pa for the boundary if the reference pressure is 0 Pa.

---

### Note

The **Reference Pressure** may be evaluated as a CEL expression. However, **Reference Pressure** values that vary over time are not supported.

If the system variable called `Pressure` (or `p`) is used in an expression defining material properties (for example, when setting a custom equation of state for density), this variable is interpolated as absolute pressure rather than relative pressure.

## 1.2.9. Buoyancy

Natural and mixed convection flows and flows in which gravity is important can be modeled by CFX by the inclusion of buoyancy source terms. Natural convection refers to the case where convection of the fluid is driven only by local density variations, for example, in a closed box with a heat source. Mixed convection refers to the case where convection of the fluid is driven by both a pressure gradient and buoyancy forces.

Buoyancy is driven by variations in density that can arise from a number of sources:

- Local temperature variations cause changes in density; this is natural convection.
- In multicomponent flows, variations in the mass fraction cause density variations because each component usually has a different density.
- In multiphase flows, including particle transport modeling, the difference in density between the phases results in a buoyancy force. For details, see *Buoyancy in Multiphase Flow* (p. 197).
- If density is variable for a **General Fluid** (that is, defined by an expression), a buoyancy force will arise.

- For ideal gases and real fluids, local pressure variations also cause changes in density. These changes are often small and the buoyancy effect is usually not important in the flow. Buoyancy does not necessarily need to be modeled if there are no other sources of buoyancy.

Therefore, for an isothermal, single phase, single component flow using a **General Fluid** with constant density, there are no buoyancy forces.

The relative importance of buoyancy forces due to temperature variations in a mixed convection flow can be estimated by using the ratio of Grashof and Reynolds Number,

$$\frac{Gr}{Re^2} = \frac{g \beta L \Delta T}{U^2} \quad (1-4)$$

where  $\beta$  is the thermal expansion coefficient. A value approaching or exceeding unity indicates that buoyancy effects are significant in the flow, while small values indicate that buoyancy effects can be ignored.

In purely natural convection problems, the Raleigh Number ( $Ra$ ) indicates the relative strength of the buoyancy induced flow and is given by:

$$Ra = Gr Pr \quad (1-5)$$

where  $Pr$  is the fluid Prandtl number. The laminar flow regime is generally characterized by  $Ra < 10^8$ , while turbulent buoyant flow is characterized by  $Ra > 10^{10}$ .

For calculations involving buoyancy, the gravity vector components in  $x$ ,  $y$  and  $z$  must be set. These are interpreted in the coordinate frame for the domain. For information on setting the gravity vector components for a rotating domain, see [Buoyancy In Rotating Domains](#) (p. 14).

Buoyancy effects can be simulated using one of two available models in CFX:

- [Full Buoyancy Model \(Density Difference\)](#) (p. 13)
- [Boussinesq Model](#) (p. 13)

### 1.2.9.1. Full Buoyancy Model (Density Difference)

For single phase flows, this model is used when the fluid density is a function of temperature or pressure (which includes all ideal gases and real fluids) and when a multicomponent fluid is used. For Eulerian multiphase or particle tracking, it is also set even if all phases have constant density. Significant density variations with temperature occur for most gases. You should specify a **Buoyancy Reference Density** as an approximate average value of the expected domain density. For multiphase simulations, other factors must be considered. For details, see [Buoyancy in Multiphase Flow](#) (p. 197).

An explanation of the mathematical treatment of the **Full Buoyancy** model is available in [Full Buoyancy Model in the CFX-Solver Theory Guide](#).

### 1.2.9.2. Boussinesq Model

For many applications involving buoyancy, it is sufficient to assume a constant fluid density when the change in density over the expected range of conditions is relatively small. This is often true for many

liquids. When the fluid density is not a function of pressure or temperature, the Boussinesq model is employed.

The Boussinesq model uses a constant density fluid model, but applies a local gravitational body force throughout the fluid that is a linear function of fluid thermal expansivity,  $\beta$ , and the local temperature difference with reference to a datum called the **Buoyancy Reference Temperature**. You should specify the reference temperature as an approximate average value of the expected domain temperature.

The Boussinesq model is used by default for single-phase, single component simulations with heat transfer, using a constant density **General Fluid**. It may also be used for a constant density fluid in an Eulerian or particle tracking multiphase flow with heat transfer in conjunction with the full **Buoyancy Model**. For details, see *Buoyancy in Multiphase Flow* (p. 197).

An explanation of the mathematical treatment of the Boussinesq approximation is available in [Boussinesq Model in the CFX-Solver Theory Guide](#).

### 1.2.9.3. Buoyancy and Pressure

When buoyancy is activated, the pressure calculated by the solver excludes the hydrostatic pressure gradient. This modified pressure is often called motion pressure because it is responsible for driving the flow. All initial conditions and boundary conditions are interpreted in terms of this modified pressure. For details, see [Buoyancy in the CFX-Solver Theory Guide](#).

In some situations, the true pressure is required to calculate fluid properties. For example, if the fluid is compressible, the density depends on the true pressure rather than the motion pressure. In addition, it is often useful to visualize the true pressure. For these reasons, the solver automatically includes the hydrostatic contribution in the variable called `Absolute Pressure`. The relationship between absolute pressure and the pressure calculated by the solver is available in [Buoyancy in the CFX-Solver Theory Guide](#). When fluid properties are functions of pressure, the absolute pressure is automatically used to evaluate them. Absolute pressure is also written to the results file.

The calculation of absolute pressure requires a buoyancy reference location to be defined. By default, the solver chooses this to be the centroid of one of the pressure-specified boundaries, or if there are no pressure-specified boundaries, the pressure reference location. The pressure reference location is specified under **Pressure Level Information** on the **Solver Control** dialog box in CFX-Pre. For details, see [Advanced Options Tab](#). You can optionally specify the buoyancy reference location directly by providing Cartesian coordinates in the domain buoyancy settings.

### 1.2.9.4. Buoyancy In Rotating Domains

For steady-state rotating domain simulations involving buoyancy, the gravity vector must be aligned with the axis of rotation.

For transient rotating domain simulations involving buoyancy, if the gravity vector is not aligned with the vector of rotation, the solver automatically counter-rotates the relative frame gravity vector such that it has the specified value in the stationary domain.

## 1.2.10. Immersed Solids

The Immersed Solids capability of ANSYS CFX enables you to model steady state or transient simulations involving rigid solid objects that can move through fluid domains. The model involves the use of an immersed solid domain that is placed inside a fluid domain. As a simulation proceeds, CFX-Solver applies

a source of momentum to the fluid inside the immersed solid domain in order to force the flow to move with the solid.

In a parallel run, all partitions hold a copy of the entire mesh of the immersed solid domain. This facilitates the parallelization of the intersection process and eliminates unnecessary communications.

Steps to create an immersed solid:

1. Define an immersed solid domain to represent the solid. For details, see [Domain Type in the CFX-Pre User's Guide](#).

This domain should be entirely or partly within a fluid domain. Care must be taken to ensure that the immersed solid domain does not cross any fluid boundaries or collide with any solid domains or immersed solid domains. An immersed solid domain should not cross any GGI interface that involves a non-stationary domain. Do *not* create a domain interface between the immersed solid domain and the fluid domain.

2. Specify the **Domain Motion** settings for the immersed solid domain in order to prescribe the motion of the immersed solid. For details, see [Domain Motion in the CFX-Pre User's Guide](#).

The immersed solid is represented as a source term in the fluid equations that drives the fluid velocity to match the solid velocity. The size of the source term is controlled by the **Momentum Source Scaling Factor** setting, which can be set globally (in the global **Solver Control** settings) or for individual immersed solids (on the immersed solid domain **Solver Control** tab). The default value of 10 is acceptable most of the time. If robustness problems are encountered, the scaling factor may be decreased (for example, by a factor of 2), but at the expense of accuracy; the difference between the fluid velocity and the specified solid velocity will generally increase, even if only by a small amount.

For problems that have convergence difficulties, you can try using better initial conditions. You can obtain initial conditions by using one of the following methods:

- Run a case with **Momentum Source Scaling Factor** set to zero or a very small value (for example, less than 1.0).
- Run a stationary case and use the results to initialize a moving immersed solid case.

Once you have good initial conditions, you can improve the stability of the solution by using one of the following methods:

- Use the `inside()` function to initialize the flow field so that the flow inside the immersed solid moves with the immersed solid.
- Use a tighter convergence criterion and allow more coefficient loops per time step.

When you post-process a simulation that involves an immersed solid, the results file and any full transient results files contain a variable named "Inside [domain name]". This variable is set to 1 for mesh nodes inside the immersed solid, and 0 for mesh nodes outside the immersed solid.

Variables used for plots or calculations on immersed solid domain boundaries are not taken from the immersed solid domain; instead, they are interpolated from the fluid/porous domain in which the solid is immersed. The accuracy of such interpolation is dependent on the mesh densities of both the fluid/porous domain and the surface of the immersed solid domain. To visualize, or perform computations with, variables that are associated with the immersed solid domain, use slice planes, user surfaces, or other locators that are offset into the immersed solid domain, and set the applicable **Domains** setting to refer to the immersed solid domain.

**Note**

CFD-Post does not add viscous stresses to the evaluation of variables or expressions on immersed solid surfaces. Thus, using CFX-Solver Manager to monitor "force()@Immersed solid" (where 'Immersed solid' is the name you have given to a surface) gives a different result to calculating "force()@Immersed solid" in CFD-Post.

**1.2.10.1. Immersed Boundary Tracking**

By default, the fluid just outside an immersed boundary has no forcing terms to account for the boundary layer or other effects of the boundary on the flow. To better resolve these boundary effects, CFX-Solver can impose a modified forcing term near the immersed boundary. To activate these forcing terms, visit the **Immersed Solid Control** settings (see [Immersed Solid Control in the CFX-Pre User's Guide](#)), then set **Boundary Model** to `Modified Forcing` and set the **Boundary Tracking** settings.

In order for CFX-Solver to calculate the forcing terms, the nearest point on the immersed boundary must be identified for each near-wall node (see [Immersed Solid Boundary Details in the CFX-Solver Theory Guide](#)). This involves using one of two search algorithms. Which search algorithm is used depends on which option is selected for the **Boundary Tracking** setting: `Search Through Elements` or `Boundary Face Extrusion`.

The search algorithm that is used when the **Boundary Tracking** setting is `Boundary Face Extrusion` has the advantage of finding the wall normal direction in physical space (as opposed to computational space), but the success of this algorithm depends on the distance that the boundary face is extruded along the wall normal direction.

When using the `Search Through Elements` method, it is important to have the immersed solid mesh element lengths larger in the direction normal to the immersed boundary than the fluid mesh element lengths near the immersed boundary, so that the in-wall nodes tend to fall within the outer layer of immersed solid boundary elements. When using this option, CFX-Solver will search through elements near the immersed boundary and project the near-immersed-boundary fluid nodes onto the face edge or vertices of the immersed solid element. The weakness of this option is that the projection is done in the computational space so that, compared to the other option, the normal direction is generally less accurate.

When using the `Boundary Face Extrusion` method, it is important to have the extrusion distance larger than the fluid mesh element lengths near the immersed boundary, to ensure that the near-wall nodes fall within the bounding boxes of the imaginary volumes extruded from the immersed boundary face. When using this option, CFX-Solver will search through fluid nodes near the immersed boundary and project the near-immersed-boundary fluid nodes onto the faces or edges of the immersed boundary, with the projection being carried out in physical space. Because the projections are done in physical space, as opposed to computational space, accuracy is better than that of the `Search Through Elements` option.

**1.2.10.2. Limitations to using Immersed Solids**

The following modeling restrictions and limitations apply to simulations involving immersed solids:

- An immersed solid domain cannot undergo mesh deformation.
- An immersed solid domain cannot model heat transfer.
- When modeling an immersed solid governed by the rigid body solver, you cannot set initial conditions.

- A fluid domain that contains (or partly contains) an immersed solid domain cannot support many modeling options, including:
  - heat transfer
  - Additional Variables
  - combustion
- For transient cases, immersed solids do not interact properly with fluid domains that involve compressibility or multiphase flow.
- For steady state simulations, if the immersed solid is moving, the motion must not have any normal component.
- The solid surfaces of an immersed solid are not explicitly resolved by the mesh. In addition, a wall function cannot be applied to the boundary of an immersed solid. As a consequence, the quality of simulation results may be lower than can be obtained using mesh deformation or other techniques that support the use of wall boundaries to directly resolve solid surfaces.

In general, the mesh for the immersed solid should be sufficiently fine on the boundaries to resolve the shape of the boundary surface; the mesh inside the immersed solid may be arbitrarily coarse. The fluid mesh around the immersed solid should be fine enough to allow for effective interpolation of near-immersed-boundary fluid nodes onto the immersed solid. It is advised that you have at least 10 fluid domain elements on either side of the immersed solid boundary.

- Particles do not interact with the walls of an immersed solid domain; particles are tracked inside an immersed solid domain based on the fluid velocity, which is driven to match the velocity of the immersed solid domain.
- When an immersed solid straddles or crosses a periodic interface, it is not automatically replicated by the solver. If you expect this to happen, make additional copies of the immersed solid as necessary.
- If an immersed solid case is run in parallel, in some cases (including some rigid body cases) the path taken to convergence is sensitive to the number or placement of partitions, although the converged results are unaffected. You should ensure that a steady-state simulation, or each timestep in a transient simulation, is sufficiently well-converged to avoid differences in results between runs with different parallel run settings.
- The immersed solid `Modified Forcing` method is targeted at predicting turbulence for the standard  $k$ -epsilon ( $k - \epsilon$ ) and the Shear Stress Transport (SST) models only. While other two-equation turbulence models can be used with immersed solids, turbulence predictions may not be accurate. The `Modified Forcing` method cannot be used with turbulence models that are not two-equation models (for example, Reynolds Stress models, LES models, EARSM models, Zero Equation and Eddy Viscosity Transport Equation, and so on). Regardless of the immersed solid settings used, you should ensure that you understand the limitations of the accuracy of the immersed solids model in predicting turbulence for your particular application. This limitation also applies to using the `Modified Forcing` option with scalable wall functions for low Reynolds number cases.
- The force and torque callback functions may not be accurate. When calculating forces and torques on an immersed solid, the viscous contribution is typically underestimated. This is also the case when forces and torques are calculated on a rigid-body immersed solid. The accuracy of the force and torque information passed to the rigid body solver depends on the details on the problem set up, and is affected of the near-wall flow predictions. Also, callback results for forces and torques may differ on an immersed solid region from those on an immersed boundary because wall shear is not included when using a mesh region. Results for forces and torques calculated on immersed solids will differ between CFD-Post and those predicted by the CFX-Solver.

- For low Reynolds number turbulence cases, the immersed solids turbulence model cannot accurately predict the pressure fields near the immersed boundaries.
- CEL callbacks of force and torque on immersed boundary or region are currently not supported for rotating fluid domains.

## 1.2.11. Multicomponent Flow

CFX has the capability to model fluid mixtures consisting of an arbitrary number of separate physical components (or “species”). Each component fluid may have a distinct set of physical properties. The CFX-Solver will calculate appropriate average values of the properties for each control volume in the flow domain, for use in calculating the fluid flow. These average values will depend both on component property values and on the proportion of each component present in the control volume.

This section describes how to model multicomponent flow simulations, in addition to offering modeling advice.

### 1.2.11.1. Assumptions About Multicomponent Flow

In multicomponent flow, assume that the various components of a fluid are mixed at the molecular level, that they share the same mean velocity, pressure and temperature fields, and that mass transfer takes place by convection and diffusion. The more complex situation involving fluid interfaces, where different components are mixed on larger scales and may have separate velocity and temperature fields is called multiphase flow. This type of flow cannot be modeled with the multicomponent model. For details, see [Multiphase Flow Modeling](#) (p. 189).

It is further assumed that the diffusion velocity of a component obeys Fick’s Law.

### 1.2.11.2. Multicomponent Flow Terminology

The following terms are used in CFX multicomponent flow. Examples to illustrate the difference between fluids and components are shown in the next section. For details, see [Multicomponent Flow Examples](#) (p. 19).

#### 1.2.11.2.1. Pure Substance

A pure substance is a material with specified physical properties, such as density and viscosity. These properties may be numeric constants, or the CFX Expression Language (CEL) may be used to specify non-constant properties.

#### 1.2.11.2.2. Component

A component is one part of a multicomponent fluid. When a pure substance is used as part of a multicomponent fluid it is referred to as a component of that fluid. A fixed composition mixture could also be treated as a component of another fluid. The properties of a component are calculated from the mass fractions of the constituent materials and are based on the materials forming an ideal mixture below. For details, see [Ideal Mixture](#) (p. 19).

#### 1.2.11.2.3. Multicomponent Fluid

A multicomponent fluid contains two or more components and its properties are calculated from those of the constituent components. The components are assumed to be mixed at the molecular level and the properties of the fluid are dependent on the proportion of its components.

The components can exist in fixed mass fractions (**Fixed Composition Mixture**) or in variable mass fractions (**Variable Composition Mixture**). For **Variable Composition Mixtures**, the proportions of each component present may vary in space or time. This may be caused by the conversion of one component to another through a chemical reaction, such as combustion, driven by diffusion or caused by specifying different proportions at different boundaries or in the initial conditions.

In the solution to a multicomponent simulation, a single velocity field is calculated for each multicomponent fluid and written to the results file. Individual components move at the velocity of the fluid of which they are part, with a drift velocity superimposed, arising from diffusion.

The properties of multicomponent fluids are calculated on the assumption that the constituent components form an ideal mixture below. For details, see *Ideal Mixture* (p. 19).

#### 1.2.11.2.4. Fluid

A fluid is a general reference to any pure substance or multicomponent fluid.

#### 1.2.11.2.5. Additional Variable

Additional Variables are non-reacting, scalar components that are transported through the flow. Additional Variables can be used to model the transport of a passive material in the fluid flow, such as smoke in air and dye in water, or to model other scalar variables, such as electric field. The presence of an Additional Variable does not affect the fluid flow by default, although some fluid properties may be defined to depend upon an Additional Variable by means of the CFX Expression Language. Additional Variables may be carried by, as well as diffuse through, the fluid; they are typically specified as concentrations.

#### 1.2.11.2.6. Ideal Mixture

An ideal mixture is a mixture of components such that the properties of the mixture can be calculated directly from the properties of the components and their proportions in the mixture.

#### 1.2.11.2.7. Transport Equation

If the flow of a component is modeled using a transport equation, then it is transported with the fluid and may diffuse through the fluid, and its mass fraction is calculated accordingly.

#### 1.2.11.2.8. Constraint Equation

If the flow of a component is modeled using a constraint equation, its mass fraction is calculated to ensure that all the component mass fractions sum to unity, that is, the mass fraction of the component is set equal to the total mass fractions of the other components in the same fluid subtracted from unity.

#### 1.2.11.2.9. Algebraic Equation

If a component is modeled using an algebraic equation, then its mass fraction is calculated from an expression that you can specify using the CFX Expression Language (CEL).


### 1.2.11.3. Multicomponent Flow Examples

#### 1.2.11.3.1. Example 1: Multicomponent Multiphase

All pure substances and multicomponent fluids are specified in the **Materials** details view. This can be accessed from the **Materials** workspace in CFX-Pre. A description of the use of the **Materials** details

view is available in [Material Details View: Pure Substance in the CFX-Pre User's Guide](#). In this section, the relation between fluids and components is discussed.

The following example shows a CFD simulation of a tank that contains two fluids, `Water` and `Atmosphere`. `Water` is a pure substance (single-component fluid) while `Atmosphere` is a **Variable Composition Mixture** containing `Air` and `Pollutant`. `Pollutant` is a **Pure Substance** while `Air` is a **Fixed Composition Mixture** made from other pure substances.



You cannot nest **Fixed and Variable Composition Mixtures** further than as shown in this example (for example, **Fixed Composition Mixtures** cannot be made from other **Fixed Composition Mixtures**).

Because there is more than one fluid, this is a multiphase simulation (regardless of whether or not the fluids have the same phase). For details, see [Multiphase Flow Modeling \(p. 189\)](#).

### 1.2.11.3.2. Example 2: Smoke in Air

This example illustrates the relationship between components, fluids, and Additional Variables.

Smoke in `Air` can be considered in a number of different ways:

- The flow can be considered to be that of a single fluid, `Air`. The smoke is modeled as an Additional Variable using a transport equation. For details, see:
  - [Additional Variable \(p. 19\)](#)
  - [Transport Equation \(p. 19\)](#).
- Using this model, it is assumed that the presence of the smoke does not affect the air flow. It is, therefore, most suitable for small concentrations of small smoke particles.
- The flow can be considered to be a multicomponent fluid, consisting of two components: `Smoke` and `Air`. Using this model, the presence of `Smoke` will affect the flow of the fluid through the fluid properties. However, the smoke and air are assumed to have a common velocity. This model could be used for larger concentrations of small smoke particles.
- The flow can be considered to be that of a single fluid, `Air`, with the smoke particles modeled using particle tracking.

### 1.2.11.4. Component Domain Settings

Component mass fractions can be calculated by the CFX-Solver using a **Transport Equation**, an **Algebraic Equation** and the **Constraint** condition. Additionally, they can be based on a flamelet library or they can use the algebraic slip model. For details, see:

- [Flamelet Libraries in the CFX-Solver Theory Guide](#)
- [Algebraic Slip Model \(ASM\) \(p. 235\)](#).

If an **Algebraic Equation** is used, you should enter a CEL expression that evaluates to values between 0 and 1 throughout the domain. This describes the mass fraction of the component. When more than one component uses an **Algebraic Equation**, the sum of the mass fractions at any location must be less than or equal to 1.

If the **Transport Equation** option is used, CFX solves for the transport and diffusion of the component. At least one component must be solved for using a transport equation.

The mass fractions of the components must always add up to 1. This is enforced by specifying one component as the constrained component. The mass fraction of this component is always the difference between 1 and the sum of the mass fractions of all other components. Exactly one component must use **Constraint** as the option. This results in the following restrictions:

- When only two components exist, one component must use the **Transport Equation** option and one must use the **Constraint** option.
- When more than two components exist, one component must use the **Transport Equation** option, one must use the **Constraint** option and the remaining components can use either the **Transport Equation** option or the **Algebraic Equation** option.

An **Automatic** option is also available; this will set the option to either **Transport Equation** or **Library**. If the combustion model is:

- None
- Eddy Dissipation
- Finite Rate Chemistry
- Finite Rate Chemistry and Eddy Dissipation

then **Automatic** will translate into **Transport Equation**. If the combustion model is:

- Laminar Flamelet with PDF
- Partially Premixed and Laminar Flamelet with PDF

then **Automatic** will translate into **Library**. For details, see [Flamelet Libraries in the CFX-Solver Theory Guide](#).

The **Automatic** option will not set any component as the **Constraint** component, so you must change at least one component from **Automatic** to **Constraint** in CFX-Pre.

#### 1.2.11.4.1. Algebraic Slip

The **Algebraic Slip** model is a multiphase model. For details, see [Algebraic Slip Model \(ASM\) \(p. 235\)](#).

### 1.2.11.4.2. Kinematic Diffusivity and Bulk Viscosity

If a **Transport Equation** is being solved, you can enter a value for the **Kinematic Diffusivity**. If a value is not set, then the **Bulk Viscosity** is used, that is, the molecular diffusion coefficient of the fluid is applied to all components. Turbulent diffusivity is not affected by this setting. A bulk fluid viscosity is a weighted average of the component viscosities based on the local mass fractions. If you would like to set the dynamic diffusivity, simply set the kinematic diffusivity as an expression equal to the desired dynamic diffusivity divided by the density.

### 1.2.11.4.3. Turbulent Flux Closure

If the component model is set to either transport equation or to Algebraic Slip, then you may optionally enable the specification of the **Turbulent Flux Closure**. When the specification is not enabled, the default is to apply the same settings as for the energy equation, see [Heat Transfer \(p. 9\)](#)

The **Turbulent Flux Closure** option can be used for specification of component-dependent turbulent Schmidt numbers, which may be non-constant using expressions (CEL).

### 1.2.11.5. Boundary Conditions

The implementation of boundary conditions for multicomponent flow is very similar to that for single-component flow.

- [Boundary Condition Modeling \(p. 57\)](#)  
(Physical description)
- [Boundary Conditions in the CFX-Solver Theory Guide](#)  
(Mathematical models)

However, you need to specify mass fractions of components on inlet and opening type boundary conditions.

### 1.2.11.6. Multicomponent Energy Diffusion

This option is used to control the numerical treatment for the energy diffusion term for multicomponent fluids. There are two modes: The generic formulation and the unity Lewis number formulation, which are valid only under certain conditions. For details, see [Multicomponent Energy Diffusion in the CFX-Solver Theory Guide](#). The less general mode can significantly reduce the numerical cost for assembly of the energy equation, in particular when the fluid has a large number of components.

Three options are available:

- `Automatic`  
forces the solver to use the numerically efficient unity Lewis number assembly when physically valid, and use the generic assembly otherwise; this is the default.
- `Generic Assembly`  
forces the solver to use the general enthalpy diffusion term; the default molecular diffusivity for mass fractions is equal to the fluid viscosity (unity Schmidt number,  $Sc = 1$ ). Use this option to revert to the behavior of CFX release 5.7.1 or previous.
- `Unity Lewis Number`

forces the solver to use the unity Lewis number formulation; the default molecular diffusivity for mass fractions is thermal conductivity divided by heat capacity (unity Lewis number,  $Le = 1$ ).

- `Generic Molecular and Unity Turbulent`

forces the solver to use the general formulation for molecular transport and the unity Lewis number formulation for turbulent transport; the default molecular diffusivity for mass fractions is equal to the fluid viscosity (unity Schmidt number,  $Sc = 1$ ). Use this option to revert to the behavior of CFX release 5.7.1 or previous.

- `Unity Molecular and Generic Turbulent`

forces the solver to use the unity Lewis number formulation for molecular transport and the general formulation for turbulent transport; the default molecular diffusivity for mass fractions is thermal conductivity divided by heat capacity (unity Lewis number,  $Le = 1$ ).

---

## Note

Forcing `Unity Lewis Number` mode when not appropriate may lead to inconsistent energy transport. For example, this option should not be used in combination with user-specified component diffusivities. Therefore, using the `Unity Lewis Number` option is not recommended.

For multicomponent fluids, the effective assembly options for molecular and turbulent energy transport, respectively, are reported to the CFX-Solver Output file in the section *Multi-Component Specific Enthalpy Diffusion*. For details, see [Multicomponent Specific Enthalpy Diffusion \(MCF\) in the CFX-Solver Manager User's Guide](#).

For single-component fluids or for isothermal flow the option has no effect. In the latter case the fluid viscosity is applied as the default molecular diffusivity for components.

## 1.2.12. Additional Variables

Additional Variables are non-reacting, scalar components that are transported through the flow, or through a solid (including the solid portion of a porous domain). They can be used to model, for example, the distribution of dye through a liquid, or smoke from a fire. ANSYS CFX typically interprets Additional Variables as concentrations within the fluid domain.

Additional Variables can be set up as either algebraic equations, Poisson equations, or transport equations. For algebraic Additional Variables, you must provide an expression for its value throughout the domain.

Mathematical information on the Additional Variable transport equation is available in [Transport Equations for Additional Variables in the CFX-Solver Theory Guide](#) and [Additional Variable Transfer Through the Fluid and Solid in the CFX-Solver Theory Guide](#).

### 1.2.12.1. Kinematic Diffusivity

For most applications, the transport of Additional Variables is both a convective and diffusive process (including both laminar and turbulent diffusion), and you will therefore need to specify the molecular kinematic diffusivity for each Additional Variable you use. This describes how rapidly the scalar quantity would move through the fluid in the absence of convection. It is generally a function of the properties of the fluid and the medium that the Additional Variable represents, and consequently has no default value. It is usually small (of the order  $10^{-5}$  m<sup>2</sup>/s for smoke in air).

For convection-dominated flows, the kinematic diffusivity can have little effect because convection processes dominate over diffusion processes. You may want to specify an Additional Variable whose transport through the fluid is a purely convective process. You can neglect diffusion effects by not setting a kinematic diffusivity for an Additional Variable when you include it in your domain. For turbulent flows, the turbulent diffusion (which is a consequence of averaging the advection term) is still included even when you do not set the kinematic diffusivity.

Poisson equations are diffusive and therefore the kinematic diffusivity must be specified for a successful run.

---

### Note

Diffusivity of an Additional Variable can depend on what fluid it is diffusing through. It is not possible to have density or specific heat dependent on Additional Variables. A more logical approach is to use a multicomponent fluid. For details, see *Multicomponent Flow* (p. 18).

### 1.2.12.2. Turbulent Flux Closure

The **Turbulent Flux Closure** may be optionally enabled for specification for Additional Variables that are set up as a transport equation. The default when not enabled for specification is the **Eddy Diffusivity** model with the turbulent Schmidt number set to a value of 0.9. The turbulent Schmidt number may be non-constant using expressions (CEL).

### 1.2.12.3. Volumetric and Specific Additional Variable

Volumetric and specific Additional Variables are distinguished only by a factor of material density in that the volumetric form of an Additional Variable can be obtained from the specific form by multiplying the specific Additional Variable value by density. The CFX-Solver always directly solves for the variable using the specific form, and then calculates the volumetric values at the end of the run for post processing.

A volumetric Additional Variable is specified in terms of the amount of the Additional Variable per unit volume of fluid.

$$\Phi = \frac{\text{conserved quantity}}{\text{volume of fluid}} \quad (1-6)$$

The conserved quantity often has units of mass, in which case  $\Phi$  is called mass concentration and you should set units that have dimensions of Mass / Length<sup>3</sup> (for example, kg quantity / m<sup>3</sup> fluid).

A specific Additional Variable is specified in terms of the amount of the Additional Variable per unit mass of fluid.

$$\Phi = \frac{\text{conserved quantity}}{\text{mass of fluid}} \quad (1-7)$$

Like the volumetric form, in most cases the conserved quantity will have units of mass, in which case  $\Phi$  is called mass fraction and you should set units that have dimensions of Mass / Mass (for example, kg quantity / kg fluid).

In addition, the units for boundary condition and source specifications must be consistent with the Additional Variable units:

- Additional Variable value: Units of  $\Phi$ .
- Flux boundary condition: Units of conserved quantity per unit area per unit time.
- Source value: Units of conserved quantity per unit volume per unit time.
- Source coefficient: Units of Source value per unit  $\Phi$ .

CFX-Pre will automatically make the appropriate units available when you set one of these quantities. If you use an expression and provide incorrect units, CFX-Pre will not let you set the quantity.

At the end of the solver run, the Additional Variable will be made available in the results file in both volumetric and specific form for post-processing purposes.

### 1.2.12.4. Additional Variables In Units Other Than Mass

The units of Additional Variables are more flexible than the two examples given in the previous section. In general, any units are acceptable for an Additional Variable. In this case, you just enter whatever units you like for the variable, and, if desired, also enter the appropriate diffusivity with dimensions of Length<sup>2</sup> / Time.

For example, to solve an Additional Variable equation for temperature ( $T$ ), with units of Kelvin [K], you could create a specific Additional Variable with units of [K], and the CFX-Solver will solve the following transport equation:

$$\frac{\partial (\rho T)}{\partial t} + \nabla \cdot (\rho \mathbf{U} T) = \nabla \cdot \left( \left( \rho \alpha + \frac{\mu_t}{Sc_t} \right) \nabla T \right) + S_T \quad (1-8)$$

where  $\alpha$  is the thermal diffusivity (that is,  $\alpha = k/r c_p$ ),  $\rho$  is the fluid density,  $\mu_t$  is the turbulent eddy viscosity and  $Sc_t$  is the turbulent Schmidt number. In this case, the solver writes two fields that can be viewed in CFD-Post: the specific form of the variable (temperature) with units of [K], and the volumetric form (which is simply the specific form multiplied by fluid density) with units of [K kg m<sup>-3</sup>].

### 1.2.12.5. Unspecified Additional Variables

Unspecified Additional Variables can be used when you want to calculate the value of a quantity using an algebraic expression. This type of variable can have any units you like and, if an expression is assigned to this variable, then the expression result must have the same units as the variable.

For example, you could create an Additional Variable for a pressure coefficient by creating an unspecified Additional Variable with dimensionless units and assigning it to an expression:

$$\Phi = \frac{p_{\text{abs}} - p_{\text{ref}}}{\frac{1}{2} \rho |\mathbf{V}|^2} \quad (1-9)$$

where  $p_{\text{abs}}$  is absolute pressure  $p_{\text{ref}}$  is the domain reference pressure or some other reference pressure state,  $\rho$  is the fluid density and  $\mathbf{V}$  is the fluid velocity.

### 1.2.12.6. Tensor Type

The Additional Variable's **Tensor Type** can be set to `Scalar` or `Vector`. If an Additional Variable is defined as type `Vector`, the components of a vector algebraic equation can be defined at the domain level.

Vector Additional Variables cannot be directly referenced in CEL expressions. The syntax for referencing a component of a vector Additional Variable is as follows:

```
<Component Name>.<Additional Variable Name>_x
```

### 1.2.13. Non-Newtonian Flow

Some fluids are non-Newtonian; that is, they do not obey the simple linear relationship between shear stress and shear strain rate. Many practical fluids fall into this class, and their behavior is generally well understood and described using various mathematical models.

ANSYS CFX has several models for calculating viscosity based on shear strain rate. These models are listed in [Table 1.2: Non-Newtonian Models \(p. 26\)](#) where  $\mu$  is the dynamic viscosity, and  $\dot{\gamma}$  is the shear strain rate.

**Table 1.2 Non-Newtonian Models**

Model	Description	Settings
Bingham	<p>This is a model for viscoplastic fluids.</p> $\mu = \frac{\tau_Y}{\dot{\gamma}} + K$ <p>Examples of viscoplastic fluids include tomato paste and tooth paste. A few electro-rheological fluids can be modeled as Bingham fluids with the yield stress as a function of the intensity of the electric field, or the electric current.</p> <p>Note that ANSYS CFX supports only a single-valued yield stress. The yield stress may be evaluated as a CEL expression with, for instance, values that vary over time or iteration. Yield stress values that vary spatially are not supported.</p>	Yield Stress:
		$\tau_Y$
		Viscosity Consistency:
		$K$
		Minimum Shear Strain Rate
		Maximum Shear Strain Rate

Model	Description	Settings
Bird Carr- eau	<p>This is a model intended for shear-thinning fluids.</p> $\mu = \mu_{\infty} + \frac{(\mu_0 - \mu_{\infty})}{(1 + (\lambda \dot{\gamma})^2)^{\frac{1-n}{2}}}$ <p>The model reverts to a Newtonian behavior of <math>\mu = \mu_0</math> for <math>n = 1</math>, or <math>\lambda = 0</math>.</p> <p>Examples of shear-thinning fluids include applesauce, banana purée, and orange juice concentrate.</p>	Low Shear Viscosity: $\mu_0$
		High Shear Viscosity: $\mu_{\infty}$
		Time Constant: $\lambda$
		Power Law Index: $n$
Carr- eau Yas- uda	<p>This is a generalization of Carr-eau's original model.</p> $\mu = \mu_{\infty} + \frac{(\mu_0 - \mu_{\infty})}{(1 + (\lambda \dot{\gamma})^a)^{\frac{1-n}{a}}}$	Low Shear Viscosity: $\mu_0$
		High Shear Viscosity: $\mu_{\infty}$
		Time Constant: $\lambda$
		Power Law Index: $n$
		Yasuda Exponent: $a$
Casson	<p>This model is a variation of the Bingham model for viscoplastic fluids with a square root/quadratic dependency.</p> $\sqrt{\mu} = \sqrt{\frac{\tau_Y}{\dot{\gamma}}} + \sqrt{K}$	Yield Stress: $\tau_Y$
		Viscosity Consistency: $K$
		Minimum Shear Strain Rate
		Maximum Shear Strain Rate

Model	Description	Settings
Cross	This is a model intended for shear-thinning fluids.  $\mu = \frac{\mu_0}{1 + (\lambda \dot{\gamma})^n}$	Low Shear Viscosity:  $\mu_0$
		Time Constant:  $\lambda$
		Power Law Index:  $n$
Herschel Bulkley	This is a model for viscoplastic fluids that, after yield, exhibits a power law behavior in shear stress versus shear strain rate.  $\mu = \frac{\tau_Y}{(\lambda \dot{\gamma})} + K (\lambda \dot{\gamma})^{n-1}$	Yield Stress:  $\tau_Y$
		Viscosity Consistency:  $K$
		Minimum Shear Strain Rate
		Maximum Shear Strain Rate
		Time Constant:  $\lambda$
		Power Law Index:  $n$
Ostwald de Waele	This is perhaps the most popular viscosity model because of its simplicity. However, it does not have bounded behavior either on the low or high shear limits, unlike Carreau's models.  $\mu = K (\lambda \dot{\gamma})^{n-1}$	Viscosity Consistency:  $K$
		Minimum Shear Strain Rate
		Maximum Shear Strain Rate
		Time Constant:  $\lambda$
		Power Law Index:  $n$

At the start of a steady-state calculation of non-Newtonian flow, the CFX-Solver may take several time steps to 'get going.' This is probably due to excessively high fluid viscosities resulting from small or zero initial velocities. In such cases, you can promote faster convergence by specifying a sensible initial velocity field.

---

## Note

If you want to model a non-Newtonian fluid without using any of the available models, you can specify a viscosity by value and use an expression. Note that shear strain rate is available as a CFX system variable. When developing your expression, you should consider non-physical shear strain rates and the possibility of divide-by-zero errors. One way of doing this is to use the available built-in functions `min` and `max` to bound the values of shear strain rate.

## 1.2.14. Coordinate Frames

### 1.2.14.1. Global Coordinate Frame (Coord 0)

In addition to being the default coordinate frame in CFX-Pre, the CFX-Solver always computes solutions in the global Cartesian coordinate frame, `Coord 0`. This coordinate frame's origin is located at  $[0\ 0\ 0]$  and has the Cartesian basis vectors  $\langle 1\ 0\ 0 \rangle$ ,  $\langle 0\ 1\ 0 \rangle$  and  $\langle 0\ 0\ 1 \rangle$ . Unless specified otherwise all material properties, boundary conditions, source terms and initial conditions are calculated in the global coordinate frame.

If you are using CEL expressions, the built-in variables `xGlobal`, `yGlobal`, and `zGlobal` can be used to refer to the three coordinate indexes of the global coordinate frame.

### 1.2.14.2. Local Coordinate Frames

In some cases, it may be useful to specify quantities using coordinates from a coordinate frame other than the global coordinate frame `Coord 0`. This is done by creating a local coordinate frame and applying it to a particular location (such as a boundary condition, initial condition, subdomain, domain) or other object that supports local coordinate frames (for example, a monitor point). For details on creating local coordinate frames in CFX-Pre, see [Coordinate Frames in the CFX-Pre User's Guide](#).

---

## Note

- A variable, CEL expression, or profile data that is used in the specification of some quantity is evaluated with  $x$ ,  $y$ ,  $z$  treated as being local, and all other non-scalar variables (such as  $u$ ,  $v$ ,  $w$ ) treated as being global. Non-scalar CEL functions (such as `torque`, `force`) are treated as being local. The quantity that was specified by the variable or CEL expression, once evaluated, will be treated as being local, if applicable (that is, if it is a vector or tensor quantity, or component thereof).
- If a domain uses a local coordinate frame other than the global coordinate frame, locations within that domain, such as subdomains and boundary conditions, do not necessarily use the same coordinate frame, because each location has its own independent coordinate frame specification.

Local coordinate frames are particularly useful for setting quantities that are not aligned with the global coordinate system, such as:

- Cartesian velocity components for initial or boundary conditions
- Cartesian flow directions for boundary conditions
- Cartesian momentum source components
- Spatially varying scalar boundary conditions

- Spatially varying properties

---

### Note

Cylindrical velocity components and flow directions use either a local axial coordinate direction specification or the domain rotation axis for RFR domains, as applicable. The axis specification is made using Cartesian coordinates that are interpreted in the local coordinate frame.

A local coordinate frame can have rotational frame motion applied (see [Frame Motion Settings in the CFX-Pre User's Guide](#)). A boundary condition can use such a coordinate frame to cause the *location of application* of profile data (or CEL expressions) to move in accordance with the coordinate frame motion.


### 1.2.14.3. Cartesian Coordinate Frames

Cartesian vector, vector component, and tensor quantities can be associated with any local Cartesian coordinate frame in which they are meant to be interpreted by the solver.

### 1.2.15. Rotating Frames of Reference (RFR)

**Rotating Frames of Reference (RFR)** are useful for rotating fluid machinery applications, such as pump impeller or turbine blade problems. CFX-Pre enables you to specify a domain that is rotating about an axis. When you specify a **Rotating Frame of Reference**, you must also specify the angular velocity,  $\omega$ , which can be a function of the built in CEL variable time ( $\tau$ ) in a transient simulation. To determine the direction of the rotation, use the right-hand rule.

**Figure 1.1** Direction of Rotation



When a domain with a rotating frame is specified, the CFX-Solver computes the appropriate Coriolis and centrifugal momentum terms, and solves a rotating frame total energy equation. Additional mathematical information is available in [Rotational Forces in the CFX-Solver Theory Guide](#).

You can create simulations with multiple reference frames. For details, see [Domain Interface Modeling](#) (p. 157).

### 1.2.15.1. Alternate Rotation Model

The alternate rotation model is a model for the advection term in the momentum equations. Instead of advecting the relative frame velocity, the flow solver advects the absolute frame velocity.

The main advantage of this model comes into play when the absolute frame velocity is a constant, but the relative frame velocity has a high swirl component. In this case, advecting the relative frame velocity has a high component of error, while advecting a constant absolute frame velocity will have much less error. If the relative and absolute frame velocities are both changing equally, for example, inside a blade passage on a rotating machine, then the alternate rotation model has a similar level of numerical error compared to the default advection model.

The alternate rotation model makes a significant reduction in numerical error when the absolute frame flow is essentially a constant flow parallel to the axis of rotation. For example, the approach flow to a fan or propeller is nearly constant in the absolute frame, but highly rotating flow in the relative frame. At very large radii, small errors in the advection model of the relative frame flow become large errors in the computed flow in the absolute frame. When the alternate rotation model is used in this situation, the numerical error is greatly reduced, because the absolute frame velocity is close to constant. In fact, the numerical error in the advection model reduces to zero as the absolute frame flow becomes axially constant, independent of the radial location and rotation rate.

Conversely, the model can increase errors when, for example, the exit stream is highly swirling. Errors are magnified as the length of the inlet or outlet regions is increased. The choice of whether to apply the model therefore depends on the nature of the inlet and outlet flow conditions, and the length of the inlet and outlet regions.

It has been found that in most realistic flow situations, the model reduces numerical error (or at least does not increase numerical error). The one exception is solid body rotation, where the relative frame flow is constant ( $V=0$ ) and the absolute frame flow is nonzero and varying with radius.

For more details, see [Alternate Rotation Model in the CFX-Solver Theory Guide](#).

## 1.3. Sources

Sources are optional terms that you may attach to most equations in order to model additional or specialized physical processes. They can be specified on subdomains, points, and boundaries as described in the following sections.

This section describes:

[1.3.1. Locators for Sources](#)

[1.3.2. Types of Sources](#)

[1.3.3. Multiplying Sources by Porosity](#)

The standard governing equations on these locators are modified to include user-defined source terms. For details, see [Sources in the CFX-Solver Theory Guide](#).

### 1.3.1. Locators for Sources

#### 1.3.1.1. Subdomains

Subdomains are regions of space in a domain in which volumetric sources of mass, momentum, energy, turbulence, Additional Variables, mass fractions and radiation can be specified. They can also be used to model flow resistance. Many subdomains can be created in each domain.

Subdomain regions are defined in the same way as domains, which is from 3D primitives. A 3D primitive used for a subdomain must also be contained in the parent domain. For details, see [Mesh Topology in CFX-Pre in the CFX-Pre User's Guide](#).

Sources on subdomains may be specified as either volumetric quantities (source per unit volume) or as the total source. If a total source is specified, the solver assumes a uniform source density over the subdomain in order to obtain the volumetric quantity.

The total source option is not supported for momentum sources.

### **1.3.1.2. Boundary Sources**

Boundary sources permit the specification of sources as fluxes (source per unit area) on boundary condition surfaces. This applies to all equations, including continuity.

Total sources are also available on boundaries, for which the solver assumes a uniform source density in order to obtain the flux-based quantity.

Momentum sources are not currently available on boundaries.

### **1.3.1.3. Point Sources**

Sources can also be specified at a point. The specified source is distributed among the vertices of the element in which the point is located. The effect of the source will therefore become more pronounced as the mesh is refined.

Momentum sources are not currently available at points.

## **1.3.2. Types of Sources**

### **1.3.2.1. General Sources**

A general source is a source term that is simply added to a general scalar equation. This includes the **Energy**, **Additional Variable**, **Turbulence** and **Mass Fraction** equations.

There is no restriction as to what the source term may depend on, although additional convergence control may be necessary for strongly-varying terms.

Sources for a particular component in a multicomponent fluid do not introduce any additional mass and so the sum of all component sources (including the constraint) must be zero. Note that sources may not be specified for the constraint component; the implied source for the constraint is equal to the negative of the sum of all specified component sources. For this reason, component sources might be useful to model single phase reactions, but multiphase reactions (in which a particular component is transferred from one phase to another) require the use of mass (continuity) sources. Further details on mass sources, and particular issues related to multicomponent fluids, are provided in [Mass \(Continuity\) Sources](#) (p. 35).

General sources can be applied on the solid part of a porous domain. Such a source can be multiplied by the solid fraction in the porous domain.

### 1.3.2.1.1. Source Coefficient / Total Source Coefficient

The converged solution depends only on the source value. For nonlinear sources, a linearization coefficient may be specified to improve convergence. This is specified by the optional **Source Coefficient** or **Total Source Coefficient**, which should be a reasonable approximation to the derivative

$$\text{Source Coefficient} = \frac{\partial S_{\varphi}}{\partial \varphi} \quad (1-10)$$

where  $S_{\varphi}$  is the source or total source term. Note that this derivative must be negative for stability purposes. If a positive value is specified, the solver will reverse the sign. Leaving the coefficient unspecified is equivalent to using a zero coefficient. For the energy equation, the derivative is taken with respect to temperature.

Although it is possible to set a coefficient when the source term is zero, it is not normally of practical use; it will change convergence rates without adding any source.

### 1.3.2.2. Momentum Sources

CFX supports three types of momentum sources:

- isotropic loss model
- directional loss model
- general momentum sources

The theory for these momentum source types is given in [Momentum Sources in the CFX-Solver Theory Guide](#). This section gives some additional practical tips on how to use the sources.

#### 1.3.2.2.1. Isotropic and Directional Loss Models

Isotropic and directional loss models are useful for modeling porous momentum losses either with or without the volume effect of porosity. The loss model formulations are the same in both cases, but are set up in different locations in the user interface. If the volume effect of porosity is included, you need to create a porous domain and set the loss model details on the domain details view. If it is not included, the momentum loss model is set on a subdomain. For details on how the volume effect of porosity modifies the governing equations, see [Domain Type in the CFX-Pre User's Guide](#). Note also that loss coefficients may be derived from experimental or analytical data using either true or superficial velocity. When applying a loss model, you must be aware of which velocity was used to derive the loss coefficients.

- When applying a loss model on a subdomain of a fluid domain, the solver assumes the coefficients multiply the superficial velocity, so if the coefficients were derived using true velocity, you will need to adjust the coefficients accordingly. The permeability must be multiplied by the porosity, and the loss coefficient must be divided by the porosity squared.
- When applying a loss model on a porous domain, you may choose whether the coefficients multiply the true or superficial velocity.

For many applications, a certain resistance loss is desired in a specified direction, with flow inhibited in the transverse directions. This is the case when you want to model the effect of flow straightening devices such as honeycombs, porous plates, and turning vanes without modeling the details of the flow around the obstacles. For situations like this, CFX enables the independent specification of loss for the streamwise and transverse directions.

For both the streamwise and transverse directions, both types of the loss formulations available for the isotropic loss model are available. In many cases, however, the loss coefficients are known only for the streamwise direction, and you know only that the flow is inhibited in the transverse direction. When this occurs, you may select the **Streamwise Coefficient Multiplier** for the transverse loss model. In this case, the transverse coefficients are taken to be the specified factor times the streamwise coefficients. (If the streamwise loss includes a permeability, the implied transverse permeability is divided, not multiplied, by this factor). The transverse multiplier is typically taken to be about 10-100.

In some cases, you may want to inhibit only the transverse flow without having any streamwise loss. In this case, the **Zero Loss** option may be selected for the streamwise loss. Of course, if this is chosen, the **Streamwise Coefficient Multiplier** is not appropriate for the transverse loss, because it will result in zero transverse loss.

In all cases, the directional loss model requires the streamwise direction to be specified. It may be described in either Cartesian or Cylindrical coordinates.

### 1.3.2.2.2. General Momentum Source

Momentum sources can be specified directly in terms of a force per unit volume in a specified direction. To obtain good convergence when the source is a function of velocity, the source should be linearized by including a **Momentum Source Coefficient**. In CFX, scalar coefficients may be specified as representative of the tensor:

$$-\frac{\partial p}{\partial x} = K U_x \quad (1-11)$$

Typically, the scalar coefficient is chosen to be the maximum of the three principal components of this tensor.

The **General Momentum Source** option is useful for applications that are not covered by the isotropic loss model or the directional loss model. For example, the velocity in a region may be forced to be a specified value (Dirichlet velocity condition) by setting  $C$  to a large number, for example,  $10^5 \text{ kg m}^{-3} \text{ s}^{-1}$ , for the following:

$$\begin{aligned} S_x &= -C (U_x - U_{x,\text{spec}}) \\ S_y &= -C (U_y - U_{y,\text{spec}}) \\ S_z &= -C (U_z - U_{z,\text{spec}}) \end{aligned} \quad (1-12)$$

and selecting  $-C$  as the Momentum Source Coefficient.

When setting a General Momentum Source, there are two optional parameters that may be set:

- **Redistribute in Rhie Chow** indicates whether  $S$  is included in the Rhie Chow redistribution algorithm (see Equation 11-32 in *Pressure-Velocity Coupling in the CFX-Solver Theory Guide*).
- **Include Coefficient in Rhie Chow** indicates whether  $C$  is included in the Rhie Chow coefficient (see Equation 11-29 in *Pressure-Velocity Coupling in the CFX-Solver Theory Guide*).

The defaults for both of these parameters are false, but there are cases when they should be activated. For example:

- When setting a momentum source to give a specified velocity (for example, when modelling solidification, a momentum source that scales with solid mass fraction can be used to force the solid to move at the belt velocity), **Include Coefficient Rhie Chow** should be set in order to ensure that the mass flows are consistent with the specified velocity.
- When the momentum source is meant to induce a pressure change (for example, a fan model), set both parameters to true to avoid pressure wiggles near the subdomain boundary.

#### 1.3.2.2.2.1. Post-Processing the Momentum Sources

If a momentum source has been applied, a new variable [`<fluid>.`]User Momentum Source.Bforce may be available in the results file. This variable represents the sum of:

1. Any momentum sources for the fluid defined using a Loss Model (Isotropic or Directional), plus
2. Any momentum sources for the fluid defined by a General Momentum Source for which the **Redistribute in Rhie Chow** check box is selected.

Momentum sources defined by a General Momentum Source where the **Redistribute in Rhie Chow** check box is not selected (the default) are not included in this variable.

#### 1.3.2.2.3. Immersed Solids Sources

The presence of an immersed solid in the flow field is modeled through a body force similar to the general momentum source.

The velocity in a fluid region that lies inside the immersed solid is then enforced to be the same as the velocity of the immersed solid through a body source given in [Equation 1–12 \(p. 34\)](#). The momentum source coefficient is calculated automatically inside the solver by taking account of advection and diffusion contributions from the mesh elements in the fluid region that lies inside the immersed solid. You can apply a scaling factor to the solver-calculated source coefficient to control how strongly the fluid velocity is forced to match the immersed solid velocity; this affects accuracy and robustness; for details, see [Immersed Solid Control in the CFX-Pre User's Guide](#).

For fluid nodes lying outside the immersed solid domain, this body source is set to zero by multiplying it by the inside function.

When setting up the immersed solid source, the solver also sets the `Include Coefficient in Rhie Chow` parameter to `True` to ensure that the mass flows are consistent with the immersed solid velocity. Currently, the `Redistribute in Rhie Chow` parameter is not activated in the immersed solid algorithm.

#### 1.3.2.3. Mass (Continuity) Sources

A source term to the continuity equation introduces additional fluid into the simulation. The amount of fluid introduced can be specified as `Fluid Mass Source` (on subdomains), `Fluid Mass Flux` (on boundaries), or `Total Fluid Mass Source`. A fluid mass source is the mass source per unit volume; therefore, the total mass of fluid introduced will depend on the volume of the subdomain in which the source term is applied. Similarly, a fluid mass flux is the mass source per unit area. A total fluid mass source is the total mass of fluid introduced.

Continuity sources differ from other equation sources in that they induce corresponding secondary source terms in all other equations. Therefore, in addition to specifying the mass source itself, the values of velocity, temperature, and so on, must also be specified. These values are used to compute the secondary source terms only when the mass source is positive and have a function similar to boundary condition values that are specified at an opening. In particular, for mass outflow (or negative continuity source) fluid is transported out of the domain with local values of temperature, velocity, turbulence quantities, and so on, while for mass inflow (or positive continuity source), fluid is transported into the domain with specified values. Depending on the simulation, the following variables must be set for the 'inflow' (positive mass source) case:

- Additional Variables

If the parent domain includes Additional Variables that are solved using a transport equation, then you must set the level of the Additional Variable in the fluid that is introduced into the domain. Note that there is no corresponding secondary source term for equations with no advection term (such as diffusive and Poisson Additional Variables). Therefore, values for these variables need not be specified.

- Component Mass Fractions

For fluids that are **Variable Composition Mixtures**, you must set the mass fraction values for the fluid that is introduced into the domain. The **Constraint** component will take a mass fraction such that the sum of the mass fractions is unity.

- Temperature

You must set a temperature for a continuity source if heat transfer is modeled in the domain. The property recipes of the interior material will be used automatically when needed to convert temperature to enthalpy.

- Velocity

You must set **Cartesian Velocity Components** for a continuity source to describe the direction in which the new fluid is moving.

- Eddy Dissipation and Turbulence Intensity

You must set the turbulence quantities for a continuity source when the domain uses a turbulence model (that is, when `Laminar` is not specified).

You may provide expressions for the scalar variable values introduced with the mass source. An expression for a variable associated with the mass source may depend on other variables specified for the same fluid mass source, but care is required to avoid recursion.

If the continuity source is negative (a mass sink), the values you specify will be ignored by the solver, and local solution variables will be used instead (like at an outlet or the outflow portion of an opening). However, CFX-Pre still requires that you supply values for these variables. This is because it does not know (in general) whether the mass source will evaluate to a positive or negative number.

If the simulation involves multicomponent fluids or heat transfer, however, you may force the solver to use the specified values of mass fraction and temperature even if the mass source is negative. This is controlled by the **MCF/Energy Sink Option** setting on the **Sources** tab in CFX-Pre. The **MCF/Energy Sink Option** setting can be set to one of the following:

- Local Mass Fractions and Temperature - The local solution values are used for all variables.

- **Specified Mass Fractions and Local Temperature** - Specified mass fractions are used when the mass source is positive or negative. The enthalpy is evaluated using the specified mass fractions and temperature when the mass source is positive and the specified mass fractions and local temperature when the mass source is negative.
- **Specified Mass Fractions and Temperature** - Specified mass fractions are used when the mass source is positive or negative. The enthalpy is evaluated using the specified mass fractions and temperature when the mass source is positive or negative.

Additional information on theory is available in [Mass \(Continuity\) Sources in the CFX-Solver Theory Guide](#).

### 1.3.2.3.1. Mass (Continuity) Source Coefficients

Nonlinear continuity sources may need to be linearized to improve convergence behavior. For continuity sources that are dependent on pressure, convergence behavior can be improved by supplying a pressure coefficient such as **Mass Flux Pressure Coefficient**, **Total Mass Source Pressure Coefficient** or **Mass Source Pressure Coefficient** where the pressure coefficient is defined as:

$$\text{Pressure Coefficient} = \frac{\partial S_C}{\partial p} \quad (1-13)$$

For example, in the instance where the continuity source is driven by the difference between the local fluid pressure and some external pressure outside the boundary:

$$S_C = K (P_{\text{outside}} - P_{\text{fluid}}) \quad (1-14)$$

then the pressure coefficient is given by  $-K$ .

Similarly, for continuity sources that are dependent on volume fraction, convergence behavior can be improved by supplying a volume fraction coefficient such as **Mass Flux Volume Fraction Coefficient**, **Total Mass Source Volume Fraction Coefficient** or **Mass Source Volume Fraction Coefficient**, as appropriate.

### 1.3.2.4. Bulk Sources

Bulk sources are available in multiphase flows. Information on the use of bulk sources is available in [Bulk Sources](#) (p. 212).

### 1.3.2.5. Solid Sources

Solid sources are available in a porous domain when there are physics (energy, Additional Variables) associated with the solid part of the porous domain.

Selecting the **Multiply by Solid Fraction** check box causes the equation source to be scaled by the solid fraction value  $(1 - \gamma)$ . For example, if a porous domain has a volume porosity of 0.8 and the **Multiply by Solid Fraction** check box is selected, 20% of the source is applied to the solid; if the check box is not selected, then 100% of the source is applied to the solid.

### 1.3.2.6. Radiation Sources

Information on radiation sources is available in [Sources](#) (p. 348).

### 1.3.2.7. Particle User Sources

Information on particle user sources is available in [Particle User Sources](#) (p. 256).

### 1.3.3. Multiplying Sources by Porosity

Selecting the **Multiply by Porosity** check box causes the equation source to be scaled by the porosity value. For example, if a porous domain has a volume porosity of 0.8 and the **Multiply by Porosity** check box is selected, 80% of the source is applied to the fluid; if the check box is not selected, then 100% of the source is applied to the fluid.

## 1.4. Material Properties

The **Materials** details view in CFX-Pre is used to create and modify material properties for both pure substances and mixtures. Pure substances can be solids, liquids or gases. Liquids or gases can be used in fluid domains and solids can be used for either conjugate heat transfer models or particle tracking.

Information on how to set up pure substance or mixture properties in CFX-Pre is available in [Materials and Reactions in the CFX-Pre User's Guide](#).

### 1.4.1. CEL Expressions

CEL expressions can be used to set certain material properties. Note that the variable  $p$ , when used in a CEL expression to define a material property, will be interpreted as an absolute pressure (not a relative pressure). To use reference pressure in an expression, use `Pref`.

### 1.4.2. Coord Frame

A coordinate frame can optionally be used with any material. The coordinate frame is used to evaluate properties of the material that are defined using expressions that are a function of a spatial variable ( $x$ ,  $y$ ,  $z$  or  $r$ ,  $\theta$ ,  $z$ ). For details, see [Coordinate Frames](#) (p. 29) and [Coordinate Frames in the CFX-Pre User's Guide](#).

### 1.4.3. Equation of State

Equations of state can be modeled in the following ways in CFX:

- Setting **Density** directly
- Using the built in **Ideal Gas** equation
- Using the built in **Real Gas** equations
- Using the built in **IAPWS** equation
- Reading properties from a CFX-TASCflow RGP table. For details, see [Real Fluid Properties](#) (p. 361).

All properties except density and specific heat capacity, can be modeled using any valid expressions containing CFX System Variables.

### 1.4.3.1. Option

#### 1.4.3.1.1. Value

This selection gives a fair amount of flexibility in modeling the variation in density. For example, it can be used to model a variety of different fluid types:

- Constant
- Variation with temperature and pressure not available as a built-in model

Variation with temperature and pressure can be set up using analytic CEL expressions or CEL user functions. Many of the popular thermal equations of state (for example van der Waals, Peng-Robinson, Beattie-Bridgeman,...) are explicit in pressure, rather than density. So, if the built-in Redlich Kwong equation is not suitable, then you will need to either create your own RGP table, or use a CEL user function to define your equation of state. Simply pass pressure and temperature into your user CEL function and then use a root finder to come up with values of density. For details, see [Real Gas Property \(RGP\) File Format](#) (p. 378).

The constitutive relation is set by specifying specific heat at constant pressure. Again, this can be a constant or enabled to vary as a function of temperature and pressure the same as density.

Transport properties can also be specified in the same ways as density and specific heat, but can additionally depend on other CFX System Variables, not just temperature and pressure.

The special dependency of density and specific heat capacity on local pressure or temperature can be set using the **Density Dependency** and **Specific Heat Dependency** forms. For details, see [Density and Specific Heat Dependencies](#) (p. 43).

#### 1.4.3.1.2. Ideal Gas

For many situations involving compressible flow, the thermodynamic properties for real fluids can be closely approximated using the relationships for an ideal gas. The Ideal Gas model uses the Ideal Gas law to calculate the local density variation in the fluid. The density is automatically computed using the specified molecular weight. For details, see [Dynamic Viscosity](#) (p. 44).

The relationships are especially suited to compressible gas flows at low density under the following conditions:

- At low pressures ( $\sim 1$  bar), regardless of temperature.
- At high pressures ( $\gg 1$  bar), providing the temperature is also reasonably high (that is,  $> 2 \times$  critical temperature for the gas). At temperatures lower than this, together with relatively low pressures (such as atmospheric), significant deviations from the ideal gas approximations may exist.

#### 1.4.3.1.3. Real Gas

The real gas option enables you to use the Redlich Kwong [85] or Peng Robinson [157] equations of state. These are three parameter state equations that can be used to model for gas density, and additionally, liquid density with the Peng Robinson equation. Minimal input is required. You need to enter the critical temperature, pressure and volume as well as the acentric factor for the pure substance. These equations are suitable for modeling subcritical gas phases and supercritical properties. Only the Peng Robinson equation will provide reasonably accurate results for subcritical liquid phase materials.

When you select a cubic equation of state the flow solver automatically generates a table of values for density at a range of temperatures and pressures. The default range is  $T = 100 \text{ K} - 1000 \text{ K}$  and  $p = 0.01 \text{ bar} - 2 \text{ bar}$ . You can change this range by selecting the table generation option and setting minimum and maximum temperature and pressure limits to what makes sense for your model.

In order to accurately model the influence of the vapor dome, the critical volume and acentric factor are provided. This enables the CFX-Solver to calculate where the vapor pressure curve cuts through the default temperature and pressure range or the range you have supplied.

Finally, to provide a default reference temperature and pressure the flow solver also requires the Boiling Temperature of the fluid at one atmosphere.

For details on real gases, see [Real Gas Properties in the CFX-Solver Theory Guide](#).

#### 1.4.3.1.4. IAPWS Library

The IAPWS equation of state is specific for water. If your model setup requires subcooled water or superheated steam, especially with phase change, then this is the best option available.

The presupplied materials are grouped into several temperature and pressure ranges for convenience but it is possible to define new materials with your own custom temperature and pressure range.

#### 1.4.3.2. Molar Mass

For all pure substances CFX requires that you provide the **Molar Mass** (relative molecular mass). The molecular mass of an element or compound is defined as the average mass of its molecules on a scale where one atom of  $C^{12}$  (isotope of carbon) has a mass of 12 units.

For an Ideal Gas or the Redlich Kwong equation of state, it is essential to set the correct Molar Mass because it is always used by the CFX-Solver. When you specify density directly using `Option=Value`, the Molar Mass is used only in certain situations:

- When the fluid is involved in a chemical reaction.
- When species transfer occurs for a multiphase-multicomponent simulation. For details, see [Interphase Species Mass Transfer](#) (p. 220).

In other cases, it is not essential to specify an accurate Molar Mass. However, for a multicomponent flow, the derived solution variables `<component>.Molar Concentration` and `<component>.Molar Fraction` will not be accurate unless the correct Molar Mass is set.

#### 1.4.4. Specific Heat Capacity

The Specific Heat Capacity at constant pressure determines the amount of heat energy required to raise the temperature of a fixed mass of the fluid by 1 K. You can model Specific Heat Capacity using three different options:

- By directly setting specific heat.
- Using the built in NASA Format polynomials
- Using the built in Zero Pressure Polynomial
- By reading properties from a TASCflow RGP table. For details, see [Real Fluid Properties](#) (p. 361).

### 1.4.4.1. Value

This is the most flexible option for specific heat capacity. With this option you can set specific heat to:

- A constant (Calorically Perfect)
- Varying with temperature
- Varying with temperature and/or pressure

### 1.4.4.2. NASA Format

This option defines specific heat as a function of temperature, in two distinct ranges, as a quartic polynomial and is available only when the equation of state is set to Ideal Gas. The format for the polynomial coefficients is also used by CHEMKIN [26]

The **Temperature Limit** frame expects three temperatures that define two temperature ranges for the upper and lower interval coefficients. In each interval, the same form for the polynomial is used but different coefficients can be used.

The **Upper** and **Lower Interval** coefficients are directly entered in their individual frames and correspond to the upper and lower range coefficients in the standard NASA SP-273 format. There are seven coefficients in each interval for a total of 14 coefficients. When entering these coefficients, keep in mind that the NASA format states that upper range coefficients are listed first, and lower range coefficients are listed second.

Also note that the format has changed slightly in order to accommodate proper units checking. In CFX the format followed the NASA Format to the letter: the first 7 are for the upper temperature interval, the last 7 for the lower temperature interval. In order to convert your CFX materials, you should need to load only your existing materials file into CFX-Pre and then write out the materials to a new materials file.

For each interval, the coefficients define the thermodynamic properties of the material according to the following formulae for specific heat capacity at constant pressure,

$$\frac{C_p^0}{R} = a_1 + a_2 T + a_3 T^2 + a_4 T^3 + a_5 T^4 \quad (1-15)$$

specific static enthalpy,

$$\frac{H^0}{R} = a_1 T + \frac{a_2}{2} T^2 + \frac{a_3}{3} T^3 + \frac{a_4}{4} T^4 + \frac{a_5}{5} T^5 + a_6 \quad (1-16)$$

and specific static entropy,

$$\frac{S^0}{R} = a_1 \ln T + a_2 T + \frac{a_3}{2} T^2 + \frac{a_4}{3} T^3 + \frac{a_5}{4} T^4 + a_7 \quad (1-17)$$

### 1.4.4.3. Zero Pressure Polynomial

This option is available for both **Ideal Gas** equation of state or when the equation state is given by a function of temperature and pressure (Option = Value with a CEL or User Fortran function). In either case the flow solver will build a table of values for enthalpy and entropy. In the former case the enthalpy will be a function only of temperature, and in the latter it will be a function of both temperature and pressure.

For this option, the specific heat  $c_p$  is expressed in polynomial form:

$$\frac{C_p^0}{R} = a_1 + a_2 T + a_3 T^2 + a_4 T^3 + a_5 T^4 \quad (1-18)$$

where  $R$  is the specific gas constant.

The coefficients for  $a_i$  are entered on the **Material Properties** form in CFX-Pre. The minimum and maximum temperature limits can also be supplied and define the range of applicability of the polynomial expression.

The maximum temperature limits for zero pressure polynomials are consistent in the `RULES` file, CFX-Pre, and the CFX-Solver (= 1000 K). Temperature limits for table generation are set by CFX-Pre: 5000 K for ideal gases, 1000 K for real gases.

### 1.4.4.4. Real Gas

This option is available only for materials that use a Real Gas equation of state. Ideal gas coefficients  $a_i$  must be supplied in the same way as for *Zero Pressure Polynomial* (p. 42) or *NASA Format* (p. 41). Whereas the `Zero Pressure` or `NASA Format` options allow  $c_p$  only to be a function of temperature, the `Real Gas` option takes the same coefficients as input to predict  $c_p$  as a function of both temperature and pressure.

### 1.4.4.5. Reference State Properties

#### 1.4.4.5.1. Reference Temperature and Reference Pressure

When defining specific heat capacity, you must set a reference temperature and reference pressure. These quantities are used only to define a reference level from which some derived quantities, such as a change in enthalpy or entropy, are calculated. The defaults for these values are 1 atm and 25°C. However, you should set these values to values that are representative of the average temperature and pressure that will occur in your model. You should also consider table limits as well in that it is better to choose reference values that fall in the valid range for table property generation.

#### 1.4.4.5.2. Reference Specific Enthalpy and Entropy

These values are available for input if the specific heat capacity is not given by NASA coefficients. When NASA coefficients are used, the **Reference Specific Enthalpy** and **Reference Specific Entropy** are ignored

by the CFX-Solver because they are built into the expressions for enthalpy and entropy through the upper and lower interval coefficient “constant” values.

The reference specific enthalpy is the enthalpy of formation at the specified **Reference Pressure** and **Reference Temperature** (often 1 atm, 25°C). The reference specific entropy is also evaluated at the specified reference pressure and temperature.

The reference enthalpy must be accurately set for simulations involving phase change (cavitation, evaporation and so on) or chemical reactions (for example, combustion). For details, see [Latent Heat](#) (p. 215).

### 1.4.5. Density and Specific Heat Dependencies

For a pure substance, the flow solver allows only density and specific heat capacity to be functions of temperature or pressure.

When you select the `Value` option for density or specific heat capacity, you can use an expression to specify **Density** and/or **Specific Heat Capacity**, but the expression is allowed to depend only on pressure and temperature for liquids and gases. For a solid, they can depend on temperature or spatial location (x, y, z), but not both at the same time.

For ideal gases, the density is evaluated using the Ideal Gas law and the specific heat may be a function of temperature only.

Both density and specific heat capacity can also be a function of an algebraic Additional Variable, but the algebraic Additional Variable must be a function only of temperature and pressure. CFX-Pre will not allow you to set this and you must therefore edit the CCL file to implement such a case.

If density, specific heat, or other properties are set as expressions that depend on pressure, the solver automatically uses the absolute pressure when evaluating the expression.

### 1.4.6. Table Generation Pressure and Temperature Limits

If you have defined density or specific heat capacity as a function of pressure and/or temperature using a CEL expression, User Fortran, IAPWS or Redlich Kwong equation of state then the CFX-Solver will generate tables for properties. The default temperature range is 100 K to 3000 K and the default pressure range is 0.01 bar to 10 bar.

If this range is not appropriate for the operating conditions of your model you should consider setting appropriate temperature and pressure limits for property table generation. See the **Materials** details view in CFX-Pre and complete the **Table Generation** section. For details, see [Material Properties Tab in the CFX-Pre User's Guide](#). The temperature limits specified should include enough range to convert the static temperature and total temperature range for you problem. Similarly, the pressure limits should be based on the minimum and maximum total pressure and static pressure expected in the simulation.

If the limits you enter are too narrow, then the CFX-Solver will clip properties at the bounds you have supplied. That being said though, you want to use the smallest range you can get away with because the more accurate the calculation of enthalpy will be, but the temperature and pressure in your simulation should not fall outside of the range specified.

## Important

The minimum and maximum pressures are *not* entered relative to the reference pressure (as most other pressures in CFX are). They are entered as absolute values. This is because the reference pressure is a property of a particular CFD problem and not a generic property of the material. However, an expression for density or specific heat capacity involving the CEL variable  $p$  will still use relative pressure.

The ranges are required to enable the CFX-Solver to construct a property table for the pressure-temperature-enthalpy relationship as well as entropy and, when using the Redlich Kwong and IAPWS equations of state, density and specific heat capacity.

Additional information on fluid properties and the treatment of enthalpy in ANSYS CFX is available in [Equations of State in the CFX-Solver Theory Guide](#).

## 1.4.7. Transport Properties

### 1.4.7.1. Dynamic Viscosity

Dynamic viscosity ( $\mu$ ), also called *absolute viscosity*, is a measure of the resistance of a fluid to shearing forces, and appears in the momentum equations.

#### 1.4.7.1.1. Value

You can specify a dynamic viscosity directly using either a constant value or a CEL expression.

#### 1.4.7.1.2. Rigid Non Interacting Sphere and Interacting Sphere Models

This model is based on elementary kinetic theory [82] and is valid for gases using user supplied equations of state or either of the built in equation of state models (Ideal Gas, Real Gas):

$$\mu = 26.69 \frac{\sqrt{wT}}{\Omega(T) \sigma^2} \quad (1-19)$$

where  $\mu$  is dynamic viscosity in  $\mu\text{P}$ ,  $w$  is the molecular weight in g/mol and  $T$  is temperature in Kelvin and  $\sigma$  is the collision diameter, in Angstroms, and is calculated using [83]:

$$\sigma = 0.809 \sqrt[3]{V_c} \quad (1-20)$$

where  $V_c$  is the critical molar volume in  $\text{cm}^3/\text{mol}$ . The Rigid Non Interacting Sphere model assumes that the collision function,  $\Omega$ , is unity, while the Interacting sphere model assumes that molecular collisions contribute to the viscosity and uses non-unity  $\Omega$ :

$$\Omega(T^*) = A(T^*)^B + Ce^{DT^*} + Ee^{FT^*} \quad (1-21)$$

where

$$A = 1.16145$$

$$B = -0.14874$$

$$C = 0.52487$$

$$D = -0.7732$$

$$E = 2.16178$$

$$F = -2.43787$$

$$T^* = \frac{T}{(\varepsilon/k_B)}$$

$$\frac{\varepsilon}{k_B} = \frac{T_c}{1.2593}$$

and where  $T_c$  is the critical temperature. This model was published by Chung et al. [83] [158].

#### 1.4.7.1.3. Non-Newtonian Model

For Generalized Newtonian fluids, you can specify a shear-strain-rate-dependent viscosity model. Several models are available. For details, see *Non-Newtonian Flow* (p. 26).

#### 1.4.7.1.4. Ideal Mixture

For fixed and variable composition mixtures, the `Ideal Mixture` option is used by default when you do not set a dynamic viscosity. This option causes the viscosity of the mixture to be computed by a mass-fraction-weighted average.

#### 1.4.7.1.5. Sutherland's Formula

This approximation for viscosity is valid for dilute gases and was obtained from the kinetic theory by Sutherland [81]. In this case viscosity varies only with temperature as:

$$\frac{\mu}{\mu_0} = \frac{T_{\text{ref}} + S}{T + S} \left( \frac{T}{T_{\text{ref}}} \right)^n \quad (1-22)$$

where  $\mu_0$  is the reference molecular viscosity,  $S$  is the Sutherland constant and is a characteristic of the gas,  $T_{\text{ref}}$  is usually 273.0 K, and  $n$  is the temperature exponent, usually set to 1.5 for most gases.

### 1.4.7.2. Thermal Conductivity

Thermal conductivity,  $\lambda$ , is the property of a fluid that characterizes its ability to transfer heat by conduction.

Thermal conductivity of gases tends to increase with increasing temperature, although it is relatively insensitive to changes in pressure, except at very high or very low pressures.

Thermal conductivity of liquids generally decreases with increasing temperature (notable exceptions are water and glycerine).

Typical values are in the range 0.005-0.5 W/mK for gases and 0.08-0.6 W/mK for liquids.

For **Fixed** and **Variable Composition Mixture**, the Thermal conductivity is determined by a mass fraction weighted arithmetic average. You can set Thermal conductivity for the mixture in the **Materials** details view instead, if you want.

#### 1.4.7.2.1. Sutherland's Formula

Sutherland's formula for thermal conductivity is identical to that for dynamic viscosity. The only change being the reference value is now a reference thermal conductivity. This formula is still based on kinetic theory so still applies only to dilute gases.

#### 1.4.7.2.2. Modified Eucken Model

The modified Eucken thermal conductivity model is available whenever you have selected Real Gas, NASA Format or Zero Pressure polynomial for specific heat capacity. You must use one of those two specific heat capacity options because the Eucken model requires the zero pressure polynomial coefficients. This model is also based on the kinetic theory of gases and is valid for gases over a fairly large range of temperatures below the critical point. The Modified Eucken Model is described in Poling, Prausnitz & O'Connell [84] and is given by:

$$\frac{\lambda}{\mu c_v} = 1.32 + \frac{1.77 R_g}{c_v} \quad (1-23)$$

### 1.4.8. Radiation Properties

Radiation properties are required if a thermal radiation model is used. The **Absorption Coefficient** and **Scattering Coefficient** should be positive values or zero for transparent media. If you are using either the P1 or Rosseland radiation models, and at least one of the coefficients must be nonzero. The **Refractive Index** is a value greater than or equal to 1; it is approximately equal to 1 for most gases.

For a **Fixed** or **Variable Composition Mixture**, the radiation properties are determined by a mass fraction weighted arithmetic average. This is often not the most appropriate averaging method for these quantities. You can set radiation properties for the mixture in the **Materials** details view instead, if you want. For details, see [Mixture Properties Tab in the CFX-Pre User's Guide](#).

The radiation properties specified for a mixture are ignored when using the Weighted Sum of Gray Gases or Multigray spectral models.

---

#### Important

Explicitly setting radiation properties for multicomponent flows is recommended. When a large number of components are involved, it takes a significant amount of solver CPU time to calculate these mixture properties. Often, the radiation properties are the same for all components, so computing radiation mixture properties results in wasted effort. You can avoid the radiation mixture property calculation by providing values for the mixture when it is created. An example of this is available.

For further details, see *Material Properties for Radiation* (p. 342).

## 1.4.9. Buoyancy Properties

### 1.4.9.1. Thermal Expansivity

**Thermal Expansivity** (or coefficient of thermal expansion),  $\beta$ , describes how a fluid expands with temperature. It is used in the Boussinesq approximation for buoyant flow and has dimensions of  $\theta^{-1}$  (where  $\theta$  is temperature). For details, see *Buoyancy in the CFX-Solver Theory Guide*. This parameter will be used by the flow solver only if the fluid has a constant density. Otherwise, the full buoyancy model will be used, for which thermal expansivity is not a required parameter.

## 1.4.10. Electromagnetic Properties

The electromagnetic properties of a material include its electrical conductivity and its magnetic permeability. You can specify values for both of these characteristics in the CFX-Pre **Material** details tab.

### 1.4.10.1. Electrical Conductivity

The **Electrical Conductivity** area has the following settings:

#### Option

Can be set to **Value**.

#### Electrical Conductivity

Can be set to an expression or to a value (default units are [S m<sup>-1</sup>]).

### 1.4.10.2. Magnetic Permeability

Magnetic permeability is the equivalent of the electrical permittivity, but for the magnetic field. For permeable linear materials it can be specified from the relative permeability or from the magnetic susceptibility. The **Magnetic Permeability** area has the following settings:

#### Option

Can be set to **Value**.

#### Magnetic Permeability

Can be set to an expression or to a value (default units are [H m<sup>-1</sup>]).

By default, the **Magnetic Permeability** value is set to a CEL constant called `mupermo`, which is defined as  $4\pi \times 10^{-7} [A^{-2} N]$ . See *CEL Constants in the CFX Reference Guide* for details on CEL constants.

## 1.4.11. Library Materials

CFX-Pre provides an extensive list of library materials for which the properties have already been set. These materials can be used directly in a simulation or as a template to define customized materials with similar properties. The default materials library is stored in the `MATERIALS` file located in the `CFX/etc/` directory. You can also edit/add to the `MATERIALS` file, but this is considered an expert feature. For details, see *Adding to the MATERIALS file* (p. 48). Exporting and Importing CCL files is a simpler way to transferring material data from one simulation to another.

The properties for many materials have been evaluated at Standard Temperature and Pressure (STP), defined as 0°C (273.15 K) and 1 atm (101325 Pa). The long name provided with most materials will indicate the condition at which constant properties were evaluated or possibly the range over which the

properties apply. It is important to note that using library materials will produce inaccurate results if your simulation conditions depart significantly from those at which the material properties were evaluated.

Some pre-supplied materials have properties defined in different ways, depending on the type of modeling for which they will be used. For example, there are two material groups for “gases.” In the material group drop-down list, you will see that there is a group for constant properties and a group for Ideal Gases. All the materials in the first group have both constant density and constant specific heat capacity. All materials in the second group use the Ideal Gas equation of state but have constant specific heat capacity.

In particular, Air at STP and Air Ideal Gas are two examples. In addition, a third material such as Air at 25 C is also available if Air at STP is not appropriate. The last version of Air uses material properties evaluated at 25 C instead of 0 C. You should select the appropriate material for your simulation; this may require you to modify the properties of an existing material or create a new material.

To view the properties of the template materials, you can select it in the tree view and then click the **Edit**  icon. The **Materials** details view will open and you will be able to see the material properties.

### 1.4.11.1. Adding to the MATERIALS file

If you frequently use a material that is not defined in the MATERIALS file, you may want to add it to the main MATERIALS file. Using a text editor, you can access the file

CFX/etc/MATERIALS and make any necessary revisions.

---

#### Note

You should make a local copy of the MATERIALS file and rename it so that the backup database can be restored at a later date. Your changes should then be made to copy named MATERIALS.

To enable CFX-Pre to correctly read your new material, the format should exactly match that of existing materials. Therefore, you should use one of the existing materials as a template for entering the properties of your material.

The best way to do this is to create your new material in CFX-Pre, write the material to a file using **File** > **Export** > **CCL**, and then cut and paste the material from that file into your local copy of the materials file.

## 1.5. Mixture Properties (Fixed and Variable)

**Fixed** and **Variable Composition Mixtures** both use a mass fraction weighted average for all transport properties. The only exceptions are density and molecular weight, which use a harmonic averaging.

### 1.5.1. Density

For **Fixed** and **Variable Composition Mixture**, the density is determined by a mass fraction weighted harmonic average:

$$\frac{Y_A}{\rho_A} + \frac{Y_B}{\rho_B} + \dots + \frac{Y_N}{\rho_N} = \frac{1}{\rho_{\text{mix}}} \quad (1-24)$$

You can explicitly set a density for the mixture in the **Materials** details view instead, if you want.

### 1.5.2. Molar Mass

For **Fixed** and **Variable Composition Mixture**, the **Molar Mass** is determined by a mass fraction weighted harmonic average:

$$\frac{Y_A}{w_A} + \frac{Y_B}{w_B} + \dots + \frac{Y_N}{w_N} = \frac{1}{w_{\text{mix}}} \quad (1-25)$$

You can set a **Molar Mass** for the mixture in the **Materials** details view instead, if you want.

### 1.5.3. Electromagnetic Properties

The default mixture (Ideal Mixture) has been extended to make it appropriate for electromagnetic properties. The extensions are for Electrical Conductivity (no default) and Magnetic Permeability (the permeability of free space).


## 1.6. Efficiency Calculation

The following topics are discussed in this section:

- [Isentropic Efficiency and Total Enthalpy](#) (p. 49)
- [Polytropic Efficiency](#) (p. 51)
- [Activating Efficiency Output](#) (p. 53)
- [Restrictions](#) (p. 54)

### 1.6.1. Isentropic Efficiency and Total Enthalpy

The efficiency of any device is never perfect due to both fluid dynamic and thermodynamic losses within the entire system. The losses show up in a difference in stagnation properties from the values that would be expected if the process would be perfectly isentropic. Consider the processes drawn on the T-s diagrams shown in [Figure 1.2](#) (p. 50) for a compression and expansion process.

**Figure 1.2 T-s Diagrams for Compression and Expansion Processes**

Two efficiency calculation options are possible for either process: **Total to Total** and **Total to Static**. The first option evaluates efficiency using stagnation conditions at points 1 and 2. The second option uses stagnation conditions at point 1 and static conditions at point 2, so, the efficiency is evaluated without including the kinetic energy contribution at point 2. The **Total to Total** option is most useful for devices where work is either performed on the fluid (for example, a pump or compressor) or extracted from the fluid (for example, a turbine). The **Total to Static** option is useful for evaluating losses in devices that perform no work on the fluid (for example, diffusers and nozzles).

Work is generally input for a compression process such as gas compressors, so the **Total to Total** isentropic efficiency is defined as the ratio of the required isentropic work to the actual required work for fluid compression:

$$\eta_C = \frac{H_{02'} - H_{01}}{H_{02} - H_{01}} \quad (1-26)$$

Work is usually derived from expansion processes such as steam turbines, so the **Total to Total** efficiency is the ratio of the actual expansion work to the isentropic expansion work:

$$\eta_E = \frac{H_{02} - H_{01}}{H_{02'} - H_{01}} \quad (1-27)$$

where the total enthalpy at point 1 is the mass average value of the user-selected inlet boundary condition.

In addition, the isentropic total enthalpy,  $H_{02'}$  is required. This is the fluid enthalpy evaluated at the entropy at point 1 and the total pressure at point 2. The entropy at point 1 is taken, by default, as the mass averaged value at a user-selected inlet boundary condition. The isentropic enthalpy is evaluated from the state equation:

$$H_{02',node} = f(\bar{s}_{inlet}, P_{0,node}) \quad (1-28)$$

The isentropic enthalpy is then used in [Equation 1-26 \(p. 50\)](#) or [Equation 1-27 \(p. 50\)](#) to evaluate compression or expansion efficiency. These quantities are useful for evaluating where losses are occurring in the device. Global efficiencies reported in the solver monitor are evaluated by mass averaging the field efficiencies at the user-selected outlet boundary condition.

**Total to Static** efficiencies are evaluated identically to **Total to Total** efficiency except that all stagnation conditions at point 2 are replaced by static conditions. So, for example, the **Total to Static** isentropic efficiency for an expansion process is:

$$\eta_E = \frac{h_{s2} - H_{01}}{h_{s2'} - H_{01}} \quad (1-29)$$

where

$$h_{s2',node} = f(\bar{s}_{inlet}, P_{s,node})$$

Free stream detection is also applied to the efficiency values in a similar way to the high resolution advection blending. This is because in the free stream the isentropic enthalpy change and the local enthalpy change can both be small (that is,  $O(0)$ ). A small number divided by another small number can result in a noisy looking efficiency field in inlet regions where the efficiency should be unity because no work has yet been performed on the fluid. Free stream damping blends the efficiency field to unity. The free stream damping is controlled with the expert parameter `fsdamp efficiency scale` with a default value of 0.01. Smaller values for this parameter will decrease the influence of the free stream damping, and reducing it to a value of 0.0 will switch off the free stream damping completely.

Device efficiency values reported by the CFX-Solver Manager and CFD-Post macros are calculated using a boundary averaged value of the damped efficiency field variable (for example Isentropic Efficiency). In some cases, this value may be different to one calculated from the classical formula using boundary-averaged values of enthalpy. The difference is due to the field damping, and is negligible in the vast majority of cases. However, in rare cases, for example where there is localized heating or cooling, the difference may be significant and you should check the reported values with the damping disabled.

## 1.6.2. Polytopic Efficiency

The isentropic efficiency has one significant drawback in that there is no way to separate the fluid dynamic losses from the total (fluid dynamic + thermodynamic) losses. This means that devices having different pressure ratios will have different isentropic efficiencies even though they may both be of similar fluid dynamic quality. An example would be two compressors of different pressure ratios. The higher pressure ratio compressor will have a lower isentropic efficiency because of thermodynamic losses. This property can make it difficult to comparatively evaluate different compressor designs. A similar argument applies to turbine design.

To work around this drawback, the assumed "ideal" path followed by the process does not have to be isentropic. Instead, one can evaluate the polytropic efficiency by following a path along a line of constant efficiency. Aungier [65] discusses how a constant efficiency path on a T-s diagram can be approximated by the following equation:

$$T \frac{ds}{dT} = A \quad (1-30)$$

This equation can be rearranged to give the following two relationships:

$$T ds = A dT, ds = \frac{A dT}{T} \quad (1-31)$$

The entropy change along this path is evaluated by integrating the last expression:

$$s_2 - s_1 = A \ln (T_{02}/T_{01}) \quad (1-32)$$

Rearranging this expression gives the value of the constant  $A$  along the given path:

$$A = \frac{s_2 - s_1}{\ln (T_{02}/T_{01})} \quad (1-33)$$

In order to evaluate the polytropic efficiency, evaluate the polytropic enthalpy change along the alternative path defined by the path equation. First, start with the second law:

$$T ds = dh - v dp \quad (1-34)$$

The  $v dp$  term is the polytropic work, or enthalpy change, and is what needs to be solved. First, the  $T ds$  term is substituted using [Equation 1-31 \(p. 52\)](#) to give:

$$A dT = T ds = dh - v dp \quad (1-35)$$

Integrating this equation along the polytropic path gives:

$$H_p = (H_{02} - H_{01}) - A (T_{02} - T_{01}) \quad (1-36)$$

### Note

The  $v dp$  term has been renamed to  $H_p$  to signify that the work is the polytropic enthalpy change.

The final form of the polytropic work is obtained by simply substituting for  $A$ :

$$H_p = (H_{02} - H_{01}) - \frac{(s_2 - s_1) (T_{02} - T_{01})}{\ln (T_{02}/T_{01})} \quad (1-37)$$

Now that you have an expression for this enthalpy change, you can compute the polytropic efficiency:

$$\eta_{CP} = \frac{H_p}{H_{0a} - H_{01}} \quad (1-38)$$

$$\eta_{EP} = \frac{H_{0a} - H_{01}}{H_p} \quad (1-39)$$

The polytropic efficiencies are also evaluated relative to a selected inlet boundary condition and output by the flow solver as both local (at every node in the flow) and global (overall device) quantities.

Similar to the isentropic efficiency, total to total and total to static versions of the polytropic efficiency are similarly evaluated by replacing stagnation quantities at point 2 with static quantities.

### 1.6.3. Activating Efficiency Output

Two options are available for efficiency analysis. You can monitor the overall device efficiency within the CFX-Solver Manager as well as post process field efficiencies in CFD-Post.

Efficiency output can be activated on the **Monitor** tab under **Output Control** in CFX-Pre, and enables you to monitor the device efficiencies in the CFX-Solver Manager.

#### 1.6.3.1. CFX-Solver Manager Output Variables

To calculate the overall device efficiency requires that you specify both an inlet and outlet boundary condition corresponding to points 1 and 2 on the T-s diagrams shown in [Figure 1.2 \(p. 50\)](#). Only single boundary condition regions of type inlet and outlet are currently supported. The inlet entropy and total enthalpy are based on mass flow average values. The monitored efficiency values are based on mass average field efficiency at the selected outlet boundary condition.

For single phase cases or multiphase cases running the homogeneous model, the following variables are written to the out file:

- Isentropic Compression Efficiency
- Isentropic Expansion Efficiency
- Polytropic Compression Efficiency
- Polytropic Expansion Efficiency

For multiphase cases running the homogeneous mass and momentum model, but inhomogeneous energy equations (such as condensing/evaporation disperse droplets, disperse solids):

- <Continuous Phase>.Isentropic Compression Efficiency
- <Continuous Phase>.Isentropic Expansion Efficiency
- <Continuous Phase>.Polytropic Compression Efficiency
- <Continuous Phase>.Polytropic Expansion Efficiency

Compression and expansion efficiencies are calculated only for the continuous phase; all other dispersed phases are ignored.

For multiphase cases running the inhomogeneous mass and momentum model and inhomogeneous energy equations:

- <Continuous Phase  $n$ >.Isentropic Compression Efficiency
- <Continuous Phase  $n$ >.Isentropic Expansion Efficiency
- <Continuous Phase  $n$ >.Polytropic Compression Efficiency
- <Continuous Phase  $n$ >.Polytropic Expansion Efficiency

For each continuous phase, compression and expansion efficiencies are calculated.

All of the output variables are either **Total to Total** or **Total to Static** depending on which mode you have selected in CFX-Pre.

### 1.6.3.2. Results File Output Variables

When efficiency monitoring is activated field efficiencies are also written to the final results file, Standard backup and transient results files, and Selected Variables transient files where required. When efficiency monitoring is activated, the field variables can be used in CEL expressions, monitor points (callback and point monitors), and User Fortran.

In addition to the global efficiency fields, described in the previous section, the following field variables are written to results and backup files during a simulation:

For single phase or multiphase homogeneous mass and momentum with homogeneous energy equation model:

- Isentropic Enthalpy
- Polytropic Enthalpy

For homogeneous mass and momentum with inhomogeneous energy equation:

- <Continuous Phase>.Isentropic Enthalpy
- <Continuous Phase>.Polytropic Enthalpy

For inhomogeneous mass and momentum with inhomogeneous energy equation:

- <Continuous Phase  $n$ >.Isentropic Enthalpy
- <Continuous Phase  $n$ >.Polytropic Enthalpy.

All of the output variables are either Total to Total or Total to Static depending on which mode you have selected in CFX-Pre.

### 1.6.4. Restrictions

The following restrictions apply and are enforced by the CFX-Solver and CFX-Pre:

- The efficiency calculation is possible only if you run a non-isothermal heat transfer model. This means that monitoring efficiency of an incompressible fluid (for example, an incompressible liquid pump or turbine) still requires that you run a heat transfer model. This may introduce error if the enthalpy change (or temperature change) for your device is very small, so ensure that your material definition is using a sensible (that is, as small as possible) reference enthalpy.
- The boundary lists allow only single boundary conditions of type **Inlet** or **Outlet**.
- Multiple component efficiencies cannot be directly monitored using the existing interface. The best approach is to activate the field output and use the expression monitor option to monitor the efficiency change across the given component.

- **Total to Total** and **Total to Static** efficiency values cannot be evaluated at the same time. You must select one mode or the other.

## 1.7. Wall Condensation Model

The Wall Condensation Model has been developed for use in the nuclear containment industry, although it can be used in more general situations. In this model, the condensation of gaseous vapor in a variable composition mixture is driven by the concentration gradient at the wall, and internal boundary mass sources are used to model the removal of condensate from the system. The condensate film thickness, and heat transfer through it, are assumed to be negligible and are not modeled explicitly. This is appropriate for containment scenarios where the condensate does not adhere to the surface but is absorbed by it (for example, on ceramic/concrete walls).

### 1.7.1. CFX-Pre Setup

To set up a case, you require a variable composition mixture, the condensable component of which must be part of a homogeneous binary mixture. The latter is not required to be a fluid in the domain, but must be part of the case definition. The variable composition mixture must consist of one condensable component and one or more non-condensable components.

---

#### Note

There is a template model file (`wall_condensation.ccl`) to aid the set up of cases that use the wall condensation model.

The following topics are discussed:

- [1.7.1.1. Domain Fluid Model Specification](#)
- [1.7.1.2. Boundary Condition Specification](#)
- [1.7.1.3. Restrictions](#)

#### 1.7.1.1. Domain Fluid Model Specification

To use the wall condensation model, visit the Fluid Models tab of the domain, and set **Component Models** > **Wall Condensation Model** > **Option** to **Concentration Boundary Layer Model**.

Note that the wall condensation model is allowed only for multi-component fluids defined on fluid domains on which the Thermal Energy or Total Energy model is active. Also, there must exist a unique condensable component. It is necessary to indicate which component is condensable, and which are non-condensable. For the condensable component, it is necessary to name an associated Homogeneous Binary Mixture which will be used to compute the required saturation material properties. The named Homogeneous Binary Mixture (HBM) must exist in the materials library, and must contain the condensable component as one of its components, and the condensate as the other component.

Note that the condensation model settings can be applied to only components that have the **Transport Equation** or **Algebraic Slip** option. In most applications, the condensable component will be vapor and the condensate will be liquid. However, the model is valid in other contexts, such as sublimation, so all thermodynamic states are permissible for the condensable component and the condensate.

#### 1.7.1.2. Boundary Condition Specification

Wall condensation must be explicitly activated on those wall or fluid-solid boundaries for which it is required. The default condition on these boundaries, for all components, is Zero Flux.

### **1.7.1.3. Restrictions**

The wall condensation model has the following restrictions:

- The wall condensation model is allowed only for multi-component fluids defined on fluid domains on which the Thermal Energy or Total Energy model is active.
- Only one condensable component is permitted. There is no restriction on the number of non-condensable components. The condensable component should either have Option = Transport Equation or Option = Algebraic Slip.
- Condensation boundary conditions are restricted to walls with specified temperature, and fluid-solid interfaces. The following further restrictions are imposed:
  - You cannot specify wall condensation on non-overlap boundaries.
  - Free slip and specified stress walls are allowed for laminar flows but are disallowed for turbulent flows.
- It is not possible to specify both wall condensation boundary conditions and additional user boundary mass sources on a given boundary surface.

### **1.7.2. Condensation Mass Flux in CFD-Post**

On any boundary surface where condensation boundary conditions are set, the condensation mass flux is written as a boundary-only variable to CFD-Post under the variable name <Component>.Condensation Mass Flux.

---

## Chapter 2: Boundary Condition Modeling

---

This chapter provides detail on how to use appropriate boundary conditions in CFX for basic models. Information on the mathematical representation of CFX boundary conditions is available in [Boundary Conditions in the CFX-Solver Theory Guide](#). Extended information for more complex models is provided in the related modeling chapters. For example, for information on multiphase outlets, you should consult the multiphase modeling section for specific advice. For details, see [Boundary Conditions in Multiphase Flow](#) (p. 225).

The equations relating to fluid flow can be closed (numerically) by the specification of conditions on the external boundaries of a domain. It is the boundary conditions that produce different solutions for a given geometry and set of physical models. Hence, boundary conditions determine to a large extent the characteristics of the solution you obtain. Therefore, it is important to set boundary conditions that accurately reflect the real situation to allow you to obtain accurate results.


This chapter describes:

- 2.1. The Purpose of Boundary Conditions
- 2.2. Available Boundary Conditions
- 2.3. Using Boundary Conditions
- 2.4. Inlet
- 2.5. Outlet
- 2.6. Opening
- 2.7. Wall
- 2.8. Symmetry Plane
- 2.9. Profile Boundary Conditions

### 2.1. The Purpose of Boundary Conditions

Boundary conditions are a set of properties or conditions on surfaces of domains, and are required to fully define the flow simulation. The type of boundary condition that can be set depends upon the bounding surface.

- A fluid boundary is an external surface of the fluid domain excluding surfaces where it meets other domains.
- A solid boundary is an external surface of the solid domain excluding surfaces where it meets other domains.
- A fluid-fluid interface is the interface between two fluid domains.
- A fluid-solid interface is the interface between a solid and fluid domain.
- A solid-solid interface is the interface between two solid domains.




## 2.2. Available Boundary Conditions

The following boundary types are available in ANSYS CFX:

- *Fluid Boundaries* (p. 58)
- *Solid Boundaries* (p. 59)

### 2.2.1. Fluid Boundaries



A fluid boundary is an external surface of a fluid domain and supports following boundary conditions:

- **Inlet** - Fluid predominantly\* flows into the domain.
- **Outlet** - Fluid predominantly\* flows out of the domain.
- **Opening** - Fluid can simultaneously flow both in and out of the domain. This is not available for domain with more than one fluid present.
- **Wall** - Impenetrable boundary to fluid flow.
- **Symmetry Plane** - A plane of both geometric and flow symmetry.

\* When you define an area to be an "inlet," you are telling CFX-Solver that you anticipate that flow will be into a domain. You can set either velocity or pressure at that point, and CFX-Solver will calculate

the other value. How CFX-Solver behaves during the flow calculations depends on which attribute you set:

- CFX-Solver allows both inflow and outflow due to the velocity specified conditions: “artificial walls” are not erected at inlets or inlets due to such conditions.
- If you set pressure at an inlet, you may accidentally create conditions that would lead to an outflow when the pressure inside the domain is greater than outside. Under this condition, CFX-Solver “builds” an artificial wall to prevent outflow. To disable this behavior, define the boundary to be an “opening,” rather than an inlet.

For details, see *Using Inlets, Outlets and Openings* (p. 60).

## 2.2.2. Solid Boundaries

A solid boundary is an external surface of the solid domain and supports the following boundary conditions:

- `Wall` - Impenetrable boundary to fluid flow.
- `Symmetry Plane` - A plane of both geometric and flow symmetry.

## 2.3. Using Boundary Conditions

The following topics will be discussed:

- *Specifying Well-Posed Boundary Conditions* (p. 59)
- *Recommended Configurations of Boundary Conditions* (p. 60)
- *Using Inlets, Outlets and Openings* (p. 60)
- *Using CEL Expressions With Boundary Conditions* (p. 63)

### 2.3.1. Specifying Well-Posed Boundary Conditions

For a given computational domain, boundary conditions can be given that over-specify or under-specify the problem. This usually results in non-physical solutions or failure of the solution to converge. It is important, therefore, to understand the meaning of well-posed boundary conditions.

An example of an over-specified problem is a constant area duct, with a specified fluid velocity at the inlet, and a different velocity specified at the outlet. Clearly, both conditions cannot be physically satisfied in the absence of a mass source for an isochoric fluid.

An example of an under-specified problem is that of a closed box for which only heat flux boundary conditions were specified. In this case, the temperature level is not constrained and, while the solution may converge, the resultant temperature level would be unpredictable.

The best way to determine if the boundary conditions are well posed is to ask the question “Could the configuration I have set be physically recreated in a laboratory?” In the first example above, this is clearly not possible. In the second example, no matter how good the insulation of the boundary, there would eventually be some heat flow from or into the environment that would serve to set the temperature level.

For details, see *Boundary Conditions in Multiphase Flow* (p. 225).

## 2.3.2. Recommended Configurations of Boundary Conditions

The following combinations of boundary conditions are all valid configurations commonly used in ANSYS CFX. They are listed from the most robust option to the least robust:

- **Most Robust:** Velocity/mass flow at an inlet and static pressure at an outlet. The inlet total pressure is an implicit result of the prediction.
- **Robust:** Total pressure at an inlet and velocity/mass flow at an outlet. The static pressure at the outlet and the velocity at the inlet are part of the solution.
- **Sensitive to Initial Guess:** Total pressure at an inlet and static pressure at an outlet. The system mass flow is part of the solution.
- **Very Unreliable:** Static pressure at an inlet and static pressure at an outlet. This combination is not recommended, as the inlet total pressure level and the mass flow are both an implicit result of the prediction (the boundary condition combination is a very weak constraint on the system).
- **Not Possible:** Total pressure cannot be specified at an outlet. The total pressure boundary condition is unconditionally unstable when the fluid flows out of the domain where the total pressure is specified.


With more than two inflows or outflows, the other openings should be of the boundary condition type `Opening`. This is because the flow at these other boundaries could in general be in or out, and the direction will be part of the solution.


## 2.3.3. Using Inlets, Outlets and Openings

Define regions as inlets and outlets when you expect one-way flow boundary conditions; define them as openings when you want to support simultaneous inflow and outflow over a single region. Care should be taken specifying velocity components for these boundary conditions as you are allowed to specify flow in either direction at an inlet or outlet.

### 2.3.3.1. Inlets

Inlets are used predominantly for regions where inflow is expected; however, inlets also support outflow as a result of velocity specified boundary conditions.

Artificial walls for Inlets	
<p><b>Velocity specified condition</b></p> 	<p>CFX-Solver allows both inflow and outflow, and therefore artificial walls are not erected when the specified velocity is out of the domain.</p>
<p><b>Pressure and mass flow condition</b></p>	<p>CFX-Solver enforces inflow by erecting artificial walls on those faces where the flow attempts to exit the domain.</p>



### 2.3.3.2. Outlets

Outlets are used predominantly for regions where outflow is expected; however, outlets also support inflow as a result of velocity specified boundary conditions.

Artificial walls for Outlets	
<p><b>Velocity specified condition</b></p>	CFX-Solver allows both inflow and outflow, and therefore artificial walls are not erected at inlets when the specified velocity is into the domain.
<p><b>Pressure and mass flow condition</b></p>	CFX-Solver enforces outflow by erecting artificial walls on those faces where the flow attempts to enter the domain.

### 2.3.3.3. Openings

Define a region as an “opening” when the full prescription of information at that location is not readily available; for example, if the value of pressure is known, but the direction of flow is unknown. It is also important to note how ANSYS CFX treats the value of pressure that you specify at an opening. If, during the course of the solution, flow is directed out of the domain, then the value is treated as static pressure. If, instead, the flow is entering the domain, the value is taken to be total pressure, from which the static pressure is calculated.

A large number of flow simulations can make use of the `Static Pressure` option to describe an outlet boundary where flow is out of the domain, and the `Total Pressure` option to specify an inlet boundary where flow is into the domain. As the solution progresses, inflow may occur at an outlet boundary, or outflow at an inlet boundary, due to either:

- The behavior of the solver
- A physical phenomenon, such as a recirculation zone, close to the boundary.

In either case, the CFX-Solver will try to enforce outflow by erecting artificial walls on the boundary mesh faces to prevent inflow occurring. If the full inlet/outlet is walled off and it was the only boundary condition that set the pressure level, then the artificial walls create a serious problem: temporarily, there is no pressure level felt by the code. This usually causes a linear solver failure. If you consult your output file, a message like the following should be present:

```
+-----+
|                ***** Notice *****                |
| A wall has been placed at portion(s) of an OUTLET     |
| boundary condition (at 31.4% of the faces, 12.3% of the area) |
| to prevent fluid from flowing into the domain.         |
| The boundary condition name is: exit.                 |
| The fluid name is: AirIdeal.                          |
| If this situation persists, consider switching        |
| to an Opening type boundary condition instead.        |
+-----+
```

If you suspect that the problem is a numerical one, then you overcome this by temporarily replacing the inlet/outlet boundary condition with a pressure-specified opening. Artificial walls are not erected with the opening type boundary, as both inflow and outflow are allowed (although you may have to specify information that is used if the flow becomes locally inflow). Restart the solver, and once the solution is further converged, the original boundary condition can be restored.

If you suspect that a real phenomenon is causing the inflow, for example, a recirculation region near an outlet, then two options are available to you:


- Move the outlet to a region well away from this influence by, perhaps, extending the flow domain further downstream. A good rule of thumb is to place the boundary a distance downstream that is at least 10 times the height of the last obstacle.
- Alternatively, you may have reasons to want to maintain the location of that boundary, in which case, you can use an opening to describe subsonic flow where simultaneous inflow and outflow may occur. Generally, however, it should be noted that defining the boundary of your computational domain to cross a flow recirculation region is not a good idea. You are making a poor approximation of what is happening just outside the opening by not modeling it.

The diagram below, showing flow over a backward facing step, serves to illustrate the former approach. A recirculation region builds up downstream of the step as a result of the separated flow. An initial pressure boundary intersects this region with the result that flow re-enters the domain across it. Convergence problems will arise in this situation because the CFX-Solver will try to enforce an outward-flow-only condition, which is inconsistent with the physical nature of the flow. Although placing the boundary further downstream (beyond the re-attachment point) alleviates the inflow problem, the flow is still developing in the enlarged duct. A much better location would be at a point where the flow profile is not changing, well away from any zone of influence.

If, during the course of the solution, you do still experience convergence problems, the use of a small physical timestep may help to promote convergence.


### Figure 2.1 Poor Location

Outlet pressure boundary intersects recirculation area.  
Inflow plus possible convergence problems.




### Figure 2.2 Better Location

Outlet pressure boundary no longer intersects recirculation area  
but reattached flow is still developing.



### Figure 2.3 Ideal Location

Outlet pressure boundary is well away from recirculation area.



#### 2.3.3.4. Using Pressure Specified Boundaries with Buoyant Flows

When buoyancy is activated, the pressure calculated by the solver excludes the hydrostatic pressure gradient. This modified pressure is often called motion pressure because it is responsible for driving the flow. All boundary conditions are interpreted in terms of this modified pressure. For details, see [Buoyancy and Pressure](#) (p. 14).

Furthermore, if there is a free surface flow at the boundary due to variations in density, temperature or height change; specifying a pressure profile at the boundary may be required.

#### 2.3.4. Using CEL Expressions With Boundary Conditions

Boundary condition values can be defined using any valid CEL expressions.

For details, see [CEL Operators, Constants, and Expressions in the CFX Reference Guide](#).

## 2.4. Inlet

An inlet boundary condition is used where the flow is predominantly directed into the domain. The boundary condition can be set in a number of ways depending on how you want to specify the conditions, and what particular physical models you are using for the simulation.

There are many different types of inlet boundary condition combinations for the mass and momentum equations. For all other transport equations, the value is specified directly at the inlet, or specified in terms of a simple relationship that constrains the dependent variable.

---

### Important

If you accidentally set the velocity at an inlet to be flowing out of the domain, the inlet will behave as an outlet: *wall building will not be turned on*.

Information on setting Inlet values using CFX-Pre is available. For details, see [Boundary Details: Inlet in the CFX-Pre User's Guide](#).

Information on the mathematical implementation of the inlet boundary condition is available.

- [Inlet \(Subsonic\) in the CFX-Solver Theory Guide](#)
- [Inlet \(Supersonic\) in the CFX-Solver Theory Guide](#)

### 2.4.1. Mesh Motion

Mesh motion can occur on inlet boundaries in domains where **Mesh Deformation** has been activated for the domain. See [Mesh Deformation in the CFX-Pre User's Guide](#) for information about activating mesh deformation for the domain. Note that solution errors will be introduced if any of the specified motion is normal to the boundary faces. For details, see [Mesh Deformation \(p. 3\)](#).

### 2.4.2. Inlet (Subsonic)

#### 2.4.2.1. Mass and Momentum

##### 2.4.2.1.1. Normal Speed

Specify the magnitude of the resultant normal velocity at the boundary. The value you specify is transferred from the fluid domain normal to each element face on that boundary during the execution of the CFX-Solver.

This option is especially useful for non-planar inlet boundaries (that is, curved surfaces).

If the domain is porous, the speed that you specify is interpreted as true, not superficial.

##### 2.4.2.1.2. Cartesian Velocity Components

Specify the Cartesian components of velocity on the inlet boundary. The component values are relative to the selected coordinate frame.

If the domain containing the boundary condition is rotating, then the axis of the cylindrical coordinate system will automatically be set to the rotation axis. You can specify either relative or absolute velocity components by choosing **Frame Type**:

- If the **Frame Type** is *Rotating*, then your velocity components are relative to the local domain rotating frame of reference.
- If the **Frame Type** is *Stationary*, then your velocity components are relative to the absolute (stationary) frame of reference (at its initial orientation for transient cases).

If the domain is porous, the velocity components that you specify are interpreted as true, not superficial.

### 2.4.2.1.3. Cylindrical Velocity Components

Specify the r, theta, z components of velocity on the inlet boundary in cylindrical coordinates. The axis about which the velocity components are specified depends on the domain motion (rotating or stationary) and on whether a local rotation axis is specified with the boundary condition.

If the domain containing the boundary condition is stationary, you must specify an axis in one of two ways:

- You can select the axis of the cylindrical coordinate system for the boundary condition (called the **Rotation Axis**) as an axis of the global coordinate frame, Coord 0.
- You can specify **Rotation Axis From** and **Rotation Axis To** points. These are the two end points of the axis. The global coordinate system must be used to specify these points. The positive z component of the cylindrical coordinates is in the direction of the vector from the **Rotation Axis From** point to the **Rotation Axis To** point.

If the domain containing the boundary condition is rotating, then the axis of the cylindrical coordinate system will automatically be set to the rotation axis. You can specify either relative or absolute velocity components by choosing **Frame Type**:

- If the **Frame Type** is *Rotating*, then your velocity components are relative to the local domain rotating frame of reference.
- If the **Frame Type** is *Stationary*, then your velocity components are relative to the absolute (stationary) frame of reference (at its initial orientation for transient cases).

If the domain is porous, the velocity components that you specify are interpreted as true, not superficial.

### 2.4.2.1.4. Mass Flow Rate

The total mass flow rate into the domain at the boundary is specified. A flow direction must also be given in order to fully specify the boundary condition. For details, see [Flow Direction](#) (p. 66).

### 2.4.2.1.5. Total Pressure (Stable)

If you want to specify the total pressure at an inlet, you can use the `Total Pressure` option. You must specify the **Relative Total Pressure** and a flow direction. For details, see [Flow Direction](#) (p. 66).

The boundary mass flow is an implicit result of the flow simulation. This option is available for both single and multiphase simulations. When running multiphase simulations, the boundary condition is applied as if all phases are incompressible. For details, see [Multiphase Total Pressure in the CFX-Solver Theory Guide](#).

### 2.4.2.1.6. Stationary Frame Total Pressure (Stable)

This is the same as the `Total Pressure` condition in a stationary domain. In a rotating domain, the total pressure is based on stationary frame conditions.

### 2.4.2.1.7. Static Pressure

If you want to specify the static pressure at an inlet, you can use the `Static Pressure` option. You must specify the **Relative Static Pressure** and a flow direction. For details, see [Flow Direction \(p. 66\)](#).

The boundary mass flow is an implicit result of the flow simulation. For multiphase simulations, the static pressure is the same for all phases and the flow direction on a fluid dependent basis.

This setting is less stable than the total pressure condition because it weakly constrains the momentum that passes through the boundary. It is constrained only by transverse stresses. It is therefore a useful condition to obtain a fully developed velocity profile but is also less robust than the total pressure condition.

### 2.4.2.1.8. Fluid Velocity

This option is only available for an inhomogeneous multiphase simulation. When this option is selected, the **Mass and Momentum** information is set on a per fluid basis using `Normal Speed`, `Cartesian/Cylindrical Velocity Components` or `Mass Flow Rate`.

If the domain is porous, the velocity components that you specify are interpreted as true, not superficial.

## 2.4.2.2. Flow Direction

The flow direction can be specified as normal to the boundary, in terms of Cartesian components or in terms of cylindrical direction components. The direction constraint for the normal to boundary option is the same as that for the `Normal Speed` option.

If the flow direction is set as normal to the boundary, a uniform mass influx is assumed to exist over the entire inlet boundary. Also, if the flow direction is set using Cartesian or cylindrical components, the component normal to the boundary condition is ignored. Again, a uniform mass influx is assumed.

When using cylindrical direction components, a rotation axis must be set for stationary domains and can optionally be set for rotating domains. The axis used follows the same rules as when setting cylindrical velocity components. For details, see [Cylindrical Velocity Components \(p. 65\)](#).

For static pressure inlets, the flow direction can also be set to `Zero Gradient`, which implies that the velocity gradient perpendicular to the boundary is zero. This is the most appropriate option for fully developed flow. For best accuracy with this option, the mesh elements should be close to orthogonal perpendicular to the interface.

## 2.4.2.3. Turbulence

You should set reasonable values of either the turbulence intensity, or  $k$  and  $\varepsilon$  at an inlet boundary. Several options exist for the specification of turbulence quantities at inlets. However, unless you have absolutely no idea of the turbulence levels in your simulation (in which case, you can use the `Medium (Intensity = 5%)` option), you should use well chosen values of turbulence intensities and length scales.

Nominal turbulence intensities range from 1% to 5% but will depend on your specific application. The default turbulence intensity value of 0.037 (that is, 3.7%) is sufficient for nominal turbulence through a circular inlet, and is a good estimate in the absence of experimental data. The allowable range of turbulence intensity specification for an inlet boundary is from 0.001 to 0.1 (that is, 0.1% to 10%), corresponding to very low and very high levels of turbulence in the flow, respectively.

If you know roughly the level of incoming turbulence (that is, the intensity), you can specify this together with an appropriate length scale. For internal flows, a fraction of the inlet hydraulic diameter is usually a good approximation for the length scale. If you want to specify values of  $k$  and  $\varepsilon$  directly, then you can approximate incoming levels for internal flow by using the following relationships:

$$k = \frac{3}{2} I^2 U^2 \quad (2-1)$$

where  $I$  is the specified turbulence intensity.  $\varepsilon$  can then be approximated using:

$$\varepsilon = \frac{k^{3/2}}{0.3 D_h} \quad (2-2)$$

where  $D_h$  is the hydraulic diameter of the inlet. Strictly, these relationships are only applicable for a small inlet to a large domain and should be used with caution. In cases where the hydraulic diameter is not appropriate, and no experimental data is available, you should use uniform profiles for the turbulence quantities, based on mean flow characteristics.

For external flows, such as flow over an airfoil, relationships based on the geometric scale of the inlet boundary may not be appropriate. Therefore, you should consider using a length scale that is based on the size of the object over which flow is moving.

In turbulent simulations, you should also consider the nature of the flow upstream of the region of interest, and determine whether it would increase or decrease the magnitude of the turbulence intensity in the region you want to model.

The options available for turbulence at an inlet are:

#### **2.4.2.3.1. Default Intensity and Autocompute Length Scale**

The default turbulence intensity of 0.037 (3.7%) is used together with a computed length scale to approximate inlet values of  $k$  and  $\varepsilon$ . The length scale is calculated to take into account varying levels of turbulence. In general, the autocomputed length scale is not suitable for external flows.

#### **2.4.2.3.2. Intensity and Autocompute Length Scale**

This option enables you to specify a value of turbulence intensity but the length scale is still automatically computed. The allowable range of turbulence intensities is restricted to 0.1%-10.0% to correspond to very low and very high levels of turbulence accordingly. In general, the autocomputed length scale is not suitable for external flows.

#### **2.4.2.3.3. Intensity and Length Scale**

You can specify the turbulence intensity and length scale directly, from which values of  $k$  and  $\varepsilon$  are calculated.

#### **2.4.2.3.4. Low (Intensity = 1%)**

This defines a 1% intensity and a viscosity ratio  $\mu_t/\mu$  equal to 1.

#### **2.4.2.3.5. Medium (Intensity = 5%)**

This defines a 5% intensity and a viscosity ratio  $\mu_t/\mu$  equal to 10.

This is the recommended option if you do not have any information about the inlet turbulence.

#### **2.4.2.3.6. High (Intensity = 10%)**

This defines a 10% intensity and a viscosity ratio  $\mu_t/\mu$  equal to 100.

#### **2.4.2.3.7. Specified Intensity and Eddy Viscosity Ratio**

Use this feature if you want to enter your own values for intensity and viscosity ratio.

#### **2.4.2.3.8. k and Epsilon**

Specify the values of  $k$  and  $\varepsilon$  directly.

#### **2.4.2.3.9. Zero Gradient**

Use this setting for fully developed turbulence conditions.

### **2.4.2.4. Heat Transfer**

The inlet specification for the energy equation requires a value for the fluid temperature. You should note that ALL temperatures in ANSYS CFX are interpreted as absolute values.

#### **2.4.2.4.1. Static Temperature**

Specify the **Static Temperature** (thermodynamic) at an inlet.

#### **2.4.2.4.2. Total Temperature**

Specify the **Total Temperature** at an inlet. The static temperature is calculated from this value together with the specifications in the **Mass and Momentum** section.

#### **2.4.2.4.3. Stat. Frame Total Temperature**

This is the same as the **Total Temperature** condition, except for rotating domains. Total temperature is based on stationary frame velocities.

#### **2.4.2.4.4. Total Enthalpy**


Specify the **Total Enthalpy** at an inlet. The value of total enthalpy is considered to be the absolute value, including the reference state.

#### **2.4.2.4.5. Stationary Frame Total Enthalpy**

For rotating frames the **Stationary Frame Total Enthalpy** is specified at an inlet.

### 2.4.2.5. Thermal Radiation

The P1, Discrete Transfer and Monte Carlo Radiation models allow you to account for heating of a fluid due to thermal radiation from a boundary. For the P1 model, consider the case below where a hot wall that is outside of the fluid domain results in a radiation flux into the domain through the inlet boundary.



To model the radiation in this case, you would need to specify radiation at the inlet due to the hot wall using one of the three options described below. **Radiative Flux** into the domain for the Monte Carlo and Discrete Transfer models is specified on the **Sources** tab. For details, see [Sources \(Discrete Transfer and Monte Carlo models\)](#) (p. 69).

#### 2.4.2.5.1. Radiative Heat Flux (P1 Model)

If this option is selected, you should specify the heat flux through the boundary as a result of thermal radiation.

#### 2.4.2.5.2. Radiation Intensity (P1 Model)

The radiation intensity is the isotropic mean radiation intensity at the boundary.

#### 2.4.2.5.3. External Blackbody Temperature

This is the effective blackbody temperature of the boundary, for details see [External Blackbody Temperature](#) (p. 347). In the example above, you might set this value to the temperature of the hot wall. In this case, you would be assuming that the hot wall can be treated as a blackbody and that there is no absorption of radiation in the gap between the hot wall and the inlet.

#### 2.4.2.5.4. Local Temperature

For details, see [Local Temperature](#) (p. 347).

#### 2.4.2.5.5. Sources (Discrete Transfer and Monte Carlo models)

**Radiative Flux** into the domain for the Discrete Transfer and Monte Carlo radiation models is specified via the **Sources** tab for the boundary condition in CFX-Pre. The Monte Carlo model allows directional and isotropic radiation sources to be specified: the Discrete Transfer model only allows isotropic radiation sources.

### 2.4.2.6. Transported Additional Variables at an Inlet

You must specify the values of any transported Additional Variables at an inlet.

For porous domains, if you specify a concentration for an Additional Variable, the concentration is with respect to the volume of fluid, not the total volume.

### 2.4.3. Inlet (Supersonic)

Supersonic inlet boundaries can be specified where the local Mach number is everywhere greater than unity. Supersonic boundary conditions can only be imposed if the `Total Energy` model is employed, and the fluid is either an ideal gas, a real fluid, or a general fluid whose density is a function of pressure.

#### 2.4.3.1. Mass and Momentum

At a supersonic inlet boundary, the required settings depend on the choice of **Mass and Momentum** > **Option**, as shown in [Table 2.1: Supersonic Inlet Settings](#) (p. 70):

**Table 2.1 Supersonic Inlet Settings**

Mass and Momentum Option	Required Information
Normal Speed & Pressure	<ul style="list-style-type: none"> <li>Relative static pressure</li> <li>Normal speed</li> <li>Static or total temperature</li> </ul>
Normal Speed & Total Pressure	<ul style="list-style-type: none"> <li>Relative total pressure</li> <li>Normal speed</li> <li>Static or total temperature or total enthalpy</li> </ul>
Cart. Vel. & Pressure	<ul style="list-style-type: none"> <li>Cartesian velocity components</li> <li>Relative static pressure</li> <li>Static or total temperature</li> </ul>
Cart. Vel. & Total Pressure	<ul style="list-style-type: none"> <li>Cartesian velocity components</li> <li>Relative total pressure</li> <li>Static or total temperature or total enthalpy</li> </ul>
Cyl. Vel. & Pressure	<ul style="list-style-type: none"> <li>Relative static pressure</li> <li>Cylindrical velocity components</li> <li>Static or total temperature</li> </ul>
Cyl. Vel. & Total Pressure	<ul style="list-style-type: none"> <li>Relative total pressure</li> <li>Cylindrical velocity components</li> </ul>

Mass and Momentum Option	Required Information
	<ul style="list-style-type: none"> <li>• Static or total temperature or total enthalpy</li> </ul>
Static and Total Pressure	<ul style="list-style-type: none"> <li>• Relative static pressure</li> <li>• Relative total pressure</li> <li>• Total temperature</li> </ul>

### Note

For rotating domains, the total pressure is interpreted with respect to the stationary frame of reference.

## 2.4.4. Inlet (Mixed Subsonic-Supersonic)

The mixed inlet boundary condition allows both subsonic and supersonic inflow within a single boundary condition. The blending between the two flow regimes is based on the user-specified inflow velocity components—total pressure and total temperature, or static pressure and static temperature. In either case, the flow solver evaluates the local Mach number from the user-specified values.

The Mach number calculation can be based on the velocity component normal to the boundary condition or the full velocity components. By default the flow solver uses the component normal to the boundary condition. You can select which calculation you want via the parameter **Blend Mach Number Type**.

The following types of mixed inlets are supported. In both cases, the velocity type depends on the **Frame Type** parameter (**Stationary** or **Rotating**, described in *Cartesian Velocity Components* (p. 64) and *Cylindrical Velocity Components* (p. 65)):

- Velocity, static pressure, and static temperature are specified:
  - For  $Ma < 1$  (subsonic flow), this would result into the standard 'velocity specified' inlet. The user-specified pressure information is not used, but is computed as part of the iteration process.
  - For  $Ma > 1$  (supersonic flow), all user-specified data is used as it is done for the [supersonic inlet](#).
- Velocity, total pressure, and total temperature/total enthalpy are specified:
  - For  $Ma < 1$  (subsonic flow) this would result into the standard "total pressure and direction" inlet. The inflow direction is evaluated from the specified velocity components.
  - For  $Ma > 1$  (supersonic flow) all user-specified data is used as it is done for the [supersonic inlet](#).
  - The total pressure and total temperature depend on the frame type (that is, total pressure can be in either the stationary or the local frame, and the same applies to total temperature).

When you specify velocity, total pressure, and total temperature, the flow solver evaluates the static pressure and temperature directly from those values. The total enthalpy boundary condition is available only if the total energy is solved. In this case, no transformation of the specified energy is required.

**Note**

Static and total conditions for pressure and temperature cannot be mixed for real gases or gas mixtures with real gas components. This restriction does not apply to gases and gas mixtures that obey the Ideal Gas law.

**2.4.4.1. Supported Material Types**

Mixed inlets can only be imposed if the `Total Energy` model is employed, and if the fluid is compressible. This includes the ideal gas model, NASA materials, Redlich Kwong model, RGP file materials and materials with a CEL equation of state, where density is a function of pressure.

Flows that use the wet real gas model (Homogeneous binary mixtures) are currently not supported.

**2.4.4.2. Mass and Momentum**

At a mixed inlet, all quantities must be specified. `Static` or `Total Pressure`, velocity components and `Static` or `Total Temperature` or `Total Enthalpy` are required. Whenever the `Total Pressure` option is selected, the total pressure is in the stationary frame for rotating domains.

The following options are supported:

**2.4.4.2.1. Cartesian Velocity Components and (Total) Pressure**

For the mixed flow regime inlet boundary, the Cartesian components of velocity, together with a value for the **Relative Static** or **Relative Total Pressure**.

**2.4.4.2.2. Cylindrical Velocity Components and (Total) Pressure**

For the mixed flow regime inlet boundary, the cylindrical components of velocity, together with a value for the **Relative Static** or **Relative Total Pressure** (Relative to the domain reference pressure).

**2.4.4.2.3. Normal Speed and (Total) Pressure**

For the mixed flow regime inlet boundary, the normal speed, together with a value for the **Relative Static** or **Relative Total Pressure**. The flow solver evaluates the velocity direction based on the local normal to the boundary condition.

**2.4.4.3. Heat Transfer****2.4.4.3.1. Static Temperature**

The `Static Temperature` is specified at the mixed inlet boundary.

**2.4.4.3.2. Total Temperature**

The `Total Temperature` is specified at the mixed inlet boundary. The static temperature is computed from the specified `Total Temperature`. The flow solver will apply stationary frame total temperature if the domain is rotating.

### 2.4.4.3.3. Total Enthalpy

The `Total Enthalpy` is specified at the mixed inlet boundary. The flow solver will apply stationary frame total enthalpy if the domain is rotating.

The total enthalpy boundary condition is available only if the total energy is solved. The total enthalpy boundary condition is a 'natural' boundary condition for mixed subsonic-supersonic flow as you directly specify the total energy (that is, total enthalpy) value at the inlet. Static temperature and total temperature, on the other hand, have to be converted to total enthalpy before they can be used as a boundary condition.

### 2.4.4.4. Initial Guess Recommendation

Special care is required to specify the initial guess for a simulation that involves a mixed flow regime inlet. It is strongly suggested to use the `Automatic with Value` option rather than the `Automatic` option, especially if the flow near the mixed inlet is known to be locally supersonic, which locally imposes a large difference between the static and total conditions.

Flow solver robustness and convergence will be much better behaved if the flow field near the inlet is initialized as if it would be totally supersonic.

## 2.5. Outlet

An outlet boundary condition is used where the flow is predominantly directed out of the domain. The hydrodynamic boundary condition specification (that is, those for mass and momentum) for a subsonic outlet involves some constraint on the boundary static pressure, velocity or mass flow. For all other transport equations, the outlet value of the variable is part of the solution.

---

### Important

If you accidentally set the velocity at an outlet to be flowing into the domain, the outlet will behave as an inlet: *wall building will not be turned on.*

Information on setting outlet values in CFX-Pre is available. For details, see [Boundary Details: Outlet in the CFX-Pre User's Guide](#).

Information on the mathematical implementation of an outlet boundary condition is available.

- [Outlet \(Subsonic\) in the CFX-Solver Theory Guide](#)
- [Outlet \(Supersonic\) in the CFX-Solver Theory Guide](#)

### 2.5.1. Mass and Momentum

Information on the mathematical treatment of mass and momentum for an outlet boundary condition is available in the [Mass and Momentum](#) subsection of [Outlet \(Subsonic\) in the CFX-Solver Theory Guide](#).

#### 2.5.1.1. Static Pressure

The **Relative Pressure** is maintained at a fixed specified value over the outlet boundary. The flow direction is an implicit result of the computation.

### **2.5.1.2. Normal Speed**

Specify the magnitude of the flow velocity at the outlet. The direction of the flow is taken to be locally normal to the outlet boundary surface.

### **2.5.1.3. Cartesian Velocity Components**

The boundary velocity components are specified. Care should be taken to ensure that a non-zero resultant is directed out of the domain.

### **2.5.1.4. Cylindrical Velocity Components**

The components and axis are specified in the same way as for an inlet. For details, see [Cylindrical Velocity Components](#) (p. 65). The resultant flow must be directed out of the domain.

---

#### **Note**

The last three options can cause severe robustness problems if the problem setup causes a significant departure from the specified velocity distribution anywhere the flow is approaching the outlet. In this case, you may have no choice but to use one of the other options.

### **2.5.1.5. Average Static Pressure**

When this option is selected, the static pressure is allowed to locally vary on the outlet boundary such that the average pressure is constrained in a specified manner. In all cases, the flow direction at the outlet is an implicit result of the computation. For details, see [Boundary Conditions in the CFX-Solver Theory Guide](#).

The following averaging options are available:

#### **2.5.1.5.1. Average Over Whole Outlet**

This is the most commonly used option. The average constraint is applied by comparing the area weighted pressure average over the entire outlet to the user-specified value. The pressure profile at the outlet is shifted by this difference such that the new area weighted pressure average will be equal to the user-specified value. The flow direction is an implicit result of the computation.

Note that the specified average pressure may be a pressure profile. If it is, the pressure profile will be averaged and it is this profile average which will be enforced.

#### **2.5.1.5.2. Average Above Specified Radius**

The area weighted average of pressure above the specified radius is used as the comparison to the user-specified value (instead of the area weighted average over the entire outlet). The pressure profile is then shifted by the difference between these two values. The radius is calculated as the distance from the local axis of rotation (specified on the boundary for stationary domains) or the domain rotation axis for rotating domains.

The area weighted average of pressure at the outlet in the desired region may not be identical to the specified average static pressure, but it should be quite close. If the flow solver has built artificial walls on the boundary condition the actual average may differ more from the specified value than when no artificial walls are built.

### 2.5.1.5.3. Average Below Specified Radius

This is the same as **Average Above Specified Radius**, except that the region below the specified radius is used to obtain the area weighted average.

### 2.5.1.5.4. Circumferential

In this case, the average pressure is constrained within circumferential bands defined by either a local rotation axis or the domain rotation axis. The circumferential bands are either radial or axial depending on the geometry. The average pressure profile can be set as a constant, CEL analytic expression, profile function or user defined function.

There is no restriction on how the pressure profile can spatially vary. The number of bands is automatically determined by the flow solver using the maximum number of bands that the underlying CFD mesh on the outlet will allow. Every band contains enough mesh to calculate a circumferential average. The flow solver will print a diagnostic telling you how many bands it is using. It is possible to use less bands than the value determined by the flow solver, but not more. The number of bands can be modified by setting the **Maximum Number of Circumferential Bands** text box.

**Pressure Profile Blend** is a factor that blends between the specified pressure profile and a floating pressure profile where only the average is constrained. For a **Pressure Profile Blend** factor of zero the specified pressure is used only to enforce the average pressure. This allows a transverse pressure profile to develop according to upstream influences, which is much less reflective than specifying the pressure profile itself. For some flows, setting only the average pressure does not constrain the flow enough; in this case, a small amount of blending, the default value of 0.05, or 5%, may be appropriate.

### 2.5.1.5.5. Radial Equilibrium

In the case of Radial Equilibrium, the averaged static pressure is constrained within radial circumferential bands defined by either a local rotation axis or the domain rotation axis. The band-averaged pressure satisfies radial equilibrium between the radial pressure gradient and the centrifugal force calculated using the band-averaged density and circumferential velocity. Integrating this relationship gives pressure values for each band and requires a user-specified static pressure at a radial reference position as a starting point for the integration. Three different options are available for specifying the radial reference position:

- **Option** = Specified Radius (you must specify the **Specified Radius** parameter)
- **Option** = Minimum Radius (the radius is automatically calculated by the solver)
- **Option** = Maximum Radius (the radius is automatically calculated by the solver).

The solver generates the circumferential bands the same way as for the circumferential averaged pressure option (see *Shift Pressure with Circumferential Pressure Averaging* (p. 77)), except that, in this case, bands are allowed to be oriented only in the radial direction. As for all pressure averaging options, pressure profile blending can be applied to this boundary condition.

### 2.5.1.6. Mass Flow Rate (Bulk Mass Flow Rate for Multiphase)

For single phase flows, you may specify a value for the total mass flow rate through the outlet boundary. The local velocity across the outlet boundary is part of the solution.

The `Mass Flow` update option should be chosen from one of three methods depending on the type of flow at the outlet:

Information on the mathematical treatment of mass flow rate for an outlet boundary condition is available in [Mass Flow Rate: Scale Mass Flows](#), [Mass Flow Rate: Shift Pressure with or without Pressure Profile](#) and [Mass Flow Rate: Shift Pressure with Circumferential Pressure Averaging in Outlet \(Subsonic\)](#) in the *CFX-Solver Theory Guide*.

### 2.5.1.6.1. Scale Mass Flows

This is the default option in ANSYS CFX. The mass flow distribution is a function of the mass flow just upstream of the outlet boundary. The specified mass flow is enforced at each timestep. The pressure distribution which results is an implicit part of the simulation and is not constrained by the boundary condition.

### 2.5.1.6.2. Constant Flux

This specifies a constant mass flow distribution ( $\rho U_{\text{normal}}$  is the same across the entire outflow boundary). This option is most useful when the flow is highly tangential relative to the outlet. Under these circumstances, it is difficult to determine the mass flow distribution when the `Scale Mass Flows` or `Shift Pressure` options are used. This is because the mass distribution just upstream of and normal to the outlet is a small component relative to the tangential component of the mass flow. Conversely, the `Constant Flux` option should not be used if the mass flow at the outlet is not highly tangential. This would adversely affect the flow upstream of the boundary where the mass flow distribution is not uniform.

### 2.5.1.6.3. Shift Pressure with or without Pressure Profile

This option behaves similarly to the `Scale Mass Flows` option, except that you have the additional flexibility of constraining the pressure profile over the entire boundary. If you constrain the pressure profile, the solver will compute the shift in pressure level (of your profile) that is necessary to enforce the specified mass flow rate.

If you specify no constraint on the profile, then the static pressure profile floats and becomes an implicit result of the solution. In this case, the flow solver still computes the necessary shift in the pressure level that exactly constrains the mass flow rate to your specified value. The shift value works out to the average pressure that enforces the specified mass flow rate. This option will behave almost identically to `Scale Mass Flows`.

The profile is specified by setting the **Pressure Profile** text box. This should be a value or expression that describes the pressure profile at the outlet and is entered in units of pressure. The absolute values that describe the pressure profile are irrelevant because the pressure level at the outlet is part of the solution. For example, specifying a constant pressure profile of 0 Pa is the same as specifying a constant pressure profile of 101325 Pa. When the profile is not constant (specified via an expression), only the relative variation in the profile is important.

The **Pressure Profile Blend** is a measure of enforcement of the specified pressure profile to the outlet boundary. For example, using a blend of 0.0 specifies no enforcement of the pressure profile. In this case, the behavior of the **Scale Mass Flows** method is recovered. A blend of 1.0 fully imposes the pressure profile shape (but not the level) as well as the mass flow leaving the domain. The mass flow distribution is dependent on the mass flow just upstream of the outlet boundary. For a blend,  $\theta$  between 0 and 1, the pressure is equal to:

$$\theta P_{\text{profile}} + (1 - \theta) P_{\text{floating}} \quad (2-3)$$

where  $P_{\text{profile}}$  is the pressure value calculated from the user-specified profile and  $P_{\text{floating}}$  is derived from the value just upstream of the outflow boundary.

The **Shift Pressure** method is generally useful in two situations:

- If the pressure profile at the outlet is known.
- If the pressure shape is not known, but the implicit pressure profile shape computed using the `Scale Mass Flows` option is not acceptable.

#### 2.5.1.6.4. Shift Pressure with Circumferential Pressure Averaging

A further extension of the shift pressure feature for mass flow outlets allows the local relative static pressure distribution to vary within circumferential bands, similar to the average pressure outlet. In this case, the average profile is given by the **Pressure Profile** parameter. Again, there is no restriction on how the pressure profile can spatially vary. If a spatially varying profile is used, the CFX-Solver will automatically calculate the average value of the expression within each band, allowing easy switching between a mass flow outlet with or without averaging.

#### 2.5.1.7. Degassing Condition (Multiphase only)

Degassing boundary conditions are used to model a free surface from which dispersed bubbles are permitted to escape, but the liquid phase is not. They are useful for modeling flow in bubble columns.

When **Degassing Boundary Condition** is selected as the **Flow Specification** of an outlet, the continuous phase and any dispersed solid phases that may be present see this boundary as a free-slip wall and do not leave the domain. Dispersed fluid phases and Lagrange particles see this boundary as an outlet. However, the outlet pressure is not specified. Instead, a pressure distribution is computed on this fixed-position boundary, and can be interpreted as representing the weight of the surface height variations in the real flow.

Because the **Degassing Boundary Condition** does not specify a pressure value, a fixed pressure reference point will be set automatically for a domain with an incompressible flow with degassing boundaries, but no pressure boundaries.

#### 2.5.1.8. Fluid Velocity (Multiphase only)

This option is only available for an inhomogeneous multiphase simulation. When this option is selected, the **Mass and Momentum** information is set on a per fluid basis using `Cartesian` or `Cylindrical Velocity Components`.

#### 2.5.1.9. Supercritical (Multiphase only)

Supercritical free surface flow means that the liquid velocity exceeds the local wave velocity, and nothing needs to be set at the outlet (analogous to the supersonic condition for compressible flow). However, for stability purposes, **Relative Pres. in Gas** (that is, Relative Pressure in Gas: the pressure in the gas phase above the free surface interface) needs to be set. Note that transcritical free surface flows often have two solutions: one subcritical at the outlet and the other supercritical. Because of this, you may sometimes need to start with a `Static Pressure` or `Average Static Pressure` outlet condition based on a hydrostatic condition which forces the elevation into the supercritical regime.

## 2.5.2. Turbulence, Heat Transfer, and Additional Variables

For scalar quantities, the CFX-Solver does not require any variable values to be specified. The variables are obtained implicitly from the solution information on the boundary nodes.

## 2.5.3. Thermal Radiation

This is the same as specifying **Thermal Radiation** at an inlet. For details, see [Thermal Radiation \(p. 69\)](#).

## 2.5.4. Mesh Motion

Mesh motion can occur on outlet boundaries in domains where **Mesh Deformation** has been activated for the domain. (See [Mesh Deformation in the CFX-Pre User's Guide](#) for information about activating mesh deformation for the domain.) Note that solution errors will be introduced if any of the specified motion is normal to the boundary faces. For details, see [Mesh Deformation \(p. 3\)](#).

## 2.5.5. Outlet (Supersonic)

For a supersonic outlet, the flow is not influenced at all by downstream conditions. All values of dependent variables, with the exception of radiation intensity, are extrapolated from upstream, and the constant gradient constraint is not imposed. The specification of a supersonic outlet boundary condition, therefore, requires no accompanying values unless a **Thermal Radiation** model is used. For details, see [Thermal Radiation \(p. 69\)](#).

ANSYS CFX will behave unpredictably if part or all of fluid exiting the region assigned a supersonic outlet is subsonic. The CFX-Solver might fail to converge or diverge in this situation. To correct this, you should move the outlet to a location where the flow is supersonic over the entire boundary, or move it to a subsonic location and specify a different outlet boundary condition.

## 2.6. Opening

An opening can be used at a boundary where the flow is into and/or out of the domain. The opening boundary condition type is only available for subsonic boundaries.

Information on setting the values for an opening in CFX-Pre is available. For details, see [Boundary Details: Opening in the CFX-Pre User's Guide](#).

Information on the mathematical implementation of an opening boundary condition is available in [Opening in the CFX-Solver Theory Guide](#).

### 2.6.1. Mass and Momentum

#### 2.6.1.1. Cartesian Velocity Components

The Cartesian components of the flow velocity at the opening are specified in the same way as for an inlet. For details, see [Cartesian Velocity Components \(p. 64\)](#). The components can be specified such that both inflow and outflow occur over different regions of the boundary.

### 2.6.1.2. Cylindrical Velocity Components

The components and axis are specified in the same way as for an inlet. For details, see [Cylindrical Velocity Components](#) (p. 65). The components can be specified such that both inflow and outflow occur over different regions of the boundary.

### 2.6.1.3. Opening Pressure and Direction

When the flow direction is into the domain, the pressure value is taken to be total pressure based on the normal component of velocity. When it is leaving the domain, it is taken to be relative static pressure.

This option also requires that the **Flow Direction** is specified, and is used if the flow is into the domain. For details, see [Flow Direction](#) (p. 66).

This is the most robust and stable setting for a pressure specified opening because it puts a constraint on the momentum transported through the boundary condition.

This option is available for both single and multiphase simulations. When running multiphase simulations, the total pressure is applied as if all phases are incompressible. For details, see [Multiphase Total Pressure in the CFX-Solver Theory Guide](#).

### 2.6.1.4. Static Pressure and Direction

The pressure value is taken to be static pressure for both the inflow and outflow. This option also requires that the **Flow Direction** is specified, and is used if the flow is into the domain. For details, see [Flow Direction](#) (p. 66).

If the flow is coming into the domain, this setting is the least stable because it does not constrain the momentum allowed to flow through the boundary. In this case, any momentum flow satisfies the static pressure condition, which can cause severe robustness problems. Always consider a pressure-specified opening before using this option.

### 2.6.1.5. Entrainment

When `Entrainment` is selected, the **Pressure Option** check box becomes available. When the latter is selected, you can set the sub-option to `Static Pressure` or `Opening Pressure`.

- Entrainment with the `Static Pressure` option is similar to the `Static Pressure and Direction` option, except that the direction is obtained by enforcing the velocity gradient perpendicular to the boundary to be zero.
- Entrainment with the `Opening Pressure` option has a similar behavior to a pressure-specified opening and has similar stability and robustness but does not require that a flow direction is specified. Instead, the flow solver locally calculates the flow direction based on the direction of the velocity field. When the flow direction is into the domain, the pressure value is taken to be total pressure based on the normal component of velocity. When it is leaving the domain, it is taken to be relative static pressure.

When the **Pressure Option** check box is not selected, the `Static Pressure` sub-option takes effect by default.

The `Entrainment` option can be quite useful for situations in which the main flow tends to pull fluid through the boundary where the flow direction is unknown.

### 2.6.1.6. Fluid Velocity

This option is only available for an inhomogeneous multiphase simulation. When this option is selected, the **Mass and Momentum** information is set on a per-fluid basis using `Normal Speed`, `Cartesian Velocity Components` or `Cylindrical Velocity Components`.

### 2.6.2. Loss Coefficient

You can optionally specify a **Loss Coefficient** which can be used to model the pressure drop across a screen or other planar resistance at the opening. The pressure drop is calculated using:

$$\Delta p_{\text{loss}} = \frac{1}{2} f \rho U_n^2 \quad (2-4)$$

where  $f$  is a specified **Loss Coefficient** and  $U_n$  is the normal component of velocity at the opening boundary location. When the opening behaves as an inlet, the pressure drop is applied *before* flow enters the domain. When the opening behaves as an outlet, the pressure drop is deemed to occur *after* the flow has left the domain. This results in the following behavior:

#### 2.6.2.1. For a Pressure-Specified Opening

For outflow, the boundary static pressure is the specified **Relative Pressure**, plus a pressure loss, if specified.

For inflow, the boundary static pressure is the specified **Relative Pressure** converted from **Total to Static Pressure** using the normal component of the velocity, minus a pressure loss, if specified.

#### 2.6.2.2. For a Static-Pressure-Specified Opening

For outflow, the boundary static pressure is the specified **Relative Pressure**, plus a pressure loss, if specified.

For inflow, the boundary static pressure is the specified **Relative Pressure**, minus a pressure loss, if specified.

### 2.6.3. Heat Transfer

Specify the **Heat Transfer** as for an inlet boundary condition. This value is only used for the inflow portion of the opening. You can specify either:

- Static Temperature
- Opening Temperature

The opening temperature is similar to the `Total Temperature`, but the dynamic component is based only on the normal component of velocity.

### 2.6.4. Turbulence

Specify the turbulence quantities as for an inlet boundary condition. For details, see [Turbulence \(p. 66\)](#). These values are only used for the inflow portion of the opening.

## 2.6.5. Thermal Radiation

This is the same as specifying **Thermal Radiation** at an inlet. For details, see [Thermal Radiation](#) (p. 69).

## 2.6.6. Additional Variables

Specify the values of any Additional Variables as for an inlet boundary condition. These values are only used for the inflow portion of the opening. For flow out of the domain, the CFX-Solver calculates the values of Additional Variables from the solution field.

## 2.6.7. Mesh Motion

Mesh motion can occur on opening boundaries in domains where **Mesh Deformation** has been activated for the domain. (See [Mesh Deformation in the CFX-Pre User's Guide](#) for information about activating mesh deformation for the domain.) Note that solution errors will be introduced if any of the specified motion is normal to the boundary faces. For details, see [Mesh Deformation](#) (p. 3).

## 2.7. Wall

Walls are solid (impermeable) boundaries to fluid flow. Walls allow the permeation of heat and Additional Variables into and out of the domain through the setting of flux and fixed value conditions at wall boundaries.

Walls are the default boundary condition in CFX-Pre for fluid-world and solid-world regions; any of these regions that are not part of an existing boundary condition will remain in a default wall boundary when the CFX-Solver input file is written. For details, see [Default Boundary Condition in the CFX-Pre User's Guide](#).

The treatment of wall boundary conditions for turbulent flow is the same as for laminar flow, except for no-slip conditions. For details, see [Wall Function in the CFX-Pre User's Guide](#).

Information on setting boundary conditions at walls in CFX-Pre is available in [Boundary Details: Wall in the CFX-Pre User's Guide](#).

Additional mathematical information on the wall boundary condition is available in [Wall in the CFX-Solver Theory Guide](#).

Additional information on wall boundaries in multiphase flow is available in [Wall Boundaries in Multiphase](#) (p. 225).

### 2.7.1. Mass and Momentum

The following options are available for modeling the influence of a wall boundary on mass and momentum:

- [No Slip Wall](#) (p. 82)
- [Free Slip Wall](#) (p. 83)
- [Finite Slip Wall](#) (p. 83)
- [Specified Shear](#) (p. 83)
- [Counter-rotating Wall](#) (p. 83)
- [Rotating Wall](#) (p. 83)

For additional details, see [Wall in the CFX-Solver Theory Guide](#).

### 2.7.1.1. No Slip Wall

This is the most common type of wall boundary condition implementation. The fluid immediately next to the wall assumes the velocity of the wall, which is zero by default. Non-zero wall velocities are created in two ways: by explicitly setting a wall velocity and/or by activating mesh deformation.

Cartesian or cylindrical wall velocity components can be set to emulate wall motion even when mesh motion has not been activated. When using `Cartesian Velocity Components`, the velocity is always in relation to the local (relative) frame of reference (that is, relative to the rotating frame in a rotating domain). When using `Cylindrical Velocity Components`, an axis for the cylindrical coordinate system must be specified in one of two ways:

- You can select the axis of the cylindrical coordinate system for the boundary condition (called the **Rotation Axis**) as an axis of the global coordinate frame, `Coord 0`.
- You can specify **Rotation Axis From** and **Rotation Axis To** points. These are the two end points of the axis. The global coordinate system must be used to specify these points. The positive z component of the cylindrical coordinates is in the direction of the vector from the **Rotation Axis From** point to the **Rotation Axis To** point.

For rotating domains, the axis will default to the domain axis of rotation.

---

#### Note

Only the component of the specified wall velocity that is tangent to the wall is applied. Mesh motion should be used if the desired wall velocity is normal to the wall, or has a component normal to the wall.

Mesh motion can occur on wall boundaries in domains where **Mesh Deformation** has been activated for the domain. (See [Mesh Deformation in the CFX-Pre User's Guide](#) for information about activating mesh deformation for the domain.) If this is the case, the wall velocity (as set above) can be made relative to the boundary frame or to the mesh motion occurring on the boundary. When the wall velocity is made relative to the boundary frame, only the specified wall velocity is assumed by the flow. When the wall velocity is made relative to the mesh motion, the velocity due to mesh motion is super-imposed on the specified wall velocity. The default behavior is that the wall velocity is relative to the boundary frame when `Stationary` or `Unspecified` mesh motion boundary conditions are used, and relative to the mesh motion when `Specified Location` or `Specified Displacement` boundary conditions are used. For details, see [Mesh Deformation \(p. 3\)](#).

For example, in a piston-cylinder simulation, a zero velocity, no slip condition would be applied to all walls. The wall velocity would typically be made relative to the mesh motion for the moving piston boundary, and relative to the boundary frame for the cylinder side-walls. This would ensure that the fluid is properly affected by the motion of the piston, and that it is not dragged by the motion of the mesh on the cylinder side-walls.

---

#### Note

In a multiphase case, if one fluid uses a No Slip Wall, other fluids must see the same wall velocity or use the Free Slip condition.

### 2.7.1.2. Free Slip Wall

Free-slip, where the shear stress at the wall is zero ( $\tau = 0$ ), and the velocity of the fluid near the wall is not retarded by wall friction effects. In a multiphase case, if one fluid uses a `Free Slip` wall, other fluids can use any wall influence condition.

### 2.7.1.3. Finite Slip Wall

The Finite Slip Wall option is available only for laminar flows. This option causes the fluid to “slip” at the wall when the wall shear stress is greater than a critical stress,  $\tau_c$ . A typical use of the finite slip wall option is to simulate the flow of non-Newtonian fluid. When the wall shear stress is greater than the critical stress, the wall velocity at the edge of the shear-thinning boundary layer is computed without resolving it directly. ANSYS CFX simulates the slip by using a moving wall with the wall speed computed as follows:

$$U_w = 0, \tau \leq \tau_c$$

$$U_w = U_s \left[ \frac{\tau - \tau_c}{\tau_n} \right]^m \exp\left(-\frac{BP}{\tau_n}\right), \tau > \tau_c \quad (2-5)$$

where  $U_s$  is the slip speed,  $\tau_n$  is a normalizing stress,  $m$  is a positive power,  $B$  is a pressure coefficient, and  $P$  is the pressure.

### 2.7.1.4. Specified Shear

The `Specified Shear` option enables you to specify the shear stress components on the fluid. The free-slip option is the case of a specified shear equal to 0. The current implementation removes any normal component of the user-specified shear stress.

For turbulent flows, the specified shear is applied directly; no considerations about turbulent wall functions are taken into account.

### 2.7.1.5. Counter-rotating Wall

For domains specified with a **Rotating Frame of Reference**, a `Counter-rotating Wall` can be specified. The wall boundary is assumed to be stationary with respect to the stationary frame, essentially in counter-rotation with the rotating fluid and uses a no slip condition. In a multiphase case, if one fluid uses a `Counter-rotating Wall`, other fluids must use the same condition or the `Free Slip` condition.

### 2.7.1.6. Rotating Wall

This option applies to both stationary and rotating domains and enables the wall to rotate with a specified angular velocity. The angular velocity is always in relation to the local (relative) frame of reference (that is, relative to the rotating frame in a rotating domain). An axis must be specified in a stationary domain and can optionally be specified in a rotating domain. Axis specification follows the same rules as for cylindrical velocity component inlets. For details, see [Cylindrical Velocity Components \(p. 65\)](#)

## 2.7.2. Wall Roughness

For simulations using turbulence models, you can describe the wall surface as being smooth or rough. For rough walls, the equivalent sand-grain roughness is required as input parameter. The details of the rough wall treatment for turbulence models based on the  $\varepsilon$  and  $\omega$  – equation can be found in [Treatment of Rough Walls in the CFX-Solver Theory Guide](#).

This option is not available for the `Free Slip` wall boundary condition, or when a turbulence model is not used (that is, Laminar).

## 2.7.3. Wall Contact Model

For details, see [Area Contact Model](#) (p. 226).

## 2.7.4. Wall Adhesion

The **Wall Adhesion** option is available for free surface flows when surface tension forces are modeled. For details, see [Surface Tension](#) (p. 231).

## 2.7.5. Heat Transfer

### 2.7.5.1. Adiabatic

The heat flux across the wall boundary is zero (that is, insulated). When radiation is included, the total heat flux is zero:

$$q_w = 0 = q_{\text{rad}} + q_{\text{cond}} \quad (2-6)$$

For details, see [CFX-Solver Output File \(Radiation Runs\)](#) in the *CFX-Solver Manager User's Guide*.

### 2.7.5.2. Fixed Temperature

The wall boundary is fixed at a specified temperature  $T_w$ . The heat flux into the domain is calculated for laminar flows from the temperature gradient at the wall, and for turbulent flows by:

$$q_w = h_c (T_w - T_{nw}) \quad (2-7)$$

where  $T_{nw}$  is the near-wall temperature and  $h_c$  involves the use of turbulent wall functions. For details, see [Heat Flux in the Near-Wall Region](#) in the *CFX-Solver Theory Guide*.


### 2.7.5.3. Heat Flux and Wall Heat Flux

A heat flux is specified across the wall boundary. A positive value indicates heat flux into the domain. For multiphase cases, when the bulk heat flux into both phases is set this option is labeled Wall Heat Flux instead of Heat Flux. When set on a per fluid basis, this option is labelled Heat Flux.

### 2.7.5.4. Heat Transfer Coefficient and Wall Heat Transfer Coefficient

In this case, the heat flux at a wall boundary is implicitly specified using an external heat transfer coefficient,  $h_c$ , and an outside or external boundary temperature,  $T_o$ . This boundary condition can be used to model thermal resistance outside the computational domain, as in the diagram below:

**Figure 2.4 Heat Transfer**



The heat flux at the **Heat Transfer Coefficient** wall is calculated using:

$$q_w = h_c (T_o - T_w) = q_{rad} + q_{cond} \quad (2-8)$$


where  $T_o$  is the specified outside or external boundary temperature.  $T_w$  is the temperature at the wall (edge of the domain), which for turbulent flows is calculated from a surface energy balance and for laminar flows is the boundary temperature field calculated by the solver. The heat flux  $q_w$  is the total heat flux from conduction and radiation when radiation is modeled. For details, see [CFX-Solver Output File \(Radiation Runs\) in the CFX-Solver Manager User's Guide](#).

### 2.7.5.5. ANSYS Multi-field

The wall temperature distribution or wall heat flow distribution is fixed according to the data received from the ANSYS Multi-field solver in regions that match ANSYS side, whereas adiabatic condition is imposed in regions that do not match ANSYS side. For more information about simulations involving Fluid Structure Interaction (FSI) and the ANSYS Multi-field, refer to [Coupling CFX to an External Solver: ANSYS Multi-field Simulations](#) (p. 389) and the [Mechanical APDL Coupled-Field Analysis Guide](#).

### 2.7.5.6. Results File Variables for Post-Processing

The results file contains several wall-only variables when the Thermal or Total Energy heat transfer models are active. [Figure 2.5](#) (p. 86) depicts the variables that can be written at a wall boundary condition.

**Figure 2.5 Variables at a Wall Boundary**

### 2.7.5.7. Wall Temperature ( $T_w$ )

This is the hybrid temperature field at a wall boundary condition. For Fixed Temperature walls, the wall temperature is the specified value  $T_w$ . For all other heat transfer boundary conditions, the wall temperature is backed out from turbulent wall functions when running a turbulent flow model. For laminar flow modelling the wall temperature is just the local fluid temperature at the vertex adjacent to the wall.

When running the inhomogeneous heat transfer model, this variable is written per fluid. Similarly, for a porous solid, this variable is written for the solid phase as well.

### 2.7.5.8. Wall Heat Flux and Heat Flux ( $q_w$ )

Wall Heat Flux is the total heat flux into the domain, including convective and radiative contributions. There are also variables called Wall Convective Heat Flux and Wall Radiative Heat Flux for the separate convective and radiative contributions.

When running the inhomogeneous heat transfer model, this variable is written per fluid. Similarly, for a porous solid, this variable is written for the solid phase as well.

Heat Flux is also the total heat flux into the domain, including convective and radiative contributions. This variable is different from the Wall Heat Flux in several ways:

- There are no equivalent separate variables for the convective and radiative components.
- It can be plotted local to a specific boundary condition. Wall Heat Flux contains contributions from adjacent boundary conditions. For example, edge values of Heat Flux on a heat-transfer coefficient boundary are not affected by being adjacent to an adiabatic wall.
- It is computed on boundary vertices by the post processor directly from the convective energy flows written to the results file by the CFX-Solver. This is sometimes advantageous over the Wall Heat Flux variable in that it eliminates the arithmetic averaging procedure used by the CFX-Solver to compute Wall Heat Flux at each boundary vertex from the faces adjacent to each vertex. Thus Heat Flux should be used in preference to Wall Heat Flux when this is possible.

In the CFX-Solver the heat flux variables available for use in expressions are just `Wall Heat Flux` and `Wall Convective Heat Flux`. These variables are based on energy flows and so are equivalent to the variable `Heat Flux` and its convective component in the post-processor.

### 2.7.5.9. Wall Heat Transfer Coefficient ( $h_c$ ) and Wall Adjacent Temperature ( $T_{nw}$ )

These two variables are calculated as part of the convective heat transfer at a wall.

Laminar flow model:

- Wall Heat Transfer Coefficient,  $h_c$ , is calculated by rearranging the expression for the convective heat flux in [Equation 2-7 \(p. 84\)](#) and setting the wall temperature as described above.
- Wall Adjacent Temperature,  $T_{nw}$ , is the average temperature in the element adjacent to the wall.

Turbulent flow model:

- Wall Heat Transfer Coefficient is given by the thermal wall functions. The theory of thermal wall functions can be found at [Heat Flux in the Near-Wall Region in the CFX-Solver Theory Guide](#).
- For turbulent flow without viscous work active, the Wall Adjacent Temperature is the conservative (solved for) temperature in the control volume adjacent to the wall. On the other hand, if viscous work is active, [Equation 2-251 in the CFX-Solver Theory Guide](#), can be rearranged as:

$$q_w = \frac{\tau_w c_p}{Pr_t U} \left( T_w - T_f - \frac{Pr_t U^2}{2c_p} \right) \quad (2-9)$$

Therefore, with viscous work active, the Wall Adjacent Temperature becomes:

$$T_{nw} = T_f + \frac{Pr_t U^2}{2c_p} \quad (2-10)$$

For details of the treatment of heat transfer at a wall for turbulent flows, refer to the discussion of [Heat Flux in the Near-Wall Region in the CFX-Solver Theory Guide](#).

### 2.7.5.10. Wall External Heat Transfer Coefficient and Wall External Temperature

These are the specified values when running a heat transfer coefficient and external temperature boundary condition.

Additional information for multiphase cases is available. For details, see [Wall Boundaries in Multiphase \(p. 225\)](#).

## 2.7.6. Mesh Motion

All options for **Mesh Motion** are available for wall boundaries in domains where **Mesh Deformation** has been set to `Regions of Motion Specified`. For details, see [Mesh Deformation \(p. 3\)](#).

## Note

Unlike all other boundary condition values in ANSYS CFX, which are set on mesh faces, **Mesh Motion** boundary values are applied to all *nodes* on the boundary region. Care is therefore required to ensure that consistent **Mesh Motion** boundary conditions are applied at nodes that are common to adjacent boundary regions. For example, a `Specified Displacement` condition on one boundary region must produce no displacement for nodes that are common to adjacent boundary regions where `Stationary` conditions have been applied.

## 2.7.7. Thermal Radiation

### 2.7.7.1. Opaque

Set an **Emissivity**. A blackbody exhibits perfect emission and has an **Emissivity** value of 1. For details, see *Opaque* (p. 341).

### 2.7.7.2. Sources

For the `Discrete Transfer` and `Monte Carlo` models, radiation sources can be specified at wall boundaries. For details, see *Sources (Discrete Transfer and Monte Carlo models)* (p. 69).

## 2.7.8. Equations Governing Additional Variables

The equations governing the behavior of Additional Variables are analogous to those for heat transfer, and the specification of boundary conditions at the wall are, therefore, very similar. For details, see *Heat Transfer* (p. 84).

## 2.7.9. Additional Coupling Sent Data

This setting is available for ANSYS Multi-field runs. Details can be found in *Additional Coupling Sent Data* (p. 395).

## 2.8. Symmetry Plane

Often a physical problem has the property that all aspects of the flow are symmetric about some physical (flat) plane. A problem is symmetric about a plane when the flow on one side of the plane is a mirror image of flow on the opposite side. By definition, a symmetry boundary condition refers to a planar boundary surface.

A particular case may have more than one plane of symmetry. For example, the flow in a square duct may exhibit symmetry about two independent planes (at 90° to one another). In this case, the physical problem has four-way symmetry. The computational domain can therefore be limited to one quarter of the duct, using two **Symmetry Plane** boundaries.


If you have two surfaces that meet at a sharp angle, and both are symmetry planes, you should set each surface to be a separate named boundary condition, rather than combine them into a single one.

When using an SMC turbulence model, you should position your model so that symmetry planes are perpendicular to coordinate axes if possible. This improves the performance of the CFX-Solver.

Symmetric geometry does not necessarily imply that the flow field is also symmetric. For example, a jet entering at the center of a symmetrical duct will tend to flow along one side above a certain Reynolds

number. This is known as the Coanda effect. If a symmetry plane is used in this situation, an incorrect flow field will be obtained.

**Figure 2.6 Symmetry Plane**



A symmetry plane should only be used when you have reason to believe that the flow field is also symmetrical.

A description of the mathematical details of the Symmetry Plane boundary condition is available in [Symmetry Plane in the CFX-Solver Theory Guide](#).

### 2.8.1. Mesh Motion

Stationary and unspecified boundary conditions are available for symmetry boundaries in domains where **Mesh Deformation** has been set to `Regions of Motion Specified`. (See [Mesh Deformation in the CFX-Pre User's Guide](#) for information about activating mesh deformation for the domain.) For details, see [Mesh Deformation](#) (p. 3).

## 2.9. Profile Boundary Conditions

It is possible to specify a boundary condition based on the interpolated values from a data file. This is useful to use the results of a previous simulation or experimental results as a boundary condition for the current simulation. CFX-Pre will generate CEL expressions that refer to the imported data, using interpolation functions. This data is automatically generated when creating a boundary condition using the Profile method.

To implement profile boundary conditions, follow these steps:

1. Create a BC profile file. This can be accomplished by using the **Export** feature of CFD-Post.

For details, see [Type in the CFD-Post User's Guide](#).

The data file format supports face and element definitions. Although not used in CFX-Pre and CFX-Solver, CFD-Post reads this data and displays values using the face/element information. A

list of valid variable names that can be used in profile files is available. For details, see [Standard Variable Names](#) (p. 91).

Alternatively, create your own data file (you may want to use an exported BC Profile file from CFD-Post as a template).

For details, see [Profile Data Format in the CFX-Pre User's Guide](#).

2. Initialize (read in) the profile in CFX-Pre.


Do this by selecting **Tools > Initialize Profile Data** and selecting the profile file and data to load. You can load multiple profile files and each file can contain profile data for more than one locator.

For details, see [Use Profile Data in the CFX-Pre User's Guide](#).

3. Assign the profile data to a boundary condition.

Do this by editing the boundary condition. On the **Basic Settings** tab, select **Use Profile Data**

Profile boundary conditions are always evaluated with reference to the local coordinate frame. Select the appropriate coordinate frame from the **Coord Frame** drop-down list. Additional information on coordinate frames is available in [Coordinate Frames in the CFX-Pre User's Guide](#). For details, see [Coordinate Frames](#) (p. 29).



4. Select the appropriate profile from the drop-down list, and then click **Generate Values**. The **Boundary Details** tab will be modified to use the profile data. These changes to the **Boundary Details** tab will not be applied unless you click **Apply**. If you later modify profile values using CEL, and you would like to re-apply the profile data that came from the profile file, click **Generate Values** again.

The profile boundary condition (as well as other boundary conditions) can be visualized in CFX-Pre by using the **Plot Options** tab in the **Boundary Conditions** details view. You can create a **Boundary Contour** or a **Boundary Vector** plot of the profile data. For details, see [Boundary Plot Options Tab in the CFX-Pre User's Guide](#).

The profile data is read into the CFX-Solver each time the solver is started/restarted (that is, the profile file can be edited between solver runs without returning to CFX-Pre).

### 2.9.1. Using a Profile From One Location at Another Location

There are a number of approaches that can be used to apply a profile from one location at another.

1. For locations that both have a surface normal vector of X, Y or Z, export the data as a 2D Profile (for example, for two boundaries with a normal in the Z direction, export X and Y profile data). The data from the first boundary can then be used at the second with no need for modifications to the data.
2. Create a custom coordinate frame so that the locations exported from one boundary will map correctly to a new boundary. Bear in mind that the coordinate frame you select will also be used by the solver

to interpret the U, V, W Cartesian components you enter on the **Boundary Details** tab. Also bear in mind that any expression used to specify these quantities will be interpreted with x, y, z as being in the local coordinate frame, and all other variables as being in the global coordinate frame. For details, see [Coordinate Frames in the CFX-Pre User's Guide](#). For details, see [Coordinate Frames \(p. 29\)](#).

3. Edit the data in your profile file directly to map the locations from the first boundary to the second.
4. Edit the arguments in CFX-Pre to the U, V, W expressions. As an example, the following modification is permitted in CFX-Pre: `myprofile.Velocity u(x,y,(z + 1[m]))`.

## 2.9.2. Standard Variable Names

The following table gives a list of valid variable names that can be used in profile files.

Variable	Variable Name(s) in Profile File
Epsilon	ed, Turbulence Eddy Dissipation
Fixed Temperature	T, Temperature
Heat Flux in	Qwall, Wall Heat Flux
Heat Transfer Coefficient	htc, Wall Heat Transfer Coefficient
k	ke, Turbulence Kinetic Energy
Mass Fraction	mf, Mass Fraction
Normal Speed	Velocity
Outside Temperature	T, Temperature
Pressure Profile	p, Pressure, ptot, Total Pressure, ptotstn, Total Pressure in Stn Frame
Relative Pressure	p, Pressure, ptot, Total Pressure, ptotstn, Total Pressure in Stn Frame
Relative Static Pressure	p, Pressure
Static Temperature	T, Temperature
Stationary Frame Total Temperature	T, Temperature, Ttot, Total Temperature, Ttotstn, Total Temperature in Stn Frame
Total Temperature	T, Temperature, Ttot, Total Temperature, Ttotstn, Total Temperature in Stn Frame
U	u, Velocity u, Velocity in Stn Frame u
Unit Vector X Component	veldir u, Velocity Direction u
Unit Vector Y Component	veldir v, Velocity Direction v
Unit Vector Z Component	veldir z, Velocity Direction z
V	v, Velocity v, Velocity in Stn Frame v
Velocity Axial Component	velaxial, Velocity Axial, w, Velocity w, velstn w, Velocity in Stn Frame w
Velocity r Component	velradial, Velocity Radial, u, Velocity u, velstn u, Velocity in Stn Frame u
Velocity Theta Component	velcirc, Velocity Circumferential, v, Velocity v
Volume Fraction	vf, Volume Fraction
W	w, Velocity w, Velocity in Stn Frame w

Variable	Variable Name(s) in Profile File
Wall U	u, Velocity u, Velocity in Stn Frame u
Wall V	v, Velocity v, Velocity in Stn Frame v
Wall W	w, Velocity w, Velocity in Stn Frame w
Wall Velocity r Component	u, Velocity u, Velocity in Stn Frame u
Wall Velocity Theta Component	v, Velocity v, Velocity in Stn Frame v
Wall Velocity Axial Component	w, Velocity w, Velocity in Stn Frame w

Some variables require a prefix to include the material name (for example, air.vf corresponds to the volume fraction of air). For details, see [System Variable Prefixes in the CFX Reference Guide](#).

### 2.9.3. Non-Standard Variable Names

If you have non-standard variable names in your profile file, they can still be used in CFX-Pre. Such names must be typed in as an expression directly in CFX-Pre, because they will not be picked up automatically. For example, your file may contain the variable `uvel` for velocity in the U direction. On the **Boundary Details** tab, you could enter `<profile>.uvel(x,y,z)` (where `<profile>` is the name of your profile) to pick up your `uvel` values.

### 2.9.4. Custom Variables

You may also type your own expressions to use non-standard interpolation variables, as below:

```
<prof name>.<var name>(x,y,z)
```

### 2.9.5. Using r-Theta Profiles

Using r-theta profiles in ANSYS CFX is possible, but the following points should be noted to ensure that the profiles are set up as intended.

1. The r-theta coordinates specified in the profile are used to calculate X and Y positions in the Cartesian space. The local coordinate frame (selected on the **Basic Settings** tab for each boundary condition in CFX-Pre) is used to evaluate the X and Y directions. When the r-theta and X-Y coordinates are defined with respect to the same coordinate frame, the points ( $r=1$ ,  $\theta=0$ ) correspond to ( $X=1$ ,  $Y=0$ ). For details, see [Coordinate Frames \(p. 29\)](#).
2. When specifying cylindrical velocity components, a rotation axis is used on the **Boundary Details** tab to specify the velocity component directions. Note that this axis is independent of the axis used to evaluate the r-theta coordinate positions specified in the profile file.
3. Profiles specified using r-theta positions and U, V, W velocity components may not be usable unless:
  - The U and V velocity component directions correspond with the X-Y coordinate directions that will be mapped from your r-theta coordinates by CFX-Pre (outlined in point 1, above).
  - You understand that using a custom coordinate frame to achieve the correct X-Y mapping from your r-t theta positions will also change the U, V, W velocity component directions, which you enter on the **Boundary Details** tab (and this may not be what you intend).

## 2.9.6. Data Interpolation Method

For 1D discrete profiles, the topology of the data can be determined by ordering the raw data based on the given single spatial coordinate. Linear interpolation is performed between the ordered raw data points. The data is sorted so that the order of specification is not important.

For 2D and 3D discrete profiles, a cloud of points algorithm is used to perform the interpolation. The process involves a fast lookup of the three nearest raw data points to the evaluation point, and then application of an inverse distance weighted averaging procedure. If a raw data point lies precisely at the evaluation point location, the raw data value at that point will be used.

During the solution process, the solver requires values at various locations. For example, at integration points, nodes and face center locations, as required by the specifics of the discretization and numerical integration process. In all instances, the required location is determined and the raw data is interpolated to that location.

## 2.9.7. Extracting Profile Data from Results Files

When profiles have been read into the CFX-Solver, a summary of the files will be written to the `out` file under the section **Profile Data**. All profile data is written to the results file and can be extracted using the command line utility `cfx5dfile`. As profile data is read in to the solver each time it is started/restarted, the results file contains the profile data that was most recent at the time.

`cfx5dfile` can be run from the command line and is located in the `<CFXROOT>/bin/` directory.

To find out which profile file(s) is/are referenced by the current results file, enter:

```
cfx5dfile file_001.res -list-profile-files
```

This outputs a list of all profile files stored in the results file, one per line.

For any file referenced in the results file, enter:

```
cfx5dfile file_001.res -read-profile-file <profile_name>.csv
```

to print the profile data from the file `<profile_name>` to your terminal window.

Alternatively, enter:

```
cfx5dfile file_001.res -extract-profile-file <profile_name>.csv
```

to write it to the current directory under the name `<profile_name>.csv`. If this file already exists in the current directory, it will not be overwritten.

For all files referenced in the results file, enter:

```
cfx5dfile file_001.res -extract-all-profile-files
```

to print the profile data from all the files to your terminal window.



---

## Chapter 3: Initial Condition Modeling

---

Initial values for all solved variables need to be set before the solution can begin. If your calculation is a steady-state calculation, the initial variable values serve to give the CFX-Solver a flow field from which to start its calculations. Convergence is more rapidly achieved if sensible initial values are provided. However, converged results should not be affected by the initialization.

If your calculation is a transient (unsteady) calculation, then initial values provide the flow field at the time when the CFD calculation starts. The values specified should be the actual flow field present at the beginning of the time of the simulation.

There are three options available for setting the initial values:

- automatically generated default values
- explicitly specified values
- read from an existing results file.

The first two options are specified by setting initialization parameters for the analyses (global) or domains in CFX-Pre. For details, see [Initialization in the CFX-Pre User's Guide](#) and [Initialization Tab in the CFX-Pre User's Guide](#), respectively). If you want to read initial conditions from an initial values file (an existing results file from a previous run) then this is done on the **Run Definition** tab for a simulation execution control or a configuration in CFX-Pre or the **Run Definition** tab of the **Define Run** dialog box in the CFX-Solver Manager. For details, see [Run Definition Tab in the CFX-Pre User's Guide](#), [Run Definition Tab in the CFX-Pre User's Guide](#) and [Run Definition Tab in the CFX-Solver Manager User's Guide](#), respectively. If you chose to specify an initial values file then the initial conditions read from that file will override any settings made in CFX-Pre.

Automatically generated default values are generally only recommended for steady-state runs. They are specified by choosing the `Automatic` option on the **Initialization** tabs in CFX-Pre. In this case, the CFX-Solver will calculate its own initial values, based on the physics and boundary conditions in the set up. Details of how the initial values are calculated can be found in [Initialization Parameters \(p. 97\)](#). You can set the initial conditions explicitly by choosing the `Automatic with Value` option on the **Initialization** tabs in CFX-Pre. Both of these options are discussed in [Setting the Initial Conditions in CFX-Pre \(p. 96\)](#).

Reading results from an existing results file is useful in many cases, including:

- To restart a steady-state run after a physics change.

When restarting a run with, for example, a new turbulence model, save time and resources by using a set of results from a previous run as the basis for an initial guess (even if the run was only partially converged). These initial guess values are likely to be far more accurate than using an automatic initial guess.

- To begin a transient analysis, using the results of a steady-state analysis as the initial conditions.

Transient simulations require values to be set for all variables during initialization. Starting a transient run with results from a converged steady-state analysis can lead to good convergence and solution robustness, especially if it is difficult to provide an accurate estimate of the initial conditions.

- To continue a transient run with a new mesh.

A transient moving mesh case might need to be stopped and restarted with a new mesh, if the mesh quality is poor. The run with the new mesh should continue using the values calculated by the solver when the run with the old mesh was stopped.

In addition, reading results from an existing results file is done implicitly whenever one configuration from a multi-configuration run is set to use initial values from a previous configuration (where the solver will use the results file produced by the previous configuration as its initial values file), and when a run is interrupted and restarted using the automatic remeshing capability. For details, see [Remeshing Tab](#) and "[Remeshing Guide](#)".

The process and limitations for initializing a run with values from a previous results file is described in [Reading the Initial Conditions from a File](#) (p. 107).

This chapter describes:

- [Setting the Initial Conditions in CFX-Pre](#) (p. 96)
- [Initialization Parameters](#) (p. 97)
- [Reading the Initial Conditions from a File](#) (p. 107)
- [Using the CFX-Interpolator](#) (p. 114)

## 3.1. Setting the Initial Conditions in CFX-Pre

In CFX-Pre, you can set the initialization option for each solved variable to either the `Automatic` or `Automatic with Value`. Only solved (or principal) variables are initialized; if an initial field is required for other variables, it is derived from the solved variable initial fields.

You can set initial conditions on a per-domain basis (on the [Initialization Tab](#) in the *CFX-Pre User's Guide* for the domain when you check the **Enable Initial Conditions** toggle on the domain's **Basic Settings** tab), or globally (from the *Global Initialization*  icon).

Global initialization options apply to all domains in the simulation. However, domain initialization will take precedence over global initialization for any domain in which it is specified.

For details on initialization, see [Initialization in the CFX-Pre User's Guide](#).

### 3.1.1. Automatic

Selecting the `Automatic` option allows the solver to automatically read the initial conditions from an initial values file if it can find one, or else use a solver default initialization field if no initial values file is provided. If the default initialization field is used, the CFX-Solver will calculate values for the solved variable at the start of the solution. You can select an initial values file for the CFX-Solver to use from the CFX-Solver Manager or from the **Run Definition** tab for a simulation execution control or a configuration in CFX-Pre. For details, see [Reading the Initial Conditions from a File](#) (p. 107).

Choosing the `Automatic` option without providing an initial values file is only recommended for steady-state runs. For transient runs, you should provide initial conditions which correspond to the real

flow field at the start of the calculation, and the CFX-Solver will stop by default if it has to use a solver default initialization field for a transient run for any quantities except turbulence-related variables.

If the automatic initial guess fails, it is often because an inappropriate initial velocity or static pressure field exists. Poor initial guesses are one of the most common reasons for the CFX-Solver to fail. If you use `Automatic` as the initial guess method for velocity, you must understand how the initial guess field is generated in CFX-Solver; this is described below. You should think about an initial guess and use the `Automatic with Value` option to set a constant value for velocity and pressure if the `Automatic` option is inappropriate. Better still, use CEL expressions or Cloud Interpolation to initialize the velocity and pressure fields.

An automatic initial guess is always acceptable for incompressible laminar cases if a sensible velocity field is produced, as described below. It is sometimes acceptable for incompressible turbulent cases, but the `Automatic with Value` method is often better.

Additional information on the way in which the `Automatic` option calculates values, and on sensible values for initial guesses, is available in [Initialization Parameters \(p. 97\)](#).

### 3.1.2. Automatic with Value

Selecting the `Automatic with Value` option allows the CFX-Solver to automatically read the initial conditions from an initial values file if it can find one, or else use the specified value or expression. This option is often better than using the `Automatic` method (assuming a sensible value is set), and is almost always required for compressible flow cases.

### 3.1.3. Using Expressions with Initial Conditions

The initial conditions can be defined using any valid CEL expression. However, in general, to avoid infinite recursion or problems with initialization on parallel runs, the expression may only contain the CFX System Variables `x`, `y`, `z`, `r`, and `theta`.

For details, see [CFX Expression Language \(CEL\) in the CFX Reference Guide](#).

## 3.2. Initialization Parameters

The topics in this section include:

- [Coord Frame \(p. 98\)](#)
- [Frame Type \(p. 98\)](#)
- [Velocity Type \(p. 99\)](#)
- [Cartesian Velocity Components \(p. 99\)](#)
- [Cylindrical Velocity Components \(p. 101\)](#)
- [Velocity Scale \(p. 102\)](#)
- [Velocity Fluctuation \(p. 102\)](#)
- [Static Pressure \(p. 102\)](#)
- [Temperature \(p. 103\)](#)
- [K \(Turbulent Kinetic Energy\) \(p. 103\)](#)
- [Epsilon \(Turbulence Eddy Dissipation\) \(p. 103\)](#)
- [Omega \(Turbulence Eddy Frequency\) \(p. 104\)](#)

- [Reynolds Stress Components](#) (p. 105)
- [Initialization of Additional Variables](#) (p. 105)
- [Component](#) (p. 106)
- [Volume Fraction](#) (p. 106)
- [Radiation Intensity](#) (p. 106)
- [Initialization of Solid Domains](#) (p. 106)
- [Initial Conditions for a Multiphase Simulation](#) (p. 106)
- [Initialization Advice](#) (p. 107)

### 3.2.1. Coord Frame

When using domain initialization, you can optionally select a reference coordinate frame other than the default `COORD_0` frame in which to have the solver interpret your initialization values. If a coordinate frame is not specified, the domain coordinate frame is used (although it may be overridden, as described below). Any variables used in the specification of an initialization value are interpreted as follows:

- `x, y, z`  
local coordinate frame
- other variables  
global coordinate frame

You can select any predefined coordinate frame.

Information about making local coordinate frames is available in [Coordinate Frames in the CFX-Pre User's Guide](#).

The coordinate frame used is local to initialization only and is used to interpret all `x`, `y` and `z` component values set on the **Initialization** panel.

---

#### Note

The coordinate frame set here may be ignored in some situations. For details, see [Velocity Type](#) (p. 99).

### 3.2.2. Frame Type

If a domain is rotating, you can choose to apply the initialization values relative to each domain (**Frame Type** = `Rotating`) or to the absolute frame of reference (**Frame Type** = `Stationary`). If the **Frame Type** setting is not given, the initialization values apply relative to each domain. For stationary domains, the **Frame Type** setting has no effect, and initialization values apply to the absolute frame of reference.

#### 3.2.2.1. Considerations for Multiple Domains and Global Initialization

When using the **Global Initialization** dialog box to set properties for **Frame Type**, the settings acquired by each domain in a multiple domain simulation are as follows:

- If one domain is rotating and the other is stationary, selecting a global rotating frame type will specify relative frame types for both domains. The rotating frame will therefore be initialized with its relative (rotating) frame and the stationary domain will be initialized with its relative (stationary) frame.
- If one domain is rotating and the other is stationary, selecting a global stationary frame type will specify initialization for both domains with an absolute (stationary) frame.

### 3.2.3. Velocity Type

The velocity type can be set to `Cartesian` or `Cylindrical`: There are some important considerations to note with respect to the way that coordinate frame types affect velocity types:

#### 3.2.3.1. Cartesian Coordinate Frame, Cartesian Velocity Components

The `Cartesian Velocity Components` are applied relative to the Cartesian coordinate frame selected for initialization.

#### 3.2.3.2. Cartesian Coordinate Frame, Cylindrical Velocity Components

A local axis is required, which overrides the definition of the Cartesian coordinate frame chosen for initialization. The location of  $\theta = 0$  is not important, so only the axis is required to define the cylindrical coordinate frame.

#### 3.2.3.3. Cylindrical Coordinate Frame, Cartesian Velocity Components

The specified Cartesian velocity components X, Y and Z are applied in the cylindrical coordinate frame directions for r, theta and Z, respectively.

#### 3.2.3.4. Cylindrical Coordinate Frame, Cylindrical Velocity Components

A local axis is required, which overrides the definition of the cylindrical coordinate frame chosen for initialization. The location of  $\theta = 0$  is not important so only the axis is required to define the cylindrical coordinate frame.

### 3.2.4. Cartesian Velocity Components

#### 3.2.4.1. Automatic Values

For **Automatic Values**, the initial conditions are based on a linear evaluation. Evaluation of linear initial conditions requires two points in the solution domain and initial condition values at these points. These points and initial condition values are generated using a weighted average of boundary condition information from all inlets, openings and outlets. The two points may be considered as a globally representative inlet and outlet. For example, the first point (the globally representative inlet) is located at an average of the centroids of all inlet, opening and outlet boundaries where the inlet boundary information is weighted much more heavily than the information from other boundaries. The initial condition value(s) for this point are similarly evaluated. See [Figure 3.1 \(p. 100\)](#) for an illustration.

The direction and magnitude of velocity linear initial conditions are treated independently. This reflects the use of velocity-specified (the direction and magnitude specified) boundary conditions, and of direction-specified (the total pressure and normal direction) boundary conditions.

When direction information is available from boundary conditions, it is used. If no information is available, a boundary normal direction is assumed. Note that zero vectors are possible for the globally represent-

ative inlet and outlet direction vectors because of the direction averaging (for example, two similar inlets that face each other).

Magnitude information is similarly used when it is available from the boundary conditions (note that an approximate velocity is calculated for mass flow specified boundary conditions). If no velocity magnitude information is available from boundary conditions (such as total pressure inlet, static pressure outlet), then half of the average rotational velocity (that is, the angular velocity multiplied by the mean radius) over a given boundary is used. This gives a reasonable “velocity triangle” approximation for turbo machines, and results in a magnitude of zero for stationary domains.


Note that the linear initial condition reverts to a constant velocity magnitude (or pressure) if only one value can be derived from boundary condition information (for example, constant pressure for total pressure in, mass flow out).


---

### Important

When applying initial conditions, the shape of your domain(s) is an important consideration when applying an automatic initial guess. As [Figure 3.2 \(p. 101\)](#) shows, a linearly varying prediction for velocity is not always appropriate. You can disable the automatic initial guess for velocity by setting the velocity scale to 0 m/s. For details, see [Velocity Scale \(p. 102\)](#).

**Figure 3.1 Initial Condition Values**



**Figure 3.2 Inaccurate Initial Conditions**

### 3.2.4.2. Recommended Values

If you suspect that the flow is predominantly in a particular direction through the domain (for example, in the direction of an Inlet specification), you can initialize the velocity components to this direction. You should not set a velocity higher than the inlet velocity.

If you predict that the `Automatic` method is unsuitable for your simulation, but do not want to specify Cartesian components, setting the velocity scale to zero imposes a zero velocity field throughout the domain. For details, see [Velocity Scale](#) (p. 102).

An explanation of how coordinate frames interact with velocity components is available in [Coord Frame](#) (p. 98).

Information on modeling multiphase flow is available in [Initial Conditions for a Multiphase Simulation](#) (p. 106).

## 3.2.5. Cylindrical Velocity Components

### 3.2.5.1. Automatic Values

The initial guess for velocity is calculated in the same way as for Cartesian velocity components. For details, see [Automatic Values](#) (p. 99).

### 3.2.5.2. Recommended Values

If you suspect that the flow is predominantly in a particular direction through the domain (for example, in the direction of an Inlet specification), you can initialize the velocity components to this direction. You should not set a velocity higher than the inlet velocity.

If you believe that the automatic prediction will be unsuitable for your simulation, but do not want to specify Cartesian components, setting the velocity scale to zero imposes a zero pressure and velocity field throughout the domain. For details, see [Velocity Scale](#) (p. 102).

An explanation of how coordinate frames interact with velocity components is available in [Coord Frame](#) (p. 98).

Information on modeling multiphase flow is available in [Initial Conditions for a Multiphase Simulation](#) (p. 106).

### 3.2.6. Velocity Scale

In some cases, the automatically generated initial guess for the velocity magnitude and/or direction may not be appropriate. For example, for large domains with small, high-speed inlets, the initial guess for velocity may be too high. You can optionally enforce a velocity scale (which is essentially the velocity magnitude used throughout the domain). The calculated velocity directions are unchanged. In particular, applying this velocity scale to zero direction vectors will still yield a zero velocity vector. For details, see [Automatic Values](#) (p. 99).

A zero velocity field (that is, a quiescent velocity field) results if the velocity scale is set to 0.

### 3.2.7. Velocity Fluctuation

Velocity Fluctuation is an optional parameter that can be entered for large eddy simulations. For details, see [The Large Eddy Simulation Model \(LES\)](#) (p. 137).

### 3.2.8. Static Pressure

#### 3.2.8.1. Automatic Values

The location of two globally representative inlet and outlet points is determined in the same way as for Cartesian Velocity Components. For details, see [Automatic Values](#) (p. 99).

In order to avoid the creation of walls at domain inlets and outlets, the globally representative inlet and outlet pressure values are respectively decreased and increased by 10% of the range of values. For example, globally representative inlet and outlet values of 100 kPa and 90 kPa would be updated to 91 kPa and 99 kPa, respectively.

#### 3.2.8.2. Recommended Values

The initial condition for the pressure field should be the average of the highest value of pressure specified on any of the outlet boundaries and the lowest value of pressure specified on any of the inlet boundaries. This reduces the likelihood of spurious inflow at outlets, or outflow at inlets, during the course of the solution.

For a free surface calculation, you should set a hydrostatic pressure distribution in the heavy fluid, and a constant pressure equal to the free surface value in the light fluid. For details, see [Modeling Advice for Free Surface Flow](#) (p. 233).

## 3.2.9. Temperature

### 3.2.9.1. Automatic Values

For an isothermal simulation, the temperature field is set to the specified isothermal value.

For other heat transfer models, the temperature field is calculated from an area weighted average of the boundary temperatures (inlets, outlets, openings and walls). If you have used a function or expression to specify the boundary temperature, an area weighted average of the expression over the boundary will be used to calculate an average value for that boundary.

### 3.2.9.2. Recommended Values

A sensible initial guess for the temperature field is an average of the boundary condition temperatures.

## 3.2.10. K (Turbulent Kinetic Energy)

### 3.2.10.1. Automatic Values

The default turbulent kinetic energy is calculated as:

$$k = \frac{3}{2} \left[ I_{def} \max (U_s, |U_{IG}|, U_\omega) \right]^2 \quad (3-1)$$

where:

$I_{def}$  is the default turbulent intensity of 5%.

$U_s$  is a minimum clipping velocity of 0.01 m/s to avoid a result of zero for the turbulent kinetic energy when an initial velocity value of zero exists.

$U_{IG}$  is the velocity initial guess.

$U_\omega$  is the product of the simulation average length scale and the rotation rate. This term is designed to produce a suitable velocity scale for rotating domains.

### 3.2.10.2. Recommended Values

Unless you have information about the turbulent kinetic energy for your application, use the `Automatic` initial guess.

## 3.2.11. Epsilon (Turbulence Eddy Dissipation)

### 3.2.11.1. Automatic Values

The default turbulence eddy dissipation is calculated as:

$$\varepsilon = \frac{C_\mu k^2}{\nu \cdot (\mu_T/\mu)} \quad (3-2)$$

where:

$C_\mu$  is a non-dimensional constant

$k$  is the turbulent kinetic energy

$\nu$  is the kinematic viscosity

$\mu_T/\mu$  is the eddy viscosity ratio, which is set to 10 by default

### 3.2.11.2. Recommended Values

Unless you have information about the turbulence eddy dissipation for your application, use the `Automatic` initial guess.

### 3.2.11.3. Manual Specification

Turbulence eddy dissipation can be specified as a function of:

- Omega (i.e., turbulence eddy frequency)
- Eddy Length Scale

$$\varepsilon = \frac{k^{3/2}}{l} \quad (3-3)$$

- Eddy Viscosity Ratio

$$\varepsilon = \frac{C_\mu k^2}{\nu \cdot (\mu_T/\mu)} \quad (3-4)$$

Turbulence eddy dissipation can also be specified directly as a CEL expression.

## 3.2.12. Omega (Turbulence Eddy Frequency)

### 3.2.12.1. Automatic Values

The default turbulence eddy frequency is calculated as:

$$\omega = \frac{k}{\nu \cdot \left(\mu_T/\mu\right)} \quad (3-5)$$

where:

$C_\mu$  is a non-dimensional constant

$k$  is the turbulent kinetic energy

$\nu$  is the kinematic viscosity

$\mu_T/\mu$  is the eddy viscosity ratio, which is set to 10 by default

### 3.2.12.2. Recommended Values

Unless you have information about the turbulent frequency for your application, use the `Automatic` initial guess (which is to use an `Eddy Viscosity Ratio` of 10).

### 3.2.12.3. Manual Specification

Turbulence eddy frequency can be specified as a function of:

- `Epsilon` (that is, turbulence eddy dissipation)
- `Eddy Length Scale`

$$\omega = \frac{k^{3/2}}{k C_\mu l} \quad (3-6)$$

- `Eddy Viscosity Ratio`

$$\omega = \frac{k}{\nu \cdot \left(\mu_T/\mu\right)} \quad (3-7)$$

Turbulence eddy frequency can also be specified directly as a CEL expression.

## 3.2.13. Reynolds Stress Components

Unless you have information about the Reynolds stress components for your application, use the `Automatic` initial guess method.

## 3.2.14. Initialization of Additional Variables

A recommended guess for Additional Variable levels is to set them equal to their values at the inlet.

### 3.2.15. Component

When a fluid is a variable composition mixture, set the initial mass fractions for each of the components in the fluid. If modeling combustion, setting a mass fraction of 0.232 for Oxygen, and then setting all other components to `Automatic` is a good initial guess. For details, see [Combustion Modeling \(p. 299\)](#).

For non-combusting reactions, `Automatic` is a sensible initial guess method if you do not know the initial concentrations of components at the start of the simulation.

### 3.2.16. Volume Fraction

For details on setting up initialization for multiphase cases, see [Initial Conditions for a Multiphase Simulation \(p. 106\)](#).

### 3.2.17. Radiation Intensity

A sensible value would be to assume that the fluid is in radiative equilibrium, i.e., the radiation intensity is set to the initial blackbody intensity in the fluid:

$$\text{Radiation Intensity}_{\text{initial}} = \frac{\sigma T^4}{\pi} \quad (3-8)$$

where  $\sigma$  is the Stefan-Boltzmann constant.

### 3.2.18. Initialization of Solid Domains

For solid domains, you may need to supply information for the following:

- [Coord Frame \(p. 98\)](#)
- [Frame Type \(p. 98\)](#)

Initialization data is also required for all variables (for example, Temperature, radiation, and Additional Variables) associated with the models which are activated on the solids domain.

### 3.2.19. Initial Conditions for a Multiphase Simulation

For a multiphase simulation, the initial conditions for some variables must be the same for all fluids. For example, in CFX, the pressure is assumed to be common for all fluids. However, for other variables, the initial conditions can be specified for each fluid individually.

Initial conditions for parameters common to both fluids are set in the same way as for single-phase simulations. The initial conditions that are fluid specific are set on the **Fluid Specific Initialization** frame. For details, see [Fluid Specific Initialization in the CFX-Pre User's Guide](#). As with single-phase simulations, the initial conditions can be set to `Automatic` or `Automatic with Value`. For details, see [Modeling Advice for Multiphase Flow \(p. 229\)](#).

#### 3.2.19.1. Volume Fraction

If a CFX-Solver default value is used for the **Fluid Volume Fraction**, it is distributed evenly among the fluids for which a volume fraction has not been assigned. For example, for two phase flow, an initial **Fluid Volume Fraction** of 0.5 would be assigned to each fluid if the defaults are used. For many simulations, including those containing a dilute fluid, using the Solver default values is not recommended.

Instead, set a sensible value for the initial **Fluid Volume Fraction** using `Automatic` with `Value`. Solver default values are used when the `Automatic` option is selected without an initial values file, or when `Default` is selected. If values are entered for the **Fluid Volume Fraction**, they must sum to 1.

### 3.2.19.2. Velocity

The initial velocity fields for each fluid should be slightly different to ensure a non-zero slip velocity. You should set the difference to a fraction of the expected terminal slip velocity.

### 3.2.20. Initialization Advice

If you are having problems getting your solution started, it will often be due to a poor initial guess. For many simple modeled flows, such as incompressible laminar, or incompressible turbulent with the `Zero Equation` model, a zero initial condition for all variables is sufficient for robust convergence.

Usually, however, better initial convergence rates can be achieved if the pressure and temperature initial values are set close to the boundary condition values, and if the velocity components are some fraction of an expected average value (i.e., under estimating initial velocities is better than over estimating). For turbulent flow simulations using the *k-e* model, some initial velocity scale is strongly recommended.

For more difficult flows, such as compressible flow in a complex geometry, with the 2nd order discretization option (blend factor of 1.0), and with multiple pressure specified openings, you may find that the linear equation solver fails no matter what initial values are selected.

For difficult flows, you should first obtain a solution using more robust solver settings and models. For details, see [Monitoring and Obtaining Convergence](#) (p. 438).

---

#### Important

When using an incompressible solution as the initial guess for a compressible case, you should make sure that the incompressible case had a sensible reference pressure set and that there are no negative values of pressure in the domain.

An incompressible case in which the reference pressure is zero is likely to contain negative pressures. This is not a problem for incompressible flow because only the pressure difference is of importance. For a compressible case, the absolute pressure is of importance and negative pressures are non-physical.

## 3.3. Reading the Initial Conditions from a File

Reading the initial conditions from one or more existing results files ("Initial Values Files") will often provide a flexible way to initialize a run and to provide initial conditions. See [Initial Condition Modeling](#) (p. 95) for some examples of circumstances when this may be useful. Most simulations will require the use of only one Initial Values File.

When you read initial conditions for a run from an existing results file, then there are various controls which affect how the results in the results file are used to provide the necessary initial conditions. These are described in the sections [Continuing the History](#) (p. 109), [Using Multiple Files to Provide Initial Conditions](#) (p. 111) and [Using the Mesh from the Initial Values File](#) (p. 112).

If the Initial Values File contains particle data from a Lagrangian Particle Tracking Simulation, then some limitations apply. See [Using an Initial Values File Which Contains Particles](#) (p. 112) for details.



behaves exactly the same as if the Initial Values are set to be read from a specified results file, and all the information about reading initial values from a file applies in exactly the same way. The only difference is that the actual location and exact name of the results file is not known until just before that configuration starts to execute.

### 3.3.2. Continuing the History

In some circumstances where you choose to read initial conditions from a file, you need just an approximate initial guess for the main solved variables (particularly velocity and pressure) to get your run started. However, in many circumstances you might want to continue as smoothly as possible from a previous run, particularly if you are running a single transient case which has to be stopped and restarted, perhaps to allow a new mesh to be used, or to allow the geometry to change at a particular time (for example, when a valve opens).

The setting which controls this choice is the **Continue History From** check box. This setting can be made on any panel which allows the specification of an Initial Values file. (If the CFX-Solver is being started from the command line, then the `-continue-from-file` or the `-continue-from-configuration` can be used to turn on the **Continue History From** setting.)

If you want to use an initial guess for your new run, then you can choose to clear (turn off) the **Continue History From** check box. (If the CFX-Solver is being started from the command line then the **Continue History From** setting will be off if all the Initial Values Files are specified using the `-initial-file` and `-initial-configuration` arguments.)

If you want to have the smoothest possible run continuation from a previous run, then you should select (turn on) the **Continue History From** check box. If you have just a single Initial Values file, then the history must be continued from this file. If you have multiple Initial Values files, then the history can be continued from only one file, which you must select.

The setting of the **Continue History From** check box has various effects which are tabulated in more detail below. In general, the aim of this setting is to provide as smooth a restart as possible, given the contents of the existing results file and the setup of the new CFX-Solver Input file.

<b>Continue History From check box</b>	<b>Cleared (off)<sup>a</sup></b>	<b>Selected (on)</b>
Variables	Excluding Mesh Displacement (described below), only principal variables and solver-internal derived variables that are under-relaxed or have a recursive definition are copied/interpolated. For example, mass flow integration point data will not be copied/interpolated. In general, this option should be switched off only if a rough initial guess is required.	All principal variables and dependent variables will be copied to make the run continuation as smooth as possible if the source domain and target domain have the same mesh. If the source domain and target domain have different meshes, only principal and solver-internal derived variables which are under-relaxed or have a recursive definition are interpolated. Particle database, particle tracks and particle sources will be copied/interpolated, if appropriate. Depending on the similarity between the mesh/topology/physics in the CFX-Solver

Continue History From check box	Cleared (off) <sup>a</sup>	Selected (on)
		Input file and Initial Values File(s), data on GGI interfaces, faceset data and element-set data may also be copied from the Initial Values File for use in the new run. More details can be found in <i>Interpolating from a Single File</i> (p. 115).
Mesh Displacement	<p>A mesh check is performed between the final mesh in the Initial Values File and the mesh in the Solver Input File, and the mesh displacements and the coordinates are never copied.</p> <p>This change can be reverted to the behavior of prior to Release 12.1 by setting the expert parameter <code>meshdisp interp option = 3</code> (only by changing CCL), which forces the CFX-Interpolator to always use the initial mesh from the Initial Values File for the same mesh check independent of the run mode. Additionally, setting <code>meshdisp interp option = 2</code> forces the CFX-Interpolator to always use the final mesh from the Initial Values File for the same mesh check.</p>	As for Variables, above.
Iteration/Timestep Counter	The new run will start from an Outer Iteration (steady-state) or Timestep (transient) of zero. The CEL variables Accumulated Timestep, Accumulated Coupling Step and Accumulated Iteration Number will be equivalent to Current Timestep, Current Coupling Step and Current Iteration Number, respectively.	The new run will start from the Outer Iteration (steady-state) or Timestep (transient) at which the previous run finished. The CEL variables Accumulated Timestep, Accumulated Coupling Step and Accumulated Iteration Number will <i>not</i> be equivalent to Current Timestep, Current Coupling Step and Current Iteration Number, respectively, but instead will continue to accumulate from the previous run (in the Initial Values File).
Monitor Data	The new run does not contain monitor data from the previous run.	The new run contains the monitor data from the previous run. This data will be plotted by default whenever the new run is monitored in the CFX-Solver Manager (although it can be excluded by using the <b>Monitor Properties</b> dialog

<b>Continue History From check box</b>	<b>Cleared (off)<sup>a</sup></b>	<b>Selected (on)</b>
		box and setting the <b>Timestep Range Option</b> to <b>This Run Only</b> ).
Particle Tracks	The new run does not contain any Lagrangian particles (or their tracks) from the previous run, although the particle sources to the fluid(s) from the previous run will be available.	Particle tracking will continue from the particles in the previous runs, particle tracks will be available from the previous run, and particle sources to the fluid(s) will be available. Some limitations apply: for details, see <i>Using an Initial Values File Which Contains Particles</i> (p. 112).
Run History	The new run does not contain any history relating to the existence of a previous results file nor its associated transient files.	If the results of the new run are loaded into CFD-Post with the setting <b>Load Complete History as a single case/separate cases</b> selected, then CFD-Post will be aware of the existence of the Initial Values File and all of its associated transient and files.
Transient Statistics	Transient statistics from the previous run are not used or available.	Transient statistics continue to accumulate from the Initial Values File into the new run.

<sup>a</sup>This does not apply if **Use Mesh From** is set to `Initial Values`. See *Using the Mesh from the Initial Values File* (p. 112) for details.

### 3.3.3. Using Multiple Files to Provide Initial Conditions

You might want to use more than one Initial Values Files to provide initial conditions for your new run. This is most likely to be applicable if you have simulated multiple parts of a geometry (for example, multiple stages of a rotating machine) separately, and then want to use these existing results to initialize a simulation of the full geometry (for example, the full rotating machine). Another example would be where you run a transient simulation where at some point during the calculation, a valve opens and connects two previously-separate enclosures: you could perform a lengthy transient run simulating the complex physics in one part of the geometry up to the time where the valve opens, perform a quick steady-state simulation of the less-interesting conditions in the other part of the geometry, and then use both existing results files to provide the initial conditions for the run of the full geometry after the valve opens.

Multiple Initial Values Files can be specified by creating more than one Initial Values object on any of the panels where you can specify an Initial Values File.

The **Continue History From** check box setting (see above) can only be applied to one of the Initial Values Files selected. The monitor data, particle positions and tracks, and iteration/timestep counter will be read from that file. Particle positions and tracks and monitor data from the other file(s) will be ignored.

It is recommended that where practical, separate domains are created in the new CFX-Solver Input file for the region of space occupied by each of the Initial Values Files (that is, each new domain only overlaps with the geometry from one of the Initial Values Files), particularly when the Initial Values Files do not have identical physics and material names. This is because the CFX-Interpolator interpolates

results domain by domain, and if each domain only picks up initial values from one Initial Values File, then the resulting mapping of variables is simpler. Where it is not possible to have one or more separate new domains for each existing Initial Values File, then it is recommended that you read the section *Interpolating from Multiple Files* (p. 120) to be aware of the limitations.

Where your Initial Values Files have geometry which overlap, or which do not fully cover the geometry of the new CFX-Solver Input file, it is recommended that you read the section *Interpolating from Multiple Files* (p. 120) to be aware of how the CFX-Interpolator calculates the initial values for these cases.

### 3.3.4. Using the Mesh from the Initial Values File

If you have specified only one Initial Values File, then you can choose whether the new simulation should use the mesh (and topology) from the CFX-Solver Input file (default) or the Initial Values File, by using the setting **Use Mesh From**. You should choose the `Initial Values` option only if the following conditions are satisfied:

- The number of boundary condition definitions in your current model and the results file is the same.
- The names and locations (that is, surface/face identifiers) of boundary conditions are the same.
- The mesh is the same in both your current model and the results file.

This setting is included mainly for backwards-compatibility with Release 11.0 and previous releases (where it was the default unless **Interpolate Initial Values onto Def File Mesh** was selected); however, it may occasionally be useful in other circumstances.

If the meshes in the CFX-Solver Input file and the Initial File are identical, then this setting should have no effect on the simulation if **Continue History From** is set to the single Initial Values File.

---

#### Note

If **Use Mesh From** is set to `Initial Values`, then the CFX-Interpolator is not used at all. If **Use Mesh From** is set to `Solver Input File`, then the CFX-Interpolator will be used, but it will recognize if the mesh and topology in the Initial Values File is identical to the CFX-Solver Input file and simply copy all of the variables and other settings in this circumstance - no actual interpolation will be performed. The end result should be same regardless of which option is chosen if the mesh in the CFX-Solver Input file and Initial Values File is identical, but the CFX-Solver Output file will show a section for interpolation in the case where the `Solver Input File` setting was selected for **Use Mesh From**.

When **Use Mesh From** is set to `Initial Values`, then the **Continue History From** setting behaves differently to the description in the table in *Continuing the History* (p. 109). If **Continue History From** check box is selected (turned on), then the description in the table is correct. If **Continue History From** has been cleared (turned off), then no monitor data and run history is available for the new run, and the timestep/iteration counter is reset. However, the particle data and the variable data is unaffected by the **Continue History From** check box being cleared (turned off).

### 3.3.5. Using an Initial Values File Which Contains Particles

If an Initial Values File contains the results of a Lagrangian particle tracking simulation, then three types of data can be made available to the new run:

- particle database containing particle positions at the end of the run, which will be used to continue particle tracking calculations in the new run if appropriate

- particle tracks (the tracks that the particles have already followed), which can be used for post-processing
- particle source terms in the fluid(s) equations.

If the **Continue History From** is cleared (turned off), or the new run is steady-state, then only the particle source terms in the fluid(s) equations will be made available for the new run. The particle database and existing particle tracks are not used in the new run. The only particles present in the new run will be those injected during the new run.

If **Continue History From** is set to an Initial Values File which contains particle data, and the new run is transient, then all three types of data may be made available in the new run. However, there are a number of limitations which determine the type of data made available for any given run. Three scenarios are possible, with the final scenario being the default:

- Only the particle sources are made available for the new run. In this case, the only particles present in the new run will be those injected during the new run. When post-processing, the only particle tracks available will be those calculated in the new run.
- The particle sources and the particle database are made available for the new run, but the particle tracks are not. In this case, if the new run defines particles of the same type as those contained in the Initial Values File, then the active particles from the Initial Values File will continue to be tracked from their positions and attributes at the end of the previous run (and new particles will be injected according to the settings in the new run). However, the tracks from the previous run will not be available in CFD-Post, so the history of how the particles from the Initial Values File arrived at those positions and attributes will be lost.
- All of the particle sources, particle database, and particle tracks are made available. In this case, particles from the Initial Values File continue to be tracked as described in the point above, and additionally the particle tracks post-processed using the results from the new run will include the tracks from the Initial Values File.

Limitations associated with continuing particle calculations from an Initial Values File, and in making the particle data from the Initial Values file available for a new run, are detailed below:

- Only the particle database and particle tracks from the single Initial Values File specified by the "Continue History From" setting will be made available to the new run. Particle databases and tracks in other Initial Values Files will be ignored. It is not currently possible to combine the particle databases from two or more Initial Values Files for use in the new run.
- If the new run contains a different mesh to the Initial Values File, then the CFX-Interpolator is used to "relocalize" the particles from the Initial Values File onto the mesh in the CFX-Solver Input file. This means that for each particle in the Initial Values file, the CFX-Interpolator has to locate the element in the CFX-Solver Input file which now contains the particle, given its coordinates in the particle database from the Initial Values File. If the mesh has changed, then some particles in the particle database of the Initial Values File may appear to be outside the new run's mesh even if the geometry has not changed, if the underlying geometry has curved faces and the particles were very close to the edge of the mesh in the Initial Values File. In this case, the CFX-Interpolator will attempt to remap these initially-unmapped particles to the closest element, but will only succeed if the particles are close enough to that element, to within a tolerance. You can check whether particles were mapped successfully or not by referring to the section in the CFX-Solver Output file entitled "Particle Relocalization Information". If the geometry is highly curved and the mesh is coarse, then this tolerance might need to be adjusted to ensure that all the particles in the Initial Values File are successfully relocalized. See [Adjusting the Bounding Box Tolerance \(p. 121\)](#) for details on how to do this. If the geometry is significantly different between the Initial Values File and the CFX-Solver Input file, then any particles which cannot be relocalized onto the CFX-Solver Input file mesh will be lost from the particle database.

- By default, particle tracks are stored according to the domain which contains them. The particle tracks in this format from an Initial Values File can only be made available in the new run if the CFX-Interpolator is able to match the domain which contains the particles tracks to an equivalent domain in the CFX-Solver Input file. The tracks will only be made available if the geometry between the two equivalent domains is nominally the same i.e. 90% or greater of the nodes of the domain in the CFX-Solver Input file can be mapped to the equivalent domain in the Initial Values File and the bounding box volumes overlap by at least 90% between the two domains.
  - If the geometry is the same but due to numerical error or mesh faceting (due to geometrically curved surfaces) the 90% criteria is not met, then you can control the tolerance that the CFX-Interpolator uses to decide if the nodes are mapped or not. This is described in *Adjusting the Bounding Box Tolerance* (p. 121).
  - If each domain in the Initial Values File does not have the same geometry as a domain in the CFX-Solver Input file (because the geometry has changed or because the domains have been defined differently (for example, by combining two domains into one)), then you can set the expert parameter `pt zone specific tracks = f`. This stores the particle tracks independent of the domain. This is the recommended setting for multi-configuration runs.
- Particle tracks in the new run can only be associated with a Boundary Condition if the Boundary Condition names remain the same in the CFX-Solver Input file as they were in the Initial Values File.
- Time-integrated particle boundary vertex fields (such as Time Integrated Mass Flow Density) are not accumulated from the Initial Values File into the new run unless the mesh in the Initial Values File is the same as the mesh in the CFX-Solver Input file.

### 3.4. Using the CFX-Interpolator

The CFX-Interpolator allows the results from one or more results files (the "source files") to be used as initial conditions for a run defined in a single Solver Input File (the "target file"). Although it will often be used where interpolation of results from one mesh to another is required, it can also deal efficiently with cases where no interpolation is required (the source file(s) have the same mesh as the target file), and can also be used for cases where physics and other setup information is different between the source and target files.

The CFX-Interpolator can also be used to calculate the differences between two results files. This is discussed in *Using the CFX-Interpolator to Calculate Difference Variables* (p. 124). The rest of this section considers only the use of the CFX-Interpolator to provide initial conditions.

To be able to run, the CFX-Interpolator needs to be given the names of the source and target files, and it outputs data in two places:

- it writes variables and other appropriate data to the target file
- it writes diagnostic information to a text output.

The most common way to use the CFX-Interpolator is to choose to specify one or more Initial Values Files as set on the **Run Definition** tab, either in CFX-Pre or in the CFX-Solver Manager. Unless the `Use Mesh From` option is set to `Initial Values`, the CFX-Interpolator will always be used to extract the results from the Initial Values Files for use in the new run (you do not need to explicitly select to use it). In this case, the target file itself is never seen directly by the user (it is written in the CFX-Solver working directory and deleted at the end of the run) and the text output is written to the CFX-Solver Output file.

If you want to manually use the interpolator to write variables into a specific CFX-Solver Input file (not as part of a Run Definition) then you can choose **Tools > Interpolate Results** from the CFX-Solver

Manager. In this case the specified Mesh File is used as the target file, and will be modified by the interpolation process. The text output is written into the CFX-Solver Manager's Interpolation window. You can then run the resulting target file in the CFX-Solver, using the variables written into the target file by the CFX-Interpolator as the initial conditions for the run.

You can also run the CFX-Interpolator manually using the `cfx5interp` command on the command line. See [Using the Command Line to Interpolate Results in the CFX-Solver Manager User's Guide](#) for details. In this case the target file is the file specified by the `-mesh` argument, and the text output is written to the command line window.

The details of how the CFX-Interpolator uses the results in the source file(s) to provide initial conditions for the target file are discussed in the following sections:

- [Interpolating from a Single File](#) (p. 115)
- [Interpolating from Multiple Files](#) (p. 120)

### 3.4.1. Interpolating from a Single File

This section describes how the CFX-Interpolator deals with the most common case, where the results from a single source file are interpolated onto the target file.

The CFX-Interpolator can be run in two different modes: "Initial Guess" mode and "Run Continuation" mode. The aim of Run Continuation mode is to provide the cleanest restart possible, when starting the run defined in the target file using the results in the source file. The aim of Initial Guess mode is to provide a basic initial condition for the principal (solved) variables. The differences between these are discussed in detail in [Continuing the History](#) (p. 109). If the **Continue History From** check box is selected, then the CFX-Interpolator is run in Run Continuation mode when it is called as part of the run setup. If **Continue History From** check box is cleared, then the CFX-Interpolator is run in Initial Guess mode.

The basic outline of the interpolation process (conceptually) is as follows, when the CFX-Interpolator is run in Run Continuation mode.

- For each domain (which is not of type Immersed Solid) in the target file:

1. Same Mesh Check.

Check to see if any appropriate domain in the source file has the same mesh as the target domain under consideration. (See [Mapping Data from the Source File to the Target File](#) (p. 117) for a discussion of which types of domain can be used to interpolate onto any particular domain, and what is meant by "same mesh".) If it has, then copy all the data from that domain to the target domain, including vertex values, faceset values and element-set values. No more processing needs to be performed for this target domain.

2. Determine mapped nodes.

1. Find the relevant domain in the source file which has the largest bounding box overlap with the target domain under consideration. For each node in the target domain, determine whether it can be mapped to an element in the source file domain under consideration.
2. Repeat the above step for the remaining relevant domains in the source file, in order of descending bounding box overlap.
3. If a node can be mapped to more than one source domain, then choose to map that node to the element in the source domain with most mapped destination nodes.

4. For all the target nodes that can be mapped to a source element, calculate the interpolated nodal values for the vertex variables (for example, `Pressure` or `Velocity`). These nodes need no further consideration.
3. Project unmapped target nodes which are only just outside the source geometry.

If `Simulation Control` command language is used to set the bounding box tolerance (as described in [Adjusting the Bounding Box Tolerance \(p. 121\)](#)), and, if any unmapped target nodes are within the bounding box tolerance of any source elements, then map these nodes to the nearest face/element/node of the appropriate source element. Calculate interpolated nodal values for the vertex variables appropriately; these nodes need no further consideration. This situation applies to target nodes which are only just outside the source elements, perhaps because of numerical precision issues, or because of mesh faceting of curved geometric faces.

4. Extrapolate any remaining unmapped nodes.

If any target nodes are still unmapped, then use extrapolation from the nearest mapped target nodes to provide nodal values for the vertex variables. These nodes are reported as being "unmapped" in the CFX-Interpolator diagnostic output. When unmapped nodes remain in the target domain, the interpolation will write a new variable `Interpolation Source Domain` onto the target file and the user can plot this variable in CFD-Post to visualize the location of the unmapped nodes. The value of `Interpolation Source Domain` is zero on unmapped nodes and, otherwise, a real number corresponding to a solver-internal domain number.

5. All nodes in the target domain should now have appropriate vertex values.

- For each immersed solid domain in the target file:

If there is an immersed solid domain in the source file with the same name as the target immersed solid domain, then copy the domain motion data from the source file to the target immersed solid domain.

- For each rigid body object in the target file:

If there is a rigid body object in the source file with the same name as the target rigid body then copy the rigid body motion, force, torque, and convergence data from the source file to the target rigid body object.

- For each particle type in the target file:

If the same particle type exists in the source file, then copy the appropriate particle data, as described in [Using an Initial Values File Which Contains Particles \(p. 112\)](#). For details on what is regarded as the "same" particle type, refer to [Mapping Data from the Source File to the Target File \(p. 117\)](#).

- For each Generalized Grid Interface (GGI) in the target file:

If there exists an identical GGI interface in the source file, then copy the GGI data from that GGI onto the target file GGI. The criteria used to determine whether or not the GGIs are identical are discussed below in [Mapping Data from the Source File to the Target File \(p. 117\)](#).

If the CFX-Interpolator is run in Initial Guess mode, then some of these steps are skipped: only the principal (solved) variables, derived variables, and material properties are copied/interpolated from the source file to the target file; the other data (such as variables relating to immersed solids, GGI interfaces and particle tracking, non-derived dependent variables, and monitor data) is not considered at all (except that the particle sources to the fluids' equations are copied/interpolated).

There are some additional factors to keep in mind when using the interpolator for cases involving mesh motion or remeshing:

- When the CFX-Interpolator is run in Run Continuation mode, the same mesh check is performed by comparing the initial meshes from the source with the mesh in the target domains. This is done so that mesh morphing restarts are smooth. If the meshes are the same, the CFX-Interpolator will copy the mesh displacements and the latest mesh coordinates from the source domains.
- When the CFX-Interpolator is run in Initial Guess mode, the same mesh check is performed by comparing the latest meshes from the source with mesh in the target domains. Even if the meshes are the same, the CFX-Interpolator will ignore the mesh displacements and the mesh coordinates from the source domains. This is done for backwards-compatibility with releases prior to Release 12.0.
- If the meshes are different, the node mapping is performed using the mesh in the source file at the latest time.

### 3.4.1.1. Mapping Data from the Source File to the Target File

The CFX-Interpolator has to read the objects defined in the target file (for example, particle types, fluids, domains, and GGI interfaces) to determine what the corresponding objects in the source file are, in order to copy or interpolate the correct data. The criteria listed in the table below are used.

**Table 3.1 Data-mapping Criteria**

Object	Criteria to determine which is the corresponding object in the source file (if any)
Fluid and Porous domains	Data from Fluid and Porous domains in the source file can be interpolated or copied only to domains defined as being either <code>Fluid</code> or <code>Porous</code> in the target file. Domains which have a <b>Domain Motion</b> set to <code>Rotating</code> will only be used to interpolate onto other rotating domains, and domains which have the <b>Domain Motion</b> set to <code>Stationary</code> will only be used to interpolate onto other stationary domains (note that data in one rotating domain can be interpolated onto a domain which has a different rotation rate: you must determine whether or not this will give a sensible result given your problem setup and how you are using the CFX-Interpolator). There is no requirement for Fluid and Porous domains to have the same name, mesh or geometry between the source and target files; only the geometrical overlap between the domains is important.
Solid domains	Data from a Solid domain in the source file can only be interpolated or copied to a domain of type <code>Solid</code> in the target file. There is no requirement for Solid domains to have the same name, mesh or geometry between the source and target files, only the geometrical overlap between the domains is important.
Immersed Solid domains	Immersed Solid domains are considered to be the same if they have the same name. There is no requirement to have the same mesh.
Same Mesh check	A domain in the source file is considered to have the same mesh as a domain in the target file if the following criteria are all met: <ul style="list-style-type: none"> <li>• The bounding box volumes of the domains must be the same (to within a very small tolerance).</li> <li>• The topology of the domain meshes must be the same.</li> </ul>

Object	Criteria to determine which is the corresponding object in the source file (if any)
	<ul style="list-style-type: none"> <li>• The mesh coordinates for each node must be the same (to within a very small tolerance) in order to copy the nodal solution data.</li> </ul> <p>This implies that meshes will <i>not</i> be considered to be the same if:</p> <ul style="list-style-type: none"> <li>– Node re-ordering has been used to change the order of the nodes (for instance, node 1 in one mesh does not have the same coordinates as node 1 in the other mesh)</li> <li>– The same boundary conditions (with the same boundary condition names) have not been defined on each mesh.</li> </ul> <p>If the CFX-Interpolator is run in Run Continuation mode, then:</p> <ul style="list-style-type: none"> <li>• The element-set data will be copied if the corresponding source element set is mapped to a target element set.</li> <li>• The faceset data will be copied if the corresponding source face set is mapped to a target face set.</li> <li>• The boundary condition data will be copied if the corresponding source boundary is mapped to a target boundary.</li> </ul> <p>Note that in some circumstances, the faceset order in the source file may not match that in the target file, even if the mesh is expected to be identical. This change in order may occur when:</p> <ul style="list-style-type: none"> <li>• CFX-Pre has imported a Solver Input File or Results File when creating the target file from the source file (rather than reading data from a <code>.cfx</code> file)</li> <li>• The mesh data in the source or target files was created with CFX-Pre from a release prior to Release 12.1.</li> </ul> <p>In this circumstance, the meshes are regarded as being the same, but the CFX-Interpolator will not copy any faceset data. If this data is important to obtain a smooth restart, then you may be able to select <b>Use Mesh From &gt; Initial Values</b> to retain it; see <a href="#">Using the Mesh from the Initial Values File (p. 112)</a> for information on when this option can be used.</p>
Fluid	<p>Where the source file and the target file each have a single fluid, then all variables which are stored on a per-fluid basis (such as <code>Velocity</code>) will be interpolated so that the fluid in the target file uses the results for the fluid in the source as initial conditions, regardless of the Fluid Definition name or material.</p> <p>If either of the source file or target file has two or more fluids, then the CFX-Interpolator has to ensure that fluid-specific variables in the source file (such as <code>Water.Velocity</code>) are applied to the appropriate fluid in the target file (so <code>Water.Velocity</code> in the source file is used to provide the initial condition for <code>Water</code> in the target file, and not <code>Air</code>, for example). The CFX-Interpolator will regard two fluids as being the same if they have the same Fluid Definition name. If the fluids do not have the same Fluid Definition names, then they will not be regarded as being the same. For example, if the source file contains <code>Air</code> and <code>Water</code>, and the target file</p>

Object	Criteria to determine which is the corresponding object in the source file (if any)
	<p>contains Fluid Definition 1 and Fluid Definition 2, then no fluid-specific variables will be interpolated from the source file to the target file; only the variables not specific to a fluid (such as Pressure) will be used to provide initial conditions.</p> <p>There is one exception to this. As a special case, when there is only one fluid in the source file, but there is more than one fluid defined in the target file, then the CFX-Interpolator will check to see if the fluid in the source file has the same name as any fluid in the target file. If there is no match, then it will check to see if the fluid defined in the source file shares the same material name as any fluid in the target file, and if it does, then it will map the source file fluid to the first target file fluid that has the same material name as the source file fluid. This additional checking of the material name only occurs if the source file has a single fluid and the target file has multiple fluids.</p>
Solid	<p>The logic for determining which Solid variables (for example, Copper . Temperature) in the source file should be mapped to which Solid variables in the target file is exactly the same as for Fluid variables, as described above (using the Solid Definition name instead of the Fluid Definition name).</p>
Particle Data	<p>The logic for determining which particle data in the source file should be mapped to which particle data in the target file is exactly the same as for Fluid variables, as described above.</p>
Fluid Component	<p>If a fluid is defined as a Variable Composition Mixture (for details, see <a href="#">Multicomponent Flow (p. 18)</a>) in the source file, and the CFX-Interpolator determines that this fluid should provide the initial conditions for a Variable Composition Mixture fluid in the target file, then the CFX-Interpolator needs to determine which component data from the source file should provide the initial conditions for each component in the target file. The components are considered the same if they have the same name. If a component in the fluid from the target file does not have the same name as a component in the corresponding fluid in the source file, then it will not pick up initial conditions from any results in the source file.</p>
Generalized Grid Interfaces (GGIs)	<p>The CFX-Interpolator will only copy GGI data from the source file to the target file if it finds an Interface in the source file which is identical to the interface in the target file. For the GGI interface to be considered identical, the following criteria must all be met:</p> <ul style="list-style-type: none"> <li>• The source and destination domain interfaces are both GGIs.</li> <li>• Both GGIs have the same physics type (for example, Fluid Fluid, or Fluid Porous).</li> <li>• Both GGIs have the same frame change model (for example, Frozen Rotor). Both the rotational offsets must be the same if the Frozen Rotor model is set for the GGI.</li> <li>• Both the associated domains have the same mesh (and boundary topology) in the target and source files.</li> </ul>

### 3.4.2. Interpolating from Multiple Files

The CFX-Interpolator can be used with more than one source file. When this might be useful is described in *Using Multiple Files to Provide Initial Conditions* (p. 111). Interpolation proceeds in a very similar manner to that described in *Interpolating from a Single File* (p. 115), but searching all the source files for matching domain or other data.

For each Fluid, Porous or Solid domain in the target file, the following checks are made to determine which source file and which domain the initial conditions are taken from:

- Check to see if any of the source files has a domain that has the same mesh as the target domain under consideration. If it has, then copy all the data from that domain to the target domain, including vertex values, face set values and element set values. No more processing needs to be performed for this target domain. If more than one source file contains a domain with the same mesh as the target domain, then the CFX-Interpolator will choose one of matching domains to provide the initial conditions, depending upon the order in which the source files were specified, and it will note which domain was used in the diagnostic information (in the CFX-Solver Output file if the interpolation is being done as part of a solver run).
- If there is no domain which passes the same mesh check, the CFX-Interpolator will do a "100% overlap check". If one of the source files has a domain which leads to no unmapped nodes, then the CFX-Interpolator will use only that domain to interpolate from. If more than one source file contains a domain which passes the 100% overlap check, then the CFX-Interpolator will choose one of matching domains to provide the initial conditions, depending upon the order in which the source files were specified, and it will note which domain was used in the diagnostic information.
- If none of the source domains pass the "100% overlap check", the CFX-Interpolator will identify which domains overlap, extract a list of variables which are common to those domains, and interpolate only those variables. The diagnostic information gives the node mapping information, and the list of common variables is also given. The same rules described in *Mapping Data from the Source File to the Target File* (p. 117) apply in determining which data in the sources files maps to which data in the target file.

It is recommended that where practical, the domains in the target file are set up so that each will overlap only with domains from one source file. This will allow more flexibility in the variables available in the target file. For example, consider the situation where the target file contains Water and Air. One source file also contains Air and Water but the other source file contains just Water:

- If the target file contains just one large domain (covering all the domains from both source files), then the CFX-Interpolator will interpolate only variables like `Water.Velocity` and `Pressure` onto the target file, missing all the variables relating to Air (for example, `Air.Velocity` and `Air.Volume Fraction`) as well as `Water.Volume Fraction` even in regions where these would exist. This is because the CFX-Interpolator will only interpolate variables common to both source files onto this single domain. The CFX-Solver will then just provide initial conditions for the missing variables from the Initialization set in CFX-Pre. So there will be no use made of any volume fraction results or any variables relating to Air from the source files at all.
- However, if the target file contained two domains, one covering the region of space occupied by one source file and the other covering the region of space occupied by the other source file, then the CFX Interpolation will produce better results. In the domain which corresponds to the region of the source file which contains Water and Air, it will interpolate all the variables like `Air.Velocity` and `Water.Volume Fraction` onto the target file, rather than just the variables relating to Water and the variables which are not fluid-specific. All the information provided by the two source files will be used to set the initial conditions.

When there are multiple source files, containing (between them) multiple fluids, and a target file which may also contain multiple fluids, then it is not always possible for the CFX-Interpolator to be able to match the correct fluids in the source files with the correct fluid in the target files, unless consistent Fluid Definition names are maintained across all the source and target files. You are recommended to always keep the Fluid Definitions (and Solid Definitions) consistent. If you do have to change the Fluid Definition names, then it is recommended that you always inspect the initial conditions used by the solver to check that the correct initial conditions are being used. This can best be done by visualizing (in CFD-Post) a transient or backup file written before the first timestep/iteration of the new run.

The following extra information on how the CFX-Interpolator determines whether fluids (or solids or particles) are the same applies when multiple source files are present:


- If each source file contains just a single fluid, then the fluid in second and subsequent source files will be treated the same as the fluid in the first source file, regardless of the Fluid Definition names. (You can override this behavior, and have the fluid from each source file mapped to the appropriate target file fluid using its Fluid Definition name, by setting the expert parameter `interp single phase treatment = f` in the target file - see [Expert Control Parameters in the CFX-Pre User's Guide](#).)
- If each source file contains just a single fluid, then the fluid in second and subsequent source files will be treated the same as the fluid in the first source file, regardless of the Fluid Definition names.
- If the first source file has more than one fluid, and the second or subsequent source file has only one, the fluid in the second source file will be treated as the same as the first fluid in the first source file, if no Fluid Definition names match.
- In contrast, if the first source file has only one fluid, and a second or subsequent source file has more than one fluid, then only fluids which have the same Fluid Definition name will be considered equivalent by the CFX-Interpolator.

The "first source file" will always be the one selected in **Continue History From** (or the equivalent command line argument), if this is selected. If the **Continue History From** check box is cleared, then the first source file is the one which appears first in the CFX Command Language (CCL) for the run, or is given first on the command line if the CFX-Interpolator is being run outside of a run definition. The "first fluid" is the one that appears first in the CCL for the run.

If any of the above cases apply, you should carefully check the diagnostic output and visualize the initial conditions using CFD-Post to determine that the fluids have been used as expected.

### 3.4.3. Adjusting the Bounding Box Tolerance

If the CFX-Interpolator is being used to relocalize particles from a source file mesh to a target file mesh, then if the mesh is different in the two files, some particles in the particle database of the source file may appear to be outside the mesh of the target file even if the underlying geometry is the same. This could occur if the underlying geometry has curved faces and the particles were very close to the edge of the mesh in the source file, particular if the mesh was coarse in this region. In this case, the CFX-Interpolator will attempt to remap these initially-unmapped particles to the closest element, but will only succeed if the particles are close enough to that element, to within a tolerance. This tolerance is called the Bounding Box Tolerance.



The figure above illustrates the bounding box tolerance. If the bounding box tolerance is very small (0.001) then the particle shown in the figure will appear to be unmapped (outside the target file's mesh) due to the large curvature of the geometry relative to the local mesh length scale. However, if the bounding box tolerance is increased to a larger value (for example, 0.1) then the particle will be able to be mapped to that target file mesh element. If you see that particles are (unexpectedly) unmapped in the diagnostic information provided by the CFX-Interpolator, then you should consider increasing the bounding box tolerance.

Similarly, during interpolation of variables in a domain, a target node may be initially unmapped because it lies outside the source file mesh. Nodes within the bounding box tolerance can be mapped onto the nearest element face/edge/node rather than being left as unmapped. This situation can occur when the mesh is coarse and the underlying geometry is highly-curved, as for particle relocalization. It can also occur when nodes in the target mesh are very slightly outside the source mesh simply due to numerical error (which is much less likely to happen with particles). If you see that nodes are unmapped in the diagnostic information provided by the CFX-Interpolator, but the underlying geometry in the source and target files is the same, you should consider increasing the bounding box tolerance.

To specify the bounding box tolerance values, create a file with the following CCL (in this case with a values of 0.1 and 0.01 for the particles and domains, respectively):

```
SIMULATION CONTROL:
EXECUTION CONTROL:
INTERPOLATOR STEP CONTROL:
PARTICLE RELOCALISATION CONTROL:
  Bounding Box Tolerance = 0.1
END
DOMAIN SEARCH CONTROL:
  Bounding Box Tolerance = 0.01
END
END
END
END
```

Assuming that the CCL above is in a file named `BoundingBox.ccl`, the CCL can be passed to the CFX-Interpolator in either of the following ways:

- using `-ccl BoundingBox.ccl` as an argument to the `cfx5solve` or `cfx5interp` commands.
- entering `-ccl BoundingBox.ccl` in the **Solver Arguments** field of the **Solver** tab on the **Define Run** dialog box in the CFX-Solver Manager.

### 3.4.4. Interpolating Onto a Solver Input File with Results Fields

If the CFX-Interpolator is asked to interpolate from a source file onto a target file which already contains solution variables, then it will proceed, but it will write a warning message into the diagnostic information, and you should check the results carefully as they may not be what you expect. (This should not be confused with using the CFX-Interpolator to calculate difference variables, as described in [Using the CFX-Interpolator to Calculate Difference Variables](#) (p. 124)).

This situation will occur if you select a results file as a target file (rather than a CFX-Solver Input file written by CFX-Pre with a name of the form `*.def`), or if you select a target file which has previously been used as a target file by the CFX-Interpolator (not as part of a run definition). Exactly what initial conditions will be used if the resulting target file is used by the CFX-Solver if this situation occurs is dependent upon the details of what solution fields are already present in the target file.

If you only ever use the CFX-Interpolator as part of a run definition, then you will not encounter this situation unless you choose a CFX-Solver Results file as your **Solver Input File** and specify one or more Initial Values Files as part of the run definition. This should be avoided.

If you use the CFX-Interpolator outside of a run definition (such as by using the `cfx5interp` command or by using **Tools > Interpolate Results** from the CFX-Solver Manager) then once you use a CFX-Solver Input file written by CFX-Pre as your target file, and perform the interpolation, then this CFX-Solver Input file will now contain solution fields. If you repeat the interpolation with a different target file but with the same settings as previously (particularly with respect to whether or not the CFX-Interpolator is run in **Initial Guess** mode or **Run Continuation** mode) then the results of the second interpolation will overwrite any results of the first interpolation. Using a CFX-Solver Results file as the target file, or interpolating onto a CFX-Solver Input file which has previous been used for interpolation but with different interpolator settings should be avoided.

### 3.4.5. Miscellaneous Limitations of the CFX-Interpolator

- Monitor data is not interpolated if the solution units in the source file and the target file are different.
- Particle track data is not interpolated if the solution units in the source file and the target file are different.
- The CFX-Interpolator cannot interpolate values from a fluid in the one or more source files to a fluid in the target file if the fluid is defined as a Continuous or Dispersed Fluid/Solid in one file and a Particle Transport Fluid/Solid in another file. In this case it will stop with an error about inconsistent morphology.
- When using the CFX-Interpolator in initial guess mode, and the source files are generated from CFX-Solver Release 11.0 or later, then only principal variables will be copied (if the meshes are the same) or interpolated (if the meshes are different).
- When using the CFX-Interpolator in initial guess mode, and the source files are generated from CFX-Solver Release 10.0 or earlier, then both principal and derived variables will be copied (if the meshes are the same) or interpolated (if the meshes are different).

### 3.4.6. Using the CFX-Interpolator to Calculate Difference Variables

The main use of the CFX-Interpolator is in providing initial conditions from existing results file for use in a new run. However, you can also use the CFX-Interpolator to compare two results files. When used in this mode, you provide it with a two results files, and the CFX-Interpolator writes a new set of variables into one of the results files of the form `Pressure.Difference`, which is the difference between the pressures in the two results files. These difference variables can then be viewed in CFD-Post. For a description of the general variable syntax, see [Quantitative CEL Functions in ANSYS CFX in the CFX Reference Guide](#).

For Release 12.0 and later, this use of the CFX-Interpolator is largely superseded by the ability of CFD-Post to calculate difference variables and to compare two results files in a more flexible way. For details, see [Case Comparison in the CFD-Post User's Guide](#).

The functionality to calculate difference variables using the CFX-Interpolator is available either through **Tools > Interpolate Results** in the CFX-Solver Manager, or through the `cfx5interp` command on the command line. See [Using the Command Line to Interpolate Results in the CFX-Solver Manager User's Guide](#) for details. See [Calculating Difference Variables in the CFD-Post User's Guide](#) for details on how the difference of vector variables such as `Velocity` is calculated.

For moving mesh cases, the difference variables are calculated using the final mesh positions.

---

## Chapter 4: Turbulence and Near-Wall Modeling

---

This chapter describes:

- [Turbulence Models](#) (p. 126)
- [Modeling Flow Near the Wall](#) (p. 148)

Turbulence models are used to predict the effects of turbulence in fluid flow without resolving all scales of the smallest turbulent fluctuations. For details, see [Turbulence Models in the CFX-Solver Theory Guide](#).

A number of models have been developed that can be used to approximate turbulence based on the Reynolds Averaged Navier-Stokes (RANS) equations. Some have very specific applications, while others can be applied to a wider class of flows with a reasonable degree of confidence. The models can be classified as either eddy-viscosity or Reynolds stress models. The following turbulence models based on the RANS equations are available in CFX and are described on the following pages:

- Eddy-viscosity Models:
  - Zero equation model.
  - Standard  $k - \varepsilon$  model.
  - RNG  $k - \varepsilon$  model.
  - Standard  $k - \omega$  model.
  - Baseline (BSL) zonal  $k - \omega$  based model. This model can only be selected through **Expert Control Parameters**.
  - SST zonal  $k - \omega$  based model.
  - $(k - \varepsilon)_{1E}$  model. This model can only be selected through **Expert Control Parameters**.
  - Curvature correction for two-equation models.
- Reynolds-Stress Models (RSM):
  - Launder, Reece and Rodi Isotropization of Production model (LRR Reynolds Stress).
  - Launder, Reece and Rodi Quasi-Isotropic model (QI Reynolds Stress).
  - Speziale, Sarkar and Gatski (SSG Reynolds Stress).
  - SMC- $\omega$  model (Omega Reynolds Stress).
  - Baseline (BSL) Reynolds Stress model.
  - Explicit Algebraic Reynolds Stress Model (EARSM).

CFX also provides the Large Eddy Simulation (LES) and Detached Eddy Simulation (DES) turbulence models. This class of turbulence models is not based on the RANS equations.

All turbulence models in CFX use advanced wall functions to model near-wall flow. For details, see [Modeling Flow Near the Wall](#) (p. 148).

In order to predict transition, three different transition models of varying complexity are available in ANSYS CFX; see [CFX Transition Model](#) (p. 130).

Information on turbulence modeling for multiphase flow is available in [Turbulence Modeling in Multiphase Flow](#) (p. 209).

## 4.1. Turbulence Models

The following topics will be discussed:

- [The Laminar Model](#) (p. 126)
- [The Zero Equation Model](#) (p. 126)
- [The  \$k\$ -epsilon Model](#) (p. 127)
- [The RNG  \$k\$ -epsilon Model](#) (p. 127)
- [The  \$k\$ -omega and SST Models](#) (p. 127)
- [Curvature Correction for Two-Equation Models](#) (p. 128)
- [The Reynolds Stress Model](#) (p. 128)
- [Omega-Based Reynolds Stress Models](#) (p. 130)
- [Explicit Algebraic Reynolds Stress Model](#) (p. 130)
- [CFX Transition Model](#) (p. 130)
- [The Large Eddy Simulation Model \(LES\)](#) (p. 137)
- [The Detached Eddy Simulation Model \(DES\)](#) (p. 142)
- [The Scale-Adaptive Simulation \(SAS\)](#) (p. 146)
- [Buoyancy Turbulence](#) (p. 148)

### 4.1.1. The Laminar Model

Laminar flow is governed by the unsteady Navier-Stokes equations. The laminar option does not apply a turbulence model to the simulation and is only appropriate if the flow is laminar. This typically applies at low Reynolds number flows (for example, for pipe flow the laminar flow regime is  $\sim Re < 1000$ ). Energy transfer in the fluid is accomplished by molecular interaction (diffusion). In the case of high speed flows, the work of the viscous stresses can also contribute to the energy transfer. You should always check in the output file that the maximum Reynolds number is in the laminar flow regime. If you set up a simulation using laminar flow, but the real flow is turbulent, convergence is difficult and the simulation will not reach the correct solution.

### 4.1.2. The Zero Equation Model

The Zero Equation model implemented in CFX is simple to implement and use, can produce approximate results very quickly, and provides a good initial guess for simulations using more advanced turbulence models. In CFX, a constant turbulent eddy viscosity is calculated for the entire flow domain. If you specify an eddy viscosity, this value is used instead of the solver calculated value. You should not use this model to obtain final results. For details, see [The Zero Equation Model in ANSYS CFX in the CFX-Solver Theory Guide](#).

### 4.1.3. The $k$ -epsilon Model

One of the most prominent turbulence models, the  $k - \varepsilon$  ( $k$ -epsilon) model, has been implemented in most general purpose CFD codes and is considered the industry standard model. It has proven to be stable and numerically robust and has a well established regime of predictive capability. For general purpose simulations, the  $k - \varepsilon$  model offers a good compromise in terms of accuracy and robustness.

Within CFX, the  $k - \varepsilon$  turbulence model uses the scalable wall-function approach to improve robustness and accuracy when the near-wall mesh is very fine. The scalable wall functions allow solution on arbitrarily fine near wall grids, which is a significant improvement over standard wall functions.

While standard two-equation models, such as the  $k - \varepsilon$  model, provide good predictions for many flows of engineering interest, there are applications for which these models may not be suitable. Among these are:

- Flows with boundary layer separation.
- Flows with sudden changes in the mean strain rate.
- Flows in rotating fluids.
- Flows over curved surfaces.

A Reynolds Stress model may be more appropriate for flows with sudden changes in strain rate or rotating flows, while the SST model may be more appropriate for separated flows. For details, see [The  \$k\$ -epsilon Model in ANSYS CFX in the CFX-Solver Theory Guide](#).

### 4.1.4. The RNG $k$ -epsilon Model

The RNG  $k - \varepsilon$  model is an alternative to the standard  $k - \varepsilon$  model. In general it offers little improvement compared to the standard  $k - \varepsilon$  model. For details, see [The RNG  \$k\$ -epsilon Model in ANSYS CFX in the CFX-Solver Theory Guide](#).

### 4.1.5. The $k$ -omega and SST Models

One of the main problems in turbulence modeling is the accurate prediction of flow separation from a smooth surface. Standard two-equation turbulence models often fail to predict the onset and the amount of flow separation under adverse pressure gradient conditions. This is an important phenomenon in many technical applications, particularly for airplane aerodynamics because the stall characteristics of a plane are controlled by the flow separation from the wing. For this reason, the aerodynamic community has developed a number of advanced turbulence models for this application. In general, turbulence models based on the  $\varepsilon$ -equation predict the onset of separation too late and under-predict the amount of separation later on. This is problematic, as this behavior gives an overly optimistic performance characteristic for an airfoil. The prediction is therefore not on the conservative side from an engineering stand-point. The models developed to solve this problem have shown a significantly more accurate prediction of separation in a number of test cases and in industrial applications. Separation prediction is important in many technical applications both for internal and external flows.

Currently, the most prominent two-equation models in this area are the  $k - \omega$  based models of Menter [9]. The  $k - \omega$  based Shear-Stress-Transport (SST) model was designed to give a highly accurate predictions of the onset and the amount of flow separation under adverse pressure gradients by the inclusion of transport effects into the formulation of the eddy-viscosity. This results in a major improvement in terms of flow separation predictions. The superior performance of this model has been demonstrated in a large number of validation studies (Bardina et al. [76]).

The SST model is recommended for high accuracy boundary layer simulations. To benefit from this model, a resolution of the boundary layer of more than 10 points is required. For details, see [Modeling Flow Near the Wall](#) (p. 148).

For free shear flows, the SST model is identical to the  $k - \varepsilon$  model.

The SST model was developed to overcome deficiencies in the  $k - \omega$  and BSL  $k - \omega$  models. Therefore, using the SST model over these models is recommended. Details of the differences between the three  $k - \omega$  based models available in CFX is available. For details, see [The k-omega Model in ANSYS CFX in the CFX-Solver Theory Guide](#).

One of the advantages of the  $k - \omega$  formulation is the near wall treatment for low-Reynolds number computations where it is more accurate and more robust. For details, see [Automatic Near-Wall Treatment for Omega-Based Models](#) (p. 150).

The convergence behavior of the  $k - \omega$  model is often similar to that of the  $k - \varepsilon$  model. Because the zonal  $k - \omega$  models (BSL and SST) include blending functions in the near wall region that are a function of wall distance, an additional equation is solved to compute the wall distance at the start of simulations (the first few iterations). This is done automatically by the CFX-Solver.

- [The k-omega Model in ANSYS CFX in the CFX-Solver Theory Guide](#)
- [The Baseline \(BSL\) k-Omega Model in the CFX-Solver Theory Guide](#)
- [The Shear Stress Transport \(SST\) in the CFX-Solver Theory Guide](#)

#### 4.1.6. Curvature Correction for Two-Equation Models

One weakness of the eddy-viscosity models is that these models are insensitive to streamline curvature and system rotation, which play a significant role in many turbulent flows of practical interest. A modification of the turbulence production term is available to sensitize the standard eddy-viscosity models to these effects. For details, see [Curvature Correction for Two-Equation Models in the CFX-Solver Theory Guide](#).

#### 4.1.7. The Reynolds Stress Model

Two-equation turbulence models ( $k - \varepsilon$  and  $k - \omega$  based models) offer good predictions of the characteristics and physics of most flows of industrial relevance. In flows where the turbulent transport or non-equilibrium effects are important, the eddy-viscosity assumption is no longer valid and results of eddy-viscosity models might be inaccurate. Reynolds Stress (or Second Moment Closure (SMC)) models naturally include the effects of streamline curvature, sudden changes in the strain rate, secondary flows or buoyancy compared to turbulence models using the eddy-viscosity approximation. You may consider using a Reynolds Stress model in the following types of flow:

- Free shear flows with strong anisotropy, like a strong swirl component. This includes flows in rotating fluids.
- Flows with sudden changes in the mean strain rate.
- Flows where the strain fields are complex, and reproduce the anisotropic nature of turbulence itself.
- Flows with strong streamline curvature.
- Secondary flow.
- Buoyant flow.

Reynolds Stress models have shown superior predictive performance compared to eddy-viscosity models in these cases. This is the major justification for Reynolds Stress models, which are based on transport equations for the individual components of the Reynolds stress tensor and the dissipation rate. These models are characterized by a higher degree of universality. The penalty for this flexibility is a high degree of complexity in the resulting mathematical system. The increased number of transport equations leads to reduced numerical robustness, requires increased computational effort and often prevents their usage in complex flows.

Theoretically, Reynolds Stress models are more suited to complex flows, however, practice shows that they are often not superior to two-equation models. An example of this is for wall-bounded shear layers, where despite their (theoretically) higher degree of universality, Reynolds Stress models often prove inferior to two-equation models. For wall-bounded flows try to use the SMC-BSL model. It is based on the  $\omega$ -equation and automatic wall treatment. For details, see [Omega-Based Reynolds Stress Models \(p. 130\)](#).

Three varieties of the Reynolds Stress Model are available which use different model constants:

- Reynolds Stress Model (LRR-IP)
- QI Reynolds Stress Model (LRR-IQ)
- SSG Reynolds Stress Model (SSG)

In general, the SSG model is more accurate than the LRR versions for most flows. This is particularly true for swirling flows. The SSG model is therefore recommended over the other models, which are there for historic reasons and because they are standard models.

Compared to the  $k - \varepsilon$  model, the Reynolds Stresses model has six additional transport equations that are solved for each timestep or outer coefficient loop in the flow solver. The source terms in the Reynolds Stress equations are also more complex than those of the  $k - \varepsilon$  model. As a result of these factors, outer loop convergence may be slower for the Reynolds Stress model than for the  $k - \varepsilon$  model.

In principle, the same timestep can be used for all turbulence model variants, but pragmatically the timestep should be reduced for the Reynolds Stress Model due to the increased complexity of its equations and due to numerical approximations made at general grid interfaces (GGI) and rotational periodic boundary conditions. If convergence is difficult, it is recommended that a  $k - \varepsilon$  or  $k - \omega$  based model solution be obtained first and then a Reynolds stress model solution can be attempted from the converged two-equation solution. It is frequently observed that Reynolds Stress models produce unsteady results, where two-equation models give steady state solutions. This can be correct from a physical standpoint, but requires the solution of the equations in transient mode.

The Reynolds Stress models may be used with isotropic or anisotropic turbulent diffusion terms in the Reynolds Stress and Epsilon transport equations. The difference is usually second order as there is often domination by the source terms and the effects of diffusion are small. An exception might be buoyant flows, which can be diffusion dominated. However, the model that uses isotropic turbulent diffusion terms is potentially more robust than the model that uses anisotropic turbulent diffusion terms.

Selection of the appropriate model and settings are carried out on the **Fluid Models** tab of the **Domains** form in CFX-Pre.

Further theoretical model information is available in [Reynolds Stress Turbulence Models in the CFX-Solver Theory Guide](#).

### 4.1.8. Omega-Based Reynolds Stress Models

Some of the main deficiencies of the Reynolds Stress models for the simulation of boundary layers are an inheritance from the underlying  $\varepsilon$ -equation. Particularly the accurate prediction of flow separation is problematic when the  $\varepsilon$ -equation is used. Furthermore, low-Reynolds number formulations for the  $\varepsilon$ -equation are usually complex and difficult to integrate, a deficiency which is exaggerated in combination with a Reynolds Stress model formulation. In order to avoid these issues, a Reynolds Stress model has been implemented which uses the  $\omega$ -equation instead of the  $\varepsilon$ -equation as the scale-determining equation.

There are two types of SMC- $\omega$  model in CFX:

- Omega Reynolds Stress
- Baseline (BSL) Reynolds Stress

As the freestream sensitivity of the standard  $k - \omega$  model does carry over to the Reynolds Stress model, the BSL Reynolds Stress Model was developed which is based on the  $\omega$ -equation used in the BSL model, and is preferred over the Omega Reynolds Stress Model. This is the formulation recommended when using the  $\omega$ -Reynolds Stress model.

All variants of the  $\omega$ -Reynolds Stress model are combined with automatic wall treatment, which allows a flexible grid resolution near the wall. For details, see:

- [Modeling Flow Near the Wall](#) (p. 148)
- [Omega-Based Reynolds Stress Models in the CFX-Solver Theory Guide](#)

### 4.1.9. Explicit Algebraic Reynolds Stress Model

Explicit algebraic Reynolds stress models (EARSM) represent an extension of the standard two-equation models. They are derived from the Reynolds stress transport equations and give a nonlinear relation between the Reynolds stresses and the mean strain-rate and vorticity tensors. Due to the higher order terms many flow phenomena are included in the model without the need to solve transport equations. The EARSM is an extension of the current  $k - \varepsilon$  and BSL model to capture effects of secondary flows and of flows with streamline curvature and system rotation. For details, see [Explicit Algebraic Reynolds Stress Model in the CFX-Solver Theory Guide](#).

### 4.1.10. CFX Transition Model

Engineering transition predictions are based mainly on two modeling concepts. The first is the use of low-Reynolds number turbulence models, where the wall damping functions of the underlying turbulence model trigger the transition onset. This concept is attractive, as it is based on transport equations and can therefore be implemented without much effort. However, experience has shown that this approach is not capable of reliably capturing the influence of the many different factors that affect transition, such as free-stream turbulence, pressure gradients and separation.

The second approach is the use of experimental correlations. The correlations usually relate the turbulence intensity,  $Tu$ , in the free-stream to the momentum-thickness Reynolds number,  $Re_{\theta t}$ , at transition onset. ANSYS has developed a locally formulated transport equation for intermittency, which can be used to trigger transition. The full model is based on two transport equations, one for the intermittency and one for the transition onset criteria in terms of momentum thickness Reynolds number. It is called the 'Gamma Theta Model' and is the recommended transition model for general-purpose applications. It uses a new empirical correlation (Langtry and Menter) that has been developed to cover standard bypass

transition as well as flows in low free-stream turbulence environments. This built-in correlation has been extensively validated together with the SST turbulence model for a wide range of transitional flows. The transition model can also be used with the BSL or SAS-SST turbulence models as well. A description of the full model can be found in the solver theory chapter.

In addition, a very powerful option has been included to allow you to enter your own user defined empirical correlation together with the 'Gamma Theta' model, which can then be used to control the transition onset momentum thickness Reynolds number equation. The method is driven by CCL and as a result any valid CCL expression can be used to define the correlation. A simple example is shown below where the transition Reynolds number was specified as a function of the x-coordinate:

```
FLUID MODELS:
TURBULENCE MODEL :
  Option = SST
TRANSITIONAL TURBULENCE :
  Option = Gamma Theta Model
TRANSITION ONSET CORRELATION:
  Option = User Defined
  Transition Onset Reynolds Number = 260.0*(1.0 + x/(1.0 [m]))
END
END
END
END
```

As well as the two-equation Gamma Theta transition model two reduced models are available:

1. A zero equation model, where you can prescribe the intermittency directly as a CEL expression. This model is called **Specified Intermittency**. The best way to specify the intermittency is with a user defined subroutine that is based on the x, y and z coordinates. This way, conditional statements can be used to define geometric bounds where the intermittency can be specified as zero (laminar flow) or one (turbulent flow). This method can be used to prescribe laminar zones at the leading edges of the wings, for example.
2. A one equation model, which solves only the intermittency equation using a user specified value of the transition onset Reynolds number. This model is called **Gamma Model** and you have to provide a value for the transition onset momentum thickness Reynolds number.

#### 4.1.10.1. Estimating when the Transition Model Should be Used

Because the transition model requires the solution of two extra transport equations, there are additional CPU costs associated with using it. A rough estimate is that for the same grid the transition model solution requires approximately 18 percent additional CPU time compared to a fully turbulent solution. As well, the transition model requires somewhat finer grids than are typically used for routine design purposes. This is because the max grid  $y^+$  must be approximately equal to one (that is, wall-function grids cannot be used because they cannot properly resolve the laminar boundary layer) and sufficient grid points in the streamwise direction are needed to resolve the transitional region. For this reason, it is important to be able to estimate when the additional cost of using the transition model in terms of CPU and grid generation time is justified. The relative percentage of laminar flow on a device can be estimated using the following formula, which is based on the Mayle [104] empirical correlation for transition onset.

$$\frac{Re_{xt}}{Re_x} = \frac{380000 \cdot (100 \cdot Tu)^{-\frac{5}{4}}}{(\rho/\mu) \cdot V \cdot L_{\text{Device}}} \quad (4-1)$$

Where  $Re_{xt}$  is the transition Reynolds number,  $Re_x$  is the device Reynolds number,  $L_{\text{Device}}$  is the length of the device,  $V$  is a representative velocity, and  $Tu$  is the freestream turbulence intensity, which can be calculated, as follows:

$$Tu = \frac{(2k/3)^{0.5}}{V} \quad (4-2)$$

where  $k$  is the turbulent kinetic energy. The fraction of laminar flow for some representative devices is shown in [Table 4.1: Fraction of laminar flow for a variety of different devices](#) (p. 132). Clearly, there are many cases where the assumption of fully turbulent flow is not correct and a significant amount of laminar flow could be present.

**Table 4.1 Fraction of laminar flow for a variety of different devices**


Case	$Re_x$	Tu (%)	Fraction Laminar Flow
LP Turbine blade	150 000	2.5	0.80
HP Turbine blade	500 000	6.0	0.10
Compressor blade	1 000 000	1.0	0.38
Small Aircraft wing	5 000 000	0.2	0.57
F1 Race Car Spoiler	2 000 000	0.3	0.86

#### 4.1.10.2. Grid Requirements


The effect of increasing and decreasing  $y^+$  for a flat plate test case (T3A) is shown in [Figure 4.1](#) (p. 133) and [Figure 4.2](#) (p. 133). For  $y^+$  values between 0.001 and 1, there is almost no effect on the solution.

Once the maximum  $y^+$  increases above 8, the transition onset location begins to move upstream. At a maximum  $y^+$  of 25, the boundary layer is almost completely turbulent. For  $y^+$  values below 0.001, the transition location appears to move downstream. This is presumably caused by the large surface value of the specific turbulence frequency  $\omega$ , which scales with the first grid point height. Additional simulations on a compressor test case have indicated that at very small  $y^+$  values the SST blending functions switch to  $k - \varepsilon$  in the boundary layer. For these reasons, very small (below 0.001)  $y^+$  values should be avoided at all costs.

**Figure 4.1 Effect of increasing  $y^+$  for the flat plate T3A test case**




**Figure 4.2 Effect of decreasing  $y^+$  for the flat plate T3A test case**




(Figure 4.2 (p. 133) provided by Likki, Suzen and Huang [102])

The effect of wall normal expansion ratio from a  $y^+$  value of 1 is shown in Figure 4.3 (p. 134). For expansion factors of 1.05 and 1.1, there is no effect on the solution. For larger expansion factors of 1.2 and 1.4, there is a small but noticeable upstream shift in the transition location.

**Figure 4.3 Effect of wall normal expansion ratio for the flat plate T3A test case**

The effect of streamwise grid refinement is shown in [Figure 4.4 \(p. 135\)](#). Surprisingly, the model was not very sensitive to the number of streamwise nodes. The solution differed significantly from the grid independent one only for the case of 25 streamwise nodes where there was only one cell in the transitional region. Nevertheless, the grid independent solution appears to occur when there is approximately 75 - 100 streamwise grid points. As well, separation induced transition occurs over a very short length and for cases where this is important, a fine grid is necessary. Note that the high resolution advection scheme has been used for all equations including the turbulent and transition equations and this is the recommended default setting for transitional computations. In CFX, when the transition model is active and the high resolution scheme is selected for the hydrodynamic equations, the default advection scheme for the turbulence and transition equations is automatically set to high resolution.

**Figure 4.4 Effect of streamwise grid density for the flat plate T3A test case**

One point to note is that for sharp leading edges, often transition can occur due to a small leading edge separation bubble. If the grid is too coarse, the rapid transition caused by the separation bubble is not captured.

Based on the grid sensitivity study the recommended best practice mesh guidelines are a max  $y^+$  of 1, a wall normal expansion ratio of 1.1 and about 75 - 100 grid nodes in the streamwise direction. Note that if separation induced transition is present, additional grid points in the streamwise direction are most likely needed. For a typical 2D blade assuming an H-O-H type grid, the above guide lines result in an inlet H-grid of 15x30, an O-grid around the blade of 200x80 and an outlet H-grid of 100x140 for a total of approximately 30 000 nodes, which has been found to be grid independent for most turbomachinery cases. It should also be noted that for the surfaces in the out of plane z-direction, symmetry planes should always be used, not slip walls. The use of slip walls has been found to result in an incorrect calculation of the wall distance, which is critical for calculating the transition onset location accurately. Another point to note is that all the validation cases for the transition model have been performed on hexahedral meshes. At this point, the accuracy of the transition model on tetrahedral meshes has not been investigated.

#### 4.1.10.3. Specifying Inlet Turbulence Levels

It has been observed that the turbulence intensity specified at an inlet can decay quite rapidly depending on the inlet viscosity ratio ( $\mu_t/\mu$ ) (and hence turbulence eddy frequency). As a result, the local turbulence intensity downstream of the inlet can be much smaller than the inlet value (see [Figure 4.5 \(p. 137\)](#)). Typically, the larger the inlet viscosity ratio, the smaller the turbulent decay rate. However, if too large a viscosity ratio is specified (that is,  $>100$ ), the skin friction can deviate significantly from the laminar value. There is experimental evidence that suggests that this effect occurs physically; however, at this point it is not clear how accurately the transition model reproduces this behavior. For this reason, if possible, it is desirable to have a relatively low (that is  $\approx 1 - 10$ ) inlet viscosity ratio and to estimate the inlet value of turbulence intensity such that at the leading edge of the blade/airfoil, the turbulence intensity has decayed to the desired value.

The decay of turbulent kinetic energy can be calculated with the following analytical solution:

$$k = k_{\text{inlet}} \cdot (1 + \omega_{\text{inlet}} \cdot \beta \cdot t)^{-\frac{\beta^*}{\beta}} \quad (4-3)$$

For the SST turbulence model in the freestream the constants are:

$$\beta = 0.09 \quad \beta^* = 0.0828 \quad (4-4)$$

The time scale can be determined as follows:

$$t = \frac{x}{V} \quad (4-5)$$


where  $x$  is the streamwise distance downstream of the inlet and  $V$  is the mean convective velocity. The eddy viscosity is defined as:

$$\mu_t = \frac{\rho k}{\omega} \quad (4-6)$$

The decay of turbulent kinetic energy equation can be rewritten in terms of inlet turbulence intensity ( $Tu_{\text{inlet}}$ ) and eddy viscosity ratio ( $\mu_t/\mu$ ) as follows:

$$Tu = \left( Tu_{\text{inlet}}^2 \left[ 1 + \frac{3 \cdot \rho \cdot V \cdot x \cdot \beta \cdot Tu_{\text{inlet}}^2}{2 \cdot \mu \left( \mu_t / \mu \right)} \right]^{-\frac{\beta^*}{\beta}} \right)^{0.5} \quad (4-7)$$

**Figure 4.5 Decay of turbulence intensity (Tu) as a function of streamwise distance (x)**



#### 4.1.10.4. Summary

Proper grid refinement and specification of inlet turbulence levels is crucial for accurate transition prediction. In general, there is some additional effort required during the grid generation phase because a low-Re grid with sufficient streamwise resolution is needed to accurately resolve the transition region. As well, in regions where laminar separation occurs, additional grid refinement is necessary in order to properly capture the rapid transition due to the separation bubble. Finally, the decay of turbulence from the inlet to the leading edge of the device should always be estimated before running a solution as this can have a large effect on the predicted transition location.

### 4.1.11. The Large Eddy Simulation Model (LES)

#### 4.1.11.1. Using the LES model in CFX

Turbulent flows contain a wide range of length and time scales, with large scale motions being generally more energetic than the small scale ones. The prediction of industrially important fluctuating flow problems can be performed using the technique of LES. LES is an approach which solves for large-scale fluctuating motions and uses "sub-grid" scale turbulence models for the small-scale motion.

### 4.1.11.2. Introduction to LES

The usual approach to predicting turbulent flows is to use the Reynolds Averaged Navier-Stokes equations, (RANS), which solve for time averaged quantities. However, there are some situations where the approach is not adequate, and the alternative approaches of Large Eddy Simulation (LES) or Direct Numerical Simulation (DNS) can be adopted. With these methods, time dependent equations are solved for the turbulent motion with either no approximations and all relevant scales resolved (DNS) or the equations are filtered in some way to remove very fine time and length scales (LES). These approaches require fine grids and small timesteps, particularly for wall bounded flows, as well as a large number of timesteps to generate statistically meaningful correlations for the fluctuation velocity components. However, they can give details on the structure of turbulent flows, such as pressure fluctuations and Lighthill stresses, which cannot be obtained from a RANS formulation.

Further theoretical model information is available in [Large Eddy Simulation Theory in the CFX-Solver Theory Guide](#).

### 4.1.11.3. When to use LES

Before starting an LES simulation, you should consider if it is the most appropriate solution approach. For low Reynolds numbers ( $Re < 5000$ ) or when it is important to be able to resolve all scales (for example, for transition to turbulent flow), consider DNS if you have a large computer available. For Higher Reynolds numbers, LES might be a suitable option for cases where:

- The flow is likely to be unstable, with large scale flapping of a shear layer or vortex shedding.
- The flow is likely to be unsteady with coherent structures (cyclone, flasher).
- The flow is buoyant, with large unstable regions created by heating from below, or by lighter fluid below heavier fluid (multiphase flows in inclined pipelines).
- Conventional RANS approach are known to fail (for example due to highly anisotropic turbulence).
- A good representation of the turbulent structure is required for small-scale processes such as micro-mixing or chemical reaction.
- The noise from the flow is to be calculated, and especially when the broadband contribution is significant.
- Other fluctuating information is required (such as fluctuating forces, gusts of winds).
- You can afford to wait for up to a week for results, using an 8 to 16 processor system.

It should be noted that for wall bounded flows, so called 'streaky structures' develop in the near wall region. These 'streaky structures' must be resolved and this leads to high resolution requirements and computing times for LES of wall-bounded flows. This should be kept in mind and you should consider the SAS (Scale-Adaptive Simulation) or DES (Detached Eddy Simulation) approach first before performing a LES for wall bounded flows.

### 4.1.11.4. Setting up an LES Simulation

#### 4.1.11.4.1. Geometry for LES

Even though there might be symmetries in the geometry and flow, the geometrical model should include the full region because, while the time averaged flows may be symmetric, the instantaneous flows are not, and restricting the domain could constrain the turbulence. Two-dimensional approximations are particularly poor.

#### 4.1.11.4.2. Meshing

The mesh and timesteps are an inherent part of the model. LES models make use of the grid scale for filtering out the turbulence. If the mesh is anisotropic to resolve a jet, for example, the longer length scale in the flow direction may also have an undue effect on the cross-stream turbulence. For this reason, consider the use of isotropic grids, perhaps using tetrahedral rather than hexahedral elements.

#### 4.1.11.4.3. Boundary Layers

If the boundary layer structure is important, you should resolve it with at least 15 points across the boundary layer and with the first grid point at a position of approximately  $y^+ = 1$ . Note however, that large aspect ratios in the mesh are not suitable for LES. This often results in excessive resolution requirements for boundary layer flows.

#### 4.1.11.4.4. Analysis Type

In CFX-Pre set the **Steady State/Transient** setting to `Transient`.

#### 4.1.11.4.5. Domains

Three LES models are available: it is recommended to use the wall-adapted local eddy-viscosity model by Nicoud and Ducros [200] (LES WALE model) as a first choice. This is an algebraic model like the Smagorinsky model, but overcomes some known deficiencies of the Smagorinsky model: the WALE model produces almost no eddy-viscosity in wall-bounded laminar flows and is therefore capable to reproduce the laminar to turbulent transition. Furthermore, the WALE model has been designed to return the correct wall-asymptotic  $y^{+3}$ -variation of the subgrid-scale viscosity and needs no damping functions.

In addition to the WALE model, the Smagorinsky model [34] and the Dynamic Smagorinsky-Lilly model (Germano et al. [198], Lilly [199]) are available. The Dynamic Smagorinsky-Lilly model is based on the Germano-identity and uses information contained in the resolved turbulent velocity field to evaluate the model coefficient, in order to overcome the deficiencies of the Smagorinsky model. The model coefficient is no longer a constant value and adjusts automatically to the flow type. However this method needs explicit (secondary) filtering and is therefore more time consuming than an algebraic model. Details on the LES models can be found in [Large Eddy Simulation Theory in the CFX-Solver Theory Guide](#).

#### 4.1.11.4.6. LES Boundary Conditions: Inlet

The representation of the turbulent structures at inlets can be a difficult part of the setup. The detailed properties of the incoming flow can have a strong effect on the development of the downstream solution. This has been observed in turbulent jets, as well as developing boundary layer cases. For other cases, however, the turbulent conditions at the inlet can have relatively little impact on the flow in the device. For example, in a cyclone body, the flow can be essentially determined by very strong anisotropy effects.

If the inlet turbulence is felt to play an important role, you should consider:

1. Moving the inlet far upstream of the geometry of interest. This allows the correct turbulent structures to establish themselves before the flow reaches that geometry. Additional obstructions can be placed upstream of geometry to affect the turbulent structures. This procedure, however, will require the simulation of the transition process.
2. Using unsteady values computed from a separate LES simulation (pipe flows and channel flows).

#### 4.1.11.4.7. LES Boundary Conditions: Outlets and Openings

With the transport of turbulent eddies outside of the computational domain, some recirculation can occur at outlets. Experience shows that if the code is allowed to bring some fluid back into the domain at outlets, it can destabilize the solution. Therefore, you should use outlet boundary conditions rather than openings when using LES. Opening types of boundary conditions allow the flow to come back in, whereas with outlet boundary conditions, the code builds artificial walls at the boundary, when the flow tries to come back in. These artificial walls are later taken away when the flow goes out again.

The use of artificial walls at outlets might introduce some un-physical behavior locally, but it increases the robustness of the calculation.

#### 4.1.11.4.8. LES Initialization

For simulations initialized with values (rather than from an initial guess field), it is possible to perturb the initial guess by setting an `RMS Velocity Fluctuation`. This has the effect of kickstarting the solution process. For a velocity distribution  $V_i$ , the fluctuation is the quantity:

$$V_{\text{rms}} = \sqrt{\sum_{i=1}^N \frac{(V_i - \bar{V})^2}{N}} \quad (4-8)$$

The behavior of the velocity fluctuation is applied according to the following rules when you select `Automatic` or `Automatic with Value` as the **Initialization** option, as well as specify a velocity fluctuation:

- If an initial values file is not found, the fluctuation is applied to the initial velocity field.
- When an initial values file is used, it is assumed that you are restarting from a previous set of results, and the fluctuation is not applied.

If you want to apply a velocity fluctuation on a restart (for example, if the initial guess is a RANS solution), you can override this behavior by setting the expert parameter `apply ic fluctuations for les` to `t`.

#### 4.1.11.4.9. LES Solver Control

On the **Solver Control** form, it is recommend that you use the **Central Difference** advection scheme rather than the **High Resolution** scheme because it is less dissipative and it has provided good answers in CFX. Select the transient scheme as `2nd Order Backward Euler`.

#### 4.1.11.4.10. LES Timestep Considerations

- First order fully implicit methods in time are usually too diffusive, and the turbulence is damped out. For highly unstable problems, such as cyclones, lower order methods may work, but the results will be very damped, unless very small timesteps are used.
- For accuracy, the average Courant (or CFL) number should be in the range of 0.5-1. Larger values can give stable results, but the turbulence may be damped. For compressible flows where the acoustic behavior is being modeled (eg, for noise calculations), this conclusion still holds, but for the CFL number based on the acoustic velocity as well as the convective velocity.

- 1,000 - 10,000 timesteps are typically required for getting converged statistics. More steps are required for second order quantities (for example, variances) than for means. Check the convergence of the statistics. For a vortex-shedding problem, several cycles of the vortex shedding are required.
- The implicit coupled solver used in CFX requires the equations to be converged within each timestep to guarantee conservation. The number of coefficient loops required to achieve this is a function of the timestep size. With CFL numbers of order 0.5-1, convergence within each timestep should be achieved quickly. It is advisable to test the sensitivity of the solution to the number of coefficient loops, to avoid using more coefficient loops (and hence longer run times) than necessary. LES tests involving incompressible flow past circular cylinders indicates that one coefficient loop per timestep is sufficient if the average CFL number is about 0.75. If the physics or geometry is more complicated, additional coefficient loops (3-5) may be required. Timesteps sizes which require more coefficient loops than this will tend to degrade solution accuracy.

#### 4.1.11.5. Solver Memory

You may find, especially if running averages are to be calculated, that for some cases you will need to increase the amount of memory needed for the calculation by using a memory factor above 1 (typically 1.2).

#### 4.1.11.6. Useful Values For LES Runs

The following values can be written to results files as the solution progresses using the **Solver Output** tab in CFX-Pre. For details, see [Output Control in the CFX-Pre User's Guide](#).

Although the statistics outlined in the Statistical Reynolds Stresses are useful for any simulation, they are particularly important in the context of LES. Of particular interest, are the Reynolds Stress (RS) components:

$$\rho \overline{u_i' u_j'} \quad (4-9)$$

where  $u_i'$  is the fluctuation of the of the  $i^{\text{th}}$  velocity component. For details, see [Statistical Reynolds Stresses](#) (p. 141).

##### 4.1.11.6.1. Statistical Reynolds Stresses

In LES runs, Reynolds Stress components are automatically generated using running statistics of the instantaneous, transient velocity field. As outlined above for the calculation of the standard deviation, a Reynolds Stress component can be evaluated using the difference between the running arithmetic average of the instantaneous velocity correlation and the running arithmetic average of the instantaneous velocities as:

$$\overline{u_i' u_j'} = \overline{u_i u_j} - \overline{u_i} \overline{u_j} \quad (4-10)$$

The noted running averages are also automatically generated for LES runs.

##### 4.1.11.6.2. Delaying the Start of Reynolds Stress Calculations

Data sampling for the Statistical Reynolds Stresses begins on the first timestep by default. This is because the transient statistics used in the stress evaluation (that is, the arithmetic averages of velocity and its correlation) start accumulating on the first timestep by default.

Sampling for the Statistical Reynolds Stresses is deferred, indirectly, by explicitly creating one of the required transient statistics (that is, the arithmetic averages of velocity or its correlation) and setting the start iteration (the starting timestep index) to a value larger than unity. If different start iterations are set for each of the velocity or velocity correlation averages, then the maximum start iteration set is used for both averages to ensure that the Statistical Reynolds Stresses are correctly evaluated.

The Statistical Reynolds Stress variable is evaluated using [Equation 4-10 \(p. 141\)](#) during every timestep, regardless of the start iteration specified for the required velocity-based statistics. This means that if the current timestep is less than the start iteration specified for the velocity-based statistics, then those statistics will be initialized as outlined in [Working with Transient Statistics in the CFX-Pre User's Guide](#).

### 4.1.12. The Detached Eddy Simulation Model (DES)

In an attempt to improve the predictive capabilities of turbulence models in highly separated regions, Spalart [57] proposed a hybrid approach, which combines features of classical RANS formulations with elements of Large Eddy Simulations (LES) methods. The concept has been termed Detached Eddy Simulation (DES) and is based on the idea of covering the boundary layer by a RANS model and switching the model to a LES mode in detached regions. Ideally, DES would predict the separation line from the underlying RANS model, but capture the unsteady dynamics of the separated shear layer by resolution of the developing turbulent structures. Compared to classical LES methods, DES saves orders of magnitude of computing power for high Reynolds number flows. Though this is due to the moderate costs of the RANS model in the boundary layer region, DES still offers some of the advantages of an LES method in separated regions.

See [Detached Eddy Simulation Theory in the CFX-Solver Theory Guide](#) and the detailed CFX report [55] for theoretical model information.

#### 4.1.12.1. Using the Detached Eddy Simulation Model in CFX

##### 4.1.12.1.1. When to use DES

It is well known that RANS models does not accurately predict all flow details in massively separated flow regions. In addition, the RANS formulation does not provide any information on turbulent flow structures and spectral distribution, which might be of importance to predict flow-induced noise or vibrations. In these cases, DES can provide valuable details far exceeding RANS simulations. Typical examples of DES simulations are:

- Flow around non-aerodynamic obstacles (buildings, bridges, etc.)
- Flow around ground transport vehicles with massively separated regions (cars, trains, trucks)
- Flow around noise generating obstacles (car side-mirror, etc.)
- Massively separated flow around stalled wings

On the other hand, DES is a computer intensive method because large (detached) turbulent structures need to be resolved in space and time. While the grid resolution requirements are not significantly higher than RANS for simulations, the time resolution imposes high CPU demands. In CFX, steady-state solutions can typically be obtained within 100-200 iterations. A typical DES simulation requires several thousands timesteps using three coefficient loops each. DES is therefore at least one order of magnitude more computer intensive than RANS models. DES does not allow the use of symmetry conditions, as turbulent structures are usually not symmetric. Two-dimensional and axisymmetric simulations are not feasible, as turbulent structures are always three-dimensional. Hence, you should carefully weigh the need for additional information against the required resources.

### 4.1.12.2. Setting up a DES Simulation

#### 4.1.12.2.1. Geometry for DES

The main issue with geometry is that 2D or axisymmetric simulations are not visible. In addition, in most cases, symmetry or periodicity conditions are not allowed. As an example, RANS simulations allow the use of a half model for a car simulation. As the turbulent structures are asymmetric, this is not possible in DES.

#### 4.1.12.2.2. Meshing Requirements for DES

There are many requirements in terms of grid generation, which depend on the selection of the specific formulation of the DES model (see report [55] or [Turbulence and Wall Function Theory in the CFX-Solver Theory Guide](#)). The grid resolution requirement in the attached boundary layers is the same as that of a regular RANS solution (10-15 nodes in the boundary layer). In the DES region, the grid has to be designed in all three space dimensions to allow at least the resolution of the largest turbulent structures. As the largest grid spacing is used in the switch for the DES limiter, it is essential to have sufficient resolution in the spanwise direction (if it exists).

One of the main issues of DES models is the danger to produce grid-induced separation due to an activation of the DES limiter in the RANS region. For a detailed explanation, refer to [55]. The zonal formulation used in CFX helps to avoid the severity of this potential limitation.

Examples of DES grids are provided in [55]. For a cylinder in cross-flow, 50 nodes were used in the spanwise direction for an extension of 2 diameters. For the Ahmed car body, 70 nodes were used in the cross-flow direction.

#### 4.1.12.2.3. DES Timestep Considerations

Timestep selection is a sensitive issue, as it determines the quality of the resolution of the turbulent structures. In most cases, a typical shedding frequency can be estimated for the largest turbulent structures. An example is a cylinder in cross-flow. For a cylinder, the Strouhal number is of the order of:

$$S_t = \frac{f D}{U} \sim 0.2 \quad (4-11)$$

In the CFX simulation [55], the freestream velocity is  $U=46$  m/s and the diameter is  $D=0.37$  m. This results in a frequency  $f=24.8$  1/s. A timestep of  $D_t = 10^{-4}$  s is sufficient to resolve the turbulent structures on the given grid.

#### 4.1.12.2.4. Boundary Conditions

In almost all cases, the same boundary conditions as in RANS simulation can be applied. Exceptions are symmetry or periodicity conditions, which may not be satisfied by the turbulent structures.

For a detailed discussion of inlet conditions, see [55]. In most cases, RANS inlet conditions can be applied, particularly for flows without profile distributions at the inlet, as mostly used in industrial flows.


#### 4.1.12.2.5. DES Initialization

It is recommended to start the DES simulation from a converged RANS solution. For comparison purposes, it is useful to use the same RANS model as in the DES formulation (in CFX this means the SST model). The RANS solution supplies to the DES formulation important elliptic information on the pressure field, which might take a long time to build up in an unsteady simulation.

#### 4.1.12.2.6. Monitoring a DES Simulation

Due to high computing costs, it is essential to monitor a DES run to ensure that it approaches an appropriate solution. It is recommended to check the blending function for DES model during the simulation (every 50-100 timesteps). In regions where the function is zero, the LES model is used, and the region where its value is one, the RANS model is activated. *Figure 4.6* (p. 144) shows a typical example for the flow around a cube. The blue region behind the cube is governed by the LES part, and the red region by the RANS model. This is desirable for this case as only the structures behind the obstacle are of interest.

**Figure 4.6 Blending Function for DES Model for Flow Around Cube.**



A second variable to monitor is the invariant:

$$I = \Omega^2 - S^2 \quad (4-12)$$

where  $S$  is the absolute value of the strain rate ( $S = \text{Shear Strain Rate}$  in CFD-Post) and  $\Omega$  is the absolute value of the vorticity. Note that the vorticity has to be activated in order to be available in CFD-Post.

The following lines are to be added to the solver CCL:

```
LIBRARY:
  VARIABLE: vorticity
    Output to Postprocessor = Yes
  END
END
```

In CFD-Post, you have to define a user variable based on the following expression:


```
LIBRARY:
  CEL:
    EXPRESSIONS:
      Invariant = Vorticity^2 - Shear Strain Rate^2
    END
  END
END
USER SCALAR VARIABLE: VelGradInvariant
```

```

Boundary Values = Conservative
Expression = Invariant
Recipe = Expression
END

```

**Figure 4.7 Strain Rate Invariant for Flow Around Cube**



The above figure shows a typical picture of a successful DES simulation. In case that only single scale (or no) vortex shedding is observed, it might be necessary to consider the following options:

- Reduce timestep
- Refine grid
- Use  $F_{SST}=F1$  or even  $F_{SST}=0$  (see report [55] or [Turbulence and Wall Function Theory in the CFX-Solver Theory Guide](#)).

After the turbulent structures are visually established, the averaging process within CFX can be started. Variables of interest are vorticity, eddy viscosity, pressure, velocity and  $k$  and  $\omega$ . This is achieved by the following steps (for example, start averaging at timestep 2087):

```

FLOW:
  OUTPUT CONTROL:
    TRANSIENT STATISTICS: mean1
      Output Variables List = Vorticity, Eddy Viscosity, \
      Pressure, Velocity, \
      Turbulence Eddy Frequency, \
      Turbulence Kinetic Energy
      Option = Arithmetic Average
      Start Iteration List = 2087,2087,2087,2087,2087,2087
    END
  END
END

```


#### **4.1.12.3. Limitations/Concerns of the DES Model**

One of the requirements for DES is that the flow must develop a strong instability once the LES mode is activated. Otherwise the RANS model is reduced, but the unsteady structures do not develop quickly enough to keep the overall turbulent kinetic energy (resolved + modeled) consistent. Such a situation occurs inside boundary layers or channel/pipe flows, if the grid is refined below a critical level. Once this level is reached, the RANS model is reduced, but in most cases no instability develops quickly enough to compensate for the lowered stresses. In severe cases, this can result in grid-induced separation, as shown by Menter et al. [133]. For industrial applications this is a practical concern, as standard DES models have a RANS grid limit of  $\Delta_{max} > \delta$ , where  $\Delta_{max}$  is the maximal local cell length and  $\delta$  is the boundary layer thickness. This limit can easily be reached in industrial CFD simulations. Using the

"shielded" formulation proposed by Menter et al. [133], allows for a reduction of this limit to  $\Delta_{\max} \sim 0.1\delta$ , which is safer, but does still not eliminate the problem entirely. In addition, the shielding will limit the models ability to operate in LES mode for unsteady internal flows, where the shielding is then active over most of the flow domain.

A second requirement for DES is that the grid spacing in the LES region must immediately be of LES-quality, as otherwise the turbulence model will produce a mix of RANS and LES components ([135], [137]). A good example is the flow over a backward-facing step. Assume that the grid is of LES-quality behind the step in the main flow plane ( $x,y$ ) and that the "spanwise" resolution defines the DES limiter,  $\Delta_{\max} = \Delta_z$ . In the case that  $\Delta_z$  is larger than an upper critical limit  $\Delta_{\max} > \Delta_{RANS}$ , the model will operate in RANS mode and produce a steady state solution. In the case that  $\Delta_z$  is lower than a lower critical limit  $\Delta_{\max} < \Delta_{LES}$ , the model will operate in LES mode and develop a flow instability past the step with the correct balance of the stresses. However, if  $\Delta_{RANS} > \Delta_{\max} > \Delta_{LES}$ , the model is undefined, and the solution will be neither RANS nor LES. The most likely scenario is that starting from  $\Delta_{\max} = \Delta_{RANS}$ , refinement will impact the underlying RANS model, without allowing an unsteady solution to develop. As a result, the separation zone will grow much larger than in the experiments. From a certain point of refinement, unsteady structures will develop, but instead of starting at the step, they will start further downstream, where the DES limiter has a stronger influence. Again, this results in an overly large separation bubble. With further grid refinement, the unsteadiness will move further upstream and eventually the entire separation zone will be computed in LES mode, when  $\Delta_{\max} < \Delta_{LES}$  is reached. The situation for  $\Delta_{RANS} > \Delta_{\max} > \Delta_{LES}$  is shown in [Figure 4.8 \(p. 146\)](#) where the backward facing step of Jovic and Driver [138] was computed with the SST-DES model with a grid with only 21 cells in spanwise ( $2xH$  -  $H$ -step height) direction. The turbulent structures appear much too late and time-averaged flow reattachment takes place at  $L_{reattach} \sim 15H$ .

**Figure 4.8 Unsteady flow from DES over backward facing step using insufficient spanwise grid resolution**




### 4.1.13. The Scale-Adaptive Simulation (SAS)

The Detached Eddy Simulation is a combination of RANS and LES methods. In an alternative approach, a new class of URANS models has been developed which can provide a LES-like behavior in detached flow regions (Menter et al. [132], Menter and Egorov [130], Menter and Egorov [131], Egorov and Menter [197]). The Scale-Adaptive Simulation (SAS) concept is based on the introduction of the von Karman length-scale into the turbulence scale equation. The information provided by the von Karman length-

scale allows SAS models to dynamically adjust to resolved structures in a URANS simulation, which results in a LES-like behavior in unsteady regions of the flowfield. At the same time, the model provides standard RANS capabilities in stable flow regions.

*Figure 4.9* (p. 147) shows isosurfaces where  $S^2 - \Omega^2 = 10^5 \text{ [s}^{-2}\text{]}$  for a cylinder in cross flow ( $Re=3.6 \times 10^6$ ), calculated using the SST model (URANS) and the SAS-SST model. The URANS simulation produces only the large-scale unsteadiness, whereas the SAS-SST model adjusts to the already resolved scales in a dynamic way and allows the development of a turbulent spectrum in the detached regions.

**Figure 4.9 Resolved structures for cylinder in cross flow (top: URANS; bottom: SAS-SST)**



The original version of the SST-SAS model (Menter and Egorov [131]) has undergone continued evolution. This model is still available in ANSYS CFX, but the latest version of the SAS model (Egorov and Menter [197]) is now the default model. More details can be found in [Scale-Adaptive Simulation Theory in the CFX-Solver Theory Guide](#).

The SAS method is an improved URANS formulation, with the ability to adapt the length scale to resolved turbulent structures. In order for the SAS method to produce a resolved turbulent spectrum, the underlying turbulence model has to go unsteady. This is typically the case for flows with a global instability, as observed for flows with large separation zones, or vortex interactions. There are many technical flows, where steady state solutions cannot be obtained or where the use of smaller timesteps results in unsteady

solutions. One could argue that the occurrence of unsteady regions in a RANS simulation is the result of a non-local interaction, which cannot be covered by the single-point RANS closure. All these flows will benefit from the SAS methodology.

On the other hand, there are classes of flows where the SAS model will return a steady solution. The two main classes are attached or mildly separated boundary layers and undisturbed channel/pipe flows. These flows (or areas in a complex flow domains) will be covered by the RANS formulation. This behavior of SAS is ideal for many technical applications, as flows for which the model produces steady solutions are typically those, where a well-calibrated RANS model can produce accurate results.

Contrary to DES, SAS cannot be forced to go unsteady by grid refinement. However, it has been shown in the backstep simulation above that enforcing unsteadiness by grid refinement does require an in-depth understanding of the flow, the turbulence model and its interaction with the grid to produce reliable results. Nevertheless, there will be cases where the grid sensitivity of DES will be advantageous, as it allows unsteady simulations where SAS might produce a steady state flow-field.

This leads to the following hierarchy of models of increased complexity, which can be used as a guideline in order to estimate the needed effort:

1. URANS
2. SAS
3. DES
4. LES

#### **4.1.13.1. Using the Scale Adaptive Simulation model in CFX**

Due to the similar functionality of the SAS-SST and DES model, most of the guidelines which have been given for the DES model regarding timestepping, boundary conditions and initialization are also valid for the SAS-SST model.

#### **4.1.14. Buoyancy Turbulence**

`Buoyancy Turbulence` is an option in CFX-Pre that is available for some turbulence models when buoyancy is being modeled. When the option is set to `Production`, a buoyancy production term is included in the equation for  $k$ . When the option is set to `Production and Dissipation`, a buoyancy production term is included in the equations for  $k$ ,  $\varepsilon$ ,  $\omega$  (as applicable). See [Buoyancy Turbulence](#) and the accompanying text, which describe the treatment for the  $k - \varepsilon$  and  $k - \omega$  models.


### **4.2. Modeling Flow Near the Wall**

Near a no-slip wall, there are strong gradients in the dependent variables. In addition, viscous effects on the transport processes are large. The representation of these processes within a numerical simulation raises the following problems:

- How to account for viscous effects at the wall.
- How to resolve the rapid variation of flow variables which occurs within the boundary layer region.

Experiments and mathematical analysis have shown that the near-wall region can be subdivided into two layers. In the innermost layer, the so-called viscous sublayer, the flow is almost laminar-like, and the (molecular) viscosity plays a dominant role in momentum and heat transfer. Further away from the wall, in the logarithmic layer, turbulence dominates the mixing process. Finally, there is a region between

the viscous sublayer and the logarithmic layer called the buffer layer, where the effects of molecular viscosity and turbulence are of equal importance. The figure below illustrates these subdivisions of the near-wall region.



Assuming that the logarithmic profile reasonably approximates the velocity distribution near the wall, it provides a means to numerically compute the fluid shear stress as a function of the velocity at a given distance from the wall. This is known as a 'wall function' and the logarithmic nature gives rise to the well known 'log law of the wall.'

Two approaches are commonly used to model the flow in the near-wall region:

- The wall function method uses empirical formulas that impose suitable conditions near to the wall without resolving the boundary layer, thus saving computational resources. All turbulence models in CFX are suitable for a wall function method.

The major advantages of the wall function approach is that the high gradient shear layers near walls can be modeled with relatively coarse meshes, yielding substantial savings in CPU time and storage. It also avoids the need to account for viscous effects in the turbulence model.

- The Low-Reynolds-Number method resolves the details of the boundary layer profile by using very small mesh length scales in the direction normal to the wall (very thin inflation layers). Turbulence models based on the  $\omega$ -equation, such as the SST or SMC- $\omega$  models, are suitable for a low-Re method. Note that the low-Re method does *not* refer to the device Reynolds number, but to the turbulent Reynolds number, which is low in the viscous sublayer. This method can therefore be used even in simulations with very high device Reynolds numbers, as long as the viscous sublayer has been resolved.

The computations are extended through the viscosity-affected sublayer close to the wall. The low-Re approach requires a very fine mesh in the near-wall zone and correspondingly large number of nodes. Computer-storage and runtime requirements are higher than those of the wall-function approach and care must be taken to ensure good numerical resolution in the near-wall region to capture the rapid variation in variables. To reduce the resolution requirements, an automatic wall treatment was developed by CFX, which allows a gradual switch between wall functions and low-Reynolds number grids, without a loss in accuracy.

Wall functions are the most popular way to account for wall effects. In CFX, **Scalable Wall Functions** are used for all turbulence models based on the  $\varepsilon$ -equation. For  $k - \omega$  based models (including the SST model), an `Automatic` near-wall treatment method is applied.

### 4.2.1. Standard Wall Functions

In CFX-5.4.1 and earlier, standard wall functions were used. These have been replaced by scalable wall functions as the default but standard wall functions are still available for backward compatibility. You should not use standard wall functions, as they offer no advantage over the scalable wall functions.

### 4.2.2. Scalable Wall Functions

Scalable wall functions overcome one of the major drawbacks of the standard wall function approach in that they can be applied on arbitrarily fine meshes. If the boundary layer is not fully resolved, you will be relying on the logarithmic wall function approximation to model the boundary layer without affecting the validity of the scalable wall function approach. If you are not interested in the details of the boundary layer, then it may not be worth fully resolving it. However, if you have produced a very fine near-wall mesh to examine details of the boundary layer, then you should use the SST model with Automatic near-wall treatment to take advantage of the additional effect in the viscous sublayer.

### 4.2.3. Automatic Near-Wall Treatment for Omega-Based Models

Automatic near-wall treatment automatically switches from wall-functions to a low- $Re$  near wall formulation as the mesh is refined.

One of the well known deficiencies of the  $k - \varepsilon$  model is its inability to handle low turbulent Reynolds number computations. Complex damping functions can be added to the  $k - \varepsilon$  model, as well as the requirement of highly refined near-wall grid resolution ( $y^+ < 0.2$ ) in an attempt to model low turbulent Reynolds number flows. This approach often leads to numerical instability. Some of these difficulties may be avoided by using the  $k - \omega$  model, making it more appropriate than the  $k - \varepsilon$  model for flows requiring high near-wall resolution (for example, high wall heat transfer, transition). However, a strict low-Reynolds number implementation of the model would also require a near wall grid resolution of at least  $y^+ < 2$ . This condition cannot be guaranteed in most applications at all walls. For this reason, a new near wall treatment was developed by CFX for the  $k - \omega$  based models that allows for a smooth shift from a low-Reynolds number form to a wall function formulation. This near wall boundary condition, named automatic near wall treatment in CFX, is used as the default in all models based on the  $\omega$ -equation (standard  $k - \omega$ , Baseline  $k - \omega$ , SST,  $\omega$ -Reynolds Stress).

To take advantage of the reduction in errors offered by the automatic switch to a low- $Re$  near wall formulation, you should attempt to resolve the boundary layer using at least 10 nodes when using these models.

### 4.2.4. User Defined Wall Functions

A user-defined wall function transfer coefficient may be applied to any wall boundary condition. This is accomplished by adding the following CCL data to the wall boundary condition, in the HEAT TRANSFER block or ADDITIONAL VARIABLES block, as appropriate:

```
TURBULENT WALL FUNCTIONS:
  Option = User Defined
  Wall Function Transfer Coefficient = [expression goes here]
END
```

Note that the parameter Wall Function Transfer Coefficient must be a normalized value having dimensions of  $[L T^{-1}]$  (that is, the units of kinematic diffusivity divided by length). The definition of the two different types of wall function transfer coefficient and their normalized values are presented next, followed by examples of CCL implementations.

### 4.2.4.1. Heat Flux

```
heat flux = C* (Vertex Temperature - Wall Temperature)
```

where C represents the wall heat flux transfer coefficient before normalization.

The Wall Function Transfer Coefficient parameter is then calculated as:

```
Wall Function Transfer Coefficient = C / (density * Cp)
```

### 4.2.4.2. Additional Variable Flux

```
additional variable flux = C * (Vertex AV - Wall AV)
```

where C represents the wall scalar flux transfer coefficient before normalization.

The Wall Function Transfer Coefficient parameter is then calculated as:

```
Wall Function Transfer Coefficient = C / density
```

### 4.2.4.3. Example of User-Defined Wall Function for Heat Flux

In the following example, a user-defined wall function, in the form of a wall function transfer coefficient for heat flux, is defined and applied to a wall boundary condition.

```
LIBRARY :
  CEL:
    EXPRESSIONS:
      sn = 1.E-20
      prandtl = viscosity * Cp / cond
      pryplus = prandtl * yplus
      beta1 = (3.85 * prandtl^1/3 - 1.3) ^ 2
      gamma = 0.01 * prandtl * yplus ^ 3 / \
      (1./(yplus*prandtl^3+sn) + 5.0)
      tplusub = pryplus
      tpluslog = max(2.12*log(pryplus+sn)+beta1,0.)
      tplus = tplusub*exp(-gamma) + tpluslog*exp(-1./(gamma+sn))
      twftfcl = ustar / (tplus + sn)
    END
  END
END
FLOW
DOMAIN: flatplate
BOUNDARY : Wall
  Boundary Type = WALL
  Coord Frame = Coord 0
  BOUNDARY CONDITIONS :
    MASS AND MOMENTUM :
      Option = No Slip Wall
    END
    WALL ROUGHNESS :
      Option = Rough Wall
      Roughness Height = 0.019 [in]
    END
    HEAT TRANSFER :
      Option = Fixed Temperature
      Fixed Temperature = 100[C]
    TURBULENT WALL FUNCTIONS:
      Option = User Defined
      Wall Function Transfer Coefficient = twftfcl
    END
  END
END
END
END
END
END
```

#### 4.2.4.4. Example of User-Defined Wall Function for an Additional Variable

The CCL implementation of a user-defined wall function for an Additional Variable is similar to that shown in the example for heat flux. The CCL block in the boundary condition is (using a specified quantity as an example):

```
FLOW
  DOMAIN: flatplate
  BOUNDARY : Wall
    BOUNDARY CONDITIONS :
      ADDITIONAL VARIABLE: my_av
      Wall Function Transfer Coefficient = 10 [m s^-1]
    END
  END
END
END
END
```

#### 4.2.5. Treatment of Rough Walls

The near wall treatment which has been discussed above (Scalable Wall Functions, Automatic Wall Treatment) is appropriate when walls can be considered as hydraulically smooth. For rough walls, the logarithmic profile exists, but moves closer to the wall. The near wall treatment becomes more complex, because it depends now on two variables: the dimensionless wall distance  $y^+$  and the roughness height.

The roughness height which must be specified in the wall boundary section (see also [Wall Roughness \(p. 84\)](#)), is the equivalent sand grain roughness height. Note that the sand-grain roughness is not equal to the geometric roughness height of the surface under consideration. Wall friction depends not only on roughness height but also on the type of roughness (shape, distribution, etc.). Therefore, one must determine the appropriate equivalent sand-grain roughness height. Guidance can be obtained from White [14], Schlichting [77] and Coleman et al. [193]. Details on the formulation of the rough wall treatment for turbulence models based on the  $\varepsilon$  and  $\omega$ -equation can be found in [Treatment of Rough Walls in the CFX-Solver Theory Guide](#).

If the ANSYS-CFX two-equation transition model is used together with rough walls, then the roughness correlation must be turned on in the user interface. This correlation requires the geometric roughness height as input parameter. More details can be found in [ANSYS CFX Transition Model Formulation in the CFX-Solver Theory Guide](#).

#### 4.2.6. Solver Yplus and Yplus

Yplus ( $y^+$ ) is the dimensionless distance from the wall. It is used to check the location of the first node away from a wall. This was more important when standard wall functions were used, as you had to avoid  $y^+$  values smaller than approximately 20. With the scalable wall functions and the automatic wall treatment, these values are only provided for information on the near wall resolution. Two variables related to  $y^+$  are output to the results file, Yplus and Solver Yplus.

- The variable `Yplus` is based on the distance from the wall to the first node and the wall shear stress. This is the usual definition in the CFD community.
- The variable `Solver Yplus` is used internally by the CFX-Solver. It uses different definitions for the wall distance of the first wall point. This variable is available for backwards consistency, but is of little use to you.

There is usually no need for you to work with the  $y^+$  used internally (Solver `Yplus`). The information required to judge the near wall mesh spacing should be based on the standard  $y^+$  (`Yplus`) definition.

## 4.2.7. Guidelines for Mesh Generation

One of the most essential issues for the optimal performance of turbulence models is the proper resolution of the boundary layer. In this section, two criteria are suggested for judging the quality of a mesh:

- Minimum spacing between nodes in the boundary layer
- Minimum number of nodes in the boundary layer

These are simple guidelines for the generation of meshes which satisfy the minimal requirements for accurate boundary layer computations.

### 4.2.7.1. Minimum Node Spacing

The goal is to determine the required near wall mesh spacing,  $\Delta y$ , in terms of Reynolds number, running length, and a  $\Delta y^+$  target value. This target value depends on the flow type and the turbulence model in use, or in other words the near wall treatment in use. See [Scalable Wall Functions](#) and [Automatic Near-Wall Treatment for Omega-Based Models in the CFX-Solver Theory Guide](#) for more information.

#### 4.2.7.1.1. Determination of the Near Wall Spacing

The estimates will be based on correlations for a flat plate with a Reynolds number of:

$$Re_L = \frac{\rho U_\infty L}{\mu} \quad (4-13)$$

with characteristic velocity  $U_\infty$  and length of the plate  $L$ .

The correlation for the wall shear stress coefficient,  $c_f$ , is given by White [14]:

$$c_f = 0.027 Re_x^{-1/7} \quad (4-14)$$

where  $x$  is the distance along the plate from the leading edge.

The definition of  $\Delta y^+$  for this estimate is:

$$\Delta y^+ = \frac{\Delta y u_\tau}{\nu} \quad (4-15)$$

with  $\Delta y$  being the mesh spacing between the wall and the first node away from the wall.

Using the definition

$$c_f = 2 \frac{\rho u_\tau^2}{\rho U_\infty^2} = 2 \left( \frac{u_\tau}{U_\infty} \right)^2 \quad (4-16)$$

$u_\tau$  can be eliminated in [Equation 4-15](#) (p. 153) to yield:

$$\Delta y = \Delta y^+ \sqrt{\frac{2}{c_f}} \frac{v}{U_\infty} \quad (4-17)$$

$c_f$  can be eliminated using [Equation 4-14](#) (p. 153) to yield:

$$\Delta y = L \Delta y^+ \sqrt{74} Re_x^{1/14} \frac{1}{Re_L} \quad (4-18)$$

Further simplification can be made by assuming that:

$$Re_x = C Re_L$$

where  $C$  is some fraction.

Assuming that  $C^{1/14} \approx 1$ , then, except for very small  $Re_x$ , the result is:

$$\Delta y = L \Delta y^+ \sqrt{74} Re_L^{-13/14} \quad (4-19)$$

This equation allows us to set the target  $\Delta y^+$  value at a given  $x$  location and obtain the mesh spacing,  $\Delta y$  for nodes in the boundary layer.

## 4.2.7.2. Minimum Number of Nodes

### 4.2.7.2.1. Goal

A good mesh should have a minimum number of mesh points inside the boundary layer in order for the turbulence model to work properly. As a general guideline, a boundary layer should be resolved with at least:

$$N_{\text{normal, min}} = \begin{cases} 10 & \text{for wall function} \\ 15 & \text{for low-Remodel} \end{cases} \quad (4-20)$$

where  $N_{\text{normal, min}}$  is the minimum number of nodes that should be placed in the boundary layer in the direction normal to the wall.

### 4.2.7.2.2. Formulation

The boundary layer thickness  $\delta$  can then be computed from the correlation:

$$Re_{\delta} = 0.14 Re_x^{6/7} \quad (4-21)$$

to be:

$$\delta = 0.14 L Re_x^{6/7} \frac{1}{Re_L} \quad (4-22)$$

The boundary layer for a blunt body does not start with zero thickness at the stagnation point for  $Re_x$ . It is, therefore, safe to assume that  $Re_{\delta}$  is some fraction of  $Re_L$ , say 25%. With this assumption, you get:

$$\delta = 0.035 L Re_L^{-1/7} \quad (4-23)$$

You would, therefore, select a point, say the fifteenth off the surface (for a low-Re model, or 10th for a wall function model) and check to make sure that:

$$n(15) - n(1) \leq \delta \quad (4-24)$$



---

## Chapter 5: Domain Interface Modeling

---

This chapter describes:

- 5.1. Overview of Domain Interfaces
- 5.2. Interface Type
- 5.3. Interface Models
- 5.4. Mesh Connection Options
- 5.5. Defining Domain Interfaces as Thin Surfaces
- 5.6. Recommendations For Using Domain Interfaces
- 5.7. Automatic Creation and Treatment of Domain Interfaces

### 5.1. Overview of Domain Interfaces

Before reading this section, you should be familiar with the concepts of primitive regions, composite regions, and assemblies in CFX-Pre. For details, see [Mesh Topology in CFX-Pre in the CFX-Pre User's Guide](#).

Domain Interfaces provide a way of connecting meshes or domains together. There are many uses of them. For example, they can be used in the following situations:

- If the flow field is repeated in multiple identical regions, then only one region needs to be solved, but the boundaries are specified as periodic (via a rotation or translation). A pressure change or mass flow rate may also be imposed for a translationally periodic interface.
- Domains can be connected together with a domain interface. This is often useful for connecting static domains together with non-matching grids. For example, hex meshes can be connected to tetrahedral or hybrid meshes. This is a useful strategy for reducing meshing effort. Pitch change can also be included.
- You can use domain interfaces to reduce mesh generation effort. The “divide and conquer” principle is useful, where the daunting task of generating a single mesh for the entire domain is divided into the much simpler task of generating a series of meshes that are later connected together.
- Domains that have a change in the reference frame (such as rotor-stator) can be connected together. Pitch change can also be included.
- Domains with different physical types can be connected together. For example, energy may flow through a fluid-solid interface. These interface types are often generated automatically. Other examples are fluid-porous and solid-porous interfaces.
- A domain may contain multiple mesh blocks. Non-matching interfaces can be connected together using a domain interface.
- A domain interface can be defined as a thin surface; a thin surface that has its **Mass and Momentum** set to `Conservative Interface Flux` can have physics defined across it.

Two methods of connecting meshes exist in ANSYS CFX; these are one-to-one (direct) and general grid interface (GGI). Additional information on these connections and when they are used is available in [Mesh Connection Options](#) (p. 168).

## 5.2. Interface Type

The interface type is used to define the type of domain model connection across the interface. It may be set to one of the following options:


- Fluid Fluid
- Fluid Porous
- Fluid Solid
- Porous Porous
- Solid Porous
- Solid Solid

## 5.3. Interface Models

The interface model defines the way the solver models flow physics across the interface. The available interface model options are:

- Translational Periodicity
- Rotational Periodicity
- General Connection

The periodic options allow a simplified geometry to be used if the full problem features multiple identical regions, as in the following pictures.

**Figure 5.1 Periodic Interfaces**

The periodic condition ensures that the flow out of one side of the interface automatically appears on the other side. Periodicity is most common for fluid-fluid interfaces, but is also available for all other interface types.

### 5.3.1. Translational Periodicity

In this case, the two sides of the interface must be parallel to each other such that a single translation transformation can be used to map `Region List 1` to `Region List 2`. The trivial case is where the two sides already coincide so that a translation of  $\langle 0, 0, 0 \rangle$  is used; this is equivalent to a general connection with no frame change or pitch change (discussed below).

A translational periodic interface could be used, for example, to represent an infinite straight row (a linear cascade) of turbine blades. For details, see [Translational Periodicity](#) (p. 166).

### 5.3.2. Rotational Periodicity

In this case, the two sides of the periodic interface can be mapped by a single rotational transformation about an axis. This is the most common case of periodicity and is used, for example, in the analysis of a single blade passage in a rotating machine.

If a domain interface involves rotational periodicity, the axis for the rotational transformation must also be specified.

### 5.3.3. General Connection


The `General Connection` interface model is a powerful way to connect regions together. A general connection can be used to:

- Apply a frame change at the interface between a rotor and stator
- Connect non-matching grids
- Apply fully transient sliding interfaces between domains


Pitch change can also be applied. For example, a domain interface can connect a stator domain with a rotor domain where the number of stator blades is not equal to the number of rotor blades, even if the mesh contains only one blade from each side.

Examples of the general connection type are shown below:

**Figure 5.2 General Connection: No Frame Change**



**Figure 5.3 General Connection: Frame Change and Pitch Change**



The `General Connection` option is necessary when the frame of reference or pitch changes across the interface. For example, the general connection option must be used in the following cases:

- One side is in a stationary frame of reference and the other side is in a rotating frame of reference
- Both sides are in a rotating frame of reference but each with a different rate of rotation
- Both sides are in the same frame of reference but have unequal pitches. In this situation, the flows through the interface must account for pitch change.

When a general connection is selected, the following details need to be specified:

- *Frame Change/Mixing Model* (p. 161)
- *Pitch Change* (p. 164)

### 5.3.3.1. Frame Change/Mixing Model

There are three types of frame change/mixing models available in ANSYS CFX:

- Frozen Rotor
- Stage
- Transient Rotor-Stator

Each side of the interface must be a surface of revolution and both sides must sweep out the same surface of revolution.

#### 5.3.3.1.1. None

Select `None` when there is no frame change or pitch change.

#### 5.3.3.1.2. Frozen Rotor

The frame of reference and/or pitch is changed but the relative orientation of the components across the interface is fixed. The two frames of reference connect in such a way that they each have a fixed relative position throughout the calculation. If the frame changes the appropriate equation transformations are made. If the pitch changes, the fluxes are scaled by the pitch change.

This model produces a steady state solution to the multiple frame of reference problem, with some account of the interaction between the two frames. The quasi-steady approximation involved becomes small when the through flow speed is large relative to the machine speed at the interface. `Frozen Rotor` analysis is most useful when the circumferential variation of the flow is large relative to the component pitch. This model requires the least amount of computational effort of the three frame change/mixing models.

The disadvantages of this model are that the transient effects at the frame change interface are not modeled. Modeling errors are incurred when the quasi-steady assumption does not apply. Also, the losses incurred in the real (transient) situation as the flow is mixed between stationary and rotating components is not modeled.

##### 5.3.3.1.2.1. Rotational Offset

The **Rotational Offset** settings control the angle by which the side 1 or side 2 domains are rotated before the interface calculation is performed. The domain axis of rotation is used to perform the rotation. The rotational offset that is applied to the domains on side 1 or 2 depends on whether domains are rotating on side 1, 2, both, or none. The ways in which rotational offsets are stored in results file and are interpreted by CFD-Post are:

- If the side 1 domains are rotating and the side 2 domains are stationary then a rotational offset will be written for the side 1 domains, and interpreted by CFD-Post.
- If the sides 1 and 2 domains are rotating then a rotational offset will be written for the side 1 domains, and interpreted by CFD-Post.
- If the side 1 domains are stationary and the side 2 domains are rotating then a rotational offset will be written for the side 2 domains, and interpreted as a counter-rotation by CFD-Post.


- If the sides 1 and 2 domains are stationary then a rotational offset will be written for the side 1 domains, but not interpreted by CFD-Post; the rotational offset will not be applied.

You can use a rotational offset if you want to change the relative position of the components on each side of the interface without altering the position of the meshes. The positive direction for an offset is determined by the right-hand rule. *Figure 5.4* (p. 162) shows how a rotational offset will alter the relative position of a rotor and stator component.

### Note

As an alternative to the **Rotational Offset** parameter, you can also apply a domain rotation in CFX-Pre and create a new CFX-Solver input file.

**Figure 5.4 Rotational Offset**



By default, the domain positions are stored in their original (non-offset) location. To have the domains appear in their offset positions in CFD-Post, include the expert parameter `rotational offset` for `post=t` in the problem definition and, in CFD-Post, open **Edit > Options**, then set the **CFD-Post** option **Angular Shift for Transient Rotating Domains** to **Always Rotate**. Click **OK** to save the change.

#### 5.3.3.1.3. Stage

The *Stage* model is an alternative to the *Frozen Rotor* model for modeling frame and/or pitch change. Instead of assuming a fixed relative position of the components, the stage model performs a circumferential averaging of the fluxes through bands on the interface. Steady state solutions are then obtained in each reference frame. This model enables steady state predictions to be obtained for multi-stage machines. The stage averaging at the frame change interface incurs a one-time mixing loss. This loss is equivalent to assuming that the physical mixing supplied by the relative motion between components is sufficiently large to cause any upstream velocity profile to mix out prior to entering the downstream machine component. *Stage* analysis is most appropriate when the circumferential variation of the flow is of the order of the component pitch.

*Stage* averaging between blade passages accounts for time average interaction effects, but neglects transient interaction effects. *Stage* analysis is not appropriate when the circumferential variation of the flow is significant relative to the component pitch (for example, a pump and volute combination at off-design conditions).

The `Stage` model usually requires more computational effort than the `Frozen Rotor` model to converge, but not as much as the `Transient Rotor-Stator` model. You should obtain an approximate solution using a `Frozen Rotor` interface and then restart with a `Stage` interface to obtain the best results.

#### **5.3.3.1.3.1. Pressure Profile Decay**

The pressure profile at a `Stage` interface is determined by extrapolation from the pressure profile just inside the interface location (just upstream or just downstream of the `Stage` interface, for the upstream and downstream sides respectively). Sometimes, this procedure is unstable and a small amount of stiffness needs to be added to the pressure profile rather than just letting it float. By default, the pressure profile is decayed by 5% towards a constant value. The amount of decay can be controlled by this setting. Using a 5% pressure profile decay is recommended.

#### **5.3.3.1.3.2. Downstream Velocity Constraint**

At a stage interface, the average static pressure within each band on both the upstream and downstream side of the interface is set to the average band pressure. There are three possible treatments for velocity on the downstream side:

- It may be calculated as the average band velocity. (`Stage Average Velocity`)
- It may be calculated from the average band total pressure and direction in the absolute frame (`Constant Total Pressure, Frame Type=Stationary`).
- It may be calculated from the average band total pressure and direction in the relative frame (`Constant Total Pressure, Frame Type=Rotating`).

The constant total pressure options permit the downstream velocity profile to naturally adjust to downstream influences. For tightly-coupled components, these models are generally better than the default. To obtain results comparable to CFX-TASCflow, use `Constant Total Pressure, Frame Type=Rotating`.

#### **5.3.3.1.4. Transient Rotor-Stator**

This model should be used any time it is important to account for transient interaction effects at a sliding (frame change) interface. It predicts the true transient interaction of the flow between a stator and rotor passage. In this approach the transient relative motion between the components on each side of the GGI connection is simulated. It ultimately accounts for all interaction effects between components that are in relative motion to each other. The interface position is updated each timestep, as the relative position of the grids on each side of the interface changes. It is possible to use a transient sliding interface anywhere a `Stage` or `Frozen Rotor` sliding interface could be used.

The principle disadvantage of this method is that the computer resources required may be large, in terms of simulation time, disk space and quantitative post processing of the data. The resource requirement problem is exacerbated if unequal pitch between components occurs. In these situations, spatial periodicity cannot formally be used to limit the analysis to a single blade passage per component. Often the problem of unequal pitch is addressed by modifying the geometry to the nearest integer pitch ratio, which may affect the validity of the analysis. In practice, components of unequal pitch can be treated by solving  $N$  passages on one side and  $M$  passages on the other side, with  $N$  and  $M$  determined such that the net pitch change across the interface is close to unity. As with a `Frozen Rotor` interface, pitch change is automatically accounted for by scaling of flows by the pitch ratio.

It is possible to start a `Transient Rotor-Stator` computation from a simple initial guess, or from an existing prediction. If you are interested in the start-up transient of the machine, then start from the

appropriate physical initial conditions. If you are interested in simulating a periodic-in-time quasi-steady state, then it may be helpful to first obtain a steady state solution using `Frozen Rotor` interfaces between components. This solution will contain most of the overall flow features, and should converge to the desired transient simulation in the fewest transient cycles.

Translational relative motion is not supported at a transient sliding interface (only rotational motion is supported).

### 5.3.3.2. Pitch Change

To connect dissimilar meshes, an intersection algorithm is used to find the overlapping parts of each mesh face at the interface; for details, see [GGI and MFR Theory in the CFX-Solver Theory Guide](#). The CFX-Solver must decide the most appropriate way to perform this intersection. The choices are:

- Intersect in physical space. The connection will be made as is with no correction for pitch change or rotational offset. This method is used when the pitch change model is set to `None`.
- Intersection in the radial direction. This method is used when the pitch change model is not `None` and the radial variation at the interface is larger than the axial ( $z$ -) variation. For example, this method is used for the surface of constant  $z$  in [Figure 5.5 \(p. 164\)](#).
- Intersect in the axial direction. This method is used when the pitch change model is not `None` and the axial variation at the interface is larger than the radial variation. For example, this method is used for the surface of constant radius in [Figure 5.5 \(p. 164\)](#).


If the pitch change model is not `None`, then the intersection algorithm will fail if the interface has any of the following:

- surfaces of zero radius
- surfaces of constant radius with surfaces of constant  $z$

For example, an interface cannot contain both highlighted regions in [Figure 5.5 \(p. 164\)](#). Instead, two separate interfaces should be used.


In addition, for best accuracy, the interface should not be highly curved. For example, if a small change in radius produces a large change in  $z$  and a small change in  $z$  produces a large change in radius in the same interface, then separate interfaces should be used instead.

**Figure 5.5 Radial vs. Z Direction**



When there is pitch change, a transformation is also performed between components to account for the fact that they may not be rotationally aligned. This does not affect the relative position of the components. In [Figure 5.6 \(p. 165\)](#) the components are not aligned; flow passes through the overlapping area as expected, but the flow that reaches the interface at 1 is transformed such that it emerges at 2 having crossed the interface.

**Figure 5.6 Misaligned Components**



### 5.3.3.2.1. None

Using `None` as the pitch change option will cause the connection to be made “as is.” If you have non-aligned components, as shown in [Figure 5.6 \(p. 165\)](#), flow will only pass through the overlapping region. Therefore, this option should only be used when the overall extent and shape of each side of the interface perfectly match and the surfaces are aligned with each other. It may therefore be suitable when full 360 degree or exactly equal pitch components are being analyzed. A pitch change option of `None` cannot be used for a stage interface.

### 5.3.3.2.2. Automatic

The `Automatic` pitch change option is the standard option for accounting for pitch change between components. The pitch ratio is taken to be the ratio of the areas of the two components. The two sides must each have the same radial or axial extent and can therefore only differ in extent in the direction of rotation of the frame of reference. This means that the surfaces on each side of a frame change interface must sweep on the same surface of revolution.

For the `Frozen Rotor` model, the flow variable profiles in the pitch-wise direction are stretched or compressed to the extent that there is pitch change across the interface. All flows (mass, momentum, energy, and so on) are scaled accordingly, based on the pitch change.

For the `Stage` model, the pitch change adjustment is made by applying average values calculated from the upstream side of the interface to the downstream side. The averaging is performed in a conservative manner. Meridional variation of the flow is maintained across the interface. Circumferential variation of all flow variables except pressure are removed across the interface. The average pressure is maintained at each meridional location across the interface, with independent local variation in pressure permitted.

The computational accuracy degrades rapidly with increasing pitch change. It is recommended that sufficient blade components be analyzed on each side of the interface to minimize pitch change. Any

pitch change will result in a non-physical transient interaction: the entire 360 degree components must be solved for truly “accurate” transient interactions if the pitch ratio is non-integer. Small pitch changes will introduce relatively smaller errors, large pitch changes will introduce larger errors.

On some meshes, the flow solver will fail to find the correct pitch angles. For example, this may happen when the vertices on the hub curve are not all at the same radial or axial position. Usually on this type of mesh, the flow solver will be unable to calculate the pitch angle and it will stop with an error message. However, sometimes the algorithm that determines the pitch angle will find an incorrect pitch angle. This will make the flow solution you get completely wrong. If your flow solution through the interface does not make sense, then one thing to check is if the flow solver failed to find the correct pitch angles by carefully examining the output file under the **Mesh Information** heading. If the angles do not look right, then you should specify them.

### **5.3.3.2.3. Value**

This option enables you to explicitly provide the pitch ratio. This is the ratio of the pitch angle from the side with the larger pitch angle to the side with the smaller pitch angle across the domain interface. You can use this option when the precise pitch ratio is critical to the analysis; for example, in a closed system containing multiple pitched components. In most cases, the automatic option is sufficient for determining the pitch ratio.

### **5.3.3.2.4. Specified Pitch Angles**

This option enables you to specify the pitch angle on side 1 and side 2 of the domain interface. You can use this option when the precise pitch angle is needed or when the area ratio of the two sides is not equal to the pitch ratio. In most cases, the automatic option is sufficient for determining the pitch ratio.

## **5.3.4. Mass and Momentum Models**


CFX offers two kinds of mass/momentum modeling options at domain interfaces: a user-specified pressure change and a user-specified mass flow rate. These have different applications depending on the type of domain interface.

### **5.3.4.1. Translational Periodicity**

It is often useful to model periodic flow but allow a pressure drop between the two sides of the interface. Examples of this include:

- flow through tube banks in heat exchangers
- periodic duct flow

If the pressure drop is specified, the solver will calculate the flow field including the mass flow rate. Alternatively, if the mass flow rate through the interface is known, the solver will calculate the flow field including the pressure drop. If a pressure change condition is specified, the specified pressure change is assumed to be from side 1 to side 2 of the interface (see the figure below). For pressure drop situations like flow through a duct or tube bank, this pressure change should be negative. If a mass flow rate condition is specified, the specified mass flow rate is assumed to be into the domain through side 1 and out of the domain through side 2.

**Figure 5.7 Applying a Mass Flow at a Periodic Domain Interface**

### 5.3.4.2. General Connection

The following sections describe applying a specified pressure change or a mass flow rate to a general domain interface.

#### 5.3.4.2.1. Specified Pressure Change

It is sometimes useful to apply a pressure change condition to a general domain interface. For example, a screen model might prescribe a pressure drop at the domain interface which is proportional to the local dynamic head:

$$\Delta p = -k\rho(u^2 + v^2 + w^2) \quad (5-1)$$

where  $k$  is the screen loss coefficient and  $\Delta p$  is the pressure change measured from side 1 to side 2. This screen model can be implemented using the following CEL expression:

$$\text{Pressure Change} = -k * \text{density} * (u^2 + v^2 + w^2)$$

Note that in the case that the density in the above expression is itself dependent on the pressure, such as for an ideal gas, the pressure from side 1 is used to evaluate the density.

Another application of the pressure change condition is modeling a fan for which the pressure rise is a function of the mass flow rate:


$$\Delta p = f(\dot{m}) \quad (5-2)$$

This fan model can be implemented by creating an interpolation function or CEL expression for  $\Delta p$ ; for example, if one side of the domain interface has the name `Fan Side 1`, one could create a CEL expression or interpolation function for  $\Delta p$  as follows:

$$\text{Pressure Change} = f(\text{massFlow()}@Fan Side 1)$$

#### 5.3.4.2.2. Specified Mass Flow Rate

The mass flow rate can also be specified through a general connection. The specified mass flow rate is assumed to be from side 1 to side 2 of the interface. See the figure below.

**Figure 5.8 Applying a Mass Flow at a General Connection**

The solver implements the specified mass flow condition by adjusting the pressure change until the specified mass flow rate is satisfied. Prior to convergence, the actual mass flow rate may not satisfy the specified mass flow rate, although it typically becomes close within a few dozen iterations. To enhance robustness of this condition, the pressure change is underrelaxed with a default underrelaxation factor of 0.25. This value can be increased if convergence to the specified mass flow rate is slow but monotonic and decreased if convergence to the specified mass flow rate is oscillatory or unstable.

### 5.3.4.3. Further Comments

When using a pressure change, the solver checks an additional criterion when deciding whether the problem has converged. For the pressure change condition, the solver checks whether

$$\frac{\dot{m} - \dot{m}_{old}}{\max(|\dot{m}|, |\dot{m}_{old}|)} < x \quad (5-3)$$

where  $x$  is the domain interface convergence criterion. By default,  $x$  is 0.01, but can be modified by changing **Domain Interface Target** on the **Solver Control** tab in CFX-Pre.

When using a mass flow rate condition, the solver checks the following additional criterion when deciding whether the problem has converged:

$$\frac{\Delta p - \Delta p_{old}}{\max(|\Delta p|, |\Delta p_{old}|)} < x \quad (5-4)$$

The mass flow rate through each side of the domain interface can be monitored by creating a new plot in the CFX-Solver Manager. For the plot line, select FLOW, then DOMAIN INTERFACE, then the domain interface side you want to monitor, and then choose P-MASS.

## 5.4. Mesh Connection Options

Domain interfaces connect meshes using two region lists. There are three mesh connection options:

- [Automatic Connections](#) (p. 169)
- [Direct \(One-to-One\) Connections](#) (p. 169)
- [GGI \(General Grid Interface\) Connections](#) (p. 170)

In certain situations, General Grid Interface (GGI) connections are used even when there is a direct (one-to-one) correspondence in nodes on either side of the interface. The rules for when this occurs are given below. If the physics permits a direct connection, the latter is usually preferable.

All domain interfaces automatically create boundary conditions of type “Interface” for the region lists used. For details, see [Interface Boundary Conditions in the CFX-Pre User's Guide](#).

### 5.4.1. Automatic Connections

CFX-Pre automatically chooses whether the connection is direct (one-to-one) or not, based on whether the nodes are coincident and the selection of regions on `side 1` and `side 2`. The tolerance used to determine if nodes match across the interface, **Mesh Match Tolerance**, can be set under **Edit > Options > Mesh** in CFX-Pre. The actual connection type chosen is reported by CFX-Pre when the CFX-Solver input file is written.

An automatic connection cannot be made when conditional connection control is used for the interface. In such a case, the only available mesh connection option is GGI. For details on conditional connection control, see [Conditional Connection Control in the CFX-Pre User's Guide](#) and [Conditional Connections \(p. 171\)](#).


### 5.4.2. Direct (One-to-One) Connections

The direct (one-to-one) connection is available if, after any applicable rotational or translational transformation (such as for a periodic interface), all of the nodes on one side of the interface correspond in location with all of the nodes on the other side of the interface, to within a spatial tolerance governed by the **Mesh Match Tolerance** parameter. The latter can be set in CFX-Pre by selecting **Edit > Options**, then changing the **Mesh Match Tolerance** setting, found under `CFX-Pre > Mesh` in the tree view of the **Options** dialog box. For details, see [Mesh in the CFX-Pre User's Guide](#). You can verify the type of interface that CFX-Pre will apply by right-clicking `Simulation` in the Outline tree view, and selecting **Report Interface Summary** from the shortcut menu.

In addition to requiring a precise node correspondence from one side to the other, a direct (one-to-one) connection requires that:

- The number of regions in the list for one side is equal to the number of regions in the list for the other side
- For each region in the region list for one side, there is exactly one region in the list for the other side that corresponds entirely in terms of the number of nodes and their positions
- Both sides of the interface are in the same domain for `Fluid Fluid` and `Solid Solid` interfaces
- The interface type is not `Fluid Porous` or `Porous Porous`
- A pressure change or mass flow condition is not set at the interface.

In addition, for periodic interfaces, CFX-Solver will change direct connections to GGI connections as necessary to ensure that every node that participates in multiple direct connections has only one unique required transformation (translation or rotation). For example, in [Figure 5.9 \(p. 170\)](#), the corner nodes are involved in two interfaces that have different transformations. In this case, at least one of the interfaces will be changed to use a GGI connection.

**Figure 5.9 Nodes Shared by Interfaces with Different Transformations**

A direct (one-to-one) connection cannot be made when conditional connection control is used for the interface. For details on conditional connection control, see [Conditional Connection Control in the CFX-Pre User's Guide](#) and [Conditional Connections](#) (p. 171).

### 5.4.3. GGI (General Grid Interface) Connections

General Grid Interface (GGI) connections refer to the class of grid connections where the grid on either side of the two connected surfaces does not match. In general, GGI connections permit non-matching of node location, element type, surface extent, surface shape and even non-matching of the flow physics across the connection.

All model options within CFX (for example, turbulence models, multiphase models, particle tracking, mixture models, reaction, and so on) support the use of GGI connections. Any number of GGI connection conditions are possible within a computational domain.

The GGI connection will be made in a conservative and implicit fashion, even if the nodes on the two sides of the connection are not aligned. Likewise, the element types on each side do not have to match. In addition, if the size of the connection region on one side is different than that on the other side, the connection will be made automatically between the mutually-overlapping surfaces. Finally, it is possible to perform a connection where there is a slight gap or interference between the two sides of the GGI connection. Here, "slight" means an interference or gap on the order of  $\frac{1}{2}$  the average depth of the elements touching the connection surface. This permits connections where the surfaces do not fit together perfectly (for example, curved connection with different grid densities on each side), or where the components are not perfectly aligned with each other. Even in these situations, conservation is guaranteed and strictly enforced; for details, see [GGI and MFR Theory in the CFX-Solver Theory Guide](#).

The regions that are on each side of a GGI connection are allowed to be of different size and are allowed to have non-overlap regions (see [Non-overlap Boundary Conditions](#) (p. 170)). The extent of the non-overlap region is reported in the solver output file (see [CFX-Solver Output File \(GGI Runs\) in the CFX-Solver Manager User's Guide](#)). If the extent of the non-overlap area is larger than expected, confirm that the correct regions have been selected for each side of the interface. There are Intersection Control settings that can be used to increase the accuracy of the overlap calculation if necessary (see [Intersection Control: Option in the CFX-Pre User's Guide](#)).

#### 5.4.3.1. Non-overlap Boundary Conditions

The portions of the connecting surfaces in a GGI connection that do not overlap each other behave by default in the same way as the default wall boundary condition that is made by CFX-Pre in a fluid domain. This default condition is a no-slip adiabatic wall with a zero-flux condition applied to all other transport

equations. Particles will bounce off these walls with restitution coefficients of 1, and radiation will see an adiabatic wall.

The default behavior can be changed after the domain interface has been created by visiting the boundary condition object for the side of the interface where you want the boundary condition changed. For example, you may choose to set a wall roughness, or set a wall velocity, or change to a free slip wall. You can also change the zero-flux condition for any transport equation. For example, you can allow heat transfer or the transport of Additional Variables.

CFX-Solver will output a variable, `Nonoverlap Fraction`, for each side of the interface to indicate which nodes are in the overlap portion (`Nonoverlap Fraction=0`) and which are in the non-overlap portion (`Nonoverlap Fraction=1`) of the interface. This variable is available to CFD-Post. For example, you could multiply a quantity in an expression by `Nonoverlap Fraction` or `(1-Nonoverlap Fraction)` to ignore contributions from nodes on a GGI interface that are in the overlap portion, or non-overlap portion, respectively.

### 5.4.3.2. Conditional Connections

Conditional Connection Control enables you to use an expression to control whether an interface is open (connected) or closed (not connected; a wall boundary is applied). This feature can be used to avoid having to use a moving mesh to suddenly snap interface surfaces apart at a given time (in order to force a non-overlap condition to exist), or to use multiple configurations to load different meshes during a simulation.

To set up a conditional connection control, configure the **Conditional Connection Control** settings on the **Additional Interface Models** tab for the domain interface. These settings are described in [Conditional Connection Control in the CFX-Pre User's Guide](#).

---

#### Note

When conditional connection control is used, the **Mesh Connection** option (on the **Mesh Connection** tab) is forced to be GGI.

The CFX-Solver will write diagnostics information to the `.out` file whenever the state of an interface with a specified Conditional Connection Control is changing.

### 5.4.4. Mesh Connection Recommendations

Domain interfaces that use GGI connections are a very powerful and flexible mesh connection method, but they do require some additional computational effort and memory, and may introduce numerical inaccuracy compared to an equivalent computation that does not use GGI connections. For these reasons, you should use GGI connections wisely and sparingly.

For periodic interfaces, GGI connections always introduce some error into your simulation compared with direct connections. This is because direct connections solve the equations as if the mesh were actually replicated, so there is no additional discretization error due to the presence of the interface.

For simulations involving conjugate heat transfer, on the other hand, direct connections are less desirable than GGI connections because in direct connections the discretization of heat flow through fluid-solid, porous-solid, and solid-solid interfaces is *nonsymmetric* (that is, direct connections use more information from the more conductive side of the interface, while GGI connections sample both regions equally). The direct connection's nonsymmetric treatment may lead to accuracy and/or convergence difficulties in the following situations:

- The domain interface is fluid-solid or porous-solid.
- The domain interface is solid-solid and there is a large conductivity ratio across the interface.

---

### Note

- In laminar domains, fluid-solid interfaces should be GGI to avoid the possibility of a Class 3 error.
- To avoid spurious overshoots and undershoots of the solution in the vicinity of the interface, the **Automatic** setting employs GGI for fluid-solid, porous-solid, and solid-solid interfaces.

In these situations, you should consider using a GGI connection rather than a direct connection, even if a direct connection is possible.

If you believe that an interface should be a one-to-one connection, but a GGI connection is made instead, then you should first check that you have set the correct rotation axis for a rotational periodic interface. Next, you should load the CFX-Solver input file into CFD-Post to check that the mesh appears to match. You can plot the mesh on each side of the interface using a different color to check that the two sides match. In the case of periodic interfaces, you can use an instancing transform to manually perform the transformation and then check that the meshes match. Before increasing the **Mesh Match Tolerance**, you should try to reproduce the mesh such that it matches within the default tolerance. If the meshes appear to match but a GGI connection is still created, you can increase the **Mesh Match Tolerance**. Increasing the tolerance above 0.02 (2%) is not recommended as this will result in a loss of accuracy.

## 5.5. Defining Domain Interfaces as Thin Surfaces

In Release 12.0, thin surfaces have been implemented to allow the modeling of physics (such as heat transfer, mass transfer, and momentum losses) across thin-surfaces. In previous releases, the **Create Thin Partner** option created two independent walls, which did not allow physics to be implemented. Starting with Release 12.0, you can model a thin surface either as:

- A boundary condition (for details see [Default Boundary Condition in the CFX-Pre User's Guide](#))
- A domain interface with the physics modeled across the interface.

The types of domain interfaces you can define as thin surfaces depends on the domains involved:

Domains	Allowed Domain Interface
Fluid-Fluid	Solid
Fluid-Porous	
Porous-Porous	
Solid-Fluid	Solid or Constant-Property Substance <sup>a</sup>
Solid-Porous	
Solid-Solid	

<sup>a</sup>A Constant-Property Substance could be a fluid that has no motion and that is not pressure-dependent.

### 5.5.1. Modeling Thin Surfaces: Overview

Conceptually, to create a thin surface:

1. Create your domains.
2. Define a domain interface. Physics definitions are set on the **Additional Interface Models** tab; the provided models are determined automatically from the geometry.

Choose **Conservative Interface Flux** to define a thin surface that has physics operating between the two sides; if you choose that option, set the **Interface Model** as well.

3. When you click **OK** to create the domain interface, a pair of boundaries are created (Domain Interface 1 Side 1 and Domain Interface 1 Side 2) under **Simulation > Flow Analysis > <domain\_name>**.

## 5.6. Recommendations For Using Domain Interfaces

This section describes:

- [Using Domain Interfaces](#) (p. 173)
- [Using Multiple Domain Interfaces](#) (p. 173)
- [Using Domain Interfaces in Turbomachinery Applications](#) (p. 174)

### 5.6.1. Using Domain Interfaces

The following points should be considered when using domain interfaces:

- Domain interfaces are always required when multiple assemblies are used within a domain or across multiple domains. If you do not create the required domain interfaces, the regions will remain part of the default wall boundary condition.
- Domain interfaces are also always required when multiple domains are created within a single assembly. If you do not create the required domain interfaces, default domain interfaces will be created which may or may not be appropriate.
- Domain interfaces are not required when multiple 3D regions within the same assembly are selected for a single domain.
- Any given domain must contain at least one node that is not used in a domain interface. Domains defined only by interface nodes will not be accepted by the CFX-Solver.
- You cannot use **Mesh Adaption** when a simulation contains domain interfaces.

Information on the implementation of GGI connections is available in [GGI and MFR Theory in the CFX-Solver Theory Guide](#).

### 5.6.2. Using Multiple Domain Interfaces

A given simulation can make use of multiple domain interfaces. Each Fluid Fluid interface can use a different frame change model. For example, two domains can be connected by a Fluid Fluid interface without a frame change; one of these domains might also contain a rotationally periodic interface to define a blade passage. Finally, there might be another Fluid Fluid interface between the first two domains and a third domain that uses a frame change model. A four stage axial compressor, consisting of four stators and four rotors, might contain seven Fluid Fluid interfaces with a Frozen Rotor frame change model (one at each frame change interface between components).

It is possible to have a combination of frame change models within a single problem definition. For example, in a stator/rotor/stator configuration, the first Fluid Fluid interface could be a Stage or Frozen Rotor interface, and the second interface could be a Transient Rotor-Stator interface.


This might make sense if you are only interested in accounting for the transient conditions between the rotor and the downstream stator.

### 5.6.3. Using Domain Interfaces in Turbomachinery Applications

The setup of domain interfaces is an important consideration when defining a turbomachinery problem. The following section outlines some approved practices for use in turbomachinery applications.


- Domain Interfaces should typically be placed midway between the rotor and stator for turbomachinery cases.
- Where circular domain interfaces exist, they must be axisymmetric in shape.
- The aspect ratio of elements on the domain interface should not be greater than 10:1. [Figure 5.10 \(p. 174\)](#) gives a sketch of the requirement for an element aspect ratio of less than 10 on the domain interface. The element aspect ratio ( $x/y$ ) should lie in the range 0.1 to 10 to avoid numerical errors.

**Figure 5.10 Element Aspect Ratio**




#### 5.6.3.1. Case 1: Impeller/Volute

A basic impeller/volute sketch is shown in [Figure 5.11 \(p. 175\)](#). The edge of the inner circle shows the maximum extent of the impeller blades. A good practice here is to create the domain interface halfway across the most narrow gap between the blade and volute wall. This usually occurs around the cut-off or tongue illustrated in the diagram.

**Figure 5.11 Basic Impeller/Volute**

### 5.6.3.2. Case 2: Step change between rotor and stator

For the case shown in [Figure 5.12](#) (p. 175), there is a step change between the rotor and stator. A common choice for placement of the interface would be choice 1. However, take care with this setup because the non-overlap regions above and below the interface should be specified as walls. A better alternative may be to use a domain interface upstream or downstream of the step change, at position 2 or position 3.


**Figure 5.12 Step change**

### 5.6.3.3. Case 3: Blade Passage at or close to the edge of a domain

[Figure 5.13](#) (p. 176) shows a blade that extends to the edge of the rotating domain. Although it is convenient to place a domain interface at the blade edge (1), this can result in convergence difficulties. A

better arrangement is to extend the rotating domain away from the blade edge. Domain Interfaces can then be created at (2), (3), and (4).


**Figure 5.13 Blade extending to the edge of the rotating domain.**



#### 5.6.3.4. Case 4: Blade Passage at or close to the edge of a domain

Figure 5.14 (p. 176) shows a close-up view of part of Figure 5.13 (p. 176), which models flow leaking from a volute back into the impeller region. To model the feature, you can use two domain interfaces (at position 1), or a single domain interface downstream of the leak (position 2).


**Figure 5.14 Blade passage**



### 5.6.3.5. Case 5: Blade with thick trailing edge

As *Figure 5.15* (p. 177) shows, when a blade with a thick trailing edge passes close to the domain interface, recirculating flow that crosses the interface can occur. Running a case like this with a Stage interface can produce unphysical results. It is recommended that you either move the domain interface away from possible recirculation zones, or run with the Frozen Rotor interface.

**Figure 5.15 Thick trailing edge**



## 5.7. Automatic Creation and Treatment of Domain Interfaces

You should generally create all domain interfaces that are needed in your simulation explicitly in CFX-Pre. However, CFX-Pre will create default domain interfaces in certain situations.

Domain interfaces will be automatically created, at the Write Solver File stage, when there are multiple domains within a single assembly and you have not explicitly created all the required domain interfaces. These could be `Fluid Fluid`, `Fluid Solid` or `Solid Solid` domain interfaces depending on the type of domain on either side of the interface.

When a default `Fluid Fluid` interface is created and there is no change in reference frame across the interface, the **Frame Change** option is set to `None`. When a frame change occurs, the `Frozen Rotor` model is used. If these models are not appropriate, you should explicitly create all domain interfaces to prevent the automatic creation of interfaces.

When a one-to-one node mapping does not exist, you must manually create the domain interfaces. If multiple domains are created using separate assemblies, domain interfaces are always required.

Fluid-solid 2D primitives are initially contained in the default domain boundary conditions. Any that remain there when a CFX-Solver input file is written are assigned to default `Fluid Solid` domain interfaces.

If you create a MFR case using 3D primitives from a single assembly, then a one-to-one node pairing will exist because an assembly contains a continuous mesh. However, a GGI connection is required for MFR cases. A default domain interface using the `Frozen Rotor` frame change model will be automatically created if no other domain interfaces are created.



---

## Chapter 6: Transient Blade Row Modeling

---

It can be computationally expensive to predict the unsteady phenomena that occur as a result of the interaction between adjacent blade rows or boundary disturbances. It can be even more expensive if you need to include more than a few passages per blade row to capture the phenomena more accurately.

In typical turbomachinery applications, it is very common that one or both blade rows have a prime number of blades per wheel. Formerly in such cases, it was necessary to model the whole 360° wheel in order to attain the required level of accuracy. The Transient Blade Row models available in ANSYS CFX make it possible to reduce the size of the computational problem (memory and computational time) by solving the blade row solution for one or two passages per row, while still obtaining reasonably accurate solutions, thus providing a solution to the unequal pitch problem between the blade passages of neighboring rows.

The Transient Blade Row models available in ANSYS CFX are:

- Profile Transformation
- Time Transformation
- Fourier Transformation

The Profile Transformation method overcomes the unequal pitch problem by scaling the flow profile across the blade row interfaces. In the Time Transformation method, the unequal pitch problem is overcome by applying a time transformation to the flow equations so that we can use simple periodic boundary conditions on the pitch-wise boundaries. In the Fourier Transformation method, a phase-shifted boundary condition with Fourier data compression is used to account for the unequal pitch between the blade rows passages. The Fourier Transformation and Time Transformation methods can be used to apply periodic conditions that are phase-shifted in time in order to account for inequality between signal and domain pitches for boundary disturbance cases.

For more on this topic, and for theoretical information about the Time Transformation and Fourier Transformation models, see [Transient Blade Row Modeling Theory in the CFX-Solver Theory Guide](#).

This chapter describes:

- 6.1. Transient Blade Row Modeling Terminology
- 6.2. Setting up a Transient Blade Row Model
- 6.3. Running and Postprocessing a Simulation that uses a Transient Blade Row Model
- 6.4. Profile Transformation
- 6.5. Time Transformation
- 6.6. Fourier Transformation
- 6.7. Guidelines for Using Transient Blade Row Features
- 6.8. Use Cases

### 6.1. Transient Blade Row Modeling Terminology

The following terminology applies in the context of transient blade row modeling:

- *Turbo Component* - is the sector of blades in a given blade row that are being modeled in the analysis. Transient Rotor-stator analyses involve at least two components, one rotating and one stationary component.
- *Conventional Periodicity* - are periodic boundaries with no special time lag for phase-shift treatment. In such cases, the rotating and stationary components are not necessarily periodic to each other at different instances of time.
- *Reference Solution (or Full-domain modeling)* - refers to solving a transient blade row problem using an ensemble of blade passages where the pitch ratio is one.
- *Transient Blade Row methods* - are the CFX Transient Blade Row methods:
  - Fourier Transformation method
  - Time Transformation method
  - Profile Transformation method

## 6.2. Setting up a Transient Blade Row Model

You can use the Turbomachinery wizard in CFX-Pre to set up a Transient Blade Row model.

1. Under the Basic Setting Panel set the **Analysis Type** to `Transient Blade Row`; and select either the `Time Transformation` or `Fourier Transformation` option under **Method**.
2. Define the rotor and/or stator blade passages under **Components Definition**.

When using the Fourier Transformation method, you must set up two blade passages per component and adjust the periodic interfaces accordingly. You must set the **Passages and Alignment** > **Passages/Mesh** > **Passages to Model** to 2. This will also create the Sampling Interface required for the Fourier Transformation model.

3. Set up the physics as usual (including domains, domain interfaces, boundary conditions, and so on, as required) under the **Physics Definition** panel.
4. Under the **Interface Definition** panel you can observe and modify the various sampling and periodic interfaces that are automatically generated by the TurboMachinery wizard.
5. Under the **Disturbance Definition** panel, you will specify the periodicity of the disturbance being imposed.
6. Continue clicking **Next** until the **Final Operations** panel is reached. Set **Operation** to `Enter General Mode` because you will continue to define the simulation through settings not available in the TurboMachinery wizard.
7. Ensure that there is a `Transient Blade Row Models` object under the applicable **Flow Analysis** object. If there is not, you can add one according to the instructions provided at [Inserting a New Transient Blade Row Models Object in the CFX-Pre User's Guide](#).
8. Configure the settings in the details view for the Transient Blade Models object. For details, see [Transient Blade Row Models Tab in the CFX-Pre User's Guide](#).
9. Configure the output control settings. These settings are described at [Transient Blade Row Results in the CFX-Pre User's Guide](#). It is a good practice to set up monitor points to check the results. For details, see [Setting up Monitors to Check Results \(p. 181\)](#).

For details, see [Starting a New Case in Turbo Mode in the CFX-Pre User's Guide](#).

The procedure for setting up a Transient Blade Row model in General mode is as follows:

1. Set the analysis type to `Transient Blade Row`; also set the initial time.

For details, see [Analysis Type Settings in the CFX-Pre User's Guide](#).

2. Set up the physics as usual (including domains, domain interfaces, boundary conditions, and so on, as required).

In particular, you must set the **Passage Definition** settings (**Passages in 360** and **Passages / Component**) on the **Basic Settings** tab for each domain.

When using the Fourier Transformation method, you must set up two blade passages per component and adjust the periodic interfaces accordingly. The interface(s) between passages must use a GGI connection.

3. Ensure that there is a `Transient Blade Row Models` object under the applicable **Flow Analysis** object. If there is not, you can add one according to the instructions provided at [Inserting a New Transient Blade Row Models Object in the CFX-Pre User's Guide](#).
4. Configure the settings in the details view for the `Transient Blade Models` object. For details, see [Transient Blade Row Models Tab in the CFX-Pre User's Guide](#).
5. Configure the output control settings. These settings are described at [Transient Blade Row Results in the CFX-Pre User's Guide](#). It is a good practice to set up monitor points to check the results. For details, see [Setting up Monitors to Check Results \(p. 181\)](#).

You can change an existing transient case to use Transient Blade Row models in General mode as follows:

1. Change the analysis type to `Transient Blade Row`.

For details, see [Analysis Type Settings in the CFX-Pre User's Guide](#).

2. Set the **Passage Definition** settings (**Passages in 360** and **Passages / Component**) on the **Basic Settings** tab for each domain.
3. When using the Fourier Transformation method, you must set up two blade passages per component and adjust the periodic interfaces accordingly. The interface(s) between passages must use a GGI connection.
4. Ensure that there is a `Transient Blade Row Models` object under the applicable **Flow Analysis** object. If there is not, you can add one according to the instructions provided at [Inserting a New Transient Blade Row Models Object in the CFX-Pre User's Guide](#).
5. Configure the settings in the details view for the `Transient Blade Models` object. For details, see [Transient Blade Row Models Tab in the CFX-Pre User's Guide](#).
6. Configure the output control settings. These settings are described under [Transient Blade Row Results in the CFX-Pre User's Guide](#). It is good practice to set up monitor points to verify that a periodic solution has been achieved. For details, see [Setting up Monitors to Check Results \(p. 181\)](#).

Note that a given simulation can use either the Time Transformation or Fourier Transformation model, but not both. Either of these models can be used in conjunction with the Profile Transformation model. The Profile Transformation model, when used in conjunction with one of the other methods, is not explicitly selected in the user interface. For details on the Profile Transformation model, see [Profile Transformation \(p. 182\)](#).

### 6.2.1. Setting up Monitors to Check Results

While setting up an analysis that involves the Time Transformation or Fourier Transformation model, you should add some monitor points for diagnostic purposes. The monitor points should be placed at strategic locations, and should monitor variables that are expected to have periodic fluctuating values. During or after the run, you can check the monitor point values in CFX-Solver Manager to ensure that:

- Each monitored variable value fluctuates in a repeating pattern (periodicity).
- The period of such fluctuations correspond to the blade passing frequency of the neighboring row.

### 6.3. Running and Postprocessing a Simulation that uses a Transient Blade Row Model

Time-corrected monitor plots are available for a simulation that involves the Time Transformation Transient Blade Row model. For details, see [Convergence History Plots and User Point Plots in the CFX-Solver Manager User's Guide](#).

The CFX-Solver Output file contains, for each domain, the starting and ending time steps for the data compression algorithm, as well as the fundamental period. For details, see [CFX-Solver Output File \(Transient Blade Row Runs\) in the CFX-Solver Manager User's Guide](#).

### 6.4. Profile Transformation

The `Profile Transformation` method:

- Is available when there is at least one interface that uses the `Transient Rotor Stator` frame change/mixing model.
- Applies to any domain interface using the `Transient Rotor Stator` frame change/mixing model that is not used in the `Time Transformation` or `Fourier Transformation` model.
- Uses conventional periodicity at periodic boundaries (that is, has no special time lag for phase shift treatment).
- Results in the same solution as a transient simulation that uses the `Transient Rotor Stator` frame change/mixing model with the same time step specifications.

### 6.5. Time Transformation

The main advantage of the `Time Transformation` method is that conventional periodicity boundary conditions can be applied directly, resulting in relatively fast convergence.

The `Time Transformation` method:

- Is valid only for compressible flows
- Is valid only when the pitch ratio between the modeled components does not deviate much from unity
- Requires that the pitch ratio fall within a certain range, as described by the inequality:

$$1 - \frac{M_\omega}{1 - M_\theta} < \frac{P_S}{P_R} < 1 + \frac{M_\omega}{1 + M_\theta}$$

where  $M_\omega$  is the Mach number associated with the rotor rotational speed (or signal speed in the case of an inlet disturbance problem),  $M_\theta$  is the Mach number associated with the tangential Mach number, and the ratio of  $P_S$  to  $P_R$  is the pitch ratio between the stationary component and the rotating component.

These limits are not strict, but approaching them can cause solution instability.

For most compressible turbomachinery applications (for example, gas compressors and turbines),  $M_\omega$  is in the range of 0.3 - 0.6, allowing pitch ratios in the range of 0.6 - 1.5 (Giles [217]). If necessary, you can make the pitch ratio fall within the permissible range by strategically choosing the number of passages per component for each of the components.

---

**Note**

See [Time Transformation Method in the CFX-Solver Theory Guide](#) for more theoretical information about the Time Transformation method.

### 6.5.1. Time Transformation: Workflow Requirements

The basic procedure for setting up a Transient Blade Row model is outlined in [Setting up a Transient Blade Row Model \(p. 180\)](#). When your simulation involves the Time Transformation model, your workflow should include the following steps:

- Ensure that the pitch ratio between adjacent components is within the proper range by appropriately adjusting the number of blades in each component. The proper range is described in [Time Transformation \(p. 182\)](#).
- Those transient rotor stator interfaces not referenced by a disturbance will be treated with the Profile Transformation method.
- You can model only a single stage. As a result, there must be exactly one domain interface.
- Based on the case you are working on, for a given domain, add one disturbance to the list of disturbances.
- Ensure that the relative speed associated with the disturbance is not zero.

## 6.6. Fourier Transformation

Unlike Time Transformation, the Fourier Transformation method does not have any known limitations on the pitch ratio and works with both, compressible and incompressible flows.

Similar to the Time Transformation method, Fourier transformation disturbances can be used for modeling rotational flow boundary disturbances.

---

**Note**

See [Fourier Transformation Method in the CFX-Solver Theory Guide](#) for more theoretical information about the Fourier Transformation method.

### 6.6.1. Fourier Transformation: Workflow Requirements

The basic procedure for setting up a Transient Blade Row model is outlined in [Setting up a Transient Blade Row Model \(p. 180\)](#). When your simulation involves the Fourier Transformation model, your workflow should include the following steps:

- Each turbo component requires two instances of the passages that constitutes a repeatable section. A GGI interface must be created to join the two components. Create a periodic domain interface to tie the outer blades in each blade row. This domain interface will be selected when defining the phase corrected interface. See [Fourier Transformation Disturbance Settings in the CFX-Pre User's Guide](#) for a description of the sampling domain interface.

- For a given domain, optionally add one disturbance to the list of disturbances.
- All periodic and sampling interface pairs must use the `Bitmap` intersection method. The option that controls the intersection method is found in CFX-Pre in the details view for the domain interface, on the **Basic Settings** tab, under **Mesh Connection Method > Mesh Connection > Intersection Control**. For periodic and sampling interface pairs, the `Bitmap` method takes effect when the **Intersection Control** check box is cleared. When the **Intersection Control** check box is selected, the **Option** setting is set to `Bitmap` by default.
- You must ensure that the time step is of a size that fits into the period of each disturbance an integer number of times. Ensure that no disturbance signal has a speed of zero relative to the component on which that signal acts.
- When solving a simulation that involves the Fourier Transformation method, the use of double precision is strongly recommended for accuracy.
- When solving a simulation that involves the Fourier Transformation method, ensure that you:
  - Select the **Continue History From** check box.
  - Set **Initial Values Specification > Use Mesh From**, to `Initial Values`.

## 6.7. Guidelines for Using Transient Blade Row Features

Guidelines for using Transient Blade Row features are described in the following sections:

[6.7.1. General Setup Guidelines](#)

[6.7.2. Guidelines for using the Time Transformation Feature](#)

[6.7.3. Guidelines for using the Fourier Transformation Feature](#)

[6.7.4. General Postprocessing Guidelines](#)

### 6.7.1. General Setup Guidelines

- CFX-Pre Turbomachinery Wizard:
  - When setting up your transient blade row problem, it is always recommended that you use the Turbomachinery wizard in CFX-Pre.
- Flow initialization:
  - A steady-state solution can be used as the initial condition for all transient flow simulations. You may use the Stage model (mixing-plane) or Frozen Rotor method, when modeling multiple blade rows.
- Time-integration:
  - For all transient blade row simulations, a uniform time step must be used.
  - You should not change the time step (number of time steps per period or timestep multiplier) in the middle of a simulation.
- Inflow and Outflow Boundary Conditions:
  - For proper comparison between the full domain solution and any of the transient blade row solutions, the inflow and outflow boundary conditions must be equivalent. For example: an average pressure specification on an outlet boundary should not apply on the full extent of the outlet in the full domain model but rather it should be applied to individual passage outlets to replicate the transient blade row solution boundary condition specification. Therefore it is advised to divide the full-domain inlet and outlet boundaries into multiple boundaries for each passage.

- For an inlet disturbance problem: When working with profiles as boundary conditions, be sure to double-check the periodicity of the profiles on both reference test cases and the transient blade row test cases. You can use monitors at the inlet to do this check.
- Solution Monitoring:
  - You can use solution monitor points to monitor the results of the transient simulation.
  - When comparing the full-domain reference solution with the transient blade row solution, it is important to locate the monitors in the passages of the full-domain geometry with relative locations as in the transient blade row passage configuration.

### 6.7.2. Guidelines for using the Time Transformation Feature

- Pitch ratio:
  - There is a limit on the range of pitch-ratio allowed when using the Time Transformation method. This range is strongly dependent on the Mach number associated with the rotor rotational speed (or signal speed in the case of an inlet disturbance problem). The pitch-ratio limit is defined in *Time Transformation* (p. 182).
- Solution Monitoring
  - The Time Transformation method does not support monitor points that use CEL expressions. Instead, you can use solution variables (pressure, temperature, etc.) to monitor the solution.

### 6.7.3. Guidelines for using the Fourier Transformation Feature

- When not using the Turbomachinery wizard in CFX-Pre, additional steps are needed for creating turbo topology:
  - You must create two instances of the blade passage. There are two options by which you can create a copy of the original passage:
    - Perform a turbo rotation on the copy of the original geometry (mesh) by its own pitch. The rotation angle must be specified with many decimal digits for minimum round-off error.
    - Update the number of passages per component and passages in 360 in each domain.
- It is safer to run CFX-Solver in double precision for all Fourier Transformation cases.
- When setting up a Fourier Transformation run, any domain interface that is not part of the Fourier Transformation Transient Blade Row setup should not span more than one domain.
- To restart from a steady state solution:
  - From command line: use the `-ini` flag instead of the `-ini-file` flag when specifying the steady state solution.
  - From CFX-Solver Manager: under “Initial Values Specification”:
    1. Select the **Continue History From** check box.
    2. Set **Initial Values Specification** > **Use Mesh From**, to `Initial Values`.

### 6.7.4. General Postprocessing Guidelines

- Animations:
  - Because the resulting animations of transient blade row cases are usually periodic in time, you must take care not to repeat the start/end point of the period when these are identical. The animation

panel has an advanced option to avoid this (the option is named **Don't Encode Last MPEG frame**), and you should select this option when working with a transient blade row animation.

## 6.8. Use Cases

The use cases targeted with these multi-blade row models include:

6.8.1. Case 1: Transient Rotor Stator Single Stage


6.8.2. Case 2: Flow Boundary Disturbance

### 6.8.1. Case 1: Transient Rotor Stator Single Stage

The transient rotor stator (TRS) single stage case is supported by the Time Transformation model.

- Time Transformation


**Figure 6.1 Typical Transient Rotor Stator Simulation using Time Transformation**



- You must select the transient rotor stator interface to which the transformation applies.
- No additional parameters are needed if the 'Automatic' selection of domains is applied for either side of the interface.

## 6.8.2. Case 2: Flow Boundary Disturbance

Figure 6.2 Inlet Disturbance Case



A flow boundary disturbance case involves modeling the effect of an external component (a virtual blade row upstream or downstream of the fluid mesh) via an inlet or outlet boundary condition that varies in time. Such cases are supported by the Time Transformation and Fourier Transformation models.

This type of simulation can be used as a lower-order approximation to a stage simulation. In inlet disturbance simulations the upstream component is modeled by prescribing a profile that is at the inlet and that models the wake of the upstream component.

You can prescribe wake profiles via CEL expressions or via external `*.csv` files. CEL-based profiles need not be formulated to produce rotational motion in time. If a profile does not cover the whole  $360^\circ$  wheel, then it should consist of a periodic portion that can be replicated to produce a  $360^\circ$  profile. You may optionally produce a  $360^\circ$  profile in a `*.csv` file based on a smaller profile file by using the **Expand Profile Data** dialog box in CFX-Pre (see [Expand Profile Data in the CFX-Pre User's Guide](#)).

Whether using a CEL expression or a `*.csv` file, you can cause the profile data to move (typically rotationally, about the machine axis) by associating the boundary with a moving coordinate frame. For details, see:

- [Local Coordinate Frames](#)
- [Frame Motion Settings in the CFX-Pre User's Guide](#)
- [Coord Frame in the CFX-Pre User's Guide](#)
- [Time Transformation Disturbance Settings in the CFX-Pre User's Guide](#)
- [Fourier Transformation Disturbance Settings in the CFX-Pre User's Guide](#)

For a rotational-flow disturbance case, the required **External Passage Definition** input parameters are aimed at specifying the pitch of the profile (or signal) at the inlet/outlet. These are needed to help compute the phase shift ( $\Delta T$  of [Figure 6.2 \(p. 187\)](#)). These parameters are important to guarantee that the resultant signal has periodic behavior.



---

## Chapter 7: Multiphase Flow Modeling

---

Multiphase flow refers to the situation where more than one fluid is present. Each fluid may possess its own flow field, or all fluids may share a common flow field. Unlike multicomponent flow, the fluids are not mixed on a microscopic scale in multiphase flow. Rather, they are mixed on a macroscopic scale, with a discernible interface between the fluids. ANSYS CFX includes a variety of multiphase models to allow the simulation of multiple fluid streams, bubbles, droplets, solid particles, and free surface flows.

Two distinct multiphase flow models are available in ANSYS CFX, an Eulerian-Eulerian multiphase model and a Lagrangian Particle Tracking multiphase model. Information on the use of the Lagrangian Particle Tracking model is available in [Particle Transport Modeling \(p. 237\)](#).

This chapter describes how Eulerian-Eulerian multiphase flow is modeled and also includes modeling advice. The theory of multiphase flow is available; see [Multiphase Flow Theory in the CFX-Solver Theory Guide](#).

The corresponding information for single-phase, single-component flow is available:

- For information on the models used for single-phase flow, see [Basic Capabilities Modeling \(p. 1\)](#).
- For the mathematical implementation of the single-phase flow, see [Basic Solver Capability Theory in the CFX-Solver Theory Guide](#).
- For advice on modeling, see [Advice on Flow Modeling \(p. 419\)](#).

---

### Important

Because this chapter extends the information given in the single-phase documentation, you are advised to read the relevant sections in the single-phase documentation before reading this chapter.

This chapter describes:

- 7.1. Multiphase Terminology
- 7.2. Multiphase Examples
- 7.3. Eulerian-Eulerian Multiphase Versus Particle Transport
- 7.4. Specifying Fluids for Multiphase Flow
- 7.5. The Homogeneous and Inhomogeneous Models
- 7.6. Buoyancy in Multiphase Flow
- 7.7. Multicomponent Multiphase Flow
- 7.8. Interphase Momentum Transfer Models
- 7.9. Solid Particle Collision Models
- 7.10. Interphase Heat Transfer
- 7.11. Polydispersed, Multiple Size Group (MUSIG) Model
- 7.12. Turbulence Modeling in Multiphase Flow
- 7.13. Additional Variables in Multiphase Flow
- 7.14. Sources in Multiphase Flow
- 7.15. Interphase Mass Transfer
- 7.16. Boundary Conditions in Multiphase Flow

7.17. Modeling Advice for Multiphase Flow

7.18. Free Surface Flow

7.19. Algebraic Slip Model (ASM)

7.20. Multiphase Flow Restrictions

## 7.1. Multiphase Terminology

The following terms are used in ANSYS CFX multiphase flow:

- *Multiphase Flow* (p. 190)
- *Eulerian-Eulerian* (p. 190)
- *Inhomogeneous Multiphase Flow* (p. 191)
- *Homogeneous Multiphase Flow* (p. 191)
- *Multicomponent Multiphase Flow* (p. 191)
- *Volume Fraction* (p. 191)
- *Free Surface Flow* (p. 191)
- *Surface Tension* (p. 191)

### 7.1.1. Multiphase Flow

Multiphase flow is a flow in which more than one fluid is present. In general, the fluids consist of different chemical species, such as air-water. In some applications, they may represent different thermodynamic phases of the same species, such as steam-water.

It is important to distinguish between multicomponent and multiphase flow. A multicomponent fluid is assumed to consist of a mixture of chemical species which are mixed at the molecular level. In this case, single mean velocity and temperature fields, etc., are solved for the fluid. Examples are gaseous mixtures, and solutes in liquids.

The fluids in a multiphase flow are assumed to be mixed at macroscopic length scales, much larger than molecular. Examples are gas bubbles in a liquid, liquid droplets in a gas or in another immiscible liquid, etc. In this case, it is necessary to solve for different velocity and temperature fields, etc., for each fluid. These may interact with each other by means of interfacial forces and heat and mass transfer across the phase interfaces.

For example, if cold wet particles are injected into a fast flowing stream of hot air, the particles will be accelerated by drag, they will be heated up by heat transfer across the phase boundary, and they will be dried by evaporation of water into water vapor at the phase boundary.

### 7.1.2. Eulerian-Eulerian

The Eulerian-Eulerian model is one of the two main multiphase models that has been implemented in ANSYS CFX; the other is the Lagrangian Particle Tracking Model. For details, see [Particle Transport Modeling](#) (p. 237).

Within the Eulerian-Eulerian model, certain interphase transfer terms used in momentum, heat, and other interphase transfer models, can be modeled using either the Particle Model, the Mixture Model or the Free Surface Model. In particular, the calculation of the interfacial area density, used for all inhomogeneous transfer models for a given fluid pair, is calculated according to one of these models. The model used for a particular pair of phases is set on the **Fluid Pairs** tab. The available

options depend on the morphology of each phase of the pair (for example, continuous, dispersed, etc.), and on settings found on the **Fluid Models** tab (homogeneous options, free surface model option).

### 7.1.3. Inhomogeneous Multiphase Flow

Inhomogeneous multiphase flow refers to the case where separate velocity fields and other relevant fields exist for each fluid. The pressure field is shared by all fluids. The fluids interact via interphase transfer terms. The `Particle` and `Mixture` Models are both inhomogeneous multiphase models.

### 7.1.4. Homogeneous Multiphase Flow

Homogeneous multiphase flow is a limiting case of `Eulerian-Eulerian` multiphase flow where all fluids share the same velocity fields, as well as other relevant fields such as temperature, turbulence, etc. The pressure field is also shared by all fluids.

### 7.1.5. Multicomponent Multiphase Flow

It is possible to combine the notions of multicomponent and multiphase flows. In this case, more than one fluid is present, and each such fluid may be a mixture of chemical species mixed at molecular length scales. An example is air bubbles in water in which ozone gas is dissolved in both the gaseous and liquid phases. In this case, mass transfer of common species may occur by diffusion across the phase interface.

### 7.1.6. Volume Fraction

Multiphase modeling employs the notion of interpenetrating continua. Although phases are mixed at length scales much larger than molecular, they are also assumed to be mixed at length scales smaller than you want to resolve.

Thus, each phase is assumed to be present in principle in each control volume, and assigned a volume fraction equal to the fraction of the control volume occupied by that phase. This variable appears as `<fluid>.Volume Fraction` in the results file. The variable `<fluid>.Conservative Volume Fraction` is also available but should not usually be used for post-processing. The conservative volume fraction is used by the CFX-Solver; it may exceed 1 and may not sum to unity over all fluids during the solution. However, these criteria are enforced in a converged solution.

### 7.1.7. Free Surface Flow

**Free Surface** flow refers to a multiphase situation where the fluids (commonly water and air) are separated by a distinct resolvable interface.

### 7.1.8. Surface Tension

Surface tension is a force that exists at a free surface interface which acts to minimize the surface area of the interface. It gives rise to effects such as a pressure discontinuity at the interface and capillary effects at adhesive walls.

## 7.2. Multiphase Examples

The following are examples of multiphase flow:

- [Water Droplets in Air](#) (p. 192)
- [Air Bubbles in Water](#) (p. 192)

- *Gas-Solid and Liquid-Solid Flow* (p. 192)
- *Three-Phase Flow* (p. 192)
- *Polydispersed Flow* (p. 192)

### 7.2.1. Water Droplets in Air

Water droplets in air constitute two different fluids which are mixed at the macroscopic level and not the microscopic level. Hence, you need to use a multiphase model and define two distinct fluids, `Water` and `Air`. Each fluid contains only one component comprising one material (air or water), whose properties can be defined. `Air` is the continuous fluid (*Continuous Fluid* (p. 194)), and `Water` is the dispersed fluid (*Dispersed Fluid* (p. 194)).

### 7.2.2. Air Bubbles in Water

As above, you need to use a multiphase model and define two distinct fluids: `Water` and `Air`. In this case, `Air` is the dispersed fluid (*Dispersed Fluid* (p. 194)), and `Water` is the continuous fluid (*Continuous Fluid* (p. 194)).

### 7.2.3. Gas-Solid and Liquid-Solid Flow

It is possible to model the motion of a large number of solid particles in a gas or a liquid as an `Eulerian-Eulerian` two phase flow. Examples occur in pneumatic conveying, sedimentation in rivers, and fluidized beds.

For example, the two phases may be `Water`, the continuous fluid (*Continuous Fluid* (p. 194)), and `Sand`, the dispersed fluid (*Dispersed Fluid* (p. 194)).

In such problems, you should assign the solid phase a small insignificant molecular viscosity. This is permissible, as the physics are dominated by interphase drag and turbulence effects. The solid phase should be assigned free slip boundary conditions at walls. If viscosity is not set, the solid material will not be available for selection in the **Fluids and Particle Definitions...** list on the **Basic Settings** tab of the Domains details view in CFX-Pre.

### 7.2.4. Three-Phase Flow

It is possible to have more than one dispersed phase in a continuous phase. For example, certain regimes of water-oil-gas flow in an oil pipeline may involve both oil droplets and gas bubbles immersed in a continuous water phase.

### 7.2.5. Polydispersed Flow

The above dispersed flow examples assume a single mean particle diameter for the dispersed phases. **Poly-dispersed** flows involve dispersed phases of different mean diameters.

One way to model such flows is to define a different phase for each particle size, as the particle size has a strong influence on interphase transfer. For example, to model the flow of air bubbles in water of different diameters, you need to create three fluids, such as `Air1`, `Air2`, `Air3`, each with the same material properties as air. Then, set the number of fluids equal to four, and select `Water`, `Air1`, `Air2` and `Air3` as the four fluids. Next, under **Fluid Models**, designate `Water` as the continuous phase, and the other three fluids as dispersed phases of desired mean diameters.

Information on an alternative way to model polydispersed flows is provided by the MUSIG model. For details, see *Polydispersed, Multiple Size Group (MUSIG) Model* (p. 207).

### 7.3. Eulerian-Eulerian Multiphase Versus Particle Transport

A multiphase flow containing dispersed particles may be modeled using either the particle transport (Lagrangian Particle Tracking) model or the Eulerian-Eulerian multiphase model. Some advantages and disadvantages of the Eulerian-Eulerian multiphase model are given below to aid in the choice of model. The equivalent section for the particle transport model is available in *Particle Transport Versus Eulerian-Eulerian Multiphase* (p. 238).

**Table 7.1 Eulerian-Eulerian Multiphase vs. Particle Transport**

Advantages of Eulerian-Eulerian Multiphase	Disadvantages of Eulerian-Eulerian Multiphase
Complete global information for the particle phase is available	Expensive if many sets of equations are used; that is, if there are many particle sizes. However, the homogeneous MUSIG model is an Eulerian-Eulerian model that uses a single velocity field for multiple size groups.
Applicable for wide range of volume fractions	Knowledge of the diffusion coefficients is incomplete
Relatively cheap for one additional set of equations	Difficult to get accuracy over a range of particle sizes for combustive flows
Turbulence is included automatically	When there is phase change, the particle diameter must be user-specified rather than calculated automatically by the model. This can decrease accuracy. (The droplet condensation model is an exception.)

### 7.4. Specifying Fluids for Multiphase Flow

You should first use the **Material** details view in CFX-Pre to define the properties of the materials in your simulation. You can then select these materials, in addition to predefined library materials, on the **Basic Settings** tab of the **Domain** details view. For details, see *Basic Settings Tab in the CFX-Pre User's Guide*. Defining more than one fluid implies a multiphase simulation.

Models that apply to all fluids in the simulation are set on the **Fluid Models** tab. For details, see *Fluid Models Tab in the CFX-Pre User's Guide*. Fluid specific attributes are defined on the **Fluid Specific Models** tab in CFX-Pre. For details, see *Fluid Specific Models Tab in the CFX-Pre User's Guide*. Interactions between the fluids are defined on the **Fluid Pairs** tab. For details, see *Fluid Pair Models Tab in the CFX-Pre User's Guide*.

Multiphase flows allow low speed compressibility effects to be modeled and you can mix compressible and incompressible fluids in one simulation. An example would be modeling an air-water system in which the water can be considered incompressible but the air is modeled as compressible due to the hydrostatic water pressure.

You should be aware of significant increases in memory and CPU time when using multiple fluids; these increase rapidly as more fluids are added. For details, see [CPU and Memory Requirements in the CFX-Solver Manager User's Guide](#).

### 7.4.1. Morphology

Morphology is used to describe the connectivity or distribution of the fluid - whether it forms a single continuous medium, or whether it is present, for example, in small droplets which are not connected.

You can select from:

- [Continuous Fluid](#) (p. 194)
- [Dispersed Fluid](#) (p. 194)
- [Dispersed Solid](#) (p. 194)
- [Polydispersed Fluid](#) (p. 194)

#### 7.4.1.1. Continuous Fluid

A continuous phase or continuous fluid is one which forms a continuous connected region. An example is air, when modeling rain drops in air.

#### 7.4.1.2. Dispersed Fluid

A dispersed fluid is a fluid which is present in discrete regions which are not connected. Examples are water droplets in air or gas bubbles in a liquid.

#### 7.4.1.3. Dispersed Solid

A dispersed solid is one which is present in discrete regions which are not connected, for example, solid particulates.

You must select the morphology of all fluids as continuous if you want to use the `Mixture` model on the **Multiphase Options** tab. If dispersed fluids or solids are included, then the `Particle` model will be the only valid option.

Examples of multiphase flow with different morphologies are available. For details, see [Multiphase Examples](#) (p. 191).

#### 7.4.1.4. Polydispersed Fluid

A polydispersed fluid is a fluid which is present in discrete regions which are not connected and with varying sizes of the discrete regions. Typically, this morphology is used for modeling air bubbles of varying sizes in a liquid.

### 7.4.2. Mean Diameter

For a `Dispersed Solid` or `Dispersed Fluid`, you must supply the mean diameter of the dispersed particles, droplets or bubbles constituting the phase. The mean diameter is the actual diameter for spherical particles. For non-spherical particles, you should provide the Sauter mean diameter, that is, the diameter of a sphere possessing the same volume as the particles.

### 7.4.3. Minimum Volume Fraction

For each phase, you can optionally set a minimum volume fraction. A minimum value is used for numerical robustness purposes, as the volume fractions are not allowed to go to machine zero at any location. A default value is used if you do not set a value; this is almost always appropriate. If this causes numerical problems, then set the value to be several orders of magnitude less than the minimum expected physical value, but much larger than machine zero.

### 7.4.4. Maximum Packing

For details, see *Maximum Packing* (p. 204).

## 7.5. The Homogeneous and Inhomogeneous Models

Two distinct models are available for Eulerian-Eulerian multiphase flow: the homogeneous model and the inter-fluid transfer or inhomogeneous model.

### 7.5.1. The Inhomogeneous (Interfluid Transfer) Model

Each fluid possesses its own flow field and the fluids interact via interphase transfer terms. In the inhomogeneous multiphase model, there is one solution field for each separate phase. Transported quantities interact via interphase transfer terms. For example, two phases may have separate velocity and temperature fields, but there will be a tendency for these to come to equilibrium through interphase drag and heat transfer terms.

Three different sub-models are available which differ in the way they model the interfacial area density and the interphase transfer terms. A model is selected for each fluid pair on the **Fluid Pairs** tab. The available options depend on the morphology of each phase of the pair (for example, continuous, dispersed, etc.), and on settings found on the **Fluid Models** tab (homogeneous options, free surface model option).

Descriptions of the three models follow.

#### 7.5.1.1. The Particle Model

This model is available when one of the phases is continuous and the other is dispersed or polydispersed. The dispersed phase particles or droplets are assumed to be spherical. It is suitable for modeling simple dispersed multiphase flow problems, for example, the dispersion of:

- Gas bubbles in a liquid.
- Liquid droplets in a gas or in immiscible liquid.
- Solid particles in a gas or in a liquid.

The MUSIG model is a variation of the particle model specialized for polydispersed phases. For details, see *Polydispersed, Multiple Size Group (MUSIG) Model* (p. 207).

#### 7.5.1.2. The Mixture Model

This is a very simple model which treats both phases symmetrically. It may be appropriate as a first approximation or as the basis of user supplied interfacial transfer models for a calculation of non-disperse liquid-liquid or gas-liquid two phase flow. It requires both phases to be continuous. It can be used to model more complex multiphase flow problems, for example, Churn flow.

An interfacial length scale must be specified on the tab in CFX-Pre to relate the phasic volume fractions to the interfacial contact area. For details, see:

- [Fluid Pair Models Tab in the CFX-Pre User's Guide.](#)
- [The Mixture Model in the CFX-Solver Theory Guide.](#)

### 7.5.1.3. The Free Surface Model

This model is applicable to free surface flows. The particle model or mixture model may also be used for these flows if there is entrainment of one phase inside another.

### 7.5.2. The Homogeneous Model

The homogeneous model can be viewed as a limiting case of Eulerian-Eulerian multiphase flow in which the interphase transfer rate is very large. This results in all fluids sharing a common flow field, as well as other relevant fields such as turbulence. It is valid in the following circumstances:

- In a flow under gravity, where the phases have completely stratified, for example, a free surface flow where the interface is well defined. In this case, the volume fractions of the phases are equal to one or zero everywhere except at the phase boundaries, and it makes sense to use a single velocity field.
- If the flow is drag dominated, that is,  $\alpha$  is very large, and there are no body forces, the phase velocities will tend to equalize over very short spatial length scales. This can occur in dispersed flows of extremely small particles.
- The approximation does *not in general* apply to drag dominated multiphase flow under gravity which is not stratified, for example, droplets falling under gravity in a gas. In this case, the droplets will quickly attain a fixed slip velocity relative to the continuous phase, where the interphase drag balances the differences in body forces. In this case, the homogeneous model should only be used if the resulting slip velocities are very small relative to the mean flow.

Free surface flow is a common application of the homogeneous model. The section provides additional details for this specific application. For details, see [Free Surface Flow \(p. 230\)](#).

To choose the homogeneous model for the momentum equation, select `Homogeneous Model` under **Multiphase Options**. Once this is done, the bulk momentum equation is solved to obtain the shared velocity field. The use of inhomogeneous turbulence models is also disabled.

When the homogeneous model (under **Multiphase Options**) is selected, a model for interphase momentum transfer is no longer needed, although the **Interphase Transfer Model** setting (on the **Fluid Pairs** tab) may still need to be specified due to other processes that require interphase transfer modeling. Some examples are:

- The heat transfer model may be inhomogeneous. This is required when applying the `Thermal Phase Change` model for interphase mass transfer. For details, see [Thermal Phase Change Model \(p. 213\)](#).
- Other mass transfer models (other than cavitation) also require use of the interfacial area density.
- `Interphase Additional Variable Transfer` models. For details, see [Additional Variable Interphase Transfer Models \(p. 210\)](#).

In these situations, the **Interphase Transfer Model** setting for fluid pairs (on the **Fluid Pairs** tab, for a particular pair of fluids) must be set to `Particle Model`, `Mixture Model` or `Free Surface Model`. Additional information on these models is available; for details, see

- [The Inhomogeneous \(Interfluid Transfer\) Model \(p. 195\)](#)

- [Interfacial Area Density in the CFX-Solver Theory Guide.](#)

## 7.6. Buoyancy in Multiphase Flow

You should be familiar with buoyancy in single phase flows. For details, see [Buoyancy \(p. 12\)](#).

In addition to the buoyancy forces that can exist in single phase flows, the difference in density between phases produces a buoyancy force in multiphase flows (including particle tracking). For this reason, buoyancy is almost always important in multiphase flows.

For information on modeling low-speed compressible multiphase flow, see [Buoyancy and Pressure \(p. 14\)](#).

For multiphase flows, it can be important to correctly set the buoyancy reference density. For a flow containing a continuous phase and a dilute dispersed phase, you should set the buoyancy reference density to that of the continuous phase. This is because the pressure gradient is nearly hydrostatic, so the reference density of the continuous phase cancels out buoyancy and pressure gradients in the momentum equation.

This is much the same as in single phase, where any non-buoyant calculation implicitly assumes a buoyancy reference density of the fluid, thereby avoiding potential roundoff problems. For non-dilute cases (which include all free surface cases), all terms can be equally important for each fluid, so roundoff errors will be introduced for one of the fluids if there is a significant difference in density. You should choose the density of the lighter fluid because this gives an intuitive interpretation of pressure (that is, constant in the light fluid and hydrostatic in the heavier fluid). This simplifies pressure initial conditions, pressure boundary conditions and force calculations in post-processing.

### 7.6.1. Fluid Buoyancy Model

#### 7.6.1.1. Density Difference

This is the default option for all multiphase flows. The additional buoyancy force is modeled by considering the difference in density between phases. If you are using a constant density fluid, you should consider the Boussinesq model.

$$\mathbf{F}_\alpha = (\rho_\alpha - \rho_{\text{ref}}) \mathbf{g} \quad (7-1)$$

#### 7.6.1.2. Boussinesq

This option may be selected for constant density fluids for multiphase flows with heat transfer, but it is not the default option. You should use this model to model natural convection effects within such a fluid (that is, if density fluctuations due to temperature changes are important). Note that the default option, `Density Difference`, neglects such effects if the fluid density is constant.

$$\mathbf{F}_\alpha = \left( \rho_\alpha \left( 1 - \beta_\alpha (T_\alpha - T_{\text{ref}}) \right) - \rho_{\text{ref}} \right) \mathbf{g} \quad (7-2)$$

Note further that the `Boussinesq` option may be more difficult to converge than the `Density Difference` option, because of coupling between heat transfer and momentum. It may be advantageous to obtain a converged solution first using the `Density Difference` option. This may then be used as an initial guess for a solution using the `Boussinesq` option.

Multiphase simulations use the full buoyancy model because there is usually a significant difference in density between the phases. However, you can select to use the Boussinesq buoyancy model within each phase to account for buoyancy effects due to temperature differences within the phase.

## 7.7. Multicomponent Multiphase Flow

ANSYS CFX allows the modeling of multiphase multicomponent flows. Information on multicomponent, single-phase flows is available; for details, see *Multicomponent Flow* (p. 18). One component in each phase must be calculated using a constraint component in the same way as for single-phase multicomponent flow. The limitations that currently apply to single-phase multicomponent flow also apply to multiphase multicomponent flow. You should note that the molecular diffusion coefficients are calculated using the **Kinematic Diffusivity** set on the **Fluid-Specific Details** tab for a domain in CFX-Pre. For details, see *Component Details in the CFX-Pre User's Guide*.

Source terms in multicomponent multiphase flow behave in the same way as multicomponent mass sources, but on a per fluid basis. For details, see *Sources in Multiphase Flow* (p. 212).

## 7.8. Interphase Momentum Transfer Models

The models described in this section only apply to inhomogeneous multiphase flow. When using the homogeneous model, momentum transfer between phases is assumed to be very large.

### 7.8.1. Interphase Drag

For low Mach number flows, the drag exerted on an immersed body by a moving fluid arises from two mechanisms only. The first is due to the viscous surface shear stress, and is called skin friction. The second is due to the pressure distribution around the body, and is called the form drag. The total drag force is most conveniently expressed in terms of the dimensionless drag coefficient,  $C_D$ . The calculation of  $C_D$  is available in *Interphase Drag in the CFX-Solver Theory Guide*.

#### 7.8.1.1. Interphase Drag for the Particle Model

For a particle of simple shape, immersed in a Newtonian fluid and which is not rotating relative to the surrounding free stream, the drag coefficient,  $C_D$ , depends only on the particle Reynolds number. The function  $C_D(\text{Re}_\alpha)$  may be determined experimentally, and is known as the drag curve.

ANSYS CFX offers several different models for the drag curve, and also allows you to specify the drag coefficients directly.

This section describes drag correlations specific to dispersed multiphase flow.

##### 7.8.1.1.1. Specifying a Drag Coefficient

You can choose to specify the dimensionless **Drag Coefficients**  $C_D$  directly. This is done by selecting to use the **Drag Coefficient** option on the **Fluid Pairs** tab in CFX-Pre, and entering the appropriate **Drag Coefficient**. For details, see *Fluid Pair Models Tab in the CFX-Pre User's Guide*.

You can supply your own drag coefficient correlation as an expression and you are free to define your own interfacial Reynolds number, or any other dimensionless group.

### 7.8.1.1.2. Sparsely Distributed Solid Particles

#### 7.8.1.1.2.1. Sparsely Distributed Solid Particles: Schiller Naumann Drag Model

This should only be used for solid spherical particles, or for fluid particles that are sufficiently small that they may be considered spherical. For non-spherical particles, you should supply the drag curve from experiment.

As the Schiller Naumann correlation is derived for flow past a single spherical particle, it is only valid in the dilute limit of very small solid phase volume fractions.

You can select this drag curve by selecting to use the `Schiller Naumann Drag Model` on the **Fluid Pairs** tab in CFX-Pre. For details, see [Fluid Pair Models Tab in the CFX-Pre User's Guide](#).

### 7.8.1.1.3. Densely Distributed Solid Particles

#### 7.8.1.1.3.1. Densely Distributed Solid Particles: Wen Yu Drag Model

The Wen Yu correlation is valid for solid phase volume fractions at least up to 0.2, and probably higher.

You can select this Drag Curve by selecting to use the `Wen Yu Drag Model` on the **Fluid Pairs** tab in CFX-Pre ([Fluid Pair Models Tab in the CFX-Pre User's Guide](#)). Theoretical information about the Wen Yu drag model is given at [Densely Distributed Solid Particles: Wen Yu Drag Model in the CFX-Solver Theory Guide](#).

---

#### Note

Although the Wen Yu drag law implemented in ANSYS CFX follows the implementation by Gidaspow [18] and its subsequent wide use, this implementation of the drag law is, in fact, quite different from that given in the original Wen and Yu paper [181].

#### 7.8.1.1.3.2. Densely Distributed Solid Particles: Gidaspow Drag Model

For very dense gas-solid or liquid-solid flows, such as occur in fluidized bed applications, the Gidaspow correlation is recommended.

You can select this drag curve by selecting to use the `Gidaspow Drag Model` on the **Fluid Pairs** tab in CFX-Pre ([Fluid Pair Models Tab in the CFX-Pre User's Guide](#)).

Theoretical information about the Gidaspow drag model is given at [Densely Distributed Solid Particles: Gidaspow Drag Model in the CFX-Solver Theory Guide](#).

### 7.8.1.1.4. Sparsely Distributed Fluid Particles (drops and bubbles)

#### 7.8.1.1.4.1. Sparsely Distributed Fluid Particles: Ishii-Zuber Drag Model

This is applicable to general fluid particles (drops and bubbles), for any pair of phases. ANSYS CFX automatically takes into account the spherical particle and spherical cap limits and dense fluid particle effects.

You can select this Drag Curve by selecting to use the `Ishii-Zuber Model` on the **Fluid Pairs** tab in CFX-Pre. For details, see [Fluid Pair Models Tab in the CFX-Pre User's Guide](#). This model is only available when a buoyant flow is specified and a **Surface Tension Coefficient** has been set.

#### 7.8.1.1.4.2. Sparsely Distributed Fluid Particles: Grace Drag Model

This model was developed using air-water data and produces better results for air-water systems. ANSYS CFX automatically takes into account the spherical particle and spherical cap limits. You can set a **Volume Fraction Correction Exponent** for this model for use with high bubble volume fractions, see below for details.

You can select this Drag Curve by selecting to use the `Grace Model` on the **Fluid Pairs** tab in CFX-Pre. For details, see [Fluid Pair Models Tab in the CFX-Pre User's Guide](#). This model is only available when a buoyant flow is specified and a `Surface Tension Coefficient` has been set.

#### 7.8.1.1.4.3. Sparsely Distributed Fluid Particles: Availability

Both the `Ishii Zuber` and `Grace Drag` Models make explicit use of the gravity vector and surface tension coefficient. Hence, both are only available for buoyant multiphase flows when a surface tension coefficient has been specified. The fluid morphologies must be `Continuous` and `Dispersed Fluid` respectively.

#### 7.8.1.1.5. Densely Distributed Fluid Particles

##### 7.8.1.1.5.1. Densely Distributed Fluid Particles: Ishii-Zuber Drag Model

The Ishii Zuber drag model automatically takes into account compact particle effects and is therefore suitable for modeling flows containing high fluid particle volume fractions.

A user-defined maximum packing value can be set. This is defaulted to unity for a dispersed fluid phase. For details, see [Maximum Packing \(p. 204\)](#).

You can select this drag curve by selecting to use the `Ishii Zuber Model` on the **Fluid Pairs** tab in CFX-Pre. For details, see [Fluid Pair Models Tab in the CFX-Pre User's Guide](#). This model is available only when a buoyant flow is specified and a surface tension coefficient has been set.

##### 7.8.1.1.5.2. Densely Distributed Fluid Particles: Grace Drag Model

The Grace drag model is formulated for flow past a single bubble. For details, see [Sparsely Distributed Fluid Particles \(drops and bubbles\) \(p. 199\)](#).

You can select this drag curve by selecting to use the `Grace model` on the **Fluid Pairs** tab in CFX-Pre. For details, see [Fluid Pair Models Tab in the CFX-Pre User's Guide](#). This model is only available when a buoyant flow is specified and a **Surface Tension Coefficient** has been set.

In the dilute limit, leave the **Volume Fraction Correction Exponent** at its default value of zero. For non-dilute bubble volume fractions, set a non-zero value, depending on the bubble size as discussed below.

Small bubbles tend to rise more slowly at high void fraction, due to an increase in the effective mixture viscosity. To capture this effect, a negative **Volume Fraction Correction Exponent** should be used. The Ishii Zuber correlation uses an exponent of -1 in this limit. A value of -0.5 has also been used successfully by some investigators.

Large bubbles, on the other hand, tend to rise faster at high void fractions, because they are dragged along by the wakes of other bubbles. This effect may be modeled using a positive **Volume Fraction Correction Exponent**. The Ishii Zuber correlation uses an exponent of 2 in this regime. A value of 4

has been used successfully by some investigators [74]. If you use a value of 4 and experience poor convergence for the mass equations, try reducing the value to 2.

### 7.8.1.2. Interphase Drag for the Mixture Model

The mixture model is primarily a tool to permit advanced users to specify their own interfacial transfer models for complex situations. Hence the only drag model available is the specified Drag Coefficient model. This may be a constant, or a function defined using expression language or User Fortran.

### 7.8.2. Lift Force

The lift force refers to the shear-induced lift force acting on a dispersed phase in the presence of a rotational continuous phase. Hence, it is applicable to the `Particle Model` only. Additional information on the theory is available.

You may set a non-dimensional lift coefficient  $C_L$  either as a constant, or an expression. It should be set to 0.5 for inviscid flow around a sphere. For viscous flow, the coefficient varies from 0.01 to 0.5 in a way which is only partially understood.

Several models for the lift coefficient have been proposed in the literature. See, for example, [86] and [87], and this is still a matter for current research. ANSYS CFX has the following built-in lift models:

- [The Saffman Mei Lift Force Model in the CFX-Solver Theory Guide](#)
- [The Legendre and Magnaudet Lift Force Model in the CFX-Solver Theory Guide](#)
- [The Tomiyama Lift Force Model in the CFX-Solver Theory Guide](#)

The lift force is proportional to the continuous phase density. Hence, it is mainly significant when the dispersed phase density is either less than, or of the same order of magnitude as the continuous phase density. Also, it is proportional to the continuous phase shear rate. Hence, it is most significant in shear layers whose width is comparable to the dispersed phase mean diameter.

For example, the lift force is important for bubbly flow in a vertical pipe, when the pipe diameter is comparable to the bubble diameter. In this case, the lift force induced by the continuous phase boundary layer is responsible for pushing the bubbles towards the wall. On the other hand, for bubbly downflow, the lift force tends to push bubbles towards the pipe center, leading to the phenomenon of void coring.

### 7.8.3. Virtual Mass Force

The virtual mass force is proportional to relative phasic acceleration. The ANSYS CFX implementation is applicable to the particle model only. For details, see [Virtual Mass Force in the CFX-Solver Theory Guide](#). You may specify a non-dimensional virtual mass coefficient  $C_{VM}$ .  $C_{VM} = 0.5$  for inviscid flow around an isolated sphere. In general,  $C_{VM}$  depends on shape and particle concentration. At the time of this writing, there were no universally accepted models. Such models may be implemented using CEL for  $C_{VM}$ .

The virtual mass force is proportional to the continuous phase density, hence, is most significant when the dispersed phase density is less than the continuous phase density. Also, by its nature, it is only significant in the presence of large accelerations, for example, in transient flows, and in flows through narrow restrictions.

## 7.8.4. Wall Lubrication Force

Under certain circumstances, for example, bubbly upflow in a vertical pipe, the dispersed phase is observed to concentrate in a region close to the wall, but not immediately adjacent to the wall. This effect may be modeled by the wall lubrication force, which tends to push the dispersed phase away from the wall.

The wall lubrication force is usually modeled in conjunction with the wall lift force (see [Lift Force \(p. 201\)](#)). In situations where the lift force pushes bubbles towards the wall, the wall lubrication force acts in the opposite direction to ensure that bubbles accumulate a short distance away from the wall.

Currently, ANSYS CFX has the following wall lubrication force models:

- [The Antal Wall Lubrication Force Model in the CFX-Solver Theory Guide](#)

Note that the Antal model requires a fine mesh. Grid convergence can be expected only on extremely fine meshes.

- [The Tomiyama Wall Lubrication Force Model in the CFX-Solver Theory Guide](#)

Note that the Tomiyama model is available only if the surface tension has been specified for the fluid-dispersed phase pair.

- [The Frank Wall Lubrication Force Model in the CFX-Solver Theory Guide](#)

Note that the Frank model is available only if the surface tension has been specified for the fluid-dispersed phase pair.

The wall lubrication force uses the near wall distance function. This is computed by CFX-Solver for each phase, based on walls which are specified as no slip wall for that phase. Therefore, walls for which the lubrication force is active must be specified as no-slip walls for the continuous phase.

## 7.8.5. Interphase Turbulent Dispersion Force

**Turbulent Dispersion Forces** result in additional dispersion of phases from high volume fraction regions to low volume fraction regions due to turbulent fluctuations. This is caused by the combined action of turbulent eddies and interphase drag. For example, in a dispersed two phase flow, dispersed particles get caught up in continuous phase turbulent eddies, and are transported by the effect of interphase drag. The effect is to move particles from areas of high to low concentration. Hence, this effect will usually be important in turbulent flows with significant interphase drag.

### 7.8.5.1. Favre Averaged Drag Model

This is based on the Favre or Mass weighted average of the interphase drag force. For details, see [Interphase Drag in the CFX-Solver Theory Guide](#). This model has been shown to have a wide range of universality

$\sigma_{tc}$  is the turbulent Schmidt number for continuous phase volume fraction, currently taken to be 0.9.

Expert users may also modify the model by using a CEL expression for the non-dimensional **Turbulent Dispersion Coefficient**. Its default value is unity.

For theoretical details, see [Favre Averaged Drag Model in the CFX-Solver Theory Guide](#).

### 7.8.5.2. Lopez de Bertodano Model

This is included for backwards compatibility reasons. It requires a **Turbulent Dispersion Coefficient** to be specified. Unfortunately however, there does not exist a universally valid value of the non-dimensional **Turbulent Dispersion Coefficient**. Values of 0.1 - 0.5 have been used successfully for bubbly flow with bubble diameters of order a few millimeters. See Lopez de Bertodano (1998) [21] for a general discussion on recommended values of the turbulent dispersion coefficient.

---

#### Note

- The Lopez de Bertodano turbulence model may not converge well for a coupled volume fraction case that has Turbulent Force discretization. You may be able to overcome the problem by initializing the case with a segregated volume fraction case, and then restarted with coupled volume fraction.
- The Lopez de Bertodano turbulence model cannot be set with the LES model. Instead use the Favre Averaged Drag turbulence dispersion model, which can be used in combination with the LES model.

For theoretical details, see [Lopez de Bertodano Model in the CFX-Solver Theory Guide](#).

## 7.9. Solid Particle Collision Models

The following topics will be discussed:

- [Solid Pressure Force Model](#) (p. 203)
- [Maximum Packing](#) (p. 204)
- [Kinetic Theory Models](#) (p. 204)

### 7.9.1. Solid Pressure Force Model

The `Solid Pressure Force Model` is available for dispersed solid phases in a multiphase flow. The forces due to solid collisions are taken into account by introducing additional solids pressure and solids stress terms into the solid phase momentum equations based on either the Gidaspow model or by specifying the elasticity modulus directly. Additional theoretical information on these models is available in [Solid Particle Collision Models in the CFX-Solver Theory Guide](#).

You can select the Gidaspow Model or specify the Elasticity Modulus for solids pressure on the **Fluid Specific Models** tab, for a particular dispersed solid, when creating a domain in CFX-Pre. For details, see [Multiphase Options in the CFX-Pre User's Guide](#). The Gidaspow model requires the **Reference Elasticity Modulus** and the **Compaction Modulus** to be specified. These are used to calculate an Elasticity Modulus. For details, see [Solid Particle Collision Models in the CFX-Solver Theory Guide](#). There are no universally accepted values for these. The values used by Bouillard et al. [17] are:

- Reference Elasticity Modulus = 1 Pa
- Compaction Modulus = 20 to 600

For information on setting the **Maximum Packing** parameter in CFX-Pre, see [Multiphase Options in the CFX-Pre User's Guide](#).

Results tend to be insensitive to the details of the solids pressure model. The solids pressure gradient is only activated in regions close to the maximum packing, where its tendency is to prevent solid volume fractions from becoming too large.

Using a solid pressure force model in conjunction with the Gidaspow drag model, it is possible to model the large scale features of bubbling fluidized beds. For details, see [Densely Distributed Solid Particles](#) (p. 199).

This Solid Pressure Force Model is very numerically stiff, prone to convergence problems and may cause divergence. It is needed in some two-phase flow situations, such as a fluidized bed simulation. It should be used with care as it has known issues with robustness. This behavior will be improved in future releases.

There is a more complex set of models which use the Kinetic Theory of Granular Flow to model solid pressures and stresses. For details, see [Kinetic Theory Models](#) (p. 204).

### 7.9.2. Maximum Packing

For dispersed phases, you can specify a maximum packing parameter. This is the volume fraction of the phase at its state of maximum packing. It is most commonly used for compact solid dispersed phases, for example, as you would find in fluidized beds.

The maximum packing parameter is unity by default for a dispersed fluid. For a dispersed solid phase, it may range from 0.5 to 0.74, the latter being the maximum possible packing for solid spheres. For most applications, the default value 0.62 suffices.

The maximum packing parameter is used in correlations for certain drag laws, and models for particle collision forces. Unfortunately, it is not possible to numerically guarantee that volume fractions are bounded above by the maximum packing parameter. Consequently, you may observe volume fractions higher than the maximum packing.

### 7.9.3. Kinetic Theory Models

When using solid particle collision models, the following pieces of advice may be useful:

- Only run in transient mode with very small timesteps, typically 1E-4 [s].
- Adaptive timestepping may help.

Details of the implementation of solid particle collision models are found in [Solid Particle Collision Models in the CFX-Solver Theory Guide](#).

## 7.10. Interphase Heat Transfer

In the multiphase model, there are separate enthalpy and temperature fields for each phase.

### 7.10.1. Inhomogeneous Interphase Heat Transfer Models

For heat transfer to occur between fluids, at least one fluid must use the Thermal Energy or Total Energy model and at least one other fluid must use the Thermal Energy, Total Energy or Isothermal models. In the case of two-phase flow, a Thermal Energy/Total Energy - None combination results in the modeling of heat transfer only in the phase which uses the Thermal Energy/Total Energy model. For a Thermal Energy/Total Energy - Isothermal combination,

heat transfer is not modeled in the isothermal phase but interphase transfer can still occur (that is, the isothermal fluid acts like a heat source or sink).

The phases are not in general in thermal equilibrium due to temperature differences across phase boundaries, so heat is transferred across phase interfaces via interphase transfer terms. Heat transfer across a phase boundary is usually described in terms of a **Heat Transfer Coefficient**, which is the amount of heat energy crossing a unit area per unit time per unit temperature difference. ANSYS CFX contains a number of models for calculating the heat transfer coefficient.

You must specify an Interphase heat transfer model if any of the following conditions are true:

- You selected the `Thermal Energy` or `Total Energy` model on the **Fluid Models** tab. In this case heat is transferred to / from both fluids.
- You selected the `Fluid-Dependent Heat Transfer` model on the **Fluid Models** tab, then selected the `Thermal Energy` or `Total Energy` model for both fluids on the **Fluid Specific Models** tab. This case is the same as the previous.
- You selected the **Fluid-Dependent Heat Transfer** model on the **Fluid Models** tab, then selected the `Thermal Energy` or `Total Energy` model for one fluid and the `Isothermal` model for the other fluid on the **Fluid Specific Models** tab. In this case, heat is transferred to / from the fluid which uses the `Thermal Energy/Total Energy` model; that is, the `Isothermal` fluid acts like a constant temperature heat source or sink.

All other options available for multiphase flow result do not result in interphase heat transfer. Note that selecting `Thermal Energy` or `Total Energy` for one fluid and `None` for the second fluid models heat transfer within one fluid, but no interphase heat transfer occurs.

The Interphase Heat Transfer models available for the `Particle` and `Mixture` models are described below, starting with models based on an **Overall Heat Transfer Coefficient**.

### 7.10.1.1. Particle Model Correlations for Overall Heat Transfer Coefficient

In order to specify the interphase heat transfer term, it is necessary to specify the interfacial area per unit volume and an overall heat transfer coefficient.

Information on the interfacial area density is available. For details, see *The Particle Model* (p. 195).

It is often convenient to express the heat transfer coefficient in terms of a dimensionless Nusselt number. For steady state laminar forced convection around a spherical particle, theoretical analysis shows that  $Nu = 2$  For a particle in a moving incompressible Newtonian fluid, the Nusselt number is a function of the particle Reynolds number  $Re$  and the surrounding fluid Prandtl number  $Pr$ .

The following models are available in ANSYS CFX:

- **Ranz-Marshall Correlation.** The most well tested correlation for flow past a spherical particle is that of Ranz and Marshall [75]:

$$Nu = 2 + 0.6 Re^{0.5} Pr^{0.3} \quad 0 \leq Re < 200 \quad 0 \leq Pr < 250$$

This is based on boundary layer theory for steady flow past a spherical particle. Its restriction to particle Reynolds number and Prandtl number should be noted.

- **Hughmark Correlation.** Hughmark [7] proposed the following empirical correlation for flow past a spherical particle.

$$\begin{aligned}
 2 + 0.6 Re^{0.5} Pr^{0.33} & \quad 0 \leq Re < 776.06 \quad 0 \leq Pr < 250 \\
 2 + 0.27 Re^{0.62} Pr^{0.33} & \quad 776.06 \leq Re \quad 0 \leq Pr < 250
 \end{aligned}
 \tag{7-3}$$

It extends the Ranz Marshall Correlation and can therefore be applied to a wide range of Reynolds numbers. The Reynolds number cross over point is chosen to guarantee continuity. It should not be used outside the recommended Prandtl number range.

- **Nusselt Number.** Specify the dimensionless **Nusselt Number** directly. This should be based on empirical correlations, if available, for your application.
- **Heat Transfer Coefficient.** Specify the **Heat Transfer Coefficient** directly as a value or expression. This should be based on empirical correlations, if available.
- **Interface Flux.** This is an advanced option which permits experienced users to implement interphase heat transfer models which are not of the simple form of a heat transfer coefficient multiplied by a bulk temperature difference. For details, see [Particle Model Correlations in the CFX-Solver Theory Guide](#).

### 7.10.1.2. Mixture Model Correlations for Overall Heat Transfer Coefficient

If you are using the mixture model, interphase heat transfer may be specified using either:

- A specified overall **Heat Transfer Coefficient**.
- A specified **Nusselt Number**.
- The **Interface Flux** model.

These models are as described above for the particle model.

### 7.10.1.3. Two Resistance Model for Fluid Specific Heat Transfer Coefficients

This applies to both the particle and mixture models. It is designed for advanced applications in which it is necessary to consider interphase heat transfer on each side of the interface. The Two Resistance Heat Transfer model is an essential ingredient when modeling combined heat and mass transfer due to phase change. The primary application that requires this in ANSYS CFX is the Thermal Phase Change model for interphase mass transfer. For details, see [Thermal Phase Change Model \(p. 213\)](#).

In this class of models, you need to specify two heat transfer coefficients: one for each fluid of a specified phase pair. The following points should be noted when using this model.

- The Two Resistance model can be used in conjunction with the Particle or Mixture models.
- Any model that is available for the overall heat transfer coefficient is also available for either of these fluid specific **Heat Transfer Coefficients**, within the limitation described below.
- A fluid specific **Heat Transfer Coefficient** may be specified directly for each fluid.
- A fluid specific **Nusselt Number** may be specified directly for each fluid. In this case, the **Nusselt Number** is always defined relative to the physical properties of the fluid to which it pertains. For details, see [The Two Resistance Model in the CFX-Solver Theory Guide](#).
- The Ranz Marshall and Hughmark correlations should only be used on the continuous phase side of a continuous-dispersed phase pair, using the Particle Model.
- It is possible to specify a zero resistance condition on one side of the phase interface. This is equivalent to an infinite fluid specific **Heat Transfer Coefficient**. Its effect is to force the interfacial temperature to be the same as the phase temperature.

Note that all the **Particle Model Overall Heat Transfer** coefficient correlations are equivalent to a `Two Resistance Model`, with the named heat transfer correlation on the continuous phase side, and zero resistance on the dispersed phase side. Hence, one would typically want to use a `Two Resistance Model` in situations where heat transfer in the dispersed phase is significant, for example:

- Transient flows, with small dispersed phase thermal conductivity.
- Condensation onto droplets.

## 7.10.2. Homogeneous Heat Transfer in Multiphase Flow

Unlike other transport processes, fluid-specific energy equations are solved in homogeneous multiphase flow. A separate equation will appear in the solver manager for each fluid. The results file will also contain fluid-specific temperatures, although you should find that they are essentially equal.

## 7.11. Polydispersed, Multiple Size Group (MUSIG) Model

A homogeneous MUSIG model is available. Homogeneous means that all size groups for a given polydispersed (MUSIG) fluid move at the same velocity.

The following topics will be discussed:

- [Setting up a Polydispersed \(MUSIG\) Simulation \(p. 207\)](#)
- [MUSIG Model Advice \(p. 208\)](#)

Theory documentation for the Polydispersed (MUSIG) model is available; for details, see [Multiple Size Group \(MUSIG\) Model in the CFX-Solver Theory Guide](#).

### 7.11.1. Setting up a Polydispersed (MUSIG) Simulation

---

#### Important

Before considering the MUSIG model as a modeling option, you may want to read [MUSIG Model Advice \(p. 208\)](#), which outlines the applicability and limitations of the model.

To begin setting up a MUSIG simulation, select the **Polydispersed Fluid** option for **Fluid and Particle Definitions... > <fluid definition> > Morphology** on the **Basic Settings** tab for the domain, then define at least one **Polydispersed Fluid** on the **Polydispersed Fluids** tab. Boundary conditions, initial conditions and sources should then be set as appropriate.

#### 7.11.1.1. Creating a Polydispersed (MUSIG) Fluid

On the **Polydispersed Fluid** tab, one polydispersed fluid must be added per Polydispersed (MUSIG) Fluid Definition. In future releases, multiple fluids may be selected in order to allow different size groups to move with different velocity fields.

The **Size Group Distribution** setting can be set to `Equal Mass`, `Equal Diameter`, `Geometric`, or `User Defined`. For details, see [Size Group Discretization in the CFX-Solver Theory Guide](#). When the **Size Group Distribution** setting is set to `User Defined`, the **Size Group Diameter** parameter must be defined for every **Size Group** object with the groups ordered so that the diameters are increasing monotonically. The **Reference Density** must be set if the density of the polydispersed fluid is not constant; this reference density is used only for assigning the masses of the size groups. When the size

group diameter is needed to calculate coalescence and breakup rates, the diameter is calculated from the group mass and the local fluid density.

The group names will have the format `Group <N>`, where `<N>` is an integer denoting the group number (sorted in order of increasing size).

Coalescence and breakup models must be set on the **Polydispersed Fluid** tab. For details, see [Multiple Size Group \(MUSIG\) Model in the CFX-Solver Theory Guide](#).

### 7.11.1.2. Boundary Conditions

Inlet and Opening boundary conditions require the specification of size fractions for each of the size groups. The size fractions may be set to `Value` or `Automatic`. All size fractions set to `Automatic` are calculated to have the same value such that the overall sum of size fractions (including those that are specified by value) is unity. If all size fractions are set to `Value`, you must ensure that the specified size fractions sum to unity.

### 7.11.1.3. Initial Conditions

Initial conditions can be set to either `Value` or `Automatic` in the same manner as at inlet and opening boundary conditions.

### 7.11.1.4. Sources

There are two types of sources which are relevant for polydispersed (MUSIG) fluids. The first is a continuity source, which is commonly used to model an inlet without resolving the inlet geometry. The source can be applied to a subdomain, a point, or a boundary. When specifying a continuity source, the size fraction distribution must also be provided. The specified size fractions must sum to unity. By default, if the continuity source is negative (that is, a mass sink), the specified size distribution is ignored and the local size fractions are used instead. If you would like the specified size distribution to be used even if the continuity source is negative, set the setting **MUSIG Sink Option** to `Specified Size Fractions`.

Sources may also be added directly to the size fraction equations without affecting the continuity equation. Consistency requires that the size fraction sources sum to zero when summed over all size groups.

### 7.11.1.5. Post Processing Variables

The MUSIG-specific variables available for post-processing are:

- `Size Fraction`
- `Cumulative Size Fraction`
- `Mean Diameter` (Sauter mean diameter)
- `Interfacial Area Density`

## 7.11.2. MUSIG Model Advice

The MUSIG model is best applied to flows with polydispersed, medium-size bubbles. Medium-sized in this context means bubbles that are large enough to be in the distorted particle regime, but not large enough to be in the spherical cap regime. Within the distorted particle regime, the asymptotic slip velocity of such bubbles is sufficiently small relative to inertial time scales that it can be attained almost

instantly. Within this assumption, it is reasonable to assume that all the bubble size groups share a common velocity field. This is the fundamental assumption in the homogeneous MUSIG model.

The assumptions used in deriving the homogeneous MUSIG model break down in the following situations:

- Small spherical bubbles, or large spherical cap bubbles. In these cases, the asymptotic slip velocity is proportional to the square root of the particle diameter.
- Liquid drops (sprays) or solid particles in a gas. In this case, not only are the asymptotic slip velocities dependent on particle size, but the particle relaxation times may be comparable to, or larger than, the inertial time scale. The MUSIG model would not predict segregation of solid particles of different sizes in a fluidized bed.
- Flows where non-drag forces are significant and depend on bubble size. For example, the lift force exerted on bubbly flows in pipes has a separating effect, moving large bubbles to the pipe center and small bubbles to the outside.

## 7.12. Turbulence Modeling in Multiphase Flow

This section describes the use of turbulence models in multiphase simulations. You should be familiar with the contents of *Turbulence and Near-Wall Modeling* (p. 125), which describes the use of turbulence models in single-phase flows, before reading this section.

### 7.12.1. Phase-Dependent Turbulence Models

Phase dependent turbulence models can be used in conjunction with the inhomogeneous model (particle and mixture models) only. Each phase can use a different turbulence model. All models available for single-phase calculations are also available for continuous phases in multiphase calculations, with the exception of the LES model. The models available for dispersed phases are limited to the laminar model or zero equations models because other models are not considered to be appropriate. For example, a recommended model for dilute dispersed two-phase flow uses a two-equation model, such as the SST model or  $k - \varepsilon$  model, for the continuous phase, and an algebraic eddy viscosity model for the dispersed phase, which simply sets the dispersed phase viscosity proportional to the continuous phase eddy viscosity.

For flows where the phases tend to separate, homogeneous turbulence is recommended. See the sections below for details.

#### 7.12.1.1. Algebraic Models

If using the zero-equation algebraic turbulence model, there are several options:

- The default zero-equation model uses a formula based on geometric length scale and the mean solution velocity. This should be used with caution for multiphase flow, as it is correlated for single-phase turbulent pipe flow.
- You may supply your own prescription for eddy viscosity, using a constant or an expression.
- For dispersed phases only, you may invoke the `Dispersed Phase Zero Equation` turbulence model. This is the recommended algebraic model for a dispersed phase. It is only available for the disperse fluid when the continuous fluid is set to use a turbulence model (that is, not laminar).

An **Eddy Viscosity Prandtl Number** can be specified. The default value of 1 is appropriate for bubbles or very small solid particles. For large solid particles in a gas phase it may be better to use a value greater than 1. This is highly model dependent. Several models are available in the literature.

### 7.12.1.2. Two Equation Models

The  $k - \varepsilon$  model in multiphase is very similar to the single-phase model. It is recommended for use in continuous phases. The other two equation turbulence models can be used for continuous phases, if desired.

### 7.12.1.3. Reynolds Stress Models

The multiphase versions of Reynolds stress models are equivalent to the single phase version.

## 7.12.2. Homogeneous Turbulence in Inhomogeneous Flow

When using the inhomogeneous model (particle and mixture models), you can select to solve a homogeneous turbulence field. In this case, a single turbulence field is solved for using a single turbulence model. This option is recommended for free surface flow using the inhomogeneous model, separated flow, stratified flow and any situation where the phases tend to separate out.

Note that using the fluid-dependent turbulence model option, when the same turbulence model is used in each phase, is not the same as using the homogeneous turbulence option. In the latter, a single turbulence field is solved instead of two separate fields which happen to use the same model.

The turbulence model chosen should be based on the advice given for single phase flow. For details, see [Turbulence and Near-Wall Modeling](#) (p. 125).

### 7.12.3. Turbulence Enhancement

In flows with a dispersed phase, large particles in the dispersed phase tend to increase turbulence in the continuous phase due to the presence of wakes behind the particles. This is known as particle induced turbulence. The `Sato Enhanced Eddy Viscosity` model can be used to model this effect. It is only available for fluid pairs using `Continuous | Dispersed` morphology. For details, see [Fluid Pair Models Tab in the CFX-Pre User's Guide](#).

### 7.12.4. Turbulence in Homogeneous Multiphase Flow

A common turbulence field exists in homogeneous multiphase flow, therefore a single turbulence field is solved using a single turbulence model. For this type of flow, the single phase flow modeling advice is applicable. For details, see [Turbulence and Near-Wall Modeling](#) (p. 125).

## 7.13. Additional Variables in Multiphase Flow

Additional Variables can exist in all fluids or only a limited number of fluids in a multiphase simulation. In addition, both homogeneous and phase-specific Additional Variables are supported. Phase-specific Additional Variables may be transferred between two phases provided that, for both phases, a transport equation is solved for the Additional Variable and a kinematic diffusivity has been set. It is also possible to have interphase transfer from a transported Additional Variable into an algebraic Additional Variable (that is, the algebraic Additional Variable acts like an Additional Variable source or sink).

### 7.13.1. Additional Variable Interphase Transfer Models

It is possible for an Additional Variable  $\Phi_\alpha$  to be coupled to a different Additional Variable  $\Psi_\beta$  across a phase interface between fluids  $\alpha$  and  $\beta$ . Such a situation may arise, for example, when modeling the

evaporation of water in a solid phase to water vapor in a gaseous phase. The only restriction is that  $\Phi_\alpha$  and  $\Psi_\beta$  have the same physical dimensions. Two such coupled Additional Variables constitute an Additional Variable pair  $\Phi_\alpha | \Psi_\beta$  associated with the phase pair  $\alpha | \beta$ .

Transfer of an Additional Variable across a phase boundary is described by an **Additional Variable Transfer Coefficient**, which is analogous to the **Heat Transfer Coefficient**.

It is often convenient to express the Additional Variable transfer coefficient in terms of a dimensionless Sherwood number  $Sh$ , analogous to the **Nusselt Number** in heat transfer. The Sherwood number is calculated based on the kinematic diffusivity for a volumetric variable, or the dynamic diffusivity for a specific variable.

### 7.13.1.1. Particle Model Correlations

For laminar forced convection around a spherical particle, theoretical analysis shows that  $Sh = 2$ . For a particle in a moving incompressible Newtonian fluid, the Sherwood number is a function of the particle Reynolds number  $Re$  and the Additional Variable Prandtl number  $Pr$ .

The following models are available in ANSYS CFX:

#### 7.13.1.1.1. Ranz-Marshall Correlation

This model is valid in the following ranges:

$$Sh = 2 + 0.6 Re^{0.5} Pr^{0.3} \quad 0 \leq Re < 200 \quad 0 \leq Pr < 250 \quad (7-4)$$

#### 7.13.1.1.2. Hughmark Correlation

This model is valid in the following ranges:

$$Sh = \begin{cases} 2 + 0.6 Re^{0.5} Pr^{0.33} & 0 \leq Re < 776.06 \quad 0 \leq Pr < 250 \\ 2 + 0.27 Re^{0.62} Pr^{0.33} & 776.06 \leq Re \quad 0 \leq Pr < 250 \end{cases} \quad (7-5)$$

#### 7.13.1.1.3. Sherwood Number

You specify the Sherwood number directly. This should be based on empirical correlations, if available, for your application.

#### 7.13.1.1.4. Additional Variable Transfer Coefficient

You specify the Additional Variable Transfer Coefficient directly. This should be based on empirical correlations, if available.

#### 7.13.1.1.5. Interface Flux

This is an advanced option that permits experienced users to implement interphase Additional Variable transfer models which are not of the simple form of a transfer coefficient multiplied by a bulk Additional Variable difference. You must specify the Additional Variable flux coefficients for both fluids and Additional Variable flux value from Fluid 1 to Fluid 2. For details, see [Particle Model Correlations in the CFX-Solver Theory Guide](#).

### 7.13.1.2. Mixture Model Correlations

If you are using the mixture model, interphase transport for Additional Variables may be specified using one of the following:

- A specified **Interphase Transfer Coefficient**
- A specified **Sherwood Number**
- The **Interface Flux Model**

### 7.13.2. Homogeneous Additional Variables in Multiphase Flow

Homogeneous Additional Variables are available for both homogeneous and inhomogeneous flow. However, in most cases, the homogeneous assumption is inappropriate for volumetric Additional Variables. For this reason, only specific Additional Variables are permitted to be homogeneous in ANSYS CFX.

## 7.14. Sources in Multiphase Flow

Sources in multiphase flow are very similar to those in single phase flow. Information on the single-phase source documentation is available. For details, see [Sources in the CFX-Solver Theory Guide](#). Information on setting source terms in CFX-Pre is available in [Sources Tab in the CFX-Pre User's Guide](#).

There are two types of sources in multiphase flow:

- Fluid-specific sources. For details, see [Fluid-Specific Sources](#) (p. 212).
- Bulk sources. For details, see [Bulk Sources](#) (p. 212).

### 7.14.1. Fluid-Specific Sources

Fluid-specific sources are applied directly to fluid as specified and are not multiplied by volume fraction. In other words, the sources are assumed to be specified per unit volume of geometry, not per unit volume of the phase. If you have a source expression which is per unit volume of the phase, you must either multiply the source by volume fraction or else use **Bulk Sources** which are discussed below.

Fluid-specific sources are not available for equations in homogeneous multiphase flow which span all fluids; **Bulk Sources** are the only appropriate option for these situations.

### 7.14.2. Bulk Sources

**Bulk Sources** automatically multiply the specified source by volume fraction, ensuring that the source reduces to zero as the fluid volume fraction reduces to zero. They can be used for equations which span all fluids as well as those which are fluid-dependent, such as mass fractions and Additional Variables. However, they may not be used for mass sources.

## 7.15. Interphase Mass Transfer

Interphase mass transfer occurs when mass is carried from one phase into another. It is applicable to both the inhomogeneous and homogeneous multiphase models. Some of the model libraries available in CFX-Pre contain simulation definitions for interface mass transfer cases, including boiling water and cavitation.

Possible causes of interphase mass transfer are:

- Change of thermodynamic phase. For example, melting/solidification in liquid-solid systems, evaporation/condensation in gas-liquid systems, and cavitation in gas-liquid systems.
- Diffusion of a dissolved species across a phase boundary. This may or may not involve a change of phase of the dissolved species. Examples are gas dissolution, and evaporation of a liquid into a gas containing its vapor.
- Breakup and coalescence may be treated as a mass transfer process between two phases representing different size groups of the same species.

### 7.15.1. Double Precision Solver

In some cases, using the double precision solver executable can improve convergence for interphase mass transfer cases.

### 7.15.2. User Specified Mass Transfer

For advanced applications, it is possible to directly specify the interphase mass transfer sources. You may specify the interfacial mass flux or the interfacial mass flow (volumetric mass source) between any pair of phases. The latter is more appropriate for volumetric mass transfer processes such as breakup and collision. For details, see [User Defined Interphase Mass Transfer in the CFX-Solver Theory Guide](#).

### 7.15.3. Thermal Phase Change Model

This model describes phase change induced by interphase heat transfer; it may be used to simulate boiling and condensation, or melting and solidification. For example, it may be used to model condensation of saturated vapor bubbles in sub-cooled liquid, or evaporation of saturated bubbles in superheated liquid. It is only applicable to phase changes of pure substances.

This section provides modeling information. For a discussion of the theory, see [The Thermal Phase Change Model](#).

The Thermal Phase Change model requires a number of related items of information to be provided.

#### 7.15.3.1. Saturation Temperature

There are two possible ways of defining the saturation temperature:

- Using the optional parameter **Saturation Temperature** under **Thermal Phase Change Model**, on the **Fluid Pairs** tab. It may be set as a constant, or an expression. If the latter, it should be defined as a function of absolute pressure.

---

#### Note

This option will not be available if you have created a Homogeneous Binary Mixture definition.

- Alternatively, you may define a homogeneous binary material (HBM) in the **Material** details view. For details, see [Material Details View: Homogeneous Binary Mixture in the CFX-Pre User's Guide](#). The HBM should consist of the two materials undergoing phase change, and the saturation conditions should be defined as material properties of the HBM.

You must use one of these methods to define the Saturation Temperature, otherwise an error will be generated. If you use both methods, then the Saturation Temperature parameter of the **Thermal Phase Change Model** takes precedence.

### 7.15.3.2. Wall Boiling Model

Wall boiling starts when the wall temperature achieves a temperature that is sufficiently large to initiate the activation of wall nucleation sites. This activation temperature is typically a few degrees above the saturation temperature. However, at this stage, the average temperature of the liquid in the vicinity of the heated wall is still well below the saturation temperature, hence in the sub-cooled boiling regime.

ANSYS CFX implements an RPI boiling model. Usage information is provided in the next section. For a theoretical discussion of this model, see [Wall Boiling Model](#).

#### 7.15.3.2.1. RPI Model

The RPI model for near-wall boiling can be controlled by several settings, as described next.

**Fixed Yplus for Liquid Subcooling** enables you to specify a fixed  $Y^+$  value at which the temperature is estimated for use in the bubble departure diameter and quenching heat transfer correlations. For details, see [Bubble Departure Diameter](#).

**Bubble Departure Diameter** enables you to specify the bubble departure diameter. The available options are:

- User Defined
- Tolubinski Kostanchuk

For details, see [Bubble Departure Diameter](#).

**Wall Nucleation Site Density** enables you to specify the wall nucleation site density. The available options are:

- User Defined
- Lemmert Chawla

For details, see [Wall Nucleation Site Density](#).

**Bubble Detachment Frequency** enables you to specify the bubble detachment frequency. The available options are:

- User Defined
- Terminal Velocity over Departure Diameter

For details, see [Bubble Detachment Frequency](#).

**Bubble Waiting Time** enables you to specify the bubble waiting time. The available options are:

- User Defined
- Proportional to Detachment Period

For details, see [Bubble Waiting Time](#).

**Liquid Quenching Heat Transfer Coefficient** enables you to specify the liquid quenching heat transfer coefficient. The available options are:

- User Defined
- Del Valle Kenning

For details, see [Quenching Heat Transfer](#).

**Bubble Diam. Influence Factor** enables you to specify the bubble diameter influence factor. For details, see [Partitioning of the Wall Heat Flux](#).

**Max. Area Frac. of Bubble Influence** enables you to specify the maximum area fraction of bubble influence. For details, see [Area Influence Factors](#) and [Evaporation Rate](#).

---

### Note

If using the User Defined option for any of these variables, and if any of these user defined models are CEL expression using the wall superheat, then it is important to use the phase-pair based variable that describes this; for example:

```
water | steam.Tsuperheat
```

It is not appropriate to use the phase-based temperature field such as water.Temperature to determine this. See [System Variable Prefixes in the CFX Reference Guide](#) for a description of the use of phase-pair based variables, and [Determination of the Wall Heat Flux Partition in the CFX-Solver Theory Guide](#) for a discussion on the determination of the wall superheat.

### 7.15.3.2.2. Using the Wall Boiling Model

Walls that have boiling may have a specified temperature, specified heat flux, or specified heat transfer coefficient. Walls that have boiling may not have fluid-specific heat transfer boundary conditions. The wall boiling model has its own algorithms for computing wall contact area fractions for each phase; for the purpose of computing wall heat transfer, any user-specified wall contact model is overridden.

Wall boiling needs to be switched on explicitly for those walls at which it is expected to occur. The primary details of the wall boiling model are defined on the domain form, but these may be overridden on individual walls.

Note the following restrictions on other domain-based physical models when using wall boiling:

- Cannot have radiation sources.
- Cannot have a laminar continuous phase (laminar dispersed phases are OK).
- Cannot use in conjunction with the MUSIG model.

### 7.15.3.3. Latent Heat

This is not specified directly. Rather, it is obtained *indirectly* as the difference between the static enthalpies of the two phases. For example:

$$L = H_{\text{gas}}(T_{\text{sat}}) - H_{\text{liquid}}(T_{\text{sat}}) \quad (7-6)$$

Hence, it is essential that the static enthalpy fields contain the absolute enthalpies of the two phases. This should be taken care of automatically if you select materials from the materials properties data base. On the other hand, if you define your own material properties, you should ensure that the enthalpies are defined correctly by setting the following fields in the **Material** details view:

- Reference Temperature,  $T_{\text{ref}}$
- Reference Pressure,  $p_{\text{ref}}$
- Reference Specific Enthalpy  $h_{\text{ref}}$

Definitions of these quantities are available. For details, see [Library Materials \(p. 47\)](#).

For example, if you know the latent heat  $L$  at a reference state  $(T, P)$ , then one way of ensuring that the correct latent heat is obtained at all temperatures and pressures is to set:

$$\begin{aligned} T_{\text{ref}}(\text{liq}) &= T, & P_{\text{ref}}(\text{liq}) &= P, & H_{\text{ref}}(\text{liq}) &= 0 \\ T_{\text{ref}}(\text{gas}) &= T, & P_{\text{ref}}(\text{gas}) &= P, & H_{\text{ref}}(\text{gas}) &= L \end{aligned} \quad (7-7)$$

### 7.15.3.4. Heat Transfer Models

In general, both phases should be assigned either the Thermal Energy or Total Energy model for heat transfer.

However, in the case of subcooled boiling, you should find that the vapor phase temperature remains fixed at saturation conditions. Hence, in the case of constant saturation conditions, it is possible to run the vapor phase as Isothermal, with Reference Temperature set equal to the vapor saturation temperature.

### 7.15.3.5. Interphase Heat Transfer Correlations

The Thermal Phase Change Model assumes:

- That thermodynamic equilibrium prevails at the interface between the two phases. That is, that the interfacial temperature equals the saturation temperature.
- That heat transfer either side of the phase interface may be modeled by two independent heat transfer coefficients. For details, see [Two Resistance Model for Fluid Specific Heat Transfer Coefficients \(p. 206\)](#).

Hence, the Thermal Phase Change model requires the use of the Two Resistance model for interphase heat transfer. Selection of appropriate heat transfer correlations depends on the situation being modeled. Suggestions are provided below. First, some terminology:

- A phase is said to be **saturated** if its temperature equals the saturation temperature.
- It is said to be **subcooled** if its temperature is below saturation.
- It is said to be **superheated** if its temperature is above saturation.

### 7.15.3.6. Modeling Advice

#### 7.15.3.6.1. Saturated Vapor Bubbles in Subcooled or Superheated Liquid

Vapor temperature is expected to remain at saturation conditions. There is negligible resistance to heat transfer on the dispersed phase side. Hence:

- Under *constant* saturation conditions, you should set **Zero Resistance** on the **dispersed** phase side.
- Under *variable* saturation conditions, you should set a large but finite **Nusselt Number** (of the order of 1000) on the **dispersed** phase side.

The primary resistance to heat transfer is on the continuous liquid phase side. Hence:

- For spherical bubbles, you should set either the **Ranz Marshall** or **Hughmark** correlation on the **continuous** phase side.
- For non-spherical bubbles, you may want to replace these by a user-defined correlation for **Heat Transfer Coefficient** or **Nusselt Number**.

#### 7.15.3.6.2. Subcooled or Superheated Droplets in Saturated Vapor

The situation here is entirely the opposite to the above, as there is now negligible resistance to heat transfer on the *continuous* phase side. Hence:

- Under constant saturation conditions, you should set **Zero Resistance** on the **continuous** phase side.
- Under **variable** saturation conditions, you should set a large but finite **Nusselt Number** (of the order of 1000) on the **continuous** phase side.

The primary resistance to heat transfer is on the *dispersed* droplet phase side. This is a fundamentally transient phenomenon for which there are no universally established correlations.

The simplest possible model on the **dispersed** phase side is:

$$Nu \approx 6 \quad (7-8)$$

This is based on the analytic solution of transient heat conduction inside a solid sphere. It assumes:

- That advection effects inside the drop may be neglected.
- That the time-dependent temperature field inside the sphere may be considered to be spatially constant.

#### 7.15.3.6.3. Superheated Vapor Bubbles in Liquid

In this case, there is significant resistance to heat transfer on both the dispersed and continuous phase sides. Hence:

- For spherical bubbles, use either the **Ranz Marshall** or **Hughmark** correlation on the **continuous** phase side.
- On the dispersed phase side, use a correlation appropriate to heat transfer inside a spherical fluid particle, such as the  $Nu \approx 6$  discussed above.

#### 7.15.3.6.4. Thermal Energy and Total Energy Models

- Use Thermal Energy in cases where low-speed flow exists and where viscous effects are negligible.

- Use Total Energy in the case of high-speed flow and where viscous effects are not negligible.

### 7.15.4. Cavitation Model

Cavitation refers to the process by which vapor forms in a low pressure regions of a liquid flow. It occurs in a variety of applications such as throttles, pumps and injectors. In ANSYS CFX, cavitation is implemented as a multiphase model. Most simulations can use the homogeneous multiphase model because the vapor velocity field is often assumed to be the same as that of the liquid. However, the inhomogeneous model can be used if desired.

When solving a cavitating flow problem, you should first obtain a converged solution with the cavitation model turned off at the conditions where you would expect to see cavitation. The cavitation model can be turned on and off by selecting **Cavitation** or **None** in the **Mass Transfer** section of the **Fluid Pairs** tab, found on the **Domains** tab. The initial guess should use a liquid volume fraction of 1 and a gas vapor volume fraction of 0.

It should be emphasized that if a poor initial guess is supplied with the cavitation model active (that is, a non-zero initial vapor volume fraction), then it is possible to arrive at a physically impossible situation where most of the flow domain is cavitating.

For cavitation problems, the pressure level should be set at one of the boundaries, or by setting pressure level information on the **Advanced** tab of the **Solver Control** settings in CFX-Pre. For details, see [Pressure Level Information \(p. 437\)](#). This is because the cavitation rate is driven by the difference between the local pressure and vapor pressure, so the pressure level is important. Inflow boundaries would normally use a vapor volume fraction of 0 because the vapor is generated within the domain.

When solving cavitation problems, several variables in the results file are new or are modified from their standard behavior:

- **Interphase Mass Transfer Rate:** The cavitation rate is calculated by the solver.
- **Pressure:** The cavitation model is a model for the interphase mass transfer rate, and does not guarantee that all absolute pressures calculated by the solver will be positive. They will, however, be less negative than if cavitation is not modeled.

In order to make post-processing more convenient, the variable called `Pressure` that is written to the results file is clipped in such a way that negative values for absolute pressure are clipped to zero. For example, if the reference pressure is  $1e5$  Pa, the `Pressure` variable is clipped to be not smaller than  $-1e5$  Pa. The actual (non-clipped) pressure field computed by the solver can be visualized using the variable called `Solver Pressure`.

Note, however, that the solver will output `Pressure` with non-clipped values (as for `Solver Pressure`) if you refer to `Pressure`:

- in an expression
- for output to a selected variables transient file
- in the definition of a monitor point

the solver will interpret this as `Solver Pressure` (non-clipped values). To use the clipped pressure in these contexts, use the variable name `Clipped Pressure` instead.

- **Absolute Pressure:** To avoid robustness issues associated with negative absolute pressure (for example if the simulation includes an ideal gas equation state), the variable called `Absolute Pressure` is clipped to be no smaller than the saturation pressure. However, the true absolute pressure must be used to calculate the cavitation rate. This variable is not available in the results file, but may be accessed

in CEL (for example, for user defined cavitation models) with the name `Nonclipped Absolute Pressure`.

- **Density:** To enhance numerical stability, the vapor density field is clipped in a user-controlled fashion through the `Maximum Density Ratio` parameter, described below. The vapor density field in the results file shows the clipped values. The unclipped density (which is used to calculate the cavitation rate itself) is available in the variable field called `Nonclipped Density`.

The cavitation model appears as an interphase mass transfer option. If you choose cavitation as a mass transfer model, you have the choice between the Rayleigh Plesset model and a user-defined model:

#### 7.15.4.1. Rayleigh Plesset Model

The Rayleigh Plesset cavitation model requires the following parameters:

- **Saturation Pressure:** The saturation pressure must be specified as a value or expression. Note that this is an absolute, not relative, pressure. In ANSYS CFX, saturation data is *not* read from material property files (such as `.rgp` files used for defining real fluids). There are two possible ways of defining the saturation pressure:
  - Using the optional parameter `Saturation Pressure` under **Rayleigh Plesset Model** on the Fluid Pairs tab. It may be set as a constant, or an expression. If the latter, it should be defined as a function of temperature.
  - Alternatively, you may define a Homogeneous Binary Material (HBM) under the **Material** details view. The HBM should consist of the two materials undergoing phase change, and the saturation conditions should be defined as material properties of the HBM.

You must use one of these methods to define the Saturation Pressure; otherwise, an error will be generated. If you use both methods, then the Saturation Pressure parameter of the **Rayleigh Plesset Model** takes precedence.

- **Mean Diameter:** The mean nucleation site diameter must be specified. The default value of  $2e-06$  m is a reasonable value.

The following optional parameters can also be set. If not specified, the default values shown are used. These defaults are appropriate for most cavitation simulations.

- **Cavitation Condensation Coefficient:** This is an empirical factor to account for the fact that condensation usually occurs slowly. The default value is 0.01.
- **Cavitation Vaporization Coefficient:** This is an empirical factor to account for the fact that vaporization usually occurs quickly. The default value is 50.
- **Maximum Density Ratio:** This is used to clip the vapor density for all terms except the cavitation source term itself, which must use the true density specified as the material property. The default value is 1000.
- **Nuclei Volume Fraction:** This is the volume fraction of the nucleation sites. The default value is  $5e-4$ .
- **Cavitation Rate Under Relaxation Factor:** The default value is 0.25.

Additional theoretical information on this model is available. For details, see [The Rayleigh Plesset Model in the CFX-Solver Theory Guide](#).

#### 7.15.4.2. User Defined Cavitation Models

A user-defined cavitation model can be implemented for advanced users. It requires the following parameters:

- **Cavitation Rate:** This should be set through CEL or User Fortran. The cavitation rate is simply  $\dot{m}_{fg}$ , the interphase mass transfer rate per unit volume from the liquid to the vapor phase, assuming the first fluid in the fluid pair is the liquid and the second is the vapor. If the order in the pair is reversed, the sign must be reversed. As an example, the interphase mass transfer rate for the Rayleigh Plesset model in ANSYS CFX is given by [The Rayleigh Plesset Model in the CFX-Solver Theory Guide](#).
- **Saturation Pressure:** The saturation pressure must be specified as a value or expression. This may be set in the same way as explained above for the Rayleigh-Plesset Model.

The following optional parameters can also be set. If not specified, the default values shown are used. These defaults are appropriate for most cavitation simulations.

- **Maximum Density Ratio:** This is used to clip the vapor density for all terms except the cavitation source term itself, which must use the true density specified as the material property. The default value is 1000.
- **Cavitation Rate Under Relaxation Factor:** The default value is 0.25.

When developing an expression for a user-defined cavitation rate, keep in mind the following points:

- It was noted above that the cavitation model does not guarantee that all absolute pressures will be positive. If you calculate the vapor density as a CEL function of pressure, make sure you use the variable `pabs` in your expression. This variable is clipped to the saturation pressure, which is numerically well-behaved even when the absolute pressure becomes negative.
- The cavitation rate is driven by  $p_v - p$ . The pressure used in this expression should be the nonclipped absolute pressure (variable name is `pabsnc`).
- The cavitation rate is typically proportional to the vapor density. The vapor density, however, may have been clipped by the **Maximum Density Ratio** parameter, which is inappropriate in this context. Instead, the true vapor density should be used, which is available as the variable `densitync`.

Solver information about user-defined models is available. For details, see [User Defined Cavitation Models in the CFX-Solver Theory Guide](#).

### 7.15.5. Interphase Species Mass Transfer

This describes mass transfer of dissolved species by diffusion across a phase interface. Examples are:

- **Evaporation** of a liquid into a gaseous mixture containing its vapor; for example, the evaporation of water droplets into air + water vapor.
- **Absorption/Dissolution** of a dissolved gas in a liquid from a gaseous mixture; for example, the absorption of ammonia by water from a mixture of air+ammonia.

Additional theoretical information is available in [General Species Mass Transfer in the CFX-Solver Theory Guide](#).

Species transfer requires a number of related items of information to be provided.

#### 7.15.5.1. Component Pairs

In ANSYS CFX, interphase species transfer may be specified between any two components  $A$  and  $B$  in fluids  $\alpha$  and  $\beta$  respectively, subject to the following conditions:

- The mass fractions  $A$  and  $B$  must both be determined from transport equations.

- It is not possible to specify species transfer of a component whose mass fraction is determined algebraically, or from the constraint equation.
- Unless the **Mass Transfer** option **Sum Species Mass Transfers** is selected, the resulting interphase mass flow rate is sufficiently small that continuity equation sources may be neglected, and latent heat effects in the energy equation are negligible.

This will be generalized in future releases.

The coupled components  $\alpha$  |  $\beta$  constitute a *Component Pair* associated with the fluid pair  $\alpha$  |  $\beta$ . Component pairs are analogous to Additional Variables Pairs. For details, see [Additional Variables in Multiphase Flow](#) (p. 210).

### 7.15.5.2. Two Resistance Model

The species transfer model assumes:

- That dynamic equilibrium prevails at the interface between the two phases.
- That mass transfer either side of the phase interface may be modeled by two independent mass transfer coefficients.

Hence, species transfer is implemented as a Two Resistance Model, analogous to the Two Resistance Model for heat transfer. For details, see

- [Two Resistance Model for Fluid Specific Heat Transfer Coefficients](#) (p. 206)
- [Two Resistance Model with Negligible Mass Transfer in the CFX-Solver Theory Guide](#).

### 7.15.5.3. Single Resistance Model

The Single Resistance options Ranz Marshall, Sherwood Number, Hughmark and Mass Transfer Coefficient apply the corresponding correlation on the continuous fluid side and a zero resistance on the dispersed phase side of the interphase. The correlations are analogous to Additional Variable mass transfer. For details, see [Particle Model Correlations](#) (p. 211).

### 7.15.5.4. Interfacial Equilibrium Models

A number of interfacial equilibrium models are available. Different ones are recommended for different physical situations. Additional theoretical information is available in [Equilibrium Models in the CFX-Solver Theory Guide](#).

#### 7.15.5.4.1. Liquid Evaporation (Raoult's Law)

For evaporation of an ideal liquid into a gas containing its vapor, **Raoult's Law** should be employed to describe the equilibrium condition. This requires the following additional information:

- The **Thermodynamic Phase** (liquid or gas) must be declared on the **Materials Properties** tab for each fluid  $\alpha$  and  $\beta$ .
- The **Saturation Pressure** must be declared for the vapor component. This may be a constant or an expression. In the latter case, it should be a function of absolute temperature. There are two possible ways of defining the saturation pressure:
  - Using the optional parameter **Saturation Pressure** under the option for Raoult's Law in the **Component Pair Details** frame. It may be set as a constant or an expression. If the latter, be defined as a function of temperature.

- Alternatively, you may define a Homogeneous Binary Material (HBM) under the **Material** details view. The HBM should consist of the two components in the component pair and the saturation conditions should be defined as material properties of the HBM.
- You must use one of these methods to define the Saturation Pressure; otherwise, an error will be generated. If you use both methods, then the **Saturation Pressure** parameter of **Raoult's Law** takes precedence.

#### 7.15.5.4.2. Gas Absorption / Dissolution (Henry's Law)

For absorption/dissolution of a dissolved gas from a liquid into a gaseous mixture, **Henry's Law** should be employed to describe the equilibrium condition. This requires the following additional information:

- The **Thermodynamic Phase** (liquid or gas) must be declared on the **Materials Properties** tab for each fluid  $\alpha$  and  $\beta$ .
- **Henry's Coefficient** must be declared for the vapor component.

Care should be exercised in defining the Henry coefficient. There is no agreed convention as to its correct definition, so a units conversion may be necessary. ANSYS CFX has a choice of two conventions:

**Molar Fraction Henry Coefficient**,  $H^x$ , with units of pressure, or

**Molar Concentration Henry Coefficient**,  $H^c$ , with units of pressure per molar concentration.

#### 7.15.5.4.3. Other Situations

In situations where the above two simple laws do not apply, such as liquid-liquid extraction, or multicomponent transfer, you may specify empirical data for the equilibrium condition, if available. For this purpose, you have a choice of three dimensionless quantities:

- **Molar Concentration Equilibrium Ratio**
- **Molar Fraction Equilibrium Ratio**
- **Mass Fraction Equilibrium Ratio.**

These specify the equilibrium ratios of the indicated concentration variables, for the first fluid divided by the second fluid.

#### 7.15.5.5. Species Mass Transfer Coefficients

The Two Resistance model applies to both the Particle and Mixture models, which determine the interfacial area density. It remains to specify the two mass transfer coefficients on each side of the phase interface.

The available correlations for mass transfer coefficients are analogous to those for heat transfer and Additional Variables.

- A fluid specific **Mass Transfer Coefficient** may be specified directly for each fluid.
- A fluid specific **Sherwood Number** may be specified directly for each fluid. The Sherwood number is always defined relative to the physical properties of the fluid to which it pertains:

$$S h_\alpha = \frac{k_\alpha d_{\alpha\beta}}{\rho_\alpha D_\alpha} \quad (7-9)$$

$k_\alpha$  is the mass transfer coefficient and  $d_{\alpha\beta}$  is the interfacial length scale (the mean particle diameter for the Particle Model and the mixture length scale for the Mixture Model).

- **Ranz Marshall** and **Hughmark** correlations are available on the **continuous phase side only** of a continuous-dispersed phase pair, using the **Particle Model**.
- It is possible to specify a **Zero Resistance** condition on one side of the phase interface. This is equivalent to an infinite fluid specific mass transfer coefficient  $k_\alpha \rightarrow \infty$ . Its effect is to force the interfacial concentration to be the same as the bulk concentration of that phase.

The selection of physically correct mass transfer correlations is highly problem dependent. In the case of mass transfer between a continuous phase and a dispersed phase of approximately spherical particles, the following should be adequate for most problems of interest:

- **Ranz Marshall** or **Hughmark** in the continuous phase.
- **Zero Resistance** in the dispersed phase.

The latter assumption implies that mass transfer occurs very quickly between the dispersed phase and the interface. Consequently, interfacial concentrations on the dispersed phase side are assumed equal to the bulk dispersed phase concentrations. This will usually be valid for droplet evaporation, or gas absorption / dissolution in bubbles.

In cases where there is significant resistance to mass transfer on the dispersed phase side, the Zero Resistance model should be replaced by a user-specified correlation for dispersed phase Mass Transfer Coefficient or Sherwood Number.

### 7.15.5.6. Modeling Advice

#### 7.15.5.6.1. Liquid Evaporation

For evaporation of a pure liquid into its vapor, use Raoult's Law for the interfacial equilibrium model. For most cases of droplet evaporation, the resistance mass transfer on the droplet side is negligible. If that is the case, use Zero Resistance on the dispersed phase side, and Ranz-Marshall or Hughmark on the continuous phase side.

If the liquid consists of just one component, you should define it as a two component mixture with a dummy material as the Constraint material, and the pure liquid as the Transported material. You will then be able to define a component pair consisting of the pure liquid coupled to its vapor component in the gaseous phase.

#### 7.15.5.6.2. Gas Dissolution

Use Henry's Law for the interfacial equilibrium model. If the resistance to mass transfer on the dispersed phase side is negligible, then use Zero Resistance on the dispersed phase side, and Ranz-Marshall or Hughmark on the continuous phase side.

### 7.15.5.6.3. Mixture Properties

By default, ANSYS CFX computes thermodynamic properties of mixtures assuming that they are ideal mixtures. This is not appropriate, for example, for gases dissolved in a liquid. If the effect of the gas phase properties (for example, density) on the liquid phase properties is negligible, then you explicitly specify mixture properties in CFX-Pre to override the solver calculated mixture properties with appropriate values. The most important mixture property to override is density, but molar mass, dynamic viscosity and specific heat capacity should also be defined if you believe the solver calculated values will be inappropriate. Information on how the solver calculates mixture properties is available in [Radiation Properties](#) (p. 46).

### 7.15.5.6.4. Current Limitations

The ANSYS CFX implementation of component mass transfer is a preliminary implementation, with some limitations which are repeated here.

- The resulting interphase mass flow rate is assumed to be sufficiently small that continuity equation sources may be neglected.
- Consequently, latent heat effects in the energy equation are neglected.

Thus, component mass transfer is assumed to transfer very small amounts of material between phases, and the driving force is assumed to be governed solely by concentration differences. Component mass transfer due to heat transfer is not yet modeled.

## 7.15.6. Droplet Condensation Model

To activate the Droplet Condensation Model (or Nonequilibrium Steam Model when steam is the working fluid), use the following steps:

1. Choose your vapor and liquid materials, as well as a homogeneous binary mixture to define saturation properties. For each condensed phase, there should be a binary mixture defined between each droplet phase and the continuous phase. For steam calculations, the IAPWS library is recommended.
2. Choose a multiphase simulation with one continuous vapor phase and as many dispersed liquid phases as appropriate. (Each droplet phase is assumed to be monodispersed at each point in space, although the diameter can differ through the domain.)
3. For many condensing droplet applications, the homogeneous multiphase model is appropriate. When the droplets become bigger (for example, 1  $\mu\text{m}$  or larger), then the inhomogeneous multiphase model should be considered.
4. For the heat transfer model, ensure that **Homogeneous Model** is deactivated and select **Fluid Dependent**.
5. Set the droplet phase morphology to `Droplets with Phase Change`.
6. Set the continuous phase heat transfer model to `Total Energy`.
7. Subsequent modeling choices depend on whether the droplets are small or not.

For small (less than 1  $\mu\text{m}$ ) droplets, the following recommendations apply:

- a. Select `Small Droplet Temperature` (recommended) or `Total Energy` as the heat transfer model. Note that the droplet temperature setting implies that no transport equation is solved for the energy state of the droplet, but is determined from an algebraic relationship valid for sub-micron droplets.

- b. Activate the homogeneous nucleation model if you expect nucleation to occur in the domain. For multidomain applications (for example, multistage turbines), the nucleation model can be controlled independently for each domain. This allows one to model polydispersed droplets where a new set of droplets nucleates in each stage component (rotor or stator). To do this, one droplet phase can be defined for each turbine component (or group of components), and for a particular component (group) the nucleation model activated only for the corresponding droplet phase. Each droplet phase will continue to grow through the entire machine.
- c. On the Fluid Pairs tab, select `Small Droplets` for **Interphase Heat Transfer Model**. For mass transfer, select `Phase Change` and choose the small droplets option

For larger droplets, the following recommendations apply:

1. Select `Total Energy` (recommended) or `Thermal Energy` as the heat transfer model
2. On the Fluid Pairs tab, select `Two Resistance` as the interphase heat transfer model. On the continuous phase side, select the Ranz Marshall correlation, while on the droplet side, a Nusselt number of 6 is appropriate. For mass transfer, select `Phase Change` and choose the thermal phase change model

In addition, keep the following in mind when setting boundary conditions and initial conditions:

- Droplets may or may not appear through inlets and openings. If they do appear, choose the droplet volume fraction and droplet diameter (or droplet number) as appropriate. If they do not enter the boundary, choose zero for the volume fraction and droplet number; the droplet diameter is irrelevant
- The gas temperature at inlets, openings, and for initial conditions should not extend too far in the supercooled (or superheated) region when a second phase is present. A good rule of thumb is that these temperatures should not be more than 5 [K] below (or above) the saturation temperature, or else nonphysical mass transfer rates will develop which could cause divergence.

The following procedure is often helpful to solve droplet condensation problems:

1. Obtain a solution with the nucleation model turned off. This allows the supercooling to develop naturally in the flow, sets up a realistic expansion rate, and provides a very good initial guess for the full calculation.
2. Activate the nucleation model.

## 7.16. Boundary Conditions in Multiphase Flow

The use of boundary conditions for multiphase flow is very similar to that for single-phase flow. For details, see [Boundary Condition Modeling](#) (p. 57). The main differences are:

- Boundary conditions need to be specified for all fluids for all variables except the shared pressure field.
- Volume fractions of all phases must be specified on inlet and opening boundary conditions. These must sum to unity.
- A degassing boundary condition is available for multiphase flow containing a dispersed phase. For details, see [Degassing Condition \(Multiphase only\)](#) (p. 77).

### 7.16.1. Wall Boundaries in Multiphase

For multiphase flows, it is convenient to allow two distinct methods for you to specify wall boundary conditions:

- Bulk wall boundary conditions are defined as boundary condition attributes of the wall, and subsequently shared amongst the phases in a well defined manner. The algorithm for sharing wall fluxes amongst fluids depends on the concept of a wall contact model (which will be explained shortly).
- Alternatively, wall boundary conditions may be defined on a per fluid basis. This is a more advanced option, permitting the user complete flexibility in the definition of multiphase wall boundary conditions.

### 7.16.1.1. Bulk Wall Boundary Conditions

This is the simplest and most useful option. In most applications, wall boundary conditions are known as attributes of the wall. It is then part of the modeling procedure to decide how the consequent wall fluxes are allocated amongst the phases in contact with the wall.

For example, for bulk heat transfer, you may specify either:

- A bulk heat flux to the wall,  $Q_{\text{wall}}$ . The heat fluxes  $Q_{\alpha}$  to each phase  $\alpha$  are determined as follows:

$$Q_{\alpha} = A_{\alpha} Q_{\text{wall}} \quad (7-10)$$

Where  $A_{\alpha}$  is the contact area fraction of phase  $\alpha$  at the wall, calculated from the Area Contact Model as described below.

- A bulk heat transfer coefficient  $h_{\text{wall}}$  and outer temperature  $T_o$ . The heat fluxes to each phase are determined as follows:

$$Q_{\alpha} = A_{\alpha} h_{\text{wall}} (T_o - T_{\alpha}) \quad (7-11)$$

The difference between the specified wall temperature and the calculated phase temperature together with the heat transfer coefficient determines the heat flux to the phase. The contact area fraction is also taken into account.

- A bulk wall temperature  $T_{\text{wall}}$ . The specified wall temperature is allocated to all phases in contact with the wall, and resulting wall heat fluxes are partitioned amongst phases using the contact area fraction.

#### 7.16.1.1.1. Area Contact Model

By default, the contact area fraction  $A_{\alpha}$  of phase  $\alpha$  at the wall is identical to the volume fraction in the control volume adjacent to the wall:

$$A_{\alpha} = r_{\alpha} \quad (7-12)$$

However, there are situations in which an alternative model may be required, in which case it can be over-ridden by providing a value or an expression for each phase. For example, for annular gas-liquid flow, the liquid forms a thin film at the wall and is therefore sensible to assign:

$$A_{\text{liquid}} = 1 \quad A_{\text{gas}} = 0 \quad (7-13)$$

Similarly, in dispersed gas-solid flows with spherical solid particles, the wall contact area of the dispersed phase may be considered to be negligible relative to the continuous phase.

Hence, ANSYS CFX includes a facility for you to over-ride the default wall contact area model by providing a value or an expression for the contact area fraction for each phase. Note:

- Contact area fractions must sum to unity over all phases.
- Specified contact area fractions are applied to all transport processes at the wall, that is, wall stresses, heat fluxes, Additional Variable fluxes, etc.
- You should only use the simple model:

$$A_\alpha = 1 \quad A_\beta = 0 \quad (7-14)$$

in situations where phase  $\alpha$  does not vanish at the wall. Otherwise, it is possible that you will be applying a non-zero wall flux to a region of zero volume of phase  $\alpha$ , which could cause the calculation to overflow. For the same reason, your initial guess should not set the fluid volume fraction to be zero at a wall when that phase uses a non-zero area fraction.

- In general it, is desirable, though not essential, to express contact area fractions as functions of volume fraction such that:

$$A_\alpha \rightarrow 0 \quad \text{as} \quad r_\alpha \rightarrow 0 \quad (7-15)$$

This ensures that finite wall fluxes do not enter regions of zero volume of phase  $\alpha$ .

### 7.16.1.2. Fluid Dependent Wall Boundary Conditions

This option is included to give the advanced user complete flexibility in assigning wall boundary conditions to individual phases. For example, for **heat transfer**, you may specify either:

- The temperature,  $T_\alpha$  of phase  $\alpha$ , or
- The heat flux  $Q_\alpha$  to phase  $\alpha$ , or
- Phase specific heat transfer coefficient  $h_\alpha$  outer temperature  $T_{o\alpha}$  in which case:

$$Q_\alpha = h_\alpha (T_{o\alpha} - T_\alpha) \quad (7-16)$$

Note:

- These options may be mixed arbitrarily amongst the phases.
- Heat fluxes arising from phase specific isothermal boundary conditions are automatically multiplied by contact area fraction.
- However, specified heat fluxes  $Q_\alpha$  are **not** automatically multiplied by contact area fractions  $A_\alpha$ . You should include these as multiplicative factors in your expressions for  $Q_\alpha$  or  $h_\alpha$  if this is the effect that you require.
- Care should be exercised to ensure:

$$Q_\alpha \rightarrow 0 \quad \text{as} \quad r_\alpha \rightarrow 0 \quad (7-17)$$

to prevent overflow errors due to finite sources being applied to zero fluid volumes.

### 7.16.1.3. Wall Deposition

This option is only available for the Algebraic Slip Model. For details, see [Wall Deposition](#) (p. 236).

## 7.16.2. Mass Flow Inlet

Information on the mass flow rate inlet boundary condition for single phase flow is available in [Mass Flow Rate](#) (p. 65).

For multiphase flow, mass flow inlets may be specified either for a particular phase or for the bulk flow. In both cases, the flow direction and the volume fraction profile at the inlet must be specified.

If the mass flow rate for a particular phase is specified, then the mass flux (defined as mass flow per unit area of the phase) is assumed to be uniform over the entire boundary.

Boundary conditions for other phases are also required. These may also be phasic mass flow conditions, or any other available velocity specifications. The phasic mass flow inlet condition is not available for homogeneous multiphase simulations.

If a bulk mass flow inlet condition is applied, then the bulk mass flux is assumed to be uniform over the entire boundary. The mass flux of each phase is calculated from the bulk mass flux according to the specified volume fraction profile.

The bulk mass flow inlet condition is available for both homogeneous and inhomogeneous simulations.

## 7.16.3. Mass Flow Outlet

Information on the mass flow rate outlet boundary condition for single-phase flow is available in [Mass Flow Rate \(Bulk Mass Flow Rate for Multiphase\)](#) (p. 75). For multiphase flow, mass flow outlets can be specified either for a particular phase or for the bulk flow. In all cases, the volume fraction and pressure profiles at the outlet are an implicit part of the calculation. The option to specify a pressure profile together with the mass flow rate for single-phase flows is not available for multiphase simulations.

If the mass flow rate for a particular phase is specified, then the mass flow distribution is a function of the mass flow and volume fraction profiles just upstream of the outlet boundary, adjusted to enforce the specified mass flow rate of that phase.

Boundary conditions for the other phases are also required. These may also be phasic mass flow conditions or any of the other available velocity conditions. Two particular cases which may be appropriate are a zero velocity specification, in which case the boundary is closed to the phase, and a no slip velocity condition, which is possible using a CEL expression. The phasic mass flow outlet condition is not available for homogeneous multiphase simulations.

If a bulk mass flow rate outlet condition is applied, then the bulk mass flow distribution is again a function of the mass flow and volume fraction profiles just upstream of the boundary, adjusted to enforce the specified bulk mass flow rate.

The bulk mass flow outlet condition is available for both homogeneous and inhomogeneous multiphase simulations.

## 7.17. Modeling Advice for Multiphase Flow

This section describes:

- *Turbulence Models* (p. 229)
- *Minimum Volume Fraction Setting* (p. 229)
- *Buoyancy* (p. 229)
- *Initial Conditions* (p. 229)
- *Timestepping* (p. 230)
- *Convergence* (p. 230)
- *Transient Simulations* (p. 230)

For related advice, see *Modeling Advice for Free Surface Flow* (p. 233).

### 7.17.1. Turbulence Models

For flows in which a dilute phase is dispersed in a continuous phase, you should use the `Fluid Dependent` turbulence option with the  $k - \varepsilon$  model for the continuous fluid and the `Dispersed Phase Zero Equation` option for the dispersed phase. At wall boundaries, the dispersed phase should also use the `Free Slip Wall` option for **Mass And Momentum**. This type of flow can occur in bubble columns.

The turbulent Prandtl number for an algebraic model should be unity, except for large heavy particles, in which case it should be greater than unity.

For flows in which the phases tend to separate (for example, inhomogeneous free surface flows and oil-water separators), the homogeneous turbulence model is recommended.

### 7.17.2. Minimum Volume Fraction Setting

The `Default` option can almost always be used. If this causes numerical problems, then set the value to be several orders of magnitude less than the minimum expected physical value, but larger than machine zero.

### 7.17.3. Buoyancy

For details, see *Buoyancy* (p. 12).

### 7.17.4. Initial Conditions

You should ensure that the default values for the initial fluid volume fraction are appropriate for your simulation. The default volume fraction for dispersed fluids is zero, and for continuous fluids it is  $1/N$ , where  $N$  is the number of continuous phases. Note that you can leave one fluid to use the `Automatic` option - the remaining volume fraction will be assigned to this fluid such that the volume fractions sum to unity. For cases involving free-surface flows, there are additional considerations for setting the initial conditions. For details, see *Initial Conditions* (p. 234).

### 7.17.5. Timestepping

For bubble columns, use a fraction of the bubble rise time for a total of one rise time, then increase the timestep to a fraction of the fluid circulation time. If species mass transfer is modeled, it can take a considerable amount of time for some species to come to equilibrium. Try setting the timestep size for the mass fraction equations to a large value if convergence is very slow for this equation class.

For dilute particle cases, use a fraction of the dynamical time scale for the momenta. This is essentially a fluid travel time through or around the region of interest, but is not always trivial. If volume fraction convergence is slow, then the time scale for these equations can be increased suitably.

### 7.17.6. Convergence

If convergence stalls completely or becomes very slow, check the conservation and imbalances at the end of the output file. If these are acceptable, plot the residual fields. It may be that the residual fields are good almost everywhere except for a few 'hot spots.' In this case, the solution is valid. You can also monitor some important quantity, for example in a bubble column you can monitor if gas hold up has reached steady-state.

For a case with a very dilute phase, the continuous phase will have a volume fraction very close to unity everywhere. Rounding errors will affect the residuals at a much higher level for the continuous phase in this case. By default, the volume fraction residual target is 10 times the global target residual.

For some multiphase simulations, notably free surface and interphase mass transfer cases, using the double precision solver executable can improve convergence significantly. For details, see [Advection Schemes for Multiphase Volume Fractions](#) (p. 435).

### 7.17.7. Transient Simulations

The default of 10 coefficient loops per timestep is usually adequate to resolve the strong nonlinearities present in multiphase flows. It may sometimes be necessary to use a larger number during the initial transient. If you feel that convergence is not sufficient with this number of coefficient loops, you should reduce the timestep size rather than increase the number of coefficient loops.

If possible, a transient should be started from a small perturbation of a converged steady state result. This may reduce the number of coefficient loops required during the initial transient.

## 7.18. Free Surface Flow

Free surface flow refers to a multiphase flow situation where the phases are separated by a distinct interface. Examples of free surface flows include open channel flow, flow around ship hulls, tank filling problems, Pelton turbines, and many others.

Free surface flow with the homogeneous model should be used when possible. Free surface flow with the inhomogeneous model can be used to allow the two phases to separate. This will be required if entrainment of one phase within another occurs and you want to allow the phases to separate again.

### 7.18.1. Interface Compression Level

This controls the volume fraction advection scheme details for free surface flows, which in turn controls the interface sharpness. Allowable values are:

Setting	Value
0	No special compression — The advection scheme is the same as the global advection scheme setting.
1	Intermediate compression
2	Aggressive compression — This is the default.

## 7.18.2. Supercritical and Subcritical Flow

When referring to free surface flows, a supercritical flow has a Froude number  $> 1$  and a subcritical flow has a Froude number  $< 1$ .

$$\text{Froude number} = \frac{U}{\sqrt{g l}} \quad (7-18)$$

where  $U$  is the local fluid velocity,  $g$  is gravity and  $l$  is a length scale. For shallow flow, the length scale is the depth of the fluid. The term  $\sqrt{g l}$  is the surface wave speed.

Supercritical flow has a local velocity greater than the surface wave speed, while subcritical flow has a velocity less than the wave speed. This is analogous to supersonic and subsonic flow where the local fluid velocity is compared to the speed of an infinitesimal pressure wave to determine the flow regime.

## 7.18.3. Multiphase Model Selection

Free surface flows can be simulated when using the inhomogeneous (particle or mixture models) or the homogeneous model. Use the following rules-of-thumb to decide which model is appropriate:

- Use the homogeneous model if the interface is distinct and well-defined everywhere.
- If the interface is not well-defined in some locations, perhaps because one phase is entrained in the other, an inhomogeneous model may be more appropriate. For example, if there is significant splashing, air becomes entrained in the water and behaves as a disperse phase. In this case, the particle model, using air as the disperse phase, can give superior results because the unequal velocity fields allow the air and water phases to separate and form a distinct interface. The disadvantage of the inhomogeneous models is that they require more CPU time and memory to run. Note also that whichever inhomogeneous model you choose has the same limitations as discussed in the previous chapter; for example, the accuracy of the particle model decreases at high dispersed phase volume fractions.

## 7.18.4. Surface Tension

### 7.18.4.1. Background

Surface tension is the force that holds the interface together. If an interface is cut, the magnitude of the surface tension force per unit length is called the surface tension coefficient,  $\sigma$ . Surface tension has a number of important physical effects, including:

- If the interface is curved, it induces a force normal to the interface. For a droplet at rest, this induces a pressure rise within the droplet of  $\Delta p = \sigma \kappa$ , where  $\kappa$  is the droplet curvature. The effect of this normal force is to smooth regions of high curvature; it tends to reduce the surface area of droplets.

- When the surface tension coefficient is not constant, the surface tension force has a tangential component that tends to move fluid along the interface toward regions of high surface tension coefficient. This is often called Marangoni convection.
- When the free surface interface touches a wall, the wall may attract the liquid (wetting wall) or repel the liquid (non-wetting wall). In a static situation, the wall contact angle may be measured. This phenomenon, known as wall adhesion, gives rise to effects such as the meniscus and capillary rise in tubes.

For free surface flows, you have the option of including surface tension effects. When it is enabled, a surface tension coefficient must be specified. If the surface tension coefficient is variable, the Marangoni force is automatically included. If the surface tension model is activated, using double precision is often required to avoid roundoff errors in the curvature calculation.

Additional information on the surface tension implementation in ANSYS CFX is available in [Surface Tension in the CFX-Solver Theory Guide](#).

### 7.18.4.2. Discretization Options

#### 7.18.4.2.1. Volume Fraction Smoothing Type

When evaluating the interface normal vector for the curvature and surface tension force, it is usually beneficial to take the gradient of a smoothed volume fraction field. The volume fraction smoothing method may be optionally set in CFX-Pre. The options are `None`, `Laplacian`, and `Volume-Weighted`. `Volume-Weighted` is the default. `Laplacian` is slightly more accurate, but also slightly more expensive, than `Volume-Weighted`. Occasionally, when the surface tension force is driven only by wall adhesion and there is no interior curvature, it may be beneficial to choose `None`.

#### 7.18.4.2.2. Curvature Under Relaxation Factor

This is used for underrelaxing the curvature. The default value is 1 (unity), but for flows strongly driven by surface tension, it may be useful to use a smaller value (for example, 0.25).

### 7.18.4.3. Initial Conditions

When setting initial conditions for surface tension calculations, it may also be beneficial to assign a smeared volume fraction rather than a discontinuous one. The hyperbolic tangent function (available in CEL) is useful for this purpose. For example, the following expressions defined a smeared droplet of radius 0.3 m centered at  $(x,y) = (0.5 \text{ [m]}, 0.5 \text{ [m]})$ :

```
rdrop = 0.3 [m]
```

```
dist = rdrop -sqrt((x - 0.5[m])^2 + (y - 0.5[m])^2)
```

```
delta = 0.01 [m]
```

```
drop = 0.5*tanh(dist/delta)+0.5
```

These expressions represent:

`rdrop` - droplet radius

`dist` - signed distance to the droplet interface

`delta` - smearing distance

drop - the smeared volume fraction field: 1 inside the droplet, 0 outside, and smoothly varying between 0 and 1 over a range of about  $3\delta$  on each side of the interface.

#### 7.18.4.4. Wall Adhesion

To account for wall adhesion, you should specify a contact angle when setting wall boundary conditions. This is the angle the interface makes with the wall through the **Primary Fluid** that is prescribed on the **Fluid Pairs** tab of the **Domain** details view when the **Surface Tension Coefficient** is set. If the **Primary Fluid** is a liquid and the secondary fluid is a gas then, for non-wetting walls, the contact angle is greater than 90 degrees, while for wetting walls the contact angle is less than 90 degrees.

### 7.18.5. Modeling Advice for Free Surface Flow

#### 7.18.5.1. Domains

For the Buoyancy Reference Density, choose the density of the light fluid (air). This simplifies the definition of pressure, and hence the specification of pressure initial and boundary conditions. In the hydrostatic limit:

$$\frac{dp}{dz} = - \left( \rho - \rho_{ref} \right) g \quad (7-19)$$

For details, see [Buoyancy](#) (p. 12).

#### 7.18.5.2. Turbulence Model

If the inhomogeneous multiphase model is selected, using the homogeneous turbulence option is recommended. For details, see [Homogeneous Turbulence in Inhomogeneous Flow](#) (p. 210).

#### 7.18.5.3. Boundary Conditions

Make sure that a pressure level has been set by one of the boundary conditions. For “closed box” cases, you can add a small opening to achieve this.

##### 7.18.5.3.1. Pressure Reference

A pressure level must be set at one or more boundary conditions by using the **Pressure Level Information** option on the **Solver Control** tab in CFX-Pre. For details, see [Turbulence Control](#) (p. 436). To set a pressure reference value using a boundary condition for “closed box” cases, this can be achieved by adding a small pressure opening to the top wall.

##### 7.18.5.3.2. Outlets

At pressure outlets, the elevation of the water must usually be known as part of the problem definition. The mechanism used to enforce this elevation is to set a pressure profile consistent with the known elevation. In some circumstances, the elevation is not known in advanced (for example supercritical outlets). In this case, it is best to specify a pressure profile consistent with an estimate for the outlet elevation. This assumption should not affect the flow other than possibly inducing a small kink in the flow just upstream of the outlet condition.

### 7.18.5.4. Initial Conditions

The initial conditions for the pressure field and volume fraction must be consistent (that is, the pressure field is hydrostatic in the heavy phase and uniform in light phase). This is easily done using CEL step functions. For example, the functions:


$$h = 2 \text{ [m]} \quad (7-20)$$

$$\text{initial VOF Air} = \text{step} \left( (z - h) / 1 \text{ [m]} \right) \quad (7-21)$$

$$\text{initial VOF Water} = 1 - \text{initial VOF Air} \quad (7-22)$$

$$\text{initial } P = 998 \text{ [kg m}^{-3}\text{]} * g * (h - z) * \text{initial VOF Water} \quad (7-23)$$

would be appropriate to initialize the *relative* pressure field and volume fractions as shown below.



In the equation for *initialVOFAir*, the division is required because the step function must operate on dimensionless quantities.

### 7.18.5.5. Timestep

The timestep for free surface flows should be based on a  $L/U$  (Length/Velocity) scale. The length scale should be a geometric length scale. The velocity scale should be the maximum of a representative flow velocity and a buoyant velocity, which is given by:

$$U_{\text{buoyant}} = \sqrt{g L} \quad (7-24)$$

In addition, it is often helpful to reduce the timestep for the volume fraction equations by an order of magnitude below that of the other equations.

### 7.18.5.6. Mesh Adaption

When using free surface with adaption, make sure the interface is no longer moving before doing an adaption step, otherwise the adaption will be a wasted effort.

### 7.18.5.7. Body Forces

The **Body Force Averaging Type** controls how body forces (buoyancy in particular) are averaged to elements. The default option of `Volume-Weighted` should be used in most cases. For free surface flows, you may want to use the `Harmonic` option; this is a little more robust and is less prone to generate spurious velocities in the gas phase adjacent to the interface. However, harmonic averaging does not converge as well as volume-weighted averaging. The arithmetic option is very similar to the `Volume-Weighted` option.

### 7.18.5.8. Convergence

Convergence is often hard to achieve in a residual sense. Instead use some global quantity to check if the solution is changing. Failure to converge residuals is often manifest as small spurious waves on the free surface interface. These waves may be reduced in magnitude if the timestep for the volume fraction equation is an order of magnitude smaller than for the momentum equation.

In some cases, using the double precision solver executable can improve convergence.

- [Hydro Control](#) (p. 437)
- [Advection Schemes for Multiphase Volume Fractions](#) (p. 435)

### 7.18.5.9. Parallel

Free surface may not be robust in parallel if any portion of a partition boundary is aligned with the free surface. In this case, consider trying another of the partitioning methods (recursive bisection or specified direction). If GGI boundaries are present and the domains are of the same physical type (fluid/porous and solid), consider using coupled partitioning. Finally, reducing the value of the expert parameter 'overlap relaxation fluids' from its default value of 1 may be helpful.

## 7.19. Algebraic Slip Model (ASM)

In multiphase flow, each phase has its own velocity field, governed by conservation of momentum for the phase. In `Eulerian-Eulerian` multiphase flow, the full momentum equation is considered, including inertial effects of the phase. In some cases, however, if the time scales to reach the equilibrium slip velocity are small, it is appropriate to use simplified models for calculating the velocity of dispersed phases. This is the motivation behind the Algebraic Slip Model (ASM) for multiphase flow.

### 7.19.1. Algebraic Slip Model Specification

The ASM model is not set up in the same way as other multiphase problems. Only one fluid for a variable composition mixture is used in the **Domains** tab on CFX-Pre. When setting up a problem to run with the Algebraic Slip Model, you should first create a material for the variable composition mixture. For details, see [Material Details View: Variable Composition Mixture in the CFX-Pre User's Guide](#). When setting the thermodynamic state of the mixture, the choice of liquid or gas is not important. When specifying the domain options, define the fluid in **Fluids and Particle Definitions...** and select the fluid **Material**.

### 7.19.1.1. Fluid Models

The continuous phase should be set to **Constraint** on the **Component Details** tab. The remaining phases can be set to either **Algebraic Slip** or **Transport Equation**. **Transport Equations** and **Algebraic Slip** components can be combined, meaning that a mixture of components may be present in the continuous phase. At least one component must be set to **Constraint**. For any dispersed phases, choose the **Algebraic Slip** option.

The **Algebraic Slip** option can be set to **Drag Force Balance** or **Slip Velocity**. **Drag Force Balance** uses the closed relationship for the slip velocity. For details, see [Derivation of the Algebraic Slip Equation in the CFX-Solver Theory Guide](#).

$$|u_{S\alpha}| u_{S\alpha}^i = \frac{4}{3} \frac{d_p}{\rho_c C_D} (\rho_\alpha - \rho_m) \left( \frac{\partial u_m^i}{\partial t} - u_m^j \frac{\partial u_m^i}{\partial x^j} - g^i \right) \quad (7-25)$$

where the subscript  $m$  refers to bulk quantities and  $\alpha$  refers to dispersed phase quantities. The drag coefficient  $C_D$  can be directly specified or the Schiller Naumann model can be used. In both cases, the mean diameter  $d_p$  must be specified.

The slip velocity may also be directly specified.

### 7.19.1.2. Wall Deposition

For wall boundaries, there is the option of specifying wall deposition for a dispersed phase. When deposition is selected for a phase which contacts a wall boundary, the mass of the particular phase is removed from the calculation and replaced with the mass of the ballast phase (the component which was selected as **Constraint** on the **Fluid Models** tab). The deposition rate is determined from the slip velocity of the algebraic slip component.

### 7.19.1.3. Limitations

As the model makes a number of assumptions, the model will not produce the best results when:

- Non-drag forces are significant.
- The dispersed phase does not reach terminal velocity quickly (that is, particles with significant mass are present).

For details, see [Derivation of the Algebraic Slip Equation in the CFX-Solver Theory Guide](#).

## 7.20. Multiphase Flow Restrictions

Radiation is not supported in multiphase flow in ANSYS CFX.

Note that, when using advanced multiphase physics models, such as turbulent dispersion or solids pressure forces, numerical inaccuracies at GGI interfaces may be greater than in other applications. If possible, GGI interfaces should be avoided in such applications. If they are used, check the solution close to the GGI interface.

---

## Chapter 8: Particle Transport Modeling

---

This chapter describes how Particle Transport is modeled:

- 8.1. Model Validity
- 8.2. Particle Transport Versus Eulerian-Eulerian Multiphase
- 8.3. Forces Acting on the Particles
- 8.4. Creating Particle Materials
- 8.5. Particle Domain Options
- 8.6. Particle Boundary Options and Behavior
- 8.7. Subdomains
- 8.8. Particle Injection Regions
- 8.9. Particle Output Control
- 8.10. Particle Solver Control
- 8.11. Multiphase Reactions and Combustion
- 8.12. Restrictions for Particle Transport
- 8.13. Restrictions for Particle Materials
- 8.14. Convergence Control for Particle Transport
- 8.15. Expert Parameters for Particle Tracking
- 8.16. Particle Diagnostics
- 8.17. Integrated Particle Sources for the Coupled Continuous Phase
- 8.18. Transient Simulations: What is Different for Particles?

For details on modeling advice, see [Particle Transport Theory in the CFX-Solver Theory Guide](#).

*Multiphase flow* refers to the situation where more than one fluid is present. Each fluid may possess its own flow field, or all fluids may share a common flow field. Unlike multicomponent flow, the fluids are not mixed on a microscopic scale in multiphase flow. Rather, they are mixed on a macroscopic scale, with a discernible interface between the fluids. ANSYS CFX includes a variety of multiphase models to allow the simulation of multiple fluid streams, bubbles, droplets, solid particles and free surface flows.

Two distinct multiphase flow models are available in ANSYS CFX: an **Eulerian-Eulerian** multiphase model and a **Lagrangian Particle Tracking** multiphase model. Additional information on the Eulerian-Eulerian model is available in [Multiphase Flow Modeling \(p. 189\)](#).

The Particle Transport model is capable of modeling dispersed phases which are discretely distributed in a continuous phase. The modeling involves the separate calculation of each phase with source terms generated to account for the effects of the particles on the continuous phase. Water droplets dispersed in air from the liquid sprays of a cooling tower, and solid particles dispersed in air from the pneumatic transport of solids, or transport of airborne particulates are such practical occurrences.

The implementation of particle transport modeling in ANSYS CFX can be thought of as a multiphase flow in which the particles are a dispersed phase. Instead of using an Eulerian transport model for the dispersed phase, a Lagrangian transport model is used. All continuous phases must use the Eulerian model.

With the dispersed phase, each particle interacts with the fluid and other particles discretely. Therefore, another method is required to calculate the particle behavior. The most widely applied method available to determine the behavior of the dispersed phase is to track several individual particles through the

flow field. Each particle represents a sample of particles that follow an identical path. The behavior of the tracked particles is used to describe the average behavior of the dispersed phase. This method is called *separated flow analysis*.

The separated flow analysis has been implemented as a Lagrangian tracking model to characterize the flow behavior of a dispersed phase and is available in ANSYS CFX.

The term *particle* is used to describe an individual discrete element of the dispersed phase. The particle could represent a solid, droplet, or bubble.

**Particle Number Rate** For applications involving tracking of discrete particles, it is not practical to track all physically existing particles. Instead representative particles, or parcels, are used to track these discrete particles. Each representative particle characterizes a certain number of actual particles. The actual number of particles represented by the representative particle is called the **Particle Number Rate**. The **Particle Number Rate** is determined from the mass flow rate assigned to the representative particle divided by the mass of an actual particle.

The known mass flow rate of particles can be specified on inlet, opening, wall and fluid-solid interface boundaries. This allows ANSYS CFX to know how many particles the tracked particles represent.

All the particles represented by the sample particle will follow exactly the same track, even if the turbulent particle dispersion is used.

Initialization of the particle properties in the domain is not required.

## 8.1. Model Validity

Unlike in an Eulerian multiphase calculation, the fraction of volume taken by the particles is not included in the continuous phase calculation. This means that the model is only valid for quite low volume fractions. If the volume fraction of particles is calculated, then it can show the reliability of the model. Indeed, in cases where the model is unreliable, the calculated volume fraction of particles may be greater than one.

## 8.2. Particle Transport Versus Eulerian-Eulerian Multiphase

A multiphase flow containing dispersed particles may be modeled using either the particle transport model or the Eulerian-Eulerian multiphase model. Some advantages and disadvantages of the particle transport model are given below to aid in the choice of models. The equivalent section for the Eulerian-Eulerian multiphase model is available in *Eulerian-Eulerian Multiphase Versus Particle Transport* (p. 193).

**Table 8.1 Advantages and Disadvantages of Particle Transport**

Advantages	Disadvantages
Complete information on behavior and residence time of individual particles is available.	Expensive if a large number of particles have to be tracked.
Relatively cheaper for wide range of particle sizes.	Very expensive to include turbulence.
Better detail for mass and heat transfer.	Essentially only possible as a post-process for a large number of particles.
More flexible when there is a significant size distribution leading to different particle velo-	Restricted to low particle volume fractions.

Advantages	Disadvantages
cities. (In Eulerian-Eulerian Multiphase, a momentum equation needs to be solved for each representative size which becomes very expensive.)	

## 8.3. Forces Acting on the Particles

Several different forces affect the motion of a particle in a fluid. In ANSYS CFX, the forces which have been included in the particle equation of motion are viscous drag, buoyancy force, virtual mass and pressure gradient forces, and the centripetal and Coriolis forces in rotating reference frames. A description of these terms and their implementation is available.

### 8.3.1. Drag Force

The viscous and form drag is always important and is always calculated. For details, see [Drag Force for Particles](#) (p. 250).

### 8.3.2. Reference Frame Rotational Forces

These include the centripetal and Coriolis forces. They are always calculated for rotating frame simulations.

### 8.3.3. Buoyancy Force

In addition to the buoyancy forces that arise in single phase flows, the difference in density between the particle and the continuous phase results in a buoyancy force. This is the same as for Eulerian-Eulerian multiphase flows. For details, see [Buoyancy in Multiphase Flow](#) (p. 197).

## 8.4. Creating Particle Materials

If the particles you want to model are inert, the only material property required for particles is the density. Multicomponent particles can also be created: one application of these is to model liquid and oil evaporation. For details, see:

- [Liquid Evaporation Model](#) (p. 254)
- [Liquid Evaporation Model: Oil Evaporation/Combustion](#) (p. 256).

Another is for modeling coal combustion. For details, see [Multiphase Reactions and Combustion](#) (p. 289).

If modeling heat and mass transfer, the additional material properties that must be specified are specific heat capacity and reference enthalpy (although reference enthalpy is not required if latent heat is selected for the heat release method). For details, see [Heat Release/Heat Release Distribution](#) (p. 291).

You can create new materials from the **Material** details view in CFX-Pre. For details, see [Materials and Reactions in the CFX-Pre User's Guide](#). Each material that you create will be available for selection from **Fluid and Particles Definitions...** on the **Basic Settings** tab when creating new domains. For details, see [Basic Settings Tab in the CFX-Pre User's Guide](#).

## 8.5. Particle Domain Options

The model settings described in this section are set when creating a domain in CFX-Pre. For details, see [Domains in the CFX-Pre User's Guide](#).

## 8.5.1. Basic Settings

### 8.5.1.1. Particle Morphology Options

The morphology option can be set to `Particle Transport Fluid` or `Particle Transport Solid` in CFX-Pre. For details, see [Basic Settings Tab in the CFX-Pre User's Guide](#). Gas and liquid particles should use the `Fluid Particles` option. Currently both models produce the same results because the same drag law is used for fluid and solid particles.

## 8.5.2. Fluid Models

### 8.5.2.1. Multiphase Reactions

Multiphase Reactions involving particle phases refer to a reaction between one or more components in a particle phase and one or more components in a continuous phase. For details, see [Multiphase Reactions and Combustion](#) (p. 289).

### 8.5.2.2. Buoyancy for Particles

Depending on the flow type, buoyancy (gravity) terms may need to be modeled. The density of the particle material is often much higher than that of the carrier fluid, resulting in a buoyancy force. However, other forces may dominate over the buoyancy force such that its effect is not important. The relative size of three forces needs to be considered:

- The drag force
- The inertial force
- The buoyancy force

Often the buoyancy force can be neglected if the drag and inertial forces dominate. In general, if settling of the particles is thought to be important, then the buoyancy term should be included.

If the buoyancy term is not important for the particle phase, you may still need to include it if convection due to density variations in the continuous phase is important. This is independent of particle transport modeling.

### 8.5.2.3. Turbulence for Particles

The turbulence model used in a particle tracking simulation only applies to the continuous phases. Turbulence can affect the particles through the `Particle Dispersion` force, but the particles can have no effect on the turbulence of the continuous phase, other than indirectly by affecting the velocity field. For details, see [Turbulent Dispersion Force](#) (p. 253).

### 8.5.2.4. Heat Transfer for Particles

Heat transfer between the particles and the continuous phase can be modeled. The **Fluid Models** form must use the `Fluid Dependent` option to model Heat Transfer. The heat transfer options for each phase are set on a per-material basis. For details, see [Heat Transfer](#) (p. 245).

### 8.5.2.5. Radiation for Particles

Radiation can be included in a particle transport calculation, but there is no radiation calculation in the particles themselves. To turn on radiation for particles, set the **Radiation** option to `Fluid Dependent`,

and then select a radiation model on the **Fluid Specific Models** tab for the continuous fluid. The radiation option for particles themselves is unavailable on the **Fluid Specific Models** form (because it cannot assume any value other than `None`).

## 8.5.3. Fluid Specific Models

### 8.5.3.1. Particle Diameter Distribution

A particle diameter distribution can optionally be set for a domain. If specified, then the distribution applies to all boundaries where particles are injected in that domain. A particle diameter distribution can also be set in a boundary object, in which case it overrides the domain particle diameter distribution for that boundary only. If a domain particle diameter distribution is not set, then all boundaries where particles are injected must have a particle diameter distribution set. Note that for all selections of **Particle Diameter Distribution** (except for the **Specified Diameter** option), the larger the number of particles, the better the representation of the selected distribution.

#### 8.5.3.1.1. Specified Diameter

This option sets a constant specified particle diameter for all particles.

#### 8.5.3.1.2. Uniform in Diameter by Number

This option produces an equal number of particles at all diameters between the specified minimum and maximum diameters. This results in the same number of smaller particles as larger particles.

#### 8.5.3.1.3. Uniform in Diameter by Mass

This option produces an equal mass of particles at all diameters between the specified minimum and maximum diameters. This results in a larger number of particles close to the minimum specified diameter, because many more of these are required to equal the mass of a few larger particles.

#### 8.5.3.1.4. Normal in Diameter by Number

This option uses a normal distribution of particle diameters centered about a specified mean diameter. The shape of the normal distribution is determined by the specified standard deviation.

Maximum and minimum diameters are used to clip the normal distribution.

#### 8.5.3.1.5. Normal in Diameter by Mass

Normal distribution requires `Mean Diameter`, `Standard Deviation in Diameter`, `Max Diameter` and `Min Diameter`.

#### 8.5.3.1.6. Rosin Rammler


Requires a `Rosin Rammler Size` and `Rosin Rammler Power`. The Rosin Rammler distribution has been developed for pulverized solid fuels but may also be applicable to certain sprays.

A Rosin Rammler distribution can be used to determine the distribution of the mass flow amongst particle sizes. By default, the minimum droplet size predicted by the Rosin Rammler distribution is clipped to 10% of the specified `Rosin Rammler Size`. The predicted diameter range can be controlled by specifying minimum and/or maximum values for the particle diameters. The maximum droplet diameter size is not clipped. The mass fraction,  $R$ , above a given particle diameter,  $d$ , is calculated from:

$$R = \exp \left[ - \left( \frac{d}{d_e} \right)^\gamma \right] \quad (8-1)$$

where  $d_e$  is a measure of the fineness and is equal to the diameter at which  $R$  is  $1/e$  or 0.368. The spread parameter,  $\gamma$ , is a measure of dispersion of particle sizes, a lower value indicating a wider dispersion. A typical value of  $\gamma$  for pulverized fuels is 1 to 1.3 and for sprays is 1.5 to 3.0. For a nearly monosize distribution,  $\gamma$  may have a value of 10 to 20. Given  $d_e$  and  $\gamma$ , it is possible to calculate the particle size distribution. Examples of Rosin Rammler distributions for  $d_e = 10^4$  and various values of  $\gamma$  are shown in [Figure 8.1](#) (p. 242).

**Figure 8.1 Particle Size Distributions for Various Rosin Rammler n Parameters**



### 8.5.3.1.7. Nukiyama Tanasawa

Set the Rosin Rammler Size, Rosin Rammler Power, and the Nukiyama Tanasawa Power. This distribution is a generalization of the Rosin Rammler distribution. As stated for the Rosin Rammler distribution, by default the minimum droplet size predicted by the Nukiyama Tanasawa distribution is also clipped to 10% of the specified Rosin Rammler Size. The predicted diameter range can be controlled by specifying minimum and/or maximum values for the particle diameters. The maximum droplet diameter size is not clipped.

The distribution can be specified by its probability density function,  $p(d)$ , which is given by the following expression:

$$p(d) = c d^q \exp\left(-\left(\frac{d}{d_e}\right)^\gamma\right) \quad (8-2)$$

where the constant  $c$  is determined by the distribution integrating to 1.0.  $q$  is the Nukiyama Tanasawa power. If  $q$  is equal to  $\gamma - 4$ , then this reduces to the Rosin Rammler distribution.  $d_e$  and  $\gamma$  are defined as for the Rosin Rammler distribution.

### 8.5.3.1.8. Discrete Diameter Distribution

This option enables you to model particles with different diameters. You must provide three sets of discretized distribution data, as well as other parameters. This section explains, by example, which data are required and how they are used.

This example begins with the following input data:

```
Diameter List = 1 [mm], 2 [mm], 3 [mm], 4 [mm]
Mass Fraction List = 0.1, 0.4, 0.3, 0.2
Number Of Positions > Option = Direct Specification
Number Of Positions > Number = 20
Number Fraction List = 0.2, 0.3, 0.4, 0.1
The particle density is 1000 kg/m^3.
The total particle mass flow rate of injected particles is 1 g/s.
```

**Diameter List** is a list of diameter values. In this example, particles that belong to the first band have a diameter of 1 mm, particles that belong to the second band have a diameter of 2 mm, and so on.

**Mass Fraction List** is a list of mass fractions that apply to the total mass flow of particles at the injection site. The mass fractions must sum to unity. In this example, particles that belong to the first band constitute 10% of the total mass flow of injected particles, particles in the second band constitute 40% of the mass flow of injected particles, and so on.

Physical particles are not modeled individually. Instead, a smaller number of representative (or "computational") particles are modeled. The representative particles in a given band each represent an equal share of the physical particles in that band. The total number (or in a transient case, the rate of production) of representative particles is governed by the **Number Of Positions** specification. The number of representative particles that are generated for a particular band depends on a probability distribution specified by **Number Fraction List** (a list of values that sum to unity).

In this example, 20 representative particles would be generated. Each representative particle would be assigned to one of the 4 bands by using a random number generator. Roughly 4 (or 20%) of the representative particles will be assigned to the first band, roughly 6 (or 30%) will be assigned to the second band, and so on.

After the solver has assigned all representative particles to bands, it then assigns to each representative particle:

- a diameter from the entry in **Diameter List** that corresponds with the representative particle's band, and
- a number rate of physical particles to be represented by the representative particle

The number rate is calculated for each band as follows:

mass flow rate per band / (mass of a physical particle \* number of representative particles in the band)

In this case, the number rates for representative particles in bands 1 and 2 would be calculated as follows:

- Band 1

The mass flow rate of all particles in the band is  $0.1 * 0.001 \text{ kg/s} = 0.0001 \text{ kg/s}$ .

Each physical particle has a mass of  $(4/3) * \pi * ((0.001 \text{ m})/2)^3 * 1000 \text{ kg/m}^3 = 0.524\text{E-}6 \text{ kg}$ .

Assume that 4 representative particles were assigned to the band.

Number Rate =  $(0.0001 \text{ kg/s}) / ((0.524\text{E-}6 \text{ kg/particle}) * 4) = 48 \text{ particles/s}$ .

- Band 2

The mass flow rate of all particles in the band is  $0.4 * 0.001 \text{ kg/s} = 0.0004 \text{ kg/s}$ .

Each physical particle has a mass of  $(4/3) * \pi * ((0.002 \text{ m})/2)^3 * 1000 \text{ kg/m}^3 = 4.189\text{E-}6 \text{ kg}$ .

Assume that 6 representative particles were assigned to the band.

Number Rate =  $(0.0004 \text{ kg/s}) / ((4.189\text{E-}6 \text{ kg/particle}) * 6) = 16 \text{ particles/s}$ .

### Note

If you edit CCL directly, do not enter `Number Fraction List` and `Mass Fraction List` entries using the "\*" operator. For example:

Not allowed in CCL:

```
Number Fraction List = 5 * 0.1, 0.5
```

Correct syntax:

```
Number Fraction List = 0.1, 0.1, 0.1, 0.1, 0.1, 0.5
```

This requirement applies to CCL you edit directly. If you create such CCL using CFX-Pre, the CCL will be converted automatically to the correct form.

To ensure that each band receives at least one representative particle, ensure that you specify a sufficient number of representative particles. As a minimum requirement, you must inject at least as many representative particles as there are bands. To get a rough estimate for the required number, take the inverse of the smallest number fraction in the list. The solver will tolerate an empty band if the particle mass flow for the band is specified as being less than 1% of the total mass flow, but you should try to prevent this from happening. The solver will stop during injection if a band representing more than 1% of the total injected mass did not receive any representative particles.

The diameter distribution can be specified only once on a domain level; it will be applied to each injection region separately. The total number of injected particles must guarantee a reasonable number of representative particles per injection region. For simulations with many injection regions (for example, gas washers), but with only a small number of particles per injection region, the problem of empty bands

can easily happen. Your options are to increase the number of representative particles, or to use Particle User Fortran.

### 8.5.3.2. Particle Shape Factors

Particles are assumed to be spherical by default. ANSYS CFX always calculates the diameter of the particle from the mass of the particle divided by its density, assuming it is spherical.

A **Cross Sectional Area Factor** can be included to modify the assumed spherical cross section area to allow for non-spherical particles. The factor is multiplied by the cross section area calculated assuming spherical particles. This affects the drag force calculated by ANSYS CFX.

The **Surface Area Factor** is analogous to the cross-sectional area factor. For a non-spherical particle, it is the ratio of the surface area to the surface area of a spherical particle with the same equivalent diameter. This factor affects both mass transfer and heat transfer correlations.

### 8.5.3.3. Particle Diameter Change Due to Swelling

In contrast to liquid droplets, where the diameter of the particle is determined by the mass and densities of species, the diameter of a solid particle remains relatively constant, as the density of the particle as a whole changes. The change in diameter of the particle is controlled by the mass of solid particle, and by the swelling factor. **Swelling Factor** is dimensionless and should be set with reference to the raw material, by selecting it from the **Reference Material** list in CFX-Pre. For details, see [Devolatilization in the CFX-Solver Theory Guide](#).

### 8.5.3.4. Heat Transfer

The heat transfer model for the continuous phase is set in the same way as for single-phase simulations. When a heat transfer model is activated for the continuous fluid, the heat equation for the particles is solved by default (the **Heat Transfer** option is set to `Particle Temperature` for particles). Information on the implementation of heat transfer for particle transport in ANSYS CFX is available in [Heat Transfer in the CFX-Solver Theory Guide](#).

### 8.5.3.5. Erosion

The erosion model can be set on a per-boundary or per-domain basis. When enabled for the domain, the domain settings will apply for all boundaries that do not explicitly have erosion model settings applied to them.

There is a choice of two erosion models, those of `Finnie` and `Tabakoff`. Additional information on the implementation of these models is available in [Basic Erosion Models in the CFX-Solver Theory Guide](#). The choice of one model over another is largely simulation-dependent. In general, the `Tabakoff` model provides more scope for customization with its larger number of input parameters.

In the `<install_dir>\examples\UserFortran` directory, you can find an erosion routine, `pt_erosion.F`, and corresponding CCL template, `pt_erosion.ccl`.

#### 8.5.3.5.1. Finnie

The velocity power factor corresponds to the variable  $n$ . It is set to 2 by default. The value of the exponent generally lies within the range 2.3 to 2.5 for metals.

The Reference Velocity corresponds to the variable  $V_0$  in [Equation 6–91 in the CFX-Solver Theory Guide](#).

For details, see [Model of Finnie in the CFX-Solver Theory Guide](#).

### 8.5.3.5.2. Tabakoff

The Tabakoff model requires the specification of five parameters. The  $k_{12}$  constant, 3 reference velocities and the angle of maximum erosion  $\gamma_0$  must all be specified.

[Table 8.2: Coefficients for Some Materials Using the Tabakoff Erosion Model \(p. 246\)](#) lists some values for the Tabakoff model coefficients for Quartz-Aluminium, Quartz-Steel and Coal-Steel. For details, see [Model of Tabakoff and Grant in the CFX-Solver Theory Guide](#).

**Table 8.2 Coefficients for Some Materials Using the Tabakoff Erosion Model**

Variable	Coefficient	Value	Material
$k_{12}$	$k_{12}$	$5.85 \times 10^{-1}$	Quartz - Aluminium
Ref Velocity 1	$V_1$	159.11 [m/s]	
Ref Velocity 2	$V_3$	194.75 [m/s]	
Ref Velocity 3	$V_4$	190.5 [m/s]	
Angle of Maximum Erosion	$\gamma_0$	25 [deg]	
$k_{12}$	$k_{12}$	$2.93328 \times 10^{-1}$	Quartz - Steel
Ref Velocity 1	$V_1$	123.72 [m/s]	
Ref Velocity 2	$V_3$	352.99 [m/s]	
Ref Velocity 3	$V_4$	179.29 [m/s]	
Angle of Maximum Erosion	$\gamma_0$	30 [deg]	
$k_{12}$	$k_{12}$	$-1.321448 \times 10^{-1}$	Coal - Steel
Ref Velocity 1	$V_1$	51.347 [m/s]	
Ref Velocity 2	$V_3$	87.57 [m/s]	
Ref Velocity 3	$V_4$	39.62 [m/s]	
Angle of Maximum Erosion	$\gamma_0$	25 [deg]	

### 8.5.3.5.3. User Defined

This option allows you to use a User Fortran subroutine to calculate the erosion rate density. General information on creating user routines is available in *User Fortran* (p. 483). Input arguments and return quantities of the particle user routine are specified in the **Wall Interaction** option. For details, see *Wall Interaction* (p. 264).

In the <install\_dir>\examples\UserFortran directory, you can find an erosion routine, `pt_erosion.F`, and corresponding CCL template, `pt_erosion.ccl`.

### 8.5.3.6. Particle-Rough Wall Model (Virtual Wall Model)

The particle-rough wall model can be set on a per-boundary or per-domain basis. When enabled for the domain, the domain settings will apply for all boundaries that do not explicitly have rough wall model settings applied to them.

Information on the model theory and its implementation is available in *The Sommerfeld-Frank Rough Wall Model (Particle Rough Wall Model)* in the *CFX-Solver Theory Guide*.

#### 8.5.3.6.1. Sommerfeld-Frank Model

The Sommerfeld-Frank model requires the input of parameters that describe the wall roughness structure. The input parameters are:

- The average length of a roughness element,  $L_r$ ,
- The average height of a roughness element,  $H_r$ ,
- The deviation from the average roughness height,  $\Delta H_r$ ,

For details, see *The Sommerfeld-Frank Rough Wall Model (Particle Rough Wall Model)* in the *CFX-Solver Theory Guide*.

---

#### Note

- These parameters may change in the future.
- A spatial variation of these quantities on a single boundary patch is not supported.

### 8.5.3.7. Particle Breakup Model

The particle breakup models allow you to simulate the breakup of droplets due to external aerodynamic forces. The droplet breakup models are set on a per fluid-pair basis. Note that Liu dynamic drag coefficient modification is activated by default for the TAB, ETAB, and CAB breakup models, whereas the Schmehl dynamic drag law is available only for the Schmehl breakup model.

There is a choice of five predefined secondary particle breakup models, those of Reitz and Diwakar, Schmehl, TAB, ETAB, and CAB as well as the possibility to define your own model via Particle User Fortran.

In the <install\_dir>\examples\UserFortran directory, you can find a secondary breakup routine, `pt_breakup_rd.F`, and corresponding CCL template, `pt_breakup_rd.ccl`.

The choice of one model over another is largely simulation-dependent. All model constants are accessible via the user interface. For details on the models, see [Spray Breakup Models in the CFX-Solver Theory Guide](#). Default values for each model are given in the following places:

- [Table 6.1: "Reitz and Diwakar breakup model constants and their default values "](#)
- [Table 6.2: "TAB Breakup Model Constants and their Default Values"](#)
- [Table 6.3: "ETAB Breakup Model Constants and Their Default Values"](#)
- [Table 6.4: "CAB Breakup Model Constants and Their Default Values"](#)

During droplet breakup, the particle shape may be distorted significantly and it might be desirable to modify the drag law to account for the influence of the particle distortion. Different models have been implemented in ANSYS CFX that allow you to modify the drag coefficient based on the droplet distortion. See [Dynamic Drag Models in the CFX-Solver Theory Guide](#) for the description of available models and their usage.

### 8.5.3.8. Particle Collision Model

In classical Euler-Lagrange modelling, collisions between particles are not possible because the presence of other particles is not accounted for. The stochastic particle-particle collision model by Oesterlé & Petitjean [151], which has been extended by Frank [149], Hussmann et al. [150], and Sommerfeld [152], takes interparticle collisions into consideration while the trajectories are still calculated sequentially. The main advantage of the model is the possibility of sequential trajectory calculation by creating virtual collision partners sampled from local statistical values. This offers a high potential of parallelization and thus facilitates – in conjunction with the highly parallelized CFX-Solver for the gas-phase – its use in industrial applications as a major advancement in the simulation of dense gas-particle flows. The model extension by Sommerfeld additionally takes into account a possible correlation between the velocity fluctuations of neighboring particles. The implementation in ANSYS CFX was validated based on three published experiments. These comprise a convergent channel provoking inter-particle collisions, a highly loaded vertical pipe flow, and a strongly swirling pipe flow.

The following steps summarize the implementation of this model in ANSYS CFX:

1. Calculate the instantaneous velocity of the virtual collision partner.

The velocity of virtual particle comprises of the following components:

- A mean part from the local average values
- Correlation function is determined by Large Eddy Simulation (LES) of a homogeneous isotropic turbulence field (see [Equation 6–171 in the CFX-Solver Theory Guide](#))
- A fluctuating part including a correlation term between the two particles due to Sommerfeld [152,154] and a random term (see [Equation 6–172 in the CFX-Solver Theory Guide](#))

Angular velocity of the particle is calculated the same way:

- no correlation between particles
2. Determine the collision probability and decide whether or not a collision occurs.
    - *If collision occurs:*
      - a. Compute position of virtual collision partner.
      - b. Calculate binary collision and adjust particle velocities.
    - *If collision does not occur:*

- a. Particle velocities remain unchanged in the event of no collision.
3. Discard the virtual particle.
4. Update average particle quantities and local statistical moments in each control volume.

In the `<install_dir>\examples\UserFortran` directory, you can find a collision routine, `pt_collision.F`, and corresponding CCL template, `pt_collision.ccl`.

### 8.5.3.8.1. Requirements for the Applicability of Particle-Particle Collision Model

The requirements for the applicability of particle collision model are outlined below:

- High mass loading
- Moderate volumetric concentration (<~ 20%)
- The model is limited to binary collisions only and follows the following criteria:
  - Inter-particle distance is much greater than the particle diameter
  - Aerodynamic forces dominate
  - Not suitable for fluidized beds
  - $\rho_p \gg \rho_{Gas}$
- Spherical particles

For additional information, see the following topics available under [Particle Collision Model in the CFX-Solver Theory Guide](#):

- [Introduction to the Particle Collision Model](#)
- [Implementation of a Stochastic Particle-Particle Collision Model in ANSYS CFX](#) (includes the discussion on the implementation theory, particle variables, and virtual collision partner)
- [Range of Applicability of Particle-Particle Collision Model](#)
- [Limitations of Particle-Particle Collision Model in ANSYS CFX](#)

### 8.5.3.9. Fluid Buoyancy Model

If you have selected the flow as buoyant and provided components for the gravity vector, then a **Fluid Buoyancy Model** can be set for each phase. The same treatment as Eulerian-Eulerian multiphase flow applies. For details, see [Buoyancy in Multiphase Flow](#) (p. 197).

Setting the flow as buoyant, but each fluid buoyancy model to non-buoyant is equivalent to setting the flow as non-buoyant.

## 8.5.4. Fluid Pairs

The models described in this section are selected on the **Fluid Pairs** tab when creating a domain containing particles in CFX-Pre. For details, see [Fluid Pair Models Tab in the CFX-Pre User's Guide](#).

### 8.5.4.1. Particle Fluid Pair Coupling Options

Particles can be either fully coupled to the continuous fluid or can be one-way coupled. Fully coupled particles exchange momentum with the continuous phase, allowing the continuous flow to affect the particles, and the particles to affect the continuous flow.

Full coupling is needed to predict the effect of the particles on the continuous phase flow field but has a higher CPU cost than one-way coupling. One-way coupling simply predicts the particle paths as a post-process based on the flow field and therefore it does not influence the continuous phase flow field. For details, see [Interphase Transfer Through Source Terms in the CFX-Solver Theory Guide](#).

The choice of one-way or full coupling for particles depends on the mass loading, that is, the ratio of the mass flow rate of particles to the mass flow rate of fluid. One-way coupling may be an acceptable approximation in flows with low mass loadings where particles have a negligible influence on the fluid flow. If the particles influence the fluid flow significantly, then you should use full coupling.

To optimize CPU usage, you can create two sets of identical particles. The first smaller set should be fully coupled and is used to allow the particles to influence the flow field. The second larger set should use one-way coupling and provides a more accurate calculation of the particle volume fraction as well as local forces on walls. When post-processing these types of cases, you should *not*, for example, sum the forces on the wall from both sets of particles because each set fully represents all the particles.

The CPU cost of tracking particles is proportional to the number of particles tracked multiplied by the number of times tracked. One-way coupled particles are tracked only once, at the end of the solver run. The number of times fully coupled particles are tracked depends on the iteration frequency set on the **Solver Control** tab and the number of iterations required for the simulation to converge.

You can define multiple sets of one-way coupled particles without affecting the flow field. For example, if you were conducting a parametric study with various different particle sizes, you can create multiple particle materials with the same properties and then use each one to define a set of particles with different diameters. This is not true of fully coupled particles, because each set influences the flow field.

### 8.5.4.2. Drag Force for Particles

There are three ways in which the drag forces between the continuous phase and the particle phase can be modeled:

- Use the Schiller-Naumann, Ishii-Zuber, or Grace correlations.
- Use Particle Transport Drag Coefficient and specify the drag coefficient using one of the following options:
  - Drag Coefficient - specify a constant value (CEL expressions are not permitted)
  - User Defined - specify a drag correlation using a particle user routine. See [Particle User Source Example \(p. 250\)](#) for an example of how to do this.
- Set the drag to None and set your own drag force using a particle user routine.

A description of these particle models is available in [Interphase Drag for the Particle Model \(p. 198\)](#), along with models for Euler-Euler flows.

#### 8.5.4.2.1. Particle User Source Example

This example is a basic routine used to calculate the particle drag coefficient using the Wen Yu Drag Model. The Schiller-Naumann correlation is used with a modified particle Reynolds number and a power law correction, both functions of the continuous phase volume fraction. The input arguments to the routine are Particle Reynolds number and volume fraction of the particle phase. The Fortran subroutine returns the particle drag coefficient, `C_d`. You can copy the routine (`pt_drag_factor.F`) from the `<install_dir>\examples\UserFortran` directory.

The Fortran for this example is:

```

#include "cfx5ext.h"
dllexport(pt_drag_factor)
    SUBROUTINE PT_DRAG_FACTOR (NLOC,NRET,NARG,RET,ARG,CRESLT,
        &
            CZ,DZ,IZ,LZ,RZ)
CC
CC -----
CC      Input
CC -----
CC
CC NRET   - number of components in result
CC NARG   - number of arguments in call
CC ARG()  - (NARG) argument values
CC
CC -----
CC      Modified
CC -----
CC
CC Stacks possibly.
CC
CC -----
CC      Output
CC -----
CC
CC RET()  - (NRET) return values
CC
CC -----
CC      Details
CC -----
CC
CC=====
C
C -----
C      Preprocessor includes
C -----
C
C -----
C      Global Parameters
C -----
C
C -----
C      Argument list
C -----
C
C      INTEGER NLOC,NARG,NRET
C
C      REAL ARG(NLOC,NARG), RET(NLOC,NRET)
C
C      CHARACTER CRESLT*(*)
C
C      INTEGER IZ(*)
C      CHARACTER CZ(*)*(1)
C      DOUBLE PRECISION DZ(*)
C      LOGICAL LZ(*)
C      REAL RZ(*)
C
C -----
C      External routines
C -----
C
C -----
C      Local Parameters
C -----
C
C -----
C      Local Variables
C -----
C
C -----
C      Stack pointers
C -----
C=====

```

```

C
C -----
C   Executable Statements
C -----
C
C=====
C
C   Argument variables stack:
C   -----
C   Reynolds number          :    RE_PT      = ARG(1,1)
C   Particle volume fraction :    VOLFRN_PT = ARG(1,2)
C
C   Return variables stack:
C   -----
C   Drag coefficient         :    CD          = RET(1,1)
C
C=====
C
C-----
C   Calculate the momentum source and source term coefficient
C-----
C
C   CALL USER_CD(RET(1,1),ARG(1,1),ARG(1,2))
C   END
C
C   SUBROUTINE USER_CD(CD,RE_PT,VOLFRN_PT)
C
C=====
C   Calculate the momentum source and source term coefficient
C=====
C
C -----
C   Preprocessor includes
C -----
C
C #include "cfd_sysdep.h"
C #include "cfd_constants.h"
C
C -----
C   Argument list
C -----
C
C   REAL CD, RE_PT, VOLFRN_PT
C
C -----
C   Local variables
C -----
C
C   REAL VOLFRN_C, RE_S
C
C -----
C   Executable statements
C -----
C
C---- Clip continuous phase volume fraction [0,1]
C
C   VOLFRN_C = 1. - MAX(0.0,MIN(1.0,VOLFRN_PT))
C
C---- Correct Reynolds number
C
C   RE_S = RE_PT*VOLFRN_C
C
C---- Calculate the Schiller-Naumann drag coefficient
C
C   IF (RE_S .LT. 1000.) THEN
C     CD = 24./RE_S*(1+0.15*RE_S**0.687)
C   ELSE
C     CD = 0.44
C   ENDIF
C
C---- Correct drag coefficient to account for high particle volume
C   loading

```

```

C
  CD = VOLFRN_C**-1.65*CD
C
  END

```

#### 8.5.4.2.2. Linearization Blend Factor

The linearization blend factor is a value that interpolates between simple linearization and the linearization based upon accurate differentiation of the drag. The recommended value (and the default) is 0.

#### 8.5.4.3. Particle User Source

For details, see [Particle User Sources](#) (p. 256).

#### 8.5.4.4. Non-Drag Forces

##### 8.5.4.4.1. Virtual Mass Force

Virtual mass force can be modeled with the specification of a virtual mass coefficient. The virtual mass force is proportional to the continuous phase density, hence, is most significant when the dispersed phase density is less than the continuous phase density. Also, by its nature, it is only significant in the presence of large accelerations, for example, in transient flows, and in flows through narrow restrictions. Additional information on the implementation and usage for this model is available in [Virtual Mass Force](#) (p. 201). For particle transport, the virtual mass coefficient defaults to 0.5.

##### 8.5.4.4.2. Turbulent Dispersion Force

Turbulent dispersion forces result in additional dispersion of particles from high volume fraction regions to low volume fraction regions due to turbulent fluctuations. The `Particle Dispersion` model is available to account for the turbulent dispersion force. This force is only important for small particles (approximately smaller than 100 microns for water drops in air) and when you want to see the dispersion. For example, even when the particle tracks are affected by turbulence, the effect of the particles on the continuous phase is usually the important process, and this is not affected by the turbulence.

The turbulent dispersion force is only active in regions where the turbulent viscosity ratio is above the value specified by **Eddy Viscosity Ratio Limit**. The default value is 5.

---

#### Note

Turbulent dispersion can only be used if a drag force is specified. Therefore, it is not possible to combine turbulent dispersion with a user-specified momentum source term for the drag.

##### 8.5.4.4.3. Pressure Gradient Force

The pressure gradient force is small for particles of much higher density than the continuum fluid and need not be included when this is the case. For details, see [Pressure Gradient Force in the CFX-Solver Theory Guide](#).

##### 8.5.4.5. Interphase Heat Transfer

The only available heat transfer option between the continuous phase and the particles is `Ranz Marshall`. The Ranz Marshall correlation is also applicable to Eulerian multiphase flow. For details, see [Particle Model Correlations for Overall Heat Transfer Coefficient](#) (p. 205).

### 8.5.4.5.1. Particle User Source

For details, see [Particle User Sources](#) (p. 256).

## 8.5.4.6. Interphase Radiation Transfer

### 8.5.4.6.1. Opaque

If `Opaque` is chosen, the radiation transfer can be either one-way coupled or fully coupled (if the overall coupling is fully coupled). For details, see:

- [Opaque](#) (p. 341)
- [Emissivity](#) (p. 347).

### 8.5.4.6.2. Blended Particle Emissivity

When a reacting particle case has been defined, two parameters exist to account for the change as the reacting particle changes its composition. For details, see [Multiphase Reactions and Combustion](#) (p. 289). Base Emissivity and Blended Emissivity must both be supplied. The present model assumes a linear variation in the emissivity from the reference material (for example, raw coal) value to the value of the reaction product (for example, char). For details, see [Radiative Preheating in the CFX-Solver Theory Guide](#).

## 8.5.4.7. Mass Transfer

There are a number of choices available for mass transfer in ANSYS CFX. The choices available for mass transfer depend on the type of particles that have been selected for the simulation. For any particle, simple mass transfer can be modeled with the `Ranz Marshall` model. Mass transfer from liquid drops can be modeled with the `Liquid Evaporation Model`. Coal combustion also uses mass transfer, but is set up using multiphase reactions, so no component pair information should be set at this point. For details, see [Multiphase Reactions and Combustion](#) (p. 289).

---

### Important

Regardless of the mass transfer option chosen, whenever mass transfer takes place, the particle diameter is automatically changed to reflect the change in mass.

### 8.5.4.7.1. Ranz Marshall

This option is analogous to Additional Variable species transfer, and uses the Ranz Marshall correlation on the continuous phase side of the interface and a zero resistance on the particle phase side of the phase interface. For details, see [Ranz-Marshall Correlation](#) (p. 211). A mass fraction equilibrium ratio can be set, analogous to that described in the multiphase mass transfer section. For details, see [Equilibrium Models in the CFX-Solver Theory Guide](#).

### 8.5.4.7.2. Liquid Evaporation Model

This option is used to model evaporation of a liquid species in particles to the respective gas phase species in the continuous phase. This model is restricted to evaporation of a single species and commonly used for spray dryer and oil combustion applications. A template CCL outline has been provided for general liquid evaporation. The `evaporating_drops.ccl` file (located in the `etc/model-templates/` directory of your ANSYS CFX installation) can be selected when starting a new simulation using the Library User mode. The template sets up a continuous gas phase containing `H2O` and `Air`

Ideal Gas, and defines a homogeneous binary mixture for the phase change of Water at 25 C to H2O. It also creates and specifies a domain named Domain 1 that includes the continuous and particle phases. Templates have also been provided for the Spray Dryer and Oil Combustion. For details, see:

- [Liquid Evaporation Model: Spray Dryer with Droplets Containing a Solid Substrate \(p. 255\)](#)
- [Liquid Evaporation Model: Oil Evaporation/Combustion \(p. 256\)](#).

To complete the domain specification, you would need to create a material to define the particle phase (step 1, below) and import an appropriate mesh.

Should you choose not to use the template, a general outline of the steps to set up a liquid evaporation model, including Water at 25 C evaporating from a particle into a gas mixture of H2O and Air Ideal Gas follows. You can substitute the materials below for the materials you are modeling in your simulation.

1. Create a pure substance or variable composition mixture that will be the particle phase. In the case of a variable composition mixture, it should contain the solid material(s) from which water evaporates, and the evaporating liquid (Water at 25 C).
2. Create another variable composition mixture that will be the continuous fluid. This mixture must include the gas phase component of the evaporating liquid selected in step 1 (H2O from the Gas Phase Combustion material group), as well as a constraint material (Air Ideal Gas).
3. Create a homogeneous binary mixture to set the mass transfer properties of the evaporating material. For the case of water, the homogeneous binary mixture contains Water at 25 C and H2O. The rate of evaporation in the liquid evaporation model is controlled by the binary mixture settings defined in the **Material** details view. Information on the creation of homogeneous binary mixtures is available in [Material Details View: Homogeneous Binary Mixture in the CFX-Pre User's Guide](#).
4. When creating the domain, define a fluid (or select an existing fluid) and set the **Morphology** > Option to Continuous Fluid.
5. Define a particle and set the **Morphology** > Option to Particle Transport Fluid.
6. On the **Fluid Models** form, set **Heat Transfer Model** to Fluid Dependent.
7. When setting up the **Fluid Specific Models** for the continuous mixture set H2O to use a Transport Equation and Air Ideal Gas to Constraint. Set **Heat Transfer** to use Thermal Energy for the continuous phase, and Particle Temperature for the particle phase.
8. On the **Fluid Pairs** tab, set **Heat Transfer** to Ranz Marshall (to enable interphase heat transfer). Under **Component Pairs**, enable the check mark for **H2O | Water at 25C** and set **Option** to Liquid Evaporation Model.
9. The Latent Heat setting for **Latent Heat** can be enabled if the reference enthalpies of the liquid and gas materials are inconsistent.

### 8.5.4.7.3. Liquid Evaporation Model: Spray Dryer with Droplets Containing a Solid Substrate

The evaporation of liquid from droplets containing a solid substrate is a common industrial application. The `spray_dryer.ccl` template is the same as the general liquid evaporation model, but includes the particle phase Coffee Mixture, which includes a new material Coffee and Water at 25 C. For details, see [Liquid Evaporation Model \(p. 254\)](#).

#### 8.5.4.7.4. Liquid Evaporation Model: Oil Evaporation/Combustion

The simulation of evaporating oil droplets is set up in a very similar way to the liquid evaporation model, with a **Modification** parameter named `Light Oil`, which is enabled to control the physical properties used in calculating the heat and mass transfer from the droplet. For details, see [Liquid Evaporation Model \(p. 254\)](#). This parameter should be set for all oil evaporation simulations. Enabling combustion involves creating a reaction for the gas phase mixture and then defining the gas phase mixture as a reacting mixture when setting up its material properties. For details, see [Material Details View: Reacting Mixture in the CFX-Pre User's Guide](#).

The `oil_combustion.ccl` template contains the material `JetA Liquid` (as the liquid oil) as a pure substance particle that evaporates into its gas phase equivalent `JetA`. `JetA` is part of the gas phase variable composition mixture named `Gas Mixture`. The `Gas Mixture` material itself is defined using a single-step reaction `JetA Oxygen WD1` (a reaction that specifies `JetA` and oxygen as reactants, and carbon dioxide and water as products, with an additional non-reacting `N2` component). A homogeneous binary mixture, `JetAlg`, exists to model the evaporation of `JetA Liquid` to `JetA`.

A domain named `Domain 1` is set up in a very similar way to a general liquid evaporation specification, with the `Light Oil Modification` set for the mass transfer of `JetA Liquid` to `JetA`. Additional information on the `Light Oil` treatment is available in [Light Oil Modification in the CFX-Solver Theory Guide](#).

#### 8.5.4.7.5. Latent Heat

In general, you can select `From Material Properties` for the **Latent Heat** option. The reference enthalpies will be used to determine latent heat if this option is selected. You can optionally set a latent heat by entering a value (for example, if the reference enthalpies of the liquid and gas materials are not consistent).

#### 8.5.4.8. Particle User Sources

The **Particle User Source** functionality allows you to use a User Fortran subroutine to calculate sources of momentum, heat and mass transfer. General information on creating user routines is available in [User Fortran \(p. 483\)](#).

In the `<install_dir>\examples\UserFortran` directory, you can find routines and CCL templates to calculate sources for momentum (`pt_mom_source.F`, `pt_mom_source.ccl`), heat (`pt_heat_source.F`, `pt_heat_source.ccl`), and mass transfer (`pt_mass_source.F`, `pt_mass_source.ccl`). These routines can be used as starting points for your own modifications. A particle user routine example is presented later in this section.

To use a particle user routine, you should first write the Fortran routine and create a shared library. Next, you should create a User Routine (**Insert >User Routine**) of type `Particle User Routine` in CFX-Pre. When defining the domain, particle user sources are selected by selecting the **Particle User Source** check box for the appropriate quantity, and selecting the routine from the drop-down list. For details, see:

- [Creating the Shared Libraries \(p. 491\)](#)
- [Particle User Routines in the CFX-Pre User's Guide](#).

The **Argument Variables** list should contain the fluid and particle variables needed to calculate the source (help on how to use variable names in ANSYS CFX, as well as a list of all variables, can be found in the `VARIABLES` file, in the `/etc/` directory of your ANSYS CFX installation).

The **Return Variables** list can only contain four quantities: the source itself, its derivative with respect to the associated variable in the particle, its derivative with respect to the associated variable in the fluid, and for mass sources only its derivative with respect to the temperature in the particle. The latter three quantities are optional, and the derivative with respect to the associated variable in the fluid can only be used when the overall coupling and the coupling set for the user source are both set to Fully Coupled. For momentum sources the associated variable is velocity, for heat transfer the associated variable is temperature, and for mass transfer the associated variable is mass fraction of species. Additional information on general source specification is available in [Sources \(p. 31\)](#) in *Basic Capabilities Modeling (p. 1)*.

### 8.5.4.8.1. Particle User Source example

#### Important

This example is a basic routine used to calculate a Schiller-Naumann drag force and is intended for demonstration purposes. If you want to use this example, you should set the **Drag Force** option to None on the **Fluid Pairs** tab.

This example uses a subroutine to calculate a user drag force between a particle phase Red Sand, and the fluid AirSTP. The Fortran subroutine returns a source and a source coefficient with respect to the particle and fluid. The input arguments to the routine are:

- Mean particle diameter, velocity, particle Reynolds number and slip velocity for the particle Red Sand.
- Density and velocity for the fluid AirSTP.

You can copy the routine (pt\_mom\_source.F) from the <install\_dir>\examples\UserFortran directory. The Fortran for this example is:

```
#include "cfx5ext.h"
dllexport(pt_momsource)
      SUBROUTINE PT_MOM_SOURCE (NLOC, NRET, NARG, RET, ARG, CRESLT,
&      CZ,DZ,IZ,LZ,RZ)
CC
CC User routine: template for particle user routine
CC
CC -----
CC      Input
CC -----
CC
CC NRET   - number of components in result
CC NARG   - number of arguments in call
CC ARG()  - (NARG) argument values
CC CRESLT - Result
CC
CC -----
CC      Output
CC -----
CC
CC RET()  - (NRET) return values
CC
CC -----
CC      Details
CC -----
CC=====
C
C -----
C      Argument list
C -----
C
C      INTEGER NLOC,NARG,NRET
```

```

C
C     REAL ARG(NLOC,NARG), RET(NLOC,NRET)
C
C     CHARACTER CRESLT*(*)
C
C     INTEGER IZ(*)
C     CHARACTER CZ(*)*(1)
C     DOUBLE PRECISION DZ(*)
C     LOGICAL LZ(*)
C     REAL RZ(*)
C
C -----
C     Local Variables
C -----
C
C=====
C -----
C     Executable Statements
C -----
C
C=====
C
C     Argument variables stack:
C     -----
C
C     Particle diameter      :    DIAM_PT    = ARG(1,1)
C     Particle velocity      :    VEL_PT     = ARG(1,2:4)
C     Reynolds number       :    RE_PT      = ARG(1,5)
C     Slip velocity         :    SLPVEL_PT  = ARG(1,6)
C     Fluid density         :    DENSITY_FL = ARG(1,7)
C     Fluid velocity        :    VEL_FL     = ARG(1,8:10)
C
C     Return variables stack:
C     -----
C
C     Source term           :    SOURCE     = RET(1,1:3)
C     Source coefficient    :    COEF_PT    = RET(1,4)
C     Source coefficient    :    COEF_FL    = RET(1,5)
C
C=====
C -----
C     Calculate the momentum source and source term coefficient
C -----
C
C     CALL USER_MOMENTUM_SOURCE (RET(1,1),RET(1,4),RET(1,5),
C     & ARG(1,1),ARG(1,2),ARG(1,5),ARG(1,6),
C     & ARG(1,7),ARG(1,8))
C
C     END
C     SUBROUTINE USER_MOMENTUM_SOURCE (SOURCE,COEF_PT,COEF_FL,
C     & DIAM_PT,VEL_PT,RE_PT,SLPVEL_PT,
C     & DENSITY_FL,VEL_FL)
C
C=====
C     Calculate the momentum source and source term coefficient
C=====
C
C -----
C     Preprocessor includes
C -----
C
C #include "cfd_sysdep.h"
C #include "cfd_constants.h"
C
C -----
C     Argument list
C -----
C
C     REAL SOURCE(3), COEF_PT, COEF_FL,
C     & DIAM_PT, VEL_PT(3), RE_PT, SLPVEL_PT,

```

```

      &   DENSITY_FL, VEL_FL(3)
C
C -----
C   Local variables
C -----
C
C   REAL AREA, CD, FACT
C
C -----
C   Executable statements
C -----
C
C---- Calculate the particle reference area
C
C   AREA = PI*DIAM_PT**2*QUARTER
C
C---- Calculate the Schiller-Naumann drag coefficient
C
C   IF (RE_PT.LT.1000.) THEN
C     CD = 24./RE_PT*(1+0.15*RE_PT**0.687)
C   ELSE
C     CD = 0.44
C   ENDIF
C
C---- Calculate the momentum source term and linear coefficients
C
C   FACT = HALF*DENSITY_FL*AREA*CD*SLPVEL_PT
C
C   SOURCE(1) = FACT*(VEL_FL(1)-VEL_PT(1))
C   SOURCE(2) = FACT*(VEL_FL(2)-VEL_PT(2))
C   SOURCE(3) = FACT*(VEL_FL(3)-VEL_PT(3))
C
C   COEF_PT = -FACT
C   COEF_FL =  FACT
C
C   END

```

Outlined instructions for the Fortran file is available in [Creating the Shared Libraries \(p. 491\)](#).

The specification of the input and output variables occurs in CFX-Pre. The definition for the user routine is created, setting the **Option** to Particle User Routine, setting the calling name to `pt_mom-source` and specifying the **Library Name** and **Library Path** as appropriate.

On the **Fluid Pairs** form in the **Mass and Momentum** frame, Particle User Source is created and chosen from the drop-down list.

The Argument Variables List contains the following variables:

- Red Sand.Mean Particle Diameter
- Red Sand.Velocity
- Red Sand.Particle Reynolds Number
- Red Sand.Particle Slip Velocity
- AirSTP.Density
- AirSTP.Velocity

The Return Variables List contains all of the available options:

- Source
- Source Coefficient with respect to Particle Variable
- Source Coefficient with respect to Fluid Variable

### 8.5.5. Particle Injection Regions

For details, see [Particle Injection Regions](#) (p. 268).

## 8.6. Particle Boundary Options and Behavior

The following topics will be discussed:

- [Particle-Rough Wall Model \(Virtual Wall Model\)](#) (p. 266)
- [Inlet/Opening Boundaries](#) (p. 260)
- [Outlet Boundaries](#) (p. 263)
- [Wall Boundaries](#) (p. 264)
- [Symmetry Plane Boundaries](#) (p. 267)
- [Interface Boundaries](#) (p. 267)
- [Domain Interfaces](#) (p. 267)

### 8.6.1. Inlet/Opening Boundaries

You can introduce particles into the domain by enabling the **Define Particle Behavior** toggle on the **Fluid Values** form and specifying their properties on an inflow or opening boundary. This is used when you have more than one inlet, but particles only enter through some of them. The particle velocity, injection position, diameter distribution, and mass flow rate need to be specified. For details, see [Fluid Values for Inlets and Openings in the CFX-Pre User's Guide](#).

#### 8.6.1.1. Mass and Momentum

The `Normal Speed`, `Cartesian Velocity Components`, and `Cylindrical Velocity Components` are described at [Mass and Momentum](#) (p. 64).

The `Zero Slip Velocity` option causes the particles to be injected at the local velocity of the continuous phase. It can be used at an inflow boundary that is specified using a mass flow or pressure option for the continuous phase.


#### 8.6.1.2. Particle Position

##### 8.6.1.2.1. Uniform Injection

This option produces a random injection over the entire inlet. For details, see [Number of Positions](#) (p. 262).

##### 8.6.1.2.2. Uniform Injection within Annulus

This option restricts the injection location to an annular region on the boundary condition. The annulus is defined by an axis, as well as a distance from the axis for both the inner and outer radii of the annulus.

**Figure 8.2 Annulus projected onto a boundary region**

The annulus is assumed to be infinitely long in both the positive and negative directions of its axis, which is defined by the two specified points. Particles will be injected through any portion of the boundary region intersecting the infinite annulus. If there is no overlapping region between the boundary region and the projection of the annulus onto the boundary region, then no particles will be injected.

A description of the format used to enter the First and Second Point of Axis is available in:

- [Point Data Format](#) (p. 263)
- [Number of Positions](#) (p. 262).

#### 8.6.1.2.3. Injection With Line Weighting

The **First** and **Second Line Point for Normal Distribution** define the end points of the line. A description of the format used to enter the first and second point of axis is available in [Point Data Format](#) (p. 263). It is expected that the line lies in the plane of the injection boundary. The injection weighting is a normal distribution around the line, with the **Standard Deviation for Normal Distribution** determining the shape of the distribution. For details, see [Number of Positions](#) (p. 262).

#### 8.6.1.2.4. Injection With Point Weighting

This option weights the injection location towards a point. It is expected that the point lies in the plane of the injection boundary. A normal distribution is used to determine the probability of injection as you move away from the point, using the **Standard Deviation for Normal Distribution**. A description of the format used to enter the **Center Point for Normal Distribution** is available in:

- [Point Data Format](#) (p. 263)
- [Number of Positions](#) (p. 262).

#### 8.6.1.2.5. Injection With Circular Weighting

The **Center Point for Normal Distribution** and **Distance From Center Point** define the center and radius of the circle, which is expected to lie in the plane of the injection boundary. A description of the format used to enter the center point is available in [Point Data Format](#) (p. 263).

The injection weighting follows the circumference of the circle (that is, there is a lower probability of injecting particles at the center of the circle). The **Standard Deviation for Normal Distribution** determines the shape of the normal distribution as you move away from the circumference of the circle. For details, see *Number of Positions* (p. 262).

#### 8.6.1.2.6. Injection With User Defined Weighting

The **Face Weighting Factor** is a dimensionless number that sets a weighting factor between 0 and 1 for each location on the injection boundary. It is expected to be defined by a function of  $x$ ,  $y$ , and/or  $z$  using either a CEL expression or a `User CEL Function`. For details, see *Number of Positions* (p. 262).

#### 8.6.1.2.7. Injection at Face Centers

Particles are injected at the center of each element face. An illustration of the location of face centers is available in *Discretization of the Governing Equations in the CFX-Solver Theory Guide*.

#### 8.6.1.2.8. Injection at IP Face Centers

Particles are injected at the integration points for each face. An illustration of the location of integration points is available in *Discretization of the Governing Equations in the CFX-Solver Theory Guide*.

#### 8.6.1.2.9. Number of Positions

For each particle type, you must specify the number of representative particles injected at a boundary condition or particle injection region.

For steady state simulations, the **Number of Positions** parameter sets the total number of particles to be injected. You can specify the number directly or proportional to the injected mass flow rate. In the latter case, you must specify the number of particles per unit mass flow.

For transient simulations, you must specify the number of injected particles per unit time. You can specify the number directly or proportional to the injected mass flow rate. In the latter case, you must specify the number of particles per unit time and the mass flow rate. In a transient simulation you can specify the number of particles or mass flow rate as an expression in time.

---

#### Note

For user defined injections with the number of particles being a function of the injected mass flow rate, you must specify the mass flow rate in the CCL and not in a user routine. This applies to steady state simulations, as well as to transient simulations.

When choosing the number of particles, you should remember that the modeled particles are a representative sample of the actual particles and the number of particles modeled will be much smaller than the real number of particles (for details, see *Particle Number Rate* (p. 238)). The specified **Particle Mass Flow** rate accounts for the fact that a smaller number of particles are modeled than really exist. The size and location on the boundary of the modeled particles is determined randomly (but can be weighted using a particular distribution).

The appropriate number of injected particles to be used in a simulation cannot be easily determined. This number strongly depends on several parameters such as the fluid grid size or the distribution of the particles in the domain. The area of influence of the particles in the fluid phase must be covered by enough particles per element. The number of injected particles must be varied in order to see if the number is sufficiently large, as done in grid refinement studies.

### 8.6.1.2.10. Point Data Format

Some of the options described above require point data to be entered. The format used for this in CFX-Pre should be a comma separated list corresponding to the x, y, and z coordinates, for example, 0, 0, -0.1, with the units selected from the drop-down list. If an expression is used, then the format will be similar to 0[m], 0[m], -0.1[m]; that is, with a unit specified for each coordinate.

### 8.6.1.3. Particle Locations

By default, particles are injected randomly within the location constraints which are set under the **Particle Position** option. To enforce an equal spatial distribution, you can set the **Particle Locations** option to `Equally Spaced`.

### 8.6.1.4. Particle Diameter Distribution

This option applies to domains and boundaries. When specified for boundaries, the settings applied override the domain values. For details, see [Particle Diameter Distribution](#) (p. 241).

### 8.6.1.5. Particle Mass Flow Rate

Specify the mass flow rate which is shared amongst all particles. This should be the total mass flow rate of particles through this boundary.

This need not be specified for one-way coupled particles if you are only interested in the particle tracks and not in derived quantities, such as particle volume fraction and forces on walls. It is always required for fully coupled particles.

The overall mass flow rate of the particles is shared amongst the representative particles being tracked. By dividing by the (initial) mass of the particle, this means that each representative particle has a **Particle Number Rate**. This quantity is used internally in the code for calculating overall sources to the continuous phase, and is also used in post-processing for calculating mass flows of particles through boundaries, forces on walls, and so on.

### 8.6.1.6. Heat Transfer

The static temperature is required for particle phases when a heat transfer model has been selected for the particles.

### 8.6.1.7. Component Details

This section of the form becomes available when a variable composition mixture has been used to define the particles. Mass fractions are required for each of the species in the particle phase, and must sum to unity on all boundaries.

### 8.6.1.8. Particle Actions at Inlets and Openings

When existing particles in the domain reach an inlet or an opening, they escape from the domain.

## 8.6.2. Outlet Boundaries

### 8.6.2.1. Particle Actions at Outlets

When existing particles in the domain reach an outlet, they escape from the domain.

## 8.6.3. Wall Boundaries

### 8.6.3.1. Wall Interaction

The wall interaction option is available in CFX-Pre for simulations involving Lagrangian particles or when a particle user routine has been created. The wall-interaction options available in ANSYS CFX are outlined below:

- *Standard Particle-Wall Interaction* (p. 264)
- *Advanced Particle-Wall Interaction* (p. 265)
- *User Defined Particle-Wall Interaction* (p. 265)

#### 8.6.3.1.1. Standard Particle-Wall Interaction


This is the default particle-wall interaction model in ANSYS CFX, typically controlled by setting the wall interaction mode to `Equation Dependent` in CFX-Pre. With this model, the droplet is reflected off a wall and the momentum change across the collision is described using the perpendicular and parallel coefficients of restitution. For details, see *Fluid Values for Walls in the CFX-Pre User's Guide*.

##### 8.6.3.1.1.1. Restitution Coefficients for Particles

The parallel and perpendicular restitution coefficients describe the action of particles when they hit a wall. Enter a numerical quantity or CEL based time-dependent expression to specify the value of restitution coefficients. Coefficient values of 1 describe an elastic collision, while values less than 1 describe an inelastic collision. *Figure 8.3* (p. 264) shows an example of a particle velocity before and after impacting a wall when the perpendicular restitution coefficient is 0.5 and the parallel restitution coefficient is 0.75.

**Figure 8.3 Particle Track Behavior at a Wall Boundary**

Perpendicular Restitution Coefficient = 0.5  
 Parallel Restitution Coefficient = 0.75  
 Impact angle in radians =  $\phi$



The parallel coefficient will almost always be 1. The perpendicular coefficient will depend on the particle material. Particles that bounce off walls will have a perpendicular coefficient close to 1, while particles that stick to walls (for example, water droplets) will have a perpendicular coefficient of 0.

If you want to terminate tracking of particles when they hit a wall boundary, then you can set both coefficients to zero. Although it should be noted that when a particle hits a wall and the perpendicular coefficient of restitution is set to zero then the particle comes to a stop regardless of what is set for the parallel coefficient of restitution

---

## Important

In case of a moving wall, the coefficients need to consider the velocity of the wall. This means the relevant coordinate system must always be the wall and the relative particle velocity (with respect to the wall) has to be taken into account if either of the coefficients are smaller than 1.

---

## Note

Setting the perpendicular coefficient of restitution to a small positive number is *not* a valid way to simulate particle sliding along a wall. Currently there is no method for accurately simulating this type of particle sliding.

The change in momentum of particles due to the action at a wall results in a force on the wall.

### 8.6.3.1.2. Advanced Particle-Wall Interaction

The following advanced particle-wall interaction models are available in ANSYS CFX:

- Elsaesser particle-wall interaction model
- Stick-to-wall model

For details, see [Particle-Wall Interaction in the CFX-Solver Theory Guide](#).

### 8.6.3.1.3. User Defined Particle-Wall Interaction

The user-defined particle-wall interaction model can be used to model such quantities as restitution coefficient, mass flow absorption, erosion and particle breakup using a Fortran routine. The Fortran routine should first be written, and a shared library created. For details, see [Creating the Shared Libraries](#) (p. 491). After this step, you should create a User Routine of type Particle User Routine. For details, see [Particle User Routines in the CFX-Pre User's Guide](#).

Input arguments to the subroutine can be any valid variables (selected from the Arguments drop-down list in CFX-Pre).

The returned quantities must comprise one or more of the following:

- Perpendicular / Parallel Coefficient of Restitution
- Mass Flow Absorption Coefficient
- Particle Erosion
- Particle Breakup Factor (the number rate of a particle is increased by the breakup factor, and the diameter is reduced by the cube root of the breakup factor)

In the `<install_dir>\examples\UserFortran` directory, you can find a wall-interaction particle routine, `pt_breakup_wall.F`, and corresponding CCL template, `pt_breakup_wall.ccl`.

### 8.6.3.2. Erosion Model

The erosion model can be set on a per-boundary or per-domain basis. When enabled for the domain, the domain settings will apply for all boundaries that do not explicitly have erosion model settings

applied to them. To override the domain setting, turn-on the **Erosion Model**. Additional information on erosion is available. For details, see:

- [Erosion](#) (p. 245)
- [Basic Erosion Models in the CFX-Solver Theory Guide](#).

### **8.6.3.3. Particle-Rough Wall Model (Virtual Wall Model)**

The rough wall model can be set on a per-boundary or per-domain basis. When enabled for the domain, the domain settings will apply for all boundaries that do not explicitly have rough wall model settings applied to them. To override the domain setting, turn on the Rough Wall model on the corresponding patches. Additional information on rough wall treatment is available in [Particle-Rough Wall Model \(Virtual Wall Model\)](#) (p. 247) and [The Sommerfeld-Frank Rough Wall Model \(Particle Rough Wall Model\)](#) in the [CFX-Solver Theory Guide](#).

### **8.6.3.4. Particle Breakup**

To simulate the breakup of particles due to aerodynamic forces, five different interior breakup models are available: Reitz & Diwakar, TAB, ETAB, CAB and Schmehl model. See [Spray Breakup Models in the CFX-Solver Theory Guide](#) for information on these models.

### **8.6.3.5. Mass Flow Absorption**

The mass flow absorption is available to allow a fraction of particles to leave the domain when they collide with a wall. For each particle tracked, the mass flow (number) rate is reduced whenever it strikes a wall.

### **8.6.3.6. Mass and Momentum**

Particles can be injected through walls in the same way as they are injected through inlets. For details, see [Mass and Momentum](#) (p. 260).

### **8.6.3.7. Particle Impact Angle**

The impact angle  $\varphi$  is the angle between the approaching particle track and the wall. It is measured in radians. See [Figure 8.3](#) (p. 264).

### **8.6.3.8. Particle Position**

The particle injection positions on a wall are defined in the same way as at inlets. For details, see [Particle Position](#) (p. 260).

### **8.6.3.9. Particle Diameter Distribution**

The diameter distribution on a wall is described in the same way as for a domain. For details, see [Particle Diameter Distribution](#) (p. 241).

### **8.6.3.10. Particle Mass Flow Rate**

The particle mass flow rate through a wall is defined in the same way as through inlets. For details, see [Particle Mass Flow Rate](#) (p. 263).

## 8.6.4. Symmetry Plane Boundaries

When a particle reaches a symmetry plane boundary condition, it is reflected.

## 8.6.5. Interface Boundaries

If your simulation includes any solid domains, then you may want to set particle options at the fluid-solid interface. To do this, you should first create the required fluid-solid domain interfaces, and then edit the automatically created interface boundary condition for the fluid side of the interface. The options on the fluid side of fluid-solid interfaces are specified in the same way as for wall boundaries. For details, see:

- [Wall Boundaries](#) (p. 264)
- [Interface Boundary Conditions in the CFX-Pre User's Guide](#).

## 8.6.6. Domain Interfaces

### 8.6.6.1. Fluid-Fluid


#### 8.6.6.1.1. Frame Change Option = None

When there is no frame change across a fluid-fluid domain interface, then particles simply cross the interface and continue in the next domain.

#### 8.6.6.1.2. Frame Change Option = Frozen Rotor

At a frozen rotor domain interface, particles simply cross the interface and continue in the next domain. You should not use a frozen rotor interface unless particles cross the interface approximately uniformly. For example, if most of the particles cross the interface at one location, then the transient behavior due to the relative motion of the two components will be completely lost. This is the same limitation that applies to local fluid features at frozen rotor domain interfaces. For details, see [Frozen Rotor](#) (p. 161).

#### 8.6.6.1.3. Frame Change Option = Stage



When a particle crosses a stage interface, it enters the new domain at a random location and its velocity is rotated accordingly. This is in addition to change in the relative velocity that occurs due to the particle changing to a new frame of reference. This can be thought of as equivalent to the circumferential “averaging” that is performed for the fluid flow variables at stage interfaces. For details, see [Stage](#) (p. 162).


If a pitch change occurs across the interface, the mass flow rate is updated appropriately. The balance sections of the `.OUT` file that is written by the CFX-Solver as the solution proceeds reflect these changes.

#### 8.6.6.1.4. Frame Change Option = Transient Rotor Stator

In a transient simulation, interfaces between rotating and non-rotating domains are modeled using the Transient Rotor Stator frame change option.

When particles cross such an interface, they continue at the corresponding position across the interface. This is similar to the approach used for the Frozen Rotor interface option but the correct, time dependent relative position of the two domains is taken into account. Due to the fact that rotating domains are rotated in CFD-Post, particle tracks will be contiguous across transient rotor interfaces.

#### 8.6.6.2. Periodic Connections



When a particle reaches a periodic domain interface, it emerges at the new periodic location and the particle's velocity is rotated, as expected.

### 8.7. Subdomains

For simulations with particle tracking, a subdomain has a **Fluids** tab that enables the subdomain to act as a porous medium that can absorb particles. The **Absorption Diameter** setting specifies the minimum size of particles that are absorbed (removed from the calculation) upon entering the porous region (that is, the subdomain).

Wherever multiple subdomains occupy the same volume, the smallest specified **Absorption Diameter** value is used.

### 8.8. Particle Injection Regions

Injection regions can optionally be created to inject particles on sphere or cone locators, or on a custom locator defined by a User Fortran subroutine. The user subroutine should be of type `Particle User Routine` to make it available for selection in the drop-down list.

For each method of injection, apart from the location specification itself, other quantities required are the same as those that would be required at a boundary (for example, temperature would be required if heat transfer was being modeled). For details, see *Particle Boundary Options and Behavior* (p. 260). If a

User Fortran routine is being used, all physical quantities (apart from mass fractions) can be set either in the Fortran or from the user interface.

The center and the axis (if applicable) of the injector, as well as the injection velocity (for Cartesian or cylindrical velocity components), are interpreted in the local coordinate system. The exception is for user defined injections where the particle position and the injection velocity – if returned from the user routine – refer to the global coordinate frame `Coord 0` rather than to the one specified under **Coordinate Frame**.

The local coordinate system cannot be specified with a rotating frame motion. When a domain with a rotating frame is included in the injected region, the position from which particles are injected is assumed to rotate along with the domain. For additional information, see [Rotating Frames of Reference \(RFR\)](#) (p. 30) and [GGI and MFR Theory in the CFX-Solver Theory Guide](#).

The following sections outline how to set up the locations using the following options:

8.8.1. Sphere

8.8.2. Cone

8.8.3. Cone with Primary Breakup

8.8.4. User Defined

### 8.8.1. Sphere

When creating a sphere, the injection center, injection velocity magnitude, and number of positions are required. If the radius of the injection sphere is not given, the radius defaults to zero (that is, all particles will be injected from a point).

### 8.8.2. Cone

When creating a cone, a cone may describe the shape of the particle tracks. The particles actually enter from a 2D region, which may be a point, a circle, or an annular region according to the **Cone Definition** parameters. The orientation of this plane is determined by the injection direction. Note that the direction in which the particles enter may or may not be independent of the orientation of the 2D region.

The following cone injection types are supported in CFX-Pre:

- **Point Cone**
- **Hollow Cone**
- **Ring Cone**
- **Full Cone**

The injection center, injection velocity, injection direction, number of positions, and cone definition are required for setting up various cone injection types. An optional **Dispersion Angle** of the spray can be specified for point and hollow cone types by setting one of the following parameters:

- **Dispersion Angle**: The specified value is considered to be a 'half angle' similar to the spray cone angle definition.
- **Standard Deviation of Dispersion Angle**: The specified value is considered as a normal distribution of the spray within the dispersion angle.

### 8.8.2.1. Injection Velocity

The injection velocity can be set via the specification of the *Velocity Magnitude*, *Cartesian Velocity Components*, *Cylindrical Velocity Components*, or *Zero Slip Velocity*. The *Zero Slip Velocity* option causes the particles to be injected at the local fluid velocity of the coupled continuous phase.


Note that the specification of *Cylindrical Velocity Components* is not supported for *Point Cones*.

To simplify the specification of swirl for the injection velocity a new particle variable *<Particle Type>.Particle Position* was introduced. The components of this variable hold the x, y, and z distance from the local injector center and can be used in CEL to define swirl components for the particle injection velocity vector.

Velocities for particles are always assumed to be specified in the absolute frame.



### 8.8.2.2. An Example of a Point Cone

The following illustration shows a point cone with cone angle of 45 degrees. The injection direction is specified normal to the injection boundary. As the **Cone Definition** parameter for point cone does not require the specification of inner and outer radii, the particles are injected from a point at the injection center.





### 8.8.2.3. An Example of a Point Cone Using the Dispersion Angle

This following illustration shows how the optionally specified dispersion angle,  $\gamma$ , changes the injection type from point cone (*Figure 8.4* (p. 271)) to point hollow cone (*Figure 8.5* (p. 271)). The cone angle is shown as  $\theta$ .

**Figure 8.4 Point cone with specified cone angle****Figure 8.5 Point cone with specified cone angle and dispersion angle****8.8.2.4. An Example of a Hollow Cone using the Dispersion Angle**

This following illustration shows how the optionally specified dispersion angle,  $\gamma$ , changes the spray pattern in the case of a hollow cone injection. The cone angle is shown as  $\theta$ .

**Figure 8.6 Hollow cone with specified cone angle**

**Figure 8.7 Hollow cone with specified cone angle and dispersion angle**

### 8.8.3. Cone with Primary Breakup

This option enables the use of primary breakup models to determine starting conditions for the droplets that leave the injection nozzle. In ANSYS CFX 14.0, various primary breakup models are available. For details about these models and their required input data, refer to the following sections in [CFX-Solver Theory Guide](#):

- [Blob Method](#)
- [Enhanced Blob Method](#)
- [LISA Model](#)
- [Turbulence Induced Atomization](#)

### 8.8.4. User Defined

User defined injection locations enable you to use Fortran to specify a custom injection region. The routine may optionally return a range of values (such as temperature, particle mass flow rate, and so on) or they can be specified by enabling the appropriate toggles in CFX-Pre. Information on setting up a particle routine is available in [Particle User Routines in the CFX-Pre User's Guide](#).

---

#### Note

In the case of user defined injection, the particle position and the injection velocity – if returned from the user routine – refer to the global coordinate frame `Coord 0` rather than to the one specified under **Coordinate Frame**.

An example of a Fortran routine is given below. This routine returns the following variables:

- Particle Position (X, Y, Z)
- Particle Mass Flow Rate
- Mean Particle Diameter
- Velocity (u, v, w)
- Temperature

As a result, the respective options under **Define Particle Behavior** are not entered. Similar to other routines, after the Fortran routine is written, a shared library should be created. For details, see [Creating the Shared Libraries](#) (p. 491). The routine should then be defined as a User Particle Routine in CFX-Pre. For details, see [Particle User Routines in the CFX-Pre User's Guide](#).

In the <install\_dir>\examples\UserFortran directory, you can find an injection routine, `pt_injection.F`, and corresponding CCL template, `pt_injection.ccl`.

## 8.9. Particle Output Control

The following topics are discussed in this section:


- [Transient Particle Diagnostics](#) (p. 273)
- [List of Particle Variables](#) (p. 279)

### 8.9.1. Transient Particle Diagnostics

For transient simulations with Lagrangian particles, it is very helpful to define integrated quantities:

- The axial penetration of a spray measured along the user-defined spray axis ( $S_A$  in [Figure 8.8](#) (p. 273))
- The radial penetration of a spray measured normal to the user-defined spray axis ( $S_R$  in [Figure 8.8](#) (p. 273))
- The penetration of a spray normal to the spray axis ( $S_N$  in [Figure 8.8](#) (p. 273))
- The penetration angle of a spray ( $\Theta$  in [Figure 8.8](#) (p. 273))
- The total mass of particles

**Figure 8.8 Spray Penetration**




The penetration is normally evaluated by looking at a specified fraction of the spray, that is, the axial penetration of a spray is given by a distance from the spray nozzle which contains 99 percent of the particle mass. The calculation of the axial, radial, and normal penetration depth is straightforward.

The spray angle as reported by the transient particle diagnostics is calculated as follows: An imaginary cone is created with its tip at the point of injection and the cone axis parallel to the specified injection direction. The cone angle is then gradually increased up to the point where the imaginary cone contains a certain percentage of the total spray mass (by default: 99%, this can be changed via the `Contained Spray Mass Fraction CCL` parameter). The cone half angle is then reported as the spray angle,  $\Theta$ .


Figure 8.9 (p. 274) shows two typical spray shapes and the reported spray angle,  $\Theta$ .

### Figure 8.9 Spray Angle Calculation for Different Spray Shapes



When the spray is injected with a finite injection radius as shown in Figure 8.10 (p. 274), you will need to set the `Spray Radius at Penetration Origin` parameter to the size of the injection radius, otherwise the solver will return a spray angle of  $90^\circ$ .

### Figure 8.10 Spray Angle Calculation with Finite Injection Radius with and without Spray Radius Specified



There are various different ways to calculate transient particle diagnostics. A flexible User Fortran interface is available that enables you to calculate any information from all particles (given by their position, velocity, ...) at any time step during a transient particle run.

#### 8.9.1.1. User Diagnostics Routine

Besides the hard coded penetration depth and angle it is necessary to provide a method that enables you to evaluate any transient particle diagnostics. You cannot use CEL expressions for particles. As an alternative, it is possible to call a user routine which evaluates the required diagnostics information based on a specified list of particle variables. The following particle variables can be chosen:

- Mean Particle Number
- Particle Number Rate
- Particle Position
- Particle Time
- Particle Traveling Distance
- Temperature
- Total Particle Mass
- Velocity

Following this approach, the solver provides the values of all particle variables specified for user-defined diagnostics in a local working directory, together with global information about the total number of particles (NPART) at the current time step, as well as the particle type (CPT) and particle type alias name (ALIAS). This is necessary because user routines do not support subroutine arguments besides the five Fortran stacks. The user routine can now pick up the required information from the MMS by converting the variable names specified to internal solver names for which standard LOCDAT calls can be used. The obtained pointers can be passed down to another subroutine layer, which does the final calculation.

In order to monitor values calculated within the user routine, you can store a defined list of REAL variables back to the MMS (predefined place is TPD\_VALUE in the local directory). Those variables are picked up by the solver and are written to the .out file similar to the pre-defined transient diagnostics values. The values are also added to the list of monitored values for the ANSYS CFX-Solver Manager. You must specify a list of strings (CCL-parameter: Monitored Values List) which contains names for the values to be monitored. The number of monitored values is determined from this list and the names are used in the OUT file and in the CFX-Solver Manager.

As an example for this strategy, a user routine has been created which simply calculates the particle mass within three spheres with different user-specified radii. The next subsections show the CCL and the listings of the required user routine, as well as the diagnostics output.

### 8.9.1.1.1. Example User Routine: CCL

Sphere radius and center is specified in the USER section of the CCL:

```
USER:
  CENTRE = 0.5, 0.5, 0.5
  RADIUS1 = 0.25
  RADIUS2 = 0.35
  RADIUS3 = 0.45
END
```

The CCL definition for the corresponding junction box is as follows:

```
TRANSIENT PARTICLE DIAGNOSTICS: User Routine Sphere
  Option = User Defined
  Transient Particle Diagnostics Routine = Sphere
  Particle Variables List = \
    Particle Position, \
    Total Particle Mass, \
    Particle Number Rate
  Monitored Values List = \
    First sphere, \
    Second sphere, \
    Third sphere
  Particles List = Water
END
```

As can be seen, the user routine depends on the position, mass, as well as the number rate of the particles and provides three values which are monitored during the simulation. The new diagnostics section for this CCL in the .out file looks like:

```
+-----+
|                               |
|          Transient Particle Diagnostics          |
|-----+-----+
Water
  User Routine Sphere
    First sphere                3.8847E-02
    Second sphere               5.9132E-02
    Third sphere                7.2068E-02
```

### 8.9.1.1.2. Example User Routine: Mainline Routine

In the <install\_dir>\examples\UserFortran directory, you can find an example mainline routine, pt\_tpd1.F, and corresponding CCL template, pt\_tpd1.ccl.

### 8.9.1.1.3. Example User Routine: Subroutine

```
      SUBROUTINE CALC_TPD1(TOTAL_MASS, SPHERE_CENTRE,
&                          SPHERE_RADIUS, NPART, CRD, MASST, RATE)
C
C=====
C      Subroutine for CALC_TPD1 which does the real calculation
C=====
C
      INTEGER  NPART
      REAL     TOTAL_MASS(3), SPHERE_CENTRE(3), SPHERE_RADIUS(3),
&            CRD(3,NPART), MASST(NPART), RATE(NPART)
C
      INTEGER IPART, I
      REAL    RADIUS
C
      DO I=1,3
        TOTAL_MASS(I) = 0.0
      ENDDO
C
      DO IPART=1,NPART
        RADIUS = SQRT( (CRD(1,IPART)-SPHERE_CENTRE(1))**2
&                    + (CRD(2,IPART)-SPHERE_CENTRE(2))**2
&                    + (CRD(3,IPART)-SPHERE_CENTRE(3))**2 )
        DO I=1,3
          IF (RADIUS.LE.SPHERE_RADIUS(I)) THEN
            TOTAL_MASS(I) = TOTAL_MASS(I) + MASST(IPART)*RATE(IPART)
          ENDIF
        ENDDO
      ENDDO
C
      END
```

### 8.9.1.1.4. Example: Complete CCL

The following CCL for

- Two penetration objects
  - Specified location
  - Specified particle injection region (PIR)
- One total particle mass object
- Two user defined diagnostics objects
  - User routine with three monitored values

- User routine without any monitored values

looks as follows:

```

=====
#   TRANSIENT PARTICLE DIAGNOSTICS
#=====
#
#-----
#   Penetration
#-----
#
TRANSIENT PARTICLE DIAGNOSTICS: Penetration from Location
  Option = Particle Penetration
  PENETRATION ORIGIN AND DIRECTION:
    Option = Specified Origin and Direction
    Injection Centre = 0.01 [m], 0.5 [m], 0.01 [m]
  INJECTION DIRECTION:
    Injection Direction X Component = 1.0
    Injection Direction Y Component = 0.0
    Injection Direction Z Component = 1.0
    Option = Cartesian Components
  END
END
  Contained Spray Mass Fraction = 0.98
  Particles List = Water 1
  AXIAL PENETRATION:
    Option = Axial Penetration
  END
  RADIAL PENETRATION:
    Option = Radial Penetration
  END
  NORMAL PENETRATION:
    Option = Normal Penetration
  END
  SPRAY ANGLE:
    Option = Spray Angle
  END
END
TRANSIENT PARTICLE DIAGNOSTICS: Penetration from PIR
  Option = Particle Penetration
  PENETRATION ORIGIN AND DIRECTION:
    Option = Particle Injection Region
    Particle Injection Region = Cone
  END
  Contained Spray Mass Fraction = 0.98
  Particles List = Water 1, Water 2
  AXIAL PENETRATION:
    Option = Axial Penetration
  END
  RADIAL PENETRATION:
    Option = Radial Penetration
  END
  NORMAL PENETRATION:
    Option = Normal Penetration
  END
  SPRAY ANGLE:
    Option = Spray Angle
    Spray Radius at Penetration Origin = 0.005 [m]
  END
END
#
#-----
#   Total Particle Mass
#-----
#
TRANSIENT PARTICLE DIAGNOSTICS: Total Particle Mass
  Option = Total Particle Mass
  Particles List = Water 1, Water 2
  END
#
#-----

```

```
# User Defined
#-----
#
TRANSIENT PARTICLE DIAGNOSTICS: User Routine Sphere
Option = User Defined
Transient Particle Diagnostics Routine = Sphere
Particle Variables List = \
    Particle Position, \
    Total Particle Mass, \
    Particle Number Rate
Monitored Values List = \
    First sphere, \
    Second sphere, \
    Third sphere
Particles List = Water 1, Water 2
END
TRANSIENT PARTICLE DIAGNOSTICS: User Routine Histo
Option = User Defined
Transient Particle Diagnostics Routine = Histogram
Particle Variables List = \
    Total Particle Mass, \
    Particle Number Rate, \
    Mean Particle Diameter
Particles List = Water 1, Water 2
END
```

Leading to the following lines in the OUT file and in the solver manager:

```
+-----+
|                               |
|               Transient Particle Diagnostics               |
|-----+
Water 1

User Routine Histo
User Routine Sphere
    First sphere                3.8847E-02
    Second sphere               5.9132E-02
    Third sphere                7.2068E-02
Total Particle Mass
    Total Particle Mass         1.0000E-01
Penetration from PIR
    Axial Penetration           7.7220E-01
    Radial Penetration           8.0765E-01
    Normal Penetration           2.4617E-01
    Spray Angle                  3.9586E+01
Penetration from Location
    Axial Penetration           7.7220E-01
    Radial Penetration           8.0765E-01
    Normal Penetration           2.4617E-01
    Spray Angle                  4.6757E+01

Water 2

User Routine Histo
User Routine Sphere
    First sphere                4.5829E-02
    Second sphere               6.1053E-02
    Third sphere                7.3941E-02
Total Particle Mass
    Total Particle Mass         1.0000E-01
Penetration from PIR
    Axial Penetration           7.8456E-01
    Radial Penetration           9.6701E-01
    Normal Penetration           6.7314E-01
    Spray Angle                  8.7652E+01
```

## 8.9.2. List of Particle Variables

When simulating particle-laden flows, several variables referring to the particles are written to the results file and can be used for post-processing. For details, see [Particle Variables Generated by the Solver in the CFX Reference Guide](#).

## 8.10. Particle Solver Control

The following topics are discussed in this section:

- 8.10.1. Particle Coupling Control
- 8.10.2. Particle Under Relaxation Factors
- 8.10.3. Particle Integration
- 8.10.4. Particle Termination Control
- 8.10.5. Particle Ignition
- 8.10.6. Particle Source Smoothing
- 8.10.7. Vertex Variable Smoothing
- 8.10.8. Particle Source Control

The particle integrator is completely distinct from the normal CFD solver, so separate control parameters are required. The most important control is setting the coupling between the flow calculation and the particle integration - how frequently in terms of flow iterations the particle integration is carried out.

The `Forward Euler` method is the only integration method available. The time step is implicitly determined by the **Number of Integration Steps per Element** setting.

### 8.10.1. Particle Coupling Control

#### 8.10.1.1. First Iteration for Particle Calculation

This parameter sets the iteration number when particles are first tracked. A few iterations should be completed to allow the continuous phase to settle down from the initial guess before particles are introduced. If the convergence behavior is not steady by this iteration number, then you can increase the value of the **First Iteration for Particle Calculation** parameter above default, which is 10 in a steady state simulation and 1 in a transient simulation.

When restarting a run, the iteration number refers to the total iteration number and not that of the current run.

This parameter applies to fully coupled particle phases and transient runs where the specified **First Iteration for Particle Calculation** refers to coefficient loop iterations.

#### 8.10.1.2. Iteration Frequency

Particles are injected during execution of the CFX-Solver at regular iteration intervals. The particles are then tracked using the fluid solution field from the previous iteration. Once the particle paths have been calculated, the particle sources to mass and momentum equations are calculated. The source terms are applied to the fluid equations at each subsequent iteration until they are recalculated at the next injection.

The **Iteration Frequency** parameter is the frequency at which particles are injected into the flow after the **First Iteration for Particle Calculation** iteration number. This introduces particle source terms that will often cause an immediate rise in the convergence residual levels. The iteration frequency allows the continuous phase to settle down between injections.

The default value for **Iteration Frequency** is 5 in a steady state simulation and 1 in a transient simulation.

If the continuous phase reaches its convergence criterion before the particle calculation reaches its own convergence criterion, then the code automatically overrides the value specified for the iteration frequency, and starts to track the particles on every iteration.

The parameter applies to fully coupled particle phases and transient runs where the specified iteration interval refers to coefficient loop iterations.

### 8.10.1.3. Particle Source Change Target

This parameter applies only to fully-coupled particle phases and is used to determine when the particle part of the calculation has converged, as follows:

The absolute value of the particle source for a given momentum equation is summed over all vertices; let this value be SUM. When the inequality [Equation 8-3](#) (p. 280) is satisfied for all momentum equations, the particle part of the calculation is deemed to have converged.

$$\frac{\text{SUM}_{\text{new}} - \text{SUM}_{\text{old}}}{\max(\text{SUM}_{\text{new}}, \text{SUM}_{\text{old}})} < \text{Particle Source Change Target} \quad (8-3)$$

The default value is 0.01 and it is unlikely that you will need to change this.

### 8.10.2. Particle Under Relaxation Factors

This parameter applies only to fully-coupled particle phases. Depending on the flow being solved, particles may introduce very large source terms in the hydrodynamic equations. In reacting flows, large source terms may be generated in the mass, scalar, and energy equations. In heavily laden flows, viscous drag may introduce large source terms in the momentum equations.

In some cases, these source terms may have a destabilizing influence on the convergence of the hydrodynamic equations, resulting in oscillations, or in severe cases, divergence. A simple example of the oscillatory behavior is in a reacting flow field containing burning solid particles. Consider the flow field contains an oxidant into which reacting particles are being injected. If there is sufficient particle mass to consume all of the oxidant, then the oxidant mass fraction approaches zero. The next time the particles are injected, there would be no oxidant, and therefore, no source terms would be generated. The oxidant concentration would return to its original value. Thus, the oxidant concentration may oscillate between zero and its maximum.

It is possible to minimize the oscillations by under-relaxing the particle source terms. This is done as follows:

$$S_F = (1.0 - U_F) S_F + U_F S_P \quad (8-4)$$

where:

$S_F$  = Source To Flow

$S_P$  = Source From Particles

$U_F$  = Under RelaxationFactor

### **8.10.2.1. Under Relaxation Factor for Velocity, Energy, and Mass**

In ANSYS CFX, particle source terms are generated for the momentum, heat and mass transfer equations. The Under Relaxation factors for velocity, energy, and mass provide damping for the above equation set. In a steady state calculation, the default value of 0.75 has been found to be sufficiently small to dampen solutions demonstrating oscillating convergence behavior due to particle sources. In a transient calculation, no under-relaxation is imposed, that is the default values of the under relaxation factors are 1.0. If convergence problems are found due to the particle transport coupling, this relaxation factor can be reduced. For details, see *Convergence Control for Particle Transport* (p. 295).

### **8.10.2.2. Under Relaxation Factor for First Particle Integration**

This relaxation factor is applied to particles sources into the fluid phase, if no old particle sources exist. By default, this factor is set to 0.75 for steady state runs and 1.0 for transient runs.

### **8.10.2.3. Under Relaxation at Time Step Start**

By default, no relaxation is applied to particle sources between time steps in a transient simulation. If convergence problems are found due to the particle transport coupling, this relaxation factor can be reduced.

## **8.10.3. Particle Integration**

### **8.10.3.1. Number of Integration Steps Per Element**

This setting controls the accuracy and time step of the particle tracking integration. A time step is chosen locally as the element length scale divided by the particle speed divided by the number of integration steps per element. The integration accuracy will be increased by using a higher number of integration steps at the expense of computational time. The default value of 10 is usually suitable.

### **8.10.3.2. Maximum Particle Integration Time Step**

This parameter can override the automatic time step obtained from the element size and the particle velocity. You might need to use it in bubbly flows with the virtual mass force being used.

### **8.10.3.3. Chemistry Time Step Multiplier**

When doing a calculation with multiphase reactions, the values of reactants decrease with time. If too big a time step is used, the values of reactants can become negative. To prevent this, a bound is placed on the particle integration time step. The Chemistry Time Step Multiplier is a factor (default of 1.0) that is bounded by the time it takes for a mass fraction to reach zero. If a smaller value is used, then the mass fraction will go towards zero. The need for this parameter is uncommon for most applications.

## **8.10.4. Particle Termination Control**

### **8.10.4.1. Maximum Tracking Time**

This is the real time during which the particles are integrated. This should be set to a time long enough for a particle to be tracked through the geometry but not too large or the computational cost of tracking particles which may become trapped in recirculation zones could become exceedingly large. The default value is 10 [s].

### 8.10.4.2. Maximum Tracking Distance

This is the distance over which particles are integrated. It should be large enough to enable a particle to be tracked through the geometry, but not too large or the computational cost of tracking particles which may become trapped in recirculation zones could become exceedingly large. The default value is 10 [m].

### 8.10.4.3. Maximum Number of Integration Steps

This is another control that can be used to terminate tracking of particles that may become trapped in recirculation zones. The number of integration steps is calculated as the number of integration steps per element multiplied by the number of elements crossed by a particle. The default value is 10,000. You can increase this number if you believe it will be exceeded by a particle following a normal route through the simulation.

### 8.10.4.4. Minimum Diameter

This parameter can be used for specifying the minimum allowed particle diameter. If the diameter falls below this value, then the tracking of particle is stopped. This parameter can be used for excluding particles below the specified minimum diameter, which no longer play any significant role in the simulation, and thus improves the computational time. The default value is  $10^{-8}$  [m].

### 8.10.4.5. Minimum Total Mass

This parameter can be used for specifying the minimum allowed particle mass. If the particle mass drops below this value, then the tracking of particle is stopped. This parameter can be used for excluding particles below the specified minimum total mass, which no longer play any significant role in the simulation, and thus improves the computational time. The default value is 0 [kg].

### 8.10.4.6. Mass Fraction Limits

For multi-component particles, parameters **Minimum Mass Fraction** and **Maximum Mass Fraction** can be used for specifying upper and/or lower limits for a particle component mass fraction together with the **Component Name** of the particle. If the mass fraction gets below or above the specified value, then tracking of the particle is stopped.

In the CFX-Pre user interface, you can specify the reference component name in the form of `<particle type>.<component name>`, for example, `Coal1.Ash`. Using this form restricts the use of mass fraction limits to the specified particle type only.

## 8.10.5. Particle Ignition

Particle Ignition is used to start the initial combustion process of reacting particles, which typically depends on the temperature of the Eulerian fluid phase around the particle. However, before the reactions are calculated, the fluid temperature will often be low. Therefore, this temperature can be temporarily increased to the specified **Ignition Temperature** the first time a particle is solved. Afterwards, the particle combustion itself should deliver enough energy in order to increase the fluid temperature above the required ignition temperature. The **Particle Ignition** capability is only available for steady-state simulations.

## 8.10.6. Particle Source Smoothing

A smoothing procedure similar to **Vertex Variable Smoothing** can be applied to the particle source terms, which are accumulated along the path of a particle through a control volume and stored at the corresponding vertex. This may help with convergence or grid independence.

Once **Particle Source Smoothing** is selected, choose a smoothing **Option**: Raw (no smoothing) or Smooth.

## 8.10.7. Vertex Variable Smoothing

Quantities of particles crossing a control volume are averaged and stored at the corresponding vertex. Due to the distribution of particle tracks in the domain this can result in non-contiguous vertex fields. The use of those vertex fields, for example in a CEL expression, could cause numerical problems. In these cases it may be helpful to smooth the particle vertex arrays. Only direct neighbors are involved in the smoothing process.

Once **Vertex Variable Smoothing** is selected, choose a smoothing **Option**: Raw (no smoothing) or Smooth.

## 8.10.8. Particle Source Control

For simulations with high particle loadings it might be necessary to limit the particle sources into the continuous phase to help avoid either convergence problems or solver crashes due to unphysical fluid states.

For steady state simulations, you can limit the source terms for particles by:

- [Particle Heat Source Bounding](#) (p. 284)
- [Particle Momentum Source Bounding](#) (p. 285)
- [Linearization of Particle Mass Sources](#) (p. 286)

For transient simulations, you can limit the source terms for particles only by [Linearization of Particle Mass Sources](#) (p. 286).

---

### Note

For transient simulations, there is currently no option for limiting particle heat and momentum source terms.

---

### Note

The application of source term bounding does not guarantee that a simulation will converge.

The following topics are discussed in this section:

- [8.10.8.1. Particle Heat Source Bounding](#)
- [8.10.8.2. Particle Momentum Source Bounding](#)
- [8.10.8.3. Linearization of Particle Mass Sources](#)
- [8.10.8.4. Particle Source Control Usage Notes](#)

### 8.10.8.1. Particle Heat Source Bounding

For energy sources due to convective heat transfer, you can limit the source terms by setting **Option** to `Correction Factor Bounding`.

You can use the **Stop Bounding after Iteration** option to limit the number of iterations that have source term bounding. The default value for this option is 40 iterations.

The particle convective energy source in the gas phase can be written as:

$$S_{p,E} = q (T_p - T_f) \quad (8-5)$$

where

$T_p$  is the particle temperature,

$T_f$  is the local fluid temperature, and

$q$  is a transfer coefficient.

[Equation 8-5 \(p. 284\)](#) is solved in the particle tracker at each particle iteration step and the accumulated sources are stored at a place where they are later on picked up in the energy assembly of the gas phase. By default, particles are not tracked after every fluid flow simulation, but in user defined intervals (default: every 5<sup>th</sup> fluid step in a steady state run). Whenever the particle tracker is run, new values for the particle sources are generated and these sources persist up to the next time particles are tracked. If the particle sources are just large enough, it might not be sufficient to just limit the sources once, when they are generated, but also every time they are picked up and used by the gas phase energy equation. This somehow mimics a 'low cost' particle tracking step, where only the energy sources are updated to account for changes in the fluid temperature (enthalpy) due to energy sources applied in previous flow solver steps.

The basis of the suggested modification is the equation for the particle convective energy source, [Equation 8-5 \(p. 284\)](#). This equation is reformulated as follows:

$$S_{p,E} = q (\bar{T}_p - T_{fl}) \quad (8-6)$$

where

$\bar{T}_p$  is the (average) particle temperature,

$T_{fl}$  the fluid temperature, and

$q$  is a transfer coefficient.

Building the ratio of  $S_E^n / S_E^o$  allows approximating the new value of the particle source term for the current iteration, taking the fluid temperature change from the 'old' ( $o$ ) to the current time step ( $n$ ) into account:

$$\frac{S_{p,E}^n}{S_{p,E}^o} = \frac{\bar{T}_p - T_{fl}^n}{\bar{T}_p - T_{fl}^o} \quad (8-7)$$

Note that in the above formulation the average particle temperature,  $\bar{T}_p$  from the last tracking step is used. This quantity is not changing in between successive tracking steps.  $S_{p,E}^o$  and  $T_{fl}^o$  are updated every time step.

The correction factor,  $\bar{T}_p - T_{fl}^n / \bar{T}_p - T_{fl}^o$  is limited to be in the range of [0,1]. This correction is applied before the particle source term is used by the gas phase energy equation.

---

### Note

The energy source due to mass transfer is not taken into account.

### 8.10.8.2. Particle Momentum Source Bounding

For momentum sources due to fluid drag, you can limit the source terms by setting **Option** to `Correction Factor Bounding`.

You can use the **Stop Bounding after Iteration** option to limit the number of iterations that have source term bounding. The default value for this option is 40 iterations.

Similar considerations as outlined in [Particle Heat Source Bounding](#) (p. 284), can be made to limit the particle momentum sources to the gas phase. Under the assumption that the particle drag is the major contributor to the particle momentum source term, it is possible to write the particle momentum source as:

$$S_{p,M} = q C_d |\vec{U}_S| (\vec{U}_p - \vec{U}_{Fl}) \quad (8-8)$$

where

$C_d$  is the particle drag coefficient,

$|\vec{U}_S|$  is the particle slip velocity,

$\vec{U}_F$  is the fluid velocity vector,

$\vec{U}_p$  is the particle velocity vector, and

$q$  is a coefficient, dependent on the fluid density,  $\rho_{Fl}$ .

Forming the ratio of  $S_{p,M}^n / S_{p,M}^o$  and rearranging the resulting equation for  $S_{p,M}^n$  gives:

$$S_{p,M}^n = S_{p,M}^o \frac{\rho_{Fl}^n C_d^n \left| \bar{U}_S^n \right|}{\rho_{Fl}^o C_d^o \left| \bar{U}_S^o \right|} \frac{(\bar{U}_P - \bar{U}_{Fl})^n}{(\bar{U}_P - \bar{U}_{Fl})^o} \quad (8-9)$$

Assuming that the drag coefficient,  $C_d$ , is determined by the Schiller-Naumann drag law

$$C_d = \frac{24}{Re_p} \left( 1 + 0.15 Re^{0.687} \right) \quad (8-10)$$

with

$$Re = \frac{d_p |U_s|}{\nu_{Fl}}$$

being the particle Reynolds number computed from the slip velocity between particles and fluid, the particle diameter and the fluid kinematic viscosity. Inserting the particle Reynolds number into [Equation 8-10](#) (p. 286) it is possible to simplify [Equation 8-9](#) (p. 286) to give:

$$S_{p,M}^n = S_{p,M}^o \frac{\rho_{Fl}^n}{\rho_{Fl}^o} \frac{1 + 0.15 \left| \bar{U}_S^n \right|^{0.687}}{1 + 0.15 \left| \bar{U}_S^o \right|^{0.687}} \frac{(\bar{U}_P - \bar{U}_{Fl})^n}{(\bar{U}_P - \bar{U}_{Fl})^o} \quad (8-11)$$

[Equation 8-11](#) (p. 286) is used to determine a factor that limits the particle momentum source by taking fluid velocity and density changes into account. The correction factor is limited to be in the range of [-1,1].

### 8.10.8.3. Linearization of Particle Mass Sources

In ANSYS CFX, particle mass sources are, by default, not linearized with respect to the fluid mass fraction (mass fraction equations) or the fluid pressure (continuity equation). For cases with relatively small mass transfer rates, linearization of the particle mass sources may not play an important role. This may be different, though, for cases where the particle mass transfer is large enough to significantly affect the fluid energy and/or the fluid momentum. In these cases, the use of mass source linearization may be crucial for a successful simulation run.

Linearization of particle mass sources can be included by setting **Option** to `Source Coefficient`

with respect to `Mass Fraction`. With this setting, the derivatives  $\frac{d\dot{m}_c}{dY_{F,c}}$  in the following

subsections are included in the linearization of sources in the equation for mass of the particle component (see [Interphase Transfer Through Source Terms in the CFX-Solver Theory Guide](#)).

---

#### Note

Linearization is not available for multiphase reaction and combustion cases.

### 8.10.8.3.1. Simple Mass Transfer Model

Each component of mass being transferred between the continuous and particle phases satisfies the equation:

$$\dot{m}_c = -\pi d_p \rho_F D_F Sh \left( E \cdot Y_{p,c} - Y_{F,c} \right) \quad (8-12)$$

In [Equation 8-12 \(p. 287\)](#),  $m_c$  is the mass of the constituent in the particle,  $Y_{p,c}$  is the mass fraction of component  $c$  in the particle,  $Y_{F,c}$  is the mass fraction of component  $c$  in the surrounding fluid,  $E$  is the equilibrium mass fraction ratio,  $\rho_F D_F$  is the dynamic diffusivity of the mass fraction in the continuum, and  $Sh$  is the Sherwood number.

For the mass fraction equation of species,  $c$ , the derivative of [Equation 8-12 \(p. 287\)](#) with respect to  $Y_{F,c}$  is required. This derivative can be written as:

$$\frac{d\dot{m}_c}{dY_{F,c}} = \pi d_p \rho_F D_F Sh \quad (8-13)$$

[Equation 8-13 \(p. 287\)](#) is used to compute the source term coefficient in the gas phase mass fraction equation.

The derivative of the mass transfer rate with respect to the fluid pressure is zero, because the mass transfer rate does not explicitly depend on the fluid pressure.

### 8.10.8.3.2. Liquid Evaporation Model

The liquid evaporation model is a model for particles with heat transfer and mass transfer, and in which the continuous gas phase is at a higher temperature than the particles. The model uses two mass transfer correlations depending on whether the droplet is above or below the boiling point. This is determined through an Antoine equation.

#### 8.10.8.3.2.1. Droplet Temperature Below Boiling Point

The mass transfer rate from the particle to the gas phase is determined by:

$$\dot{m}_c = \pi d_p \rho_F D_F Sh \frac{W_c}{W_{Fl}} \log \left( \frac{1 - X_{S,c}^V}{1 - X_{vap,c}^V} \right) \quad (8-14)$$

where  $m_c$  is the mass of the constituent in the particle,  $\rho_F D_F$  is the dynamic diffusivity of the mass fraction in the continuum, and  $Sh$  is the Sherwood number.  $W_c$  and  $W_{Fl}$  are the molecular weights of the vapor and the mixture in the continuous phase,  $X_{vap,c}^V$  is the molar fraction in the gas phase, and  $X_{S,c}^V$  is the equilibrium mole fraction at the droplet surface defined as the component vapor pressure divided by the pressure in the continuous phase.

The derivative of [Equation 8-14 \(p. 287\)](#) with respect to the fluid component mass fraction is:

$$\frac{d\dot{m}_c}{dY_{F,c}} = \pi d_p \rho_F D_F Sh \frac{1}{1 - \frac{X_{F,c} W_{Fl}}{W_c}} \quad (8-15)$$

As with the simple mass transfer model, there is no linearization applied with respect to the fluid continuity and volume fraction equations.

### 8.10.8.3.2.2. Droplet Temperature Above Boiling Point

If the particle is boiling, the mass transfer into the gas phase is driven by convective heat transfer and radiative heat transfer to the particle:

$$\dot{m}_c = - \frac{Q_{conv} + Q_{rad}}{V} \quad (8-16)$$

$Q_{conv}$  and  $Q_{rad}$  are the rates of convective heat transfer and radiative heat transfer to the particle, re-

spectively.  $V$  is the latent heat of vaporization. The mass transfer rate in the boiling regime does not

depend on the fluid component mass fraction,  $Y_c$ , nor on the fluid pressure,  $p$ . Therefore both derivatives

are zero:

$$\frac{d\dot{m}_c}{dY_c} = \frac{d\dot{m}_c}{dp} = 0 \quad (8-17)$$

### 8.10.8.4. Particle Source Control Usage Notes

- Cases with mass transfer (Ranz Marshall, Liquid Evaporation model) that show robustness problems should use particle mass source linearization rather than bounding heat and momentum sources only. In many cases, unphysical temperatures and/or flow fields are the result of overly large mass transfer rates and can be addressed most effectively by linearizing the particle mass sources.
- Note that **Particle Heat Source Bounding** only bounds sources that are due to convective heat transfer. In cases where convective heat transfer is small compared to other heat sources (for example, reactions, radiation), this option might not be sufficient to guarantee bounded fluid temperatures.
- Note that **Particle Momentum Source Bounding** only bounds sources that are due to particle drag. In cases where the momentum sources due to particle drag are small compared to other momentum sources (for example, pressure gradient) this option might not be sufficient to guarantee bounded fluid velocities.
- Note that particle source term bounding is applied over only a certain number of flow iterations (default: 40). Once this limit is reached, source term bounding is tuned off. In some cases, this limit might not be sufficient to let the flow solver establish a reasonable flow field; in such cases, the limit needs to be increased. The limiting iteration number can be set via the **Stop Bounding after Iteration** setting.
- In many cases where it is necessary to use a source term bounding option, it might also be necessary to set the expert parameter `pt fluid var interpolation option` to 0. This setting should

only be used to improve robustness and is no longer required once a stable flow field solution has been established. For details on this expert parameter, see [Particle-Tracking Parameters](#) (p. 478).

## 8.11. Multiphase Reactions and Combustion

Multiphase Reactions refer to reactions involving components in different phases, and is a combination of simultaneous phase change and conversion of some materials into others. The capability is available for particle tracking calculations, but not Eulerian-Eulerian multiphase flows for this release of ANSYS CFX. When setting up a multiphase reaction, the **Combustion Model** setting in the **Reaction** details view is not required because `Finite Rate Chemistry` is the only available option for multiphase reactions (although for gas phase reactions, other reaction/combustion models may be applied).

A general multiphase reaction generates three classes of fluxes:

- Component Mass Sources
- Interphase Mass Transfer
- Interphase Energy Transfer

Multiphase reactions are specified in the **Reaction** details view by setting the **Option** to `Multiphase` on the **Basic Settings** form. For details, see [Multiphase: Basic Settings in the CFX-Pre User's Guide](#).

### 8.11.1. Specification of a Binary Mixture

You should define a Homogeneous Binary Mixture (see [Material Details View: Homogeneous Binary Mixture in the CFX-Pre User's Guide](#)) that links the primary particle and gas phase materials. Primary materials are the materials that characterize the mass transfer between the particle and the gas phase. For example, when modeling decomposition of raw coal into gaseous volatiles and char, the Homogeneous Binary Mixture should be set up for 'Raw Coal' and 'Volatiles'. This allows the particle solver to calculate characteristic numbers for the particle (for example, Reynolds, Sherwood, and Nusselt numbers) based on properties in the particle boundary layer. These properties are calculated using the Antoine equation (vapor pressure equation) that is specified in the Homogeneous Binary Mixture.

### 8.11.2. Reactants/Products

Reactants and products are specified in terms of parent and child materials. The parent material defines the phase in which species react, and the child materials represent the reacting species. For this release of ANSYS CFX, reactants from different phases can only be specified for the char oxidation reactions (`Field Char Oxidation` or `Gibb Char Oxidation`). Arrhenius type multiphase reaction rates require that all reactants belong to the same phase. The stoichiometry for multiphase reactions is specified by means of mass coefficients rather than stoichiometry coefficients referring to moles.

#### 8.11.2.1. Example

As an example, consider a simplified case of coal reacting with oxygen in the reaction  $C + O_2 \rightarrow CO_2$ . The **Parent Materials List** on the **Reactants** tab contains two materials, `Coal` (a pure substance containing carbon) and `Gas mixture` (a variable composition mixture containing `O2`, `CO2` and `N2`). The child material for `Coal` would be set to `Carbon`, and the child material for `Gas Mixture` would be set to `O2`. It follows that on the **Products** tab, the **Materials List** contains `Gas Mixture` as the parent material, which in turn would contain `CO2` as its child.

**Note**

The above is presented only as an illustration of the use of the parent/child material structure.

### 8.11.3. Multiphase Reactions

The **Multiphase Reactions** tab is used to define the reaction properties for three different types of reaction rates. The `Arrhenius` option uses a very similar implementation for multiphase reactions as for single phase reactions. For details, see *Arrhenius* (p. 301). Because reactants using Arrhenius reaction type must all come from the same phase in this release of ANSYS CFX, the temperature required to calculate the Arrhenius rate comes from the single permitted phase. Additional information on heat release is available in *Heat Release/Heat Release Distribution* (p. 291).

Typical coal combustion reactions also require a model for char oxidation. Char oxidation requires higher temperatures than devolatilization and therefore occurs after devolatilization. In ANSYS CFX, char oxidation is modeled either as a global reaction of order unity (Field) or using a simple analytic approach to the diffusion of oxygen within the pores of the char particles (Gibb).

#### 8.11.3.1. Mass Arrhenius

The `Mass Arrhenius` option is the same implementation as used for single-phase reactions. For details, see *Arrhenius* (p. 301).

#### 8.11.3.2. Field Char Oxidation Model

Theory documentation for this model is available in *Field in the CFX-Solver Theory Guide*.

In the field model, a char particle is considered to be a spherical particle surrounded by a stagnant boundary layer through which oxygen must diffuse before it reacts with the char. The oxidation rate of the char is calculated on the assumption that the process is limited by the diffusion of oxygen to the external surface of the char particle and by the effective char reactivity. Additional information on Heat Release is available in *Heat Release/Heat Release Distribution* (p. 291).

#### 8.11.3.3. Gibb Char Oxidation Model

Theory documentation for this model is available in *Gibb in the CFX-Solver Theory Guide*.

The alternative char oxidation model, the Gibb model, takes into account the diffusion of oxygen within the pores of the char particle. The parameters required for this model include the void fraction  $\varepsilon$  of the char particle, the particle volume/internal surface area ratio  $a$ , the effective internal diffusion coefficient  $D_p$  of oxygen within the pores, and the molar ratio  $\varphi$  of carbon atoms/oxygen molecules involved in the oxidation processes. The molar ratio is determined by the  $\text{CO} \leftrightarrow \text{CO}_2$  equilibrium, and the relevant input data is provided by the values entered in the **Char Product Ratio** area.

#### 8.11.3.4. Particle User Routine

This option allows you to use a User Fortran subroutine to calculate the reaction rate of a multiphase reaction. General information on creating user routines is available in *User Fortran* (p. 483).

In the `<install_dir>\examples\UserFortran` directory, you can find a reaction rate routine, `pt_reaction.F`, and corresponding CCL template, `pt_reaction.ccl`.

### 8.11.3.5. Heat Release/Heat Release Distribution

Heat release specifies how much heat is released during a multiphase reaction, and heat release distribution specifies how the heat is distributed over the participating phases. There are two principal methods that define the amount of heat released; it can either be calculated from the material reference enthalpies, or can be user specified.

If the **Heat Release** option is set to `From Material Properties`, the heat release is calculated from material reference enthalpies. When set to `Specific Enthalpy`, the value of heat released per unit mass of reactants must be specified. Because none of the reactants are known to ANSYS CFX as the "fuel" component at this stage, you must also select the parent phase and reference material, so that the heat release is correctly related to the mass of the true fuel material. The Latent Heat option is equivalent to the `Specific Enthalpy` setting, except that the value for heat release is specified with the opposite sign.

The `From Material Properties` option for **Heat Release** is advantageous because the calculation guarantees the conservation of energy (that is, if a fuel and oxidant react to form some products by two separate competing reactions, then the amount of heat released automatically is the same for both reaction paths). The disadvantage is that correct reference specific enthalpies must be found and entered when the material properties are defined. Reference specific enthalpies can be difficult to determine, especially for materials that are not pure substances but mixtures of inconsistent definition (such as coal). In such cases, it is much more convenient to specify the heat release for the reaction. Heat releases for reactions can be measured directly and are therefore usually available for a given application. When specifying heat release directly, however, you must ensure that you define consistent values for heat release in the case of competing reactions or reaction paths.

The distribution of released heat to the participating phases is defined by specifying the fraction of total heat release that the individual phases receive. When setting the **Heat Release Distribution** parameters, the parent materials list must contain only materials that occur in reactants and/or products. For each phase selected, a value fraction of heat released must be specified (for example, for a gas phase receiving 25% of the heat released, the value would be 0.25). The total of all heat fractions should sum to unity.

### 8.11.4. Hydrocarbon Fuel Model Setup

The hydrocarbon fuel model offers a simple method of creating a solid particulate or liquid droplet combustion model starting from the ultimate and proximate analysis of the fuel. It uses the Lagrangian particle transport model to track representative fuel particles and uses the Eddy Dissipation model and/or the Finite Rate Chemistry model for the combustion of the volatile gases in the gas phase. Devolatilization (or pyrolysis) of the hydrocarbon fuel particles and oxidation of the resultant char are modeled by semi-empirical kinetic models with parameters that depend on the fuel composition and a standard fuel analysis. The model was mainly designed for the modeling of pulverized coal combustion but can also be applied to combustion of other solid hydrocarbon fuels in particulate form or liquid sprays.

This section describes the setup for the hydrocarbon fuel model. Three variants are covered here:

- Proximate/ultimate fuel analysis starting from the standard library template
- Proximate/ultimate fuel analysis when setting up from scratch
- Using generic multiphase reactions setup

The first method, using the fuel analysis directly, is recommended. The third method is mainly included for compatibility with earlier releases of the software.

### 8.11.4.1. Setup using Library Template (Recommended)

The recommended way of setting up the hydrocarbon fuel model is to start by loading from the library provided. This approach uses the full functionality of the model, but avoids unnecessarily repeating the definition of materials and reactions. All fuel dependent data, like material composition and heat release, is gathered in the hydrocarbon fuel material definition. Therefore, after loading the library, most objects do not need to be changed by you. In most cases, it will be sufficient to only edit the hydrocarbon fuel material object.

The pre-defined multiphase reactions assume certain names for the hydrocarbon fuel material and for the gas mixture. The name of the hydrocarbon fuel is `HC Fuel`. The gas mixture material name depends on the fuel-nitrogen model: `Gas Mixture HCN NO` with the fuel-nitrogen model; and `Gas Mixture` without.

The hydrocarbon fuel model without the fuel-nitrogen sub-model can be set up using the provided library as follows:

1. From either the `Materials` or the `Reactions` object, select **Import Library Data** from the context menu to import all objects from the hydrocarbon fuel library `Hydrocarbon_Fuel.ccl` located in the `reactions-extra/` directory. Additional materials and reactions will be included automatically from the standard libraries. Note that when loading the `Hydrocarbon_Fuel.ccl` file using the general **File > Import CCL...** route, then some additional materials and reactions will not be loaded automatically, thus causing corresponding physics error messages. In this case the missing materials and reactions need to be loaded manually in order to resolve the error messages.
2. Edit the imported material `HC Fuel`. The parameters on the **Proximate/Ulimate Analysis** tab need to be adjusted in order to match the actual fuel specification:
  - a. Proximate analysis
    - As Received (mass fractions sum to 1)
    - Dry Ash Free (fixed carbon and volatiles sum to 1)
  - b. Ulimate analysis
    - As Received (mass fractions sum to 1 – ash – moisture)
    - Dry Ash Free (mass fractions sum to 1)
  - c. Heating value
  - d. Volatiles yield enhancement (ratio of actual volatile yield to proximate yield) - Defaults for remaining parameters
3. Create the domain:
  - a. Fluid material: `Gas Mixture`
  - b. Particle material `HC Fuel`
  - c. Multiphase reactions:
    - `HC Fuel Devolat`
    - `HC Fuel Char Field` or `HC Fuel Char Gibb`
  - d. Heat transfer model fluid dependent:

- Fluid: Thermal or Total Energy
  - Particle: Particle Temperature
- e. Combustion model fluid dependent:
- Fluid: Eddy Dissipation
- f. Radiation model fluid dependent:
- Fluid: Pl, Discrete Transfer, or Monte Carlo
- g. Fluid component details:
- **N2**: Constraint
  - Others: Automatic
- h. Particle diameter change during pyrolysis (Fluid: HC Fuel):
- **Option** = Swelling Model
  - **Reference Material** = Raw Combustible
  - **Swelling Factor** = <real> # 0.0 for constant diameter
- i. Thermal radiation transfer (Fluid Pair: HC Fuel | Gas Mixture HCN NO):
- **Option** = Blended Particle Emissivity
  - **Reference Material** = Raw Combustible
  - **Base Emissivity** = <real> # Emissivity of char and ash
  - **Blend Emissivity** = <real> # Emissivity of raw combustible
4. Set particle ignition under **Solver Control/Particle Control**:
- **Particle Ignition / Ignition Temperature** = 1000 [K]

No boundary conditions for particle components will be defined. The remaining setup is the same as for pure-material particles and a variable composition fluid.

The fuel-nitrogen model can be enabled by the following changes to the above procedure:

1. Edit the HC Fuel material. On the **Mixture Materials** tab change the option in the **Gas Mixture section**:
  - a. **Gas Mixture/Option** = Mixture with HCN NO
  - b. **Mixture Material** = Gas Mixture HCN NO
  - c. Component materials:
    - HCN Material = HCN
    - HCO Material = HCO
    - NO Material = NO

- d. Remaining parameters unchanged
2. Change the fluid and the multiphase reactions on the **Edit Domain** form:
    - a. Fluid material Gas Mixture HCN NO
    - b. Multiphase reactions:
      - HC Fuel Devolat HCN
      - HC Fuel Char Field HCN or HC Fuel Char Gibb HCN

### 8.11.4.2. Setup from Scratch (Experts)

The setup from scratch is usually not required and is intended for expert users only. For this procedure, the definition of material and reaction objects is completely left to you. When doing so, one needs to keep in mind that the hydrocarbon fuel model can only detect certain types of reactions for computation of mass coefficients and stoichiometric coefficients. The auto-computed coefficients are reported to the 'out' file and should be checked for consistency.

In order to set up the coal model from scratch, the following additional steps are required to create the required materials and reactions:

1. Create component materials:
  - a. Gas phase components: Fuel Gas, O<sub>2</sub>, CO<sub>2</sub>, H<sub>2</sub>O, N<sub>2</sub>, ..., NO, HCN, HCO
  - b. Hydrocarbon fuel components: Ash, Char, Raw Combustible
2. Create gas phase reactions:
  - a. Fuel gas oxidation
  - b. Pollutants reactions (for example, for NO)
3. Create mixture materials:
  - a. Homogeneous binary mixture: Fuel Gas, Raw Combustible
  - b. Gas phase reacting mixture: components from [Step 1.a](#) (p. 294); reactions from [Step 2](#) (p. 294)
  - c. Hydrocarbon fuel: Proximate/ultimate analysis data; homogeneous binary mixture material; gas mixture material
4. Create multi-phase reactions:
  - a. Devolatilization (with or without fuel nitrogen)
  - b. Char oxidation (with or without fuel nitrogen)

From this point on the setup can be continued as described in section [Setup using Library Template \(Recommended\)](#) (p. 292), with the materials and reactions replaced with those created locally.

### 8.11.4.3. Using Generic Multiphase Reactions Setup

A third way of specifying combustion of a hydrocarbon fuel is to use the generic multiphase multi-component and reaction machinery. In this case, it is up to you to set the appropriate particle component

boundary values, stoichiometric coefficients for reactions, and heat release for the gas phase reactions (by means of volatiles reference enthalpy).

## 8.12. Restrictions for Particle Transport

The following limitations apply to the Lagrangian particle tracking model in ANSYS CFX:

- When combined with the Eulerian-Eulerian multiphase model, only a single continuous phase may contain particles. There is no exchange of momentum between particles and a dispersed Eulerian phase.
- There are no particle source terms to the turbulence equations; therefore, turbulence is not modulated by the discrete phase.
- Particle interactions might be important in flows where the discrete phase volumetric concentration is greater than 1% (ref. [67]). In such cases, the solid particle-particle interaction should be used.
- You cannot create Additional Variables in particles.
- In steady state simulations that involve mesh movement, particles are still solved at the user-specified intervals. For accuracy reasons we recommend to solve particles after each time step by setting the solution interval to '1'. Note that this will also ensure that particle mass flows through GGI interfaces will always be written to the results file.

## 8.13. Restrictions for Particle Materials

A particle may consist of an arbitrary number of different materials. For each material the following restrictions apply:

- Only constant value properties are supported for density, viscosity, and conductivity
- For material specific heat values, either constant values, Zero Pressure Polynomials, or NASA polynomials are supported

## 8.14. Convergence Control for Particle Transport

Within the particle transport model, the total flow of the particle phase is modeled by tracking individual particles from their injection point until they escape the domain or some integration limit criterion is met. The fluid affects the particle and conversely, there is a counteracting influence of the particle on the fluid flow. This effect is termed coupling between the phases. Particle source terms are generated for each particle as they are tracked through the flow. The sources are applied in the control volume that the particle is in during the time step.

Depending on the flow being solved, particles may introduce very large source terms to the hydrodynamic equations. In reacting flows, large source terms may be generated in the mass, component mass fraction, and energy equations. In heavily laden flows, viscous drag may introduce large source terms in the momentum equations. In some cases, these source terms may have a destabilizing influence on the convergence of the hydrodynamic equations, resulting in oscillations, or in severe cases, divergence.

A possibility to minimize the oscillations is to under-relax the particle source terms more strongly (that is, to decrease the values of the following CCL parameters from their defaults of 1.0 to a smaller value):

Source Term	CCL Parameter
Momentum	Velocity Under Relaxation Factor

Source Term	CCL Parameter
Energy	Energy Under Relaxation Factor
Mass	Mass Under Relaxation Factor

The effects of the sources on the continuous phase are often linearizable, because drag depends upon the fluid velocity, and so on. The linear coefficient is calculated as the derivative of the source with respect to the relevant fluid variable (for example,  $dS/dV_eIF$  for momentum). Sometimes, it is useful for convergence to multiply this linear coefficient by a factor ( $<10$ ) using the expert parameter: `pt_linear_src_coef_multiplier`

In a rapidly changing fluids solution, you may want to increase the iteration interval from its default value of 5, updating tracks and sources less often, so that the flow has a chance to relax between successive calls to the particle solver.

The particle source terms acting on the fluid phase are proportional to the `Particle Number Rate` (that is, the number of physical particles that a computational particle represents). The convergence of a simulation can be improved if a sufficiently large number of particles are tracked.

In addition to the already mentioned steps, it can be helpful to start a particle transport simulation with less than the full particle mass flow rate, and gradually increase the mass flow rate using a ramping function.

## 8.15. Expert Parameters for Particle Tracking

Expert parameters can be used to control the behavior of the particle solver in ANSYS CFX. For the full list of expert parameters for particle tracking, see [Particle-Tracking Parameters \(p. 478\)](#).

## 8.16. Particle Diagnostics

Additional particle diagnostics output is available in the out file and monitor file of the CFX-Solver. This information helps to evaluate the solution process of the particles. It delivers integrated flows of the particle mass, momentum, and energy in and out of the domain and shows the global influence of the particles on the continuous phase. The output provides information about the convergence of the particle solver and summarizes the fate information for all injected particles

For additional information, see [Particle Fate Diagnostics in the CFX-Solver Manager User's Guide](#).

## 8.17. Integrated Particle Sources for the Coupled Continuous Phase

The global balances for the coupled continuous phase also contain the contribution from the coupled particle types.

## 8.18. Transient Simulations: What is Different for Particles?

Although this topic has been discussed in many areas of the particle tracking modeling documentation, this section attempts to summarize the most important differences between steady state and transient runs with respect to the particle solver.

In a **transient run**:

- You have to specify the number of particles injected per time step and not the total number of injected particles.

- Iteration control of the particle solver refers to the coefficient loop within a time step and not to the outer loop iteration.
- Different under-relaxation coefficients are used for the generated particle sources.
- The solver OUT file of a transient particle run contains additional information about time integrated particle boundary fields, mass, momentum, and energy flows.



---

## Chapter 9: Combustion Modeling

---

CFX includes combustion models to allow the simulation of flows in which combustion reactions occur. The following models are currently available:

- The eddy dissipation model (EDM)
- A finite rate chemistry model (FRC)
- A combined FRC/EDM model
- The laminar Flamelet model for diffusion flames
- A model for premixed or partially combustion using the Flamelet model for the burned mixture.

The eddy dissipation model was developed for use in a wide range of turbulent reacting flows covering premixed and diffusion flames. Because of its simplicity and robust performance in predicting turbulent reacting flows, this model has been widely applied in the prediction of industrial flames.

The finite rate chemistry model enables the computation of reaction rates described by the molecular interaction between the components in the fluid. It can be combined with the eddy dissipation model for flames where chemical reaction rates might be slow compared with the reactant mixing rates. It also enables the use of user-customized reaction rate expressions via CFX Expression Language (CEL).

These models determine the rates at which a component is consumed or created in a single reaction step during the combustion process. For multiple step reactions, the reactions are added to obtain the total reaction rate.

The flamelet model can provide information on minor species and radicals such as CO and OH, and accounts for turbulent fluctuations in temperature and local extinction at high scalar dissipation rates, for the cost of solving only two transport equations.

The burning velocity model (BVM) and the extended coherent flame model (ECFM) model the propagation of a premixed or partially premixed flame by solving a scalar transport equation for the reaction progress. The BVM uses an algebraic correlation for modeling the turbulent burning velocity (propagation speed of the flame in turbulent flow). When using the ECFM, the turbulent burning velocity is closed by solving an additional transport equation for the flame surface density.

Both the BVM and ECFM are combined with the flamelet model in order to describe the composition and properties of the burnt mixture. For partially premixed cases the flamelet model also models diffusion flame 'tails', which may occur in the burnt mixture behind the flame front.

In the CFX-Solver, a limit has not been set for the maximum number of reaction steps or components in a fluid. However, the larger the number of components, the larger the memory requirements will be.

---

### Note

You should be familiar with the multicomponent flow chapter before reading this chapter; for details, see [Multicomponent Flow](#) (p. 18). Multiphase reactions are also available in CFX; for details, see [Multiphase Reactions and Combustion](#) (p. 289).

This chapter describes:

- 9.1. Reaction Models
- 9.2. Using Combustion Models
- 9.3. Eddy Dissipation Model
- 9.4. Finite Rate Chemistry Model
- 9.5. Combined EDM/Finite Rate Chemistry Model
- 9.6. Reaction-Step Specific Combustion Model Control
- 9.7. Laminar Flamelet with PDF Model
- 9.8. Burning Velocity Model (Premixed or Partially Premixed)
- 9.9. Extended Coherent Flame Model (ECFM)
- 9.10. Residual Material Model
- 9.11. Flamelet Libraries
- 9.12. Autoignition Model
- 9.13. NO Model
- 9.14. Chemistry Post-Processing
- 9.15. Soot Model
- 9.16. Phasic Combustion
- 9.17. General Advice for Modeling Combusting Flows in CFX

## 9.1. Reaction Models

The following information relates to the setting up of reactions using the **Reaction** details view. For details, see *Reactions in the CFX-Pre User's Guide*.

### 9.1.1. Naming Convention for Reaction Schemes

For the predefined reaction schemes provided in the REACTIONS library, the following conventions apply:

- Reactions with `WDn` in the name correspond to the appropriate Westbrook and Dryer [66] reaction scheme with  $n$  number of steps.
- Reactions with `WGS` in the name correspond to reactions with the Water Gas Shift forward/backward reaction:



- Reactions with `NO PDF` in the name are schemes that include the NO formation model. For details, see *NO Model* (p. 330). The reaction rates for NO formation account for turbulent fluctuations of temperature.
- It is recommended that you do not use reactions with just `NO` in the name, as these schemes don't account for temperature fluctuations when computing reaction rates of NO, and are therefore less accurate.

For the `WDn` reactions, single reaction step schemes can still be described as multi-step when the purpose of the additional step is to add an additional passive component (N2) to a single step reaction. The reaction step itself remains single step in these cases.

### 9.1.2. Reaction Rate Types

On the **Reaction Rate** tab of a reaction definition, the following types of reaction rate may be available:

- *Arrhenius* (p. 301)
- *Arrhenius with Temperature PDF* (p. 301)

- [Expression](#) (p. 301)
- [Equilibrium](#) (p. 302)

### 9.1.2.1. Arrhenius

Two forms of the Arrhenius dependency are supported in CFX. The first is given by:

$$k = A T^{\beta} \exp \left( \frac{-E}{R T} \right) \quad (9-2)$$

where  $k$  is reaction rate coefficient,  $A$  is the pre-exponential factor,  $E$  is the activation energy,  $R$  is the universal gas constant,  $\beta$  is the temperature exponent and  $T$  is the temperature. A modified form:

$$k = A T^{\beta} \exp \left( \frac{-T_A}{T} \right) \quad (9-3)$$

where  $T_A = E/R$  is the activation temperature.

The pre-exponential factor may be an expression in space, time, absolute or static pressure, turbulence quantities ( $k, \varepsilon$ ), molar mass or mixture composition (species mass fractions, molar fractions, mass concentrations, molar concentrations).

The units of the pre-exponential factor are:

$$\text{time}^{-1} \left( \text{mol m}^{-3} \right)^{(1-n)} \quad (9-4)$$

where  $n$  is the sum of the number of reaction orders, (plus 1 for a third body term, if present). As an example, for a reaction with two reactants, both with a reaction order of 1, and a third body term,  $n = 2+1 = 3$ . The physical dimensions for the pre-exponential factor in this case are:

$$\text{s}^{-1} \text{ mol}^{-2} \text{ m}^6 \quad (9-5)$$

### 9.1.2.2. Arrhenius with Temperature PDF

Similar instructions apply here as for Arrhenius, except that a temperature limit list is required to describe the probability density function. For details, see [Arrhenius](#) (p. 301). The probability density function is a mathematical model that describes the probability of events occurring over time. This function is integrated to obtain the probability that the event time takes a value in a given time interval.

The temperature limit list requires the entry of the upper and lower bounds for temperature integration range (2 values).

### 9.1.2.3. Expression

To enter an expression, click the enter expression icon and type the name of the expression into the box. For details, see [Expressions in the CFX-Pre User's Guide](#).

### 9.1.2.4. Equilibrium

For any reversible reaction,  $a [A] \leftrightarrow b [B]$ :

$$K = [B]^b / [A]^a \quad (9-6)$$

where  $a$  and  $b$  represent the number of moles of materials A and B in the reaction. While quantities  $[A]$  and  $[B]$  represent the molar concentrations and  $K$ , the equilibrium constant (which is dependent on temperature, enthalpy, entropy). The forward and backward reaction rates are defined as:

$$R_f = F_k [A]^a \quad (9-7)$$

and

$$R_b = B_k [B]^b \quad (9-8)$$

At equilibrium,  $R_f = R_b$ , and therefore:

$$B_k [B]^b / F_k [A]^a = 1 \quad (9-9)$$

Where  $F_k$  is the forward rate and  $B_k$  is the backward rate. When applied, the Arrhenius Reaction Model calculates the rate according to the following:

$$B_k = \frac{F_k}{K} \quad (9-10)$$

The equilibrium option is only available if the forward reaction rate is set to Arrhenius.

A reaction is reversible when, for each reactant or production component, the reaction order is equal to the stoichiometric coefficient.

## 9.2. Using Combustion Models

To access Combustion Models in CFX, you must first set up a reacting fluid. This step is carried out in the **Material** details view. For details, see [Material Details View: Reacting Mixture in the CFX-Pre User's Guide](#). There are a number of pre-defined reactions that can be selected, and the **Reaction** details view enables you to create custom reactions for use in CFX-Pre. For details, see [Reactions in the CFX-Pre User's Guide](#).

If you want to specify any non-reacting components that will also be present in the domain, you can add them when creating the reacting mixture. Keep in mind that the thermodynamic properties for materials from the CFX-Pre database may not be appropriate (constant specific heat capacity) and may produce poor results if a passive component has a significant mass fraction.

The name of each material in the tree view indicates the range of validity for thermodynamical data. As an example Carbon Monoxide at STP has constant properties (density, specific heat capacity,

and so on) for standard temperature and pressure. For reacting mixtures, materials from the `Gas Phase Combustion` material group should be used. These materials have variable properties and consistent reference enthalpies for heat release. These materials typically have the chemical formulae as their material name (for example, `CO`).

All liquids and solids in the `MATERIALS` library are defined with constant specific heat capacity. The variable `Cp` is included for all ideal gases except for `Air Ideal Gas`.

You may want to keep a CCL file containing any customized materials and reaction definitions and then import this file into CFX-Pre when needed.

Thermodynamic data for the material properties used in CFX-Pre was obtained from [26]

### 9.2.1. Which Model is the Most Appropriate?

The following table is meant as a guide in helping you choose which combustion model is most suitable for your simulation. You are also encouraged to read the following sections, which describe how to set up each model to obtain the most accurate results.

Eddy Dis- sipation Model	Turbulent  Fast reaction compared to turbulent time scale (high Damköhler number)  Reaction rate dominated by turbulent mixing of reactants or fresh and burned gases (premixed)
Finite Rate Chem- istry Model	Laminar or turbulent  If turbulent, reaction rate slow compared to turbulent time scale (low Damköhler number)  Reaction rate dominated by kinetics (chemistry)  Kinetic data for reaction rates required  May need special initialization for flame ignition (temperature dependence of reaction rates)
Com- bined EDM/FRC Model	Turbulent  Whole range of Damköhler numbers  Kinetic data for reaction rates required  May need special initialization for flame ignition (temperature dependence of reaction rates).
Laminar Flamelet Model	Fast chemistry (high Damköhler number)  Turbulent  Non-premixed  "Fuel" and "Oxidizer" well defined,  Chemistry library required

Burning Velocity Model, BVM (Partially Re-mixed), (Turbulent Flame Closure)	Turbulent Premixed or partially-premixed "Fuel" and "Oxidizer" can be mixed (specify inlet mixture fraction) Chemistry library required
---	--

The Damköhler number is the ratio of flow-time scale to chemical-time scale:

$$Da = \frac{t_{\text{flow}}}{t_{\text{chem}}} \quad (9-11)$$

### 9.3. Eddy Dissipation Model

The Eddy Dissipation model is best applied to turbulent flows when the chemical reaction rate is fast relative to the transport processes in the flow. There is no kinetic control of the reaction process. Thus, ignition and processes where chemical kinetics may limit reaction rate may be poorly predicted.

By default, for the Eddy Dissipation model it is sufficient that fuel and oxidant be available in the control volume for combustion to occur. If the product limiter is enabled, by setting the **Eddy Dissipation Coefficient B** parameter to positive, then products must also be available. For details, see [Eddy Dissipation Model Coefficient A/B](#) (p. 305). However, combustion products may not always be specified as an input. In this case, products could not form unless they are introduced into the domain. Assuming the problem is one in which a stable flame may be established, initial specification of products within the domain should be sufficient to start and maintain combustion. However, if the combustion is difficult to maintain, it may be necessary to introduce a small fraction of products at an inlet.

The following topics will be discussed:

- [Fluid Models](#) (p. 304)
- [Initialization](#) (p. 306)
- [Solver Parameters](#) (p. 306)

#### 9.3.1. Fluid Models

The models settings described in this section are set when creating a domain in CFX-Pre. For details, see [Domains in the CFX-Pre User's Guide](#).

##### 9.3.1.1. Chemical Time Scale

The reaction rate is set to zero if the turbulent time scale is smaller than this value. When the model for flame extinction at high turbulence is activated, local extinction occurs when the turbulence time scale is smaller than a chemical time scale (quenching time scale) provided by you. As this is a very simple model for predicting local extinction, the specified chemical time scale may need to be adjusted in order to achieve best results for a specific problem. For methane-air combustion, good starting points are  $1.37e-4$  [s] when applying the Kolmogorov time scale, or  $5e-4$  [s] when comparing to the mixing time scale. Using the Kolmogorov time scale tends to be more aggressive and may lead to

global extinction of the flame, even in situations where this is not physical. It is for this reason that the mixing time scale is recommended. By default, the mixing time scale is applied. This may be changed by setting the expert parameter `use kolmogorov ts for extinction` to T.

### 9.3.1.2. Extinction Temperature

This is a simple model that disables the reaction wherever the temperature is less than the specified extinction temperature.

### 9.3.1.3. Maximum Flame Temperature

Because of the assumption of complete combustion, the Eddy Dissipation model may over-predict temperature under certain conditions (for example, for hydrocarbon fuels in regions with fuel-rich mixture). When the expected maximum temperature (or an estimated bound for it) is known prior to the simulation, it can be provided to the solver as a constraint. The exact limit is the adiabatic flame temperature for the local mixture. Depending on the application it may be sufficient to use a simple correlation or even a constant limit. CEL expressions may be used in the maximum flame temperature parameter. When the specified maximum flame temperature limit is reached, the reaction rate will be locally stopped, leaving behind fuel and oxidizer. The reaction may continue in other regions of the domain where the fluid temperature is lowered (for example, by mixing with cold fluid or by heat transfer). Note that the maximum flame temperature only bounds temperature increase due to reaction heat release, but it is possible that a different process such as compression or heat transfer can exceed the specified limit.

### 9.3.1.4. Mixing Rate Limit

The maximum allowed value of the local turbulent mixing rate. Only applicable if the **Eddy Dissipation Model** is used. The **Eddy Dissipation Model** sometimes predicts unphysical behavior, such as the flame creeping across walls. This is because the ratio of the turbulence quantities  $\varepsilon/k$  becomes large close to wall boundaries, but the turbulence in these regions is low. This value is used to enforce an upper limit on the value  $\varepsilon/k$  used for computing the reaction rate. For methane/air, a value of approximately 2500[1/s] is reasonable.

### 9.3.1.5. Eddy Dissipation Model Coefficient A/B

The coefficient A is a factor that appears in both the reactants and the products limiter. For details, see:

- [Reactants Limiter in the CFX-Solver Theory Guide](#)
- [Products Limiter in the CFX-Solver Theory Guide.](#)

A must always be positive. There is special treatment in the solver for negative B. If this is the case, the product limiter is not applied and the reaction rate is determined by reactants concentrations and turbulence. When B is negative, the magnitude of B is not significant.

The following default values apply:

$$A = 4.0, B = -1$$

Variable expressions (CEL) are supported for both parameters.

### 9.3.1.6. Component Details

This is used to define how the mass fraction (the ratio of the mass of a component to the total mass of the fluid) of the component is to be computed. You must set exactly one component to `Constraint`. The mass fraction of this component will be calculated to be 1 minus the mass fractions of all other components. The constraint could be any of the components, either passive or taking part in the reaction(s). For reasons of accuracy, however, this should be a major component (large mass fraction). For combustion of a fuel in air, the best choice is `N2`.

For the **Eddy Dissipation Model**, choose `Automatic` or `Transport Equation` for all other components.

### 9.3.2. Initialization

The initial guess for scalars can have a large effect on the convergence history of a combustion problem. For example, initial specification of a large concentration of fuel and oxidant in the domain can produce high, unrealistic temperatures that slow convergence. It is best to specify the concentrations in such a way that the reaction proceeds starting from the inlet and proceeds through the domain. This will help ensure reasonable flame temperatures during convergence.

In cases where the domain initially contains air, you should specify oxygen with a mass fraction of 0.232 and set each of the other species to `Automatic`. For temperature and other component mass fractions, you can safely choose `Automatic` as the option in most cases.

### 9.3.3. Solver Parameters

Timestep choice may have a significant effect on the convergence of a flow calculation. Combustion introduces large density gradients in the flow field that can increase the sensitivity of the continuity equation to the timestep. If you are having difficulty converging a combusting flow, particularly during an early stage of convergence, try reducing the timestep to improve solution of the continuity equation. For details, see *Eddy Dissipation Model* (p. 304).

If the solution of a combusting flow appears to stall with mass not well conserved, use a timestep appropriate to the fluid flow for a few iterations to push fluid through the system.

## 9.4. Finite Rate Chemistry Model

The Finite Rate Chemistry model is best applied to situations where the chemical time scale is rate-limiting. This model can be used in conjunction with both laminar and turbulent flow.

The following topics will be discussed:

- *Fluid Models* (p. 306)
- *Initialization* (p. 307)
- *Solver Parameters* (p. 307)

### 9.4.1. Fluid Models

The models settings described in this section are set when creating a domain in CFX-Pre. For details, see *Domains in the CFX-Pre User's Guide*.

### 9.4.1.1. Chemical Time Scale

The reaction rate is set to zero if the turbulent time scale is smaller than this value. When the model for flame extinction at high turbulence is activated, local extinction occurs when the turbulence time scale is smaller than a chemical time scale (quenching time scale) provided by you. Because this is a very simple model for predicting local extinction, the specified chemical time scale may need to be adjusted in order to achieve best results for a specific problem. For methane-air combustion, good starting points are  $1.37e-4$  [s] when applying the Kolmogorov time scale, or  $5e-4$  [s] when comparing to the mixing time scale. Using the Kolmogorov time scale tends to be more aggressive and may lead to global extinction of the flame, even in situations where this is not physical. It is for this reason that the mixing time scale is recommended. By default the mixing time scale is applied. This may be changed by setting the expert parameter `use kolmogorov ts for extinction` to T.

### 9.4.1.2. Extinction Temperature

This is a simple model that disables the reaction wherever the temperature is less than the specified extinction temperature.

### 9.4.1.3. Component Details

This is used to define how the mass fraction of the component is to be computed. You must set exactly one component to `Constraint`. The mass fraction of this component will be calculated to be 1 minus the mass fractions of all other components. The constraint could be any of the components, either passive or taking part in the reaction(s). For reasons of accuracy, however, this should be a major component (large mass fraction). For combustion of a fuel in air, the best choice is N2.

For the **Eddy Dissipation Model**, choose `Automatic` or `Transport Equation` for all other components.

## 9.4.2. Initialization

The Finite Rate Chemistry model initial temperature depends on the temperature dependency of the reactions. If no sensible value is known, restarting from a converged run (with residual values of the order  $10^{-4}$ ) that used the EDM model can be useful.

In cases where the domain initially contains air, you should specify oxygen with a mass fraction of 0.232 and set each of the other species to `Automatic`.

For **Temperature**, you should specify a value that is as close to the correct value as you can determine. This value should typically be above 900 K, and 1200 K is recommended as a starting point. If the mixture fails to ignite, running to a converged solution first with the Eddy Dissipation model and then restarting with the Finite Rate Chemistry model may fix the problem.

### 9.4.3. Solver Parameters

When using the Finite Rate Chemistry model, using a timestep that is too large at the beginning may cause the solver to fail due to reaction rates not converging. Under these circumstances, the timestep must be reduced.

It may help to increase time scales for energy and mass fraction equation classes after running the simulation for a while. You should always use same time scale for energy and mass fraction equation classes.

Overshooting temperatures during the first few iterations may cause convergence difficulties. Try running first few iterations with the Eddy Dissipation Model, then restart with Finite Rate Chemistry.

Enabling temperature damping may also help, but may slow down convergence (this is set using the Expert Parameter `temperature_damping=t`).

## 9.5. Combined EDM/Finite Rate Chemistry Model

For the combined Finite Rate Chemistry/Eddy Dissipation Model, the reaction rates are first computed for each model separately and then the minimum of the two is used. This procedure is applied for each reaction step separately, so while the rate for one step may be limited by the chemical kinetics, some other step might be limited by turbulent mixing at the same time and physical location.

It is also possible to apply different combustion models to each of the steps in a multi-step scheme. Some of the predefined schemes make use of this feature, regardless of the global model selection.

The combined model is valid for a wide range of configurations, provided the flow is turbulent. In particular, the model is valid for many reactions that range from low to high Damköhler numbers (chemistry slow/fast compared to turbulent time scale). Use of this model is recommended if reaction rates are limited by turbulent mixing in one area of the domain and limited by kinetics somewhere else. The Eddy Dissipation model can, however, be more robust than Finite Rate Chemistry or the combined model.

The following topics will be discussed:

- [Fluid Models](#) (p. 308)
- [Initialization](#) (p. 309)
- [Solver Parameters](#) (p. 309)

### 9.5.1. Fluid Models

The model settings described in this section are set when creating a domain in CFX-Pre. For details, see [Domains in the CFX-Pre User's Guide](#).

#### 9.5.1.1. Chemical Time Scale

The reaction rate is set to zero if the turbulent time scale is smaller than this value. When the model for flame extinction at high turbulence is activated, local extinction occurs when the turbulence time scale is smaller than a chemical time scale (quenching time scale) provided by you. As this is a very simple model for predicting local extinction, the specified chemical time scale may need to be adjusted in order to achieve best results for a specific problem. For methane-air combustion, good starting points are  $1.37 \times 10^{-4}$  [s] when applying the Kolmogorov time scale, or  $5 \times 10^{-4}$  [s] when comparing to the mixing time scale. Using the Kolmogorov time scale tends to be more aggressive and may lead to global extinction of the flame, even in situations where this is not physical. It is for this reason that the mixing time scale is recommended. By default the mixing time scale is applied. This may be changed by setting the expert parameter `use_kolmogorov_ts_for_extinction` to T.

#### 9.5.1.2. Extinction Temperature

This is a simple model that disables the reaction wherever the temperature is less than the specified extinction temperature.

### 9.5.1.3. Component Details

This is used to define how the mass fraction of the component is to be computed. You must set exactly one component to `Constraint`. The mass fraction of this component will be calculated to be 1 minus the mass fractions of all other components. The constraint could be any of the components, either passive or taking part in the reaction(s). For reasons of accuracy, however, this should be a major component (large mass fraction). For combustion of a fuel in air, the best choice is N2.

For the Eddy Dissipation Model, choose Automatic of Transport Equation for all other components.

### 9.5.2. Initialization

The Finite Rate Chemistry model initial temperature depends on the temperature dependency of the reactions. If no sensible value is known, restarting from a run that used the EDM model can be useful.

As the Finite Rate Chemistry model is more sensitive to initial guess values, you should follow the advice given in the initialization section for this model. For details, see [Initialization \(p. 307\)](#).

### 9.5.3. Solver Parameters

The advice given for the Finite Rate Chemistry model is also applicable to the combined model. For details, see [Solver Parameters \(p. 307\)](#).

## 9.6. Reaction-Step Specific Combustion Model Control

For multi-step reactions, there is the option of specifying a different combustion model for each reaction step. The choice of combustion model for each step is optional, and is made when the **Reaction or Combustion Model** check box is selected for a single-step reaction. Specification is carried out in the **Reaction** details view in CFX-Pre. For details, see [Single Step: Basic Settings in the CFX-Pre User's Guide](#).

The available choices for a reaction-step specific reaction are Eddy Dissipation Model, Finite Rate Chemistry Model, and EDM/Finite Rate Chemistry Model. For details, see:

- [Eddy Dissipation Model \(p. 304\)](#)
- [Finite Rate Chemistry Model \(p. 306\)](#)
- [Combined EDM/Finite Rate Chemistry Model \(p. 308\)](#).

When a reaction contains a reaction-step specific combustion model, the model overrides the choice of combustion model set on the **Fluid Domains** form in CFX-Pre, except if the option on the **Fluid Domains** form is set to `None`.

Because of the behavior described in the paragraph above, it is important that you select a combustion model on the **Fluid Domains** form, even if you have selected models for each and every reaction step in a multi-step reaction.

## 9.7. Laminar Flamelet with PDF Model

The laminar flamelet model solves only two transport equations for a large number of species (low computational cost). It provides information on minor species and radicals (such as CO and OH). As well as accounting for turbulent fluctuations in composition (presumed PDF), it models local extinction at high scalar dissipation rates or shear strain.

The model is only applicable for two-feed systems (fuel and oxidizer), and requires a chemistry library as input. Such libraries can be generated using CFX-RIF. The same pressure level must apply to the whole domain and the model is only for non-premixed systems.

The following topics will be discussed:

- *Fluid Models* (p. 310)
- *Boundary Settings* (p. 310)
- *Initialization* (p. 311)
- *Solver Parameters* (p. 311)

---

### Note

If you are using the NO model with the Flamelet model, you will need to set up your simulation differently. For details, see *NO Model with Flamelet Model* (p. 331).

## 9.7.1. Fluid Models

The models settings described in this section are set when creating a domain in CFX-Pre. For details, see *Domains in the CFX-Pre User's Guide*.

### 9.7.1.1. Component Details

Because transport equations are not solved for species involved in the flamelet library reactions, you should select either `Library` or `Automatic` for all such components.

Always set N2 to be a constraint. Components other than N2 and components covered by the flamelet library must be set to `Automatic` or `Library`.

Components not covered by the flamelet library should be set to `Transport Equation`. The transport equation components must be minor components, as they are either post-processed or their added mass fractions will be subtracted from the mass fraction of the constraint material. For details, see *NO Model* (p. 330).

## 9.7.2. Boundary Settings

When specifying an inlet or opening boundary condition, you will set a **Mixture** option based on the properties of the incoming fluid. The options available are:

### 9.7.2.1. Fuel

This option is used when the mass fraction of the fuel component is 1.

### 9.7.2.2. Oxidizer

This is used when the mass fraction of the oxidizer (usually air) is 1.

### 9.7.2.3. Mixture Fraction

Use this parameter when you need to specify the reacted mixture of fuel and oxidizer (for example, in a reacted pilot flame). A value of zero corresponds to 100% oxidizer, and a value of 1 corresponds to 100% fuel.

### 9.7.2.4. Mixture Fraction Mean and Variance

Used in conjunction with the **Mixture Fraction** parameter, but additionally you can specify the variance for the “unmixedness” of fuel and oxidizer. By default, the three options above imply zero variance.

### 9.7.3. Initialization

When using the Flamelet model, no initialization data for the library species is required because no transport equations are solved for them. You can set values for the mixture fraction mean and variance, but `Automatic` is fine if you do not know of sensible initial values (a value of zero corresponds to 100% oxidizer, and a value of 1 corresponds to 100% fuel).

If you are modeling the formation of NO, you will need to set an initialization option for the NO component. For details, see [NO Model](#) (p. 330).

### 9.7.4. Solver Parameters

The advice given for timestep selection in the EDM model is applicable here. For details, see [Solver Parameters](#) (p. 306).

## 9.8. Burning Velocity Model (Premixed or Partially Premixed)

This model is a combined model using:

- Model for the progress of the global reaction: Burning Velocity Model (BVM), also called Turbulent Flame Closure (TFC)
- Model for the composition of the reacted and non-reacted fractions of the fluid: Laminar Flamelet with PDF

The following topics will be discussed:

- [Fluid Models](#) (p. 312)
- [Turbulent Burning Velocity](#) (p. 312)
- [Spark Ignition Model](#) (p. 313)
- [Boundary Settings](#) (p. 313)
- [Initialization](#) (p. 314)
- [Solver Parameters](#) (p. 314)
- [Other Parameters](#) (p. 314)

Information on the theory behind this model is available in [Burning Velocity Model \(Premixed or Partially Premixed\)](#) in the *CFX-Solver Theory Guide*.

## 9.8.1. Fluid Models

The models settings described in this section are set when creating a domain in CFX-Pre. For details, see [Domains in the CFX-Pre User's Guide](#).

### 9.8.1.1. Component Details

Because transport equations are not solved for species involved in the flamelet library reactions, you should select either **Library** or **Automatic** for all such components.

Always set N2 to be a constraint. Components other than N2 and components covered by the flamelet library must be set to `Automatic` or `Library`.

Components not covered by the flamelet library should be set to Transport Equation. The transport equation components must be minor components, as either they are post-processed or their added mass fractions will be subtracted from the mass fraction of the constraint material. For details, see [NO Model](#) (p. 330).

## 9.8.2. Turbulent Burning Velocity

Select the model for the turbulent burning velocity. For many gas turbine applications, the Zimont model, which is the default, is a good choice.

### 9.8.2.1. Value

Specify the value for the turbulent burning velocity. Typically, this will be an expression in terms of the laminar burning velocity.

### 9.8.2.2. Zimont Correlation

Set the critical velocity gradient parameter to control the flame stretch and flame extinction under high turbulence. The default value of  $g_{cr} = 10000$  [1/s] is appropriate for methane/air combustion at standard conditions. At higher pressures, better results may be obtained by increasing the value. For details, see [Adjusting Model Coefficients in the CFX-Solver Theory Guide](#).

Variable expressions (CEL) may be specified for **Turbulent Burning Velocity Factor**  $A$ , **Critical Velocity Gradient**  $g_{cr}$  and **Variance Coefficient**  $\mu_{str}$ .

### 9.8.2.3. Peters Correlation

For details on the model coefficients, see [Adjusting Model Coefficients in the CFX-Solver Theory Guide](#).

### 9.8.2.4. Mueller Correlation

Set **Critical Scalar Dissipation** to control the amount of quenching occurring under rapid mixing. The default value is  $\chi_q = 1.0$  [1/s]. For details on the model coefficients, see [Adjusting Model Coefficients in the CFX-Solver Theory Guide](#).

A variable expression (CEL) may be specified for **Critical Scalar Dissipation**.

### 9.8.3. Spark Ignition Model

The spark ignition model is available only for transient simulations.

#### 9.8.3.1. Spark Kernel

Set **Kernel Center** and **Initial Volume** to the location and the initial size of the spark. Set **Transition Radius** to control when the transition from the spark model to the regular combustion model to occur. The transition radius should be sufficiently large such that the transition region can be resolved by the mesh.

#### 9.8.3.2. Ignition Time

Specify the time for spark ignition to occur.

#### 9.8.3.3. Spark Energy

Optionally, the electrical energy of the spark may be included into the model. The energy of the spark can be defined by one of the following:

- Spark energy (specifies the total energy of the spark)
- Spark power (energy flux) and duration of the spark

The **Electrode Efficiency** parameter controls the fraction of the spark energy introduced into to the fluid. The complementary fraction is modeled to be lost to the external world by heat transfer in the spark electrode.

### 9.8.4. Boundary Settings

When specifying an inlet or opening boundary condition, you will set a mixture option based on the properties of the incoming fluid. The options available are:

#### 9.8.4.1. Fuel

This option is used when the mass fraction of the fuel component is 1.

#### 9.8.4.2. Oxidizer

This is used when the mass fraction of the oxidizer (usually air) is 1.

#### 9.8.4.3. Mixture Fraction

Use this parameter when you need to specify the reacted mixture of fuel and oxidizer (for example, in a reacted pilot flame). A value of zero corresponds to 100% oxidizer, and a value of 1 corresponds to 100% fuel.

#### 9.8.4.4. Mixture Fraction Mean and Variance

Used in conjunction with the Mixture Fraction parameter, but additionally you can specify the variance for the “unmixedness” of fuel and oxidizer. By default, the three options above imply zero variance.

### 9.8.4.5. Reaction Progress

This parameter is used to specify the reaction progress variable  $c$ .  $c = 0$  corresponds to fresh (unburned) gases, whereas  $c = 1$  corresponds to completely burned gases. You can select Fresh Gases ( $c = 0$ ), Burned Gases ( $c = 1$ ), or enter a value or expression for the value of  $c$ .

## 9.8.5. Initialization

When using the Burning Velocity Model (BVM), no initialization data for the library species is required since no transport equations are solved for them. You can set values for the mixture fraction mean and variance, but Automatic is fine if you do not know of sensible initial values (a value of zero corresponds to 100% oxidizer, and a value of 1 corresponds to 100% fuel).

If you are modeling the formation of NO, you will need to set an initialization option for the NO component. For details, see [NO Model](#) (p. 330).

### 9.8.5.1. Reaction Progress

This parameter is used to specify the reaction progress variable  $c$  within the domain.  $c = 0$  corresponds to fresh (unburned) gases, whereas  $c = 1$  corresponds to completely burned gases. You can select Fresh Gases ( $c = 0$ ), Burned Gases ( $c = 1$ ), or enter a value or expression for the value of  $c$ .

## 9.8.6. Solver Parameters

The advice given for timestep selection in the EDM model is applicable here. For details, see [Solver Parameters](#) (p. 306).

## 9.8.7. Other Parameters

You can turn off the calculation of the reaction progress variable  $c$  (discussed in [Initialization](#) (p. 314)) by setting the Expert Parameter `solve reaction progress` to `f`.

## 9.9. Extended Coherent Flame Model (ECFM)

The Extended Coherent Flame Model (ECFM) is a combined model employing:

- A model for the progress of the global reaction: Extended Coherent Flame Model (ECFM), which is a member of the class of Flame Surface Density Models
- A model for the composition of the reacted and non-reacted fractions of the fluid: Laminar Flamelet with PDF. For partially premixed configurations this model does also implement post-flame fuel oxidation (diffusion flame tail)

The coupling of ECFM with the flamelet model for effects of non-premixedness extends the range of applicability of the model similar to the three-zones extension of the model found in the literature (ECFM-3Z).

The following topics will be discussed:

- [Fluid Models](#) (p. 315)
- [Spark Ignition Model](#) (p. 315)
- [Boundary Settings](#) (p. 316)

- [Initialization](#) (p. 317)
- [Solver Parameters](#) (p. 317)
- [Other Parameters](#) (p. 317)

Information on the theory behind the Extended Coherent Flame Model is available in [Extended Coherent Flame Model \(ECFM\)](#) in the *CFX-Solver Theory Guide*.

## 9.9.1. Fluid Models

The model settings described in this section are set when creating a domain in ANSYS CFX-Pre. For details, see [Domains in the CFX-Pre User's Guide](#)

### 9.9.1.1. Laminar Flame Thickness

The laminar flame thickness is an important input quantity to the Extended Coherent Flame Model. The following options are available:

- **Blint**: Applies Blint's correlation for laminar flame thickness. See [Laminar Flame Thickness in the CFX-Solver Theory Guide](#) for the definition of the correlation.
- **Value**: Specify a CEL expression for the laminar flame thickness.

### 9.9.1.2. Component Details

It is recommended that you choose  $N_2$  to be the constraint, which is the default. The remaining components in the flamelet library must be set to `Automatic` or `Library`. Components not covered by the flamelet library should be set to `Transport Equation`. The transport equation components should be minor species, as they are either post-processed or their added mass fractions will be subtracted from the mass fraction of the constraint material. For details, see [NO Model](#) (p. 330).

## 9.9.2. Spark Ignition Model

The spark ignition model is available only for transient simulations.

### 9.9.2.1. Spark Kernel

Set **Kernel Center** and **Initial Volume** to the location and the initial size of the spark. Set **Transition Radius** to control when the transition from the spark model to the regular combustion model to occur. The transition radius should be sufficiently large such that the transition region can be resolved by the mesh.

### 9.9.2.2. Ignition Time

Specify the time for spark ignition to occur.

### 9.9.2.3. Spark Energy

Optionally, the electrical energy of the spark may be included into the model. The energy of the spark can be defined by one of the following:

- Spark energy (specifies the total energy of the spark)
- Spark power (energy flux) and duration of the spark

The **Electrode Efficiency** parameter controls the fraction of the spark energy introduced into the fluid. The complementary fraction is modeled to be lost to the external world by heat transfer in the spark electrode.

### 9.9.3. Boundary Settings

When specifying an inlet or opening boundary condition, you will set options for mixture, for reaction progress and for flame surface density. When specifying a wall boundary condition an option will be set only for flame surface density.

#### 9.9.3.1. Mixture

The options available are:

- **Fuel:** This option is used when the mass fraction of the fuel component is 1.
- **Oxidizer:** This option is used when the mass fraction of the oxidizer (usually air) is 1.
- **Mixture Fraction:** Use this parameter when you need to specify the mixture of fuel and oxidizer or the equivalent reacted mixture (for example, in a reacted pilot flame). A value of zero corresponds to 100% oxidizer, and a value of 1 corresponds to 100% fuel.
- **Mixture Fraction Mean and Variance:** Used in conjunction with the **Mixture Fraction** parameter, but additionally you can specify the variance for the “unmixedness” of fuel and oxidizer. By default, the three options above imply zero variance.
- **Equivalence Ratio:** Use this parameter when you need to specify the mixture of fuel and oxidizer, or the equivalent reacted mixture. The difference to the **Mixture Fraction** option is that the value is given for the equivalence ratio: 1 = stoichiometric, <1 for lean mixtures and >1 for fuel rich mixtures.

#### 9.9.3.2. Reaction Progress

This parameter is used to specify the reaction progress variable  $c$ .  $c = 0$  corresponds to fresh (unburned) gases, whereas  $c = 1$  corresponds to completely burned gases. You can select `Fresh Gases (c=0)`, `Burned Gases (c=1)`, or enter a value or expression for the value of  $c$ .

#### 9.9.3.3. Flame Surface Density

For inlet or opening boundary conditions a value will be specified for the flame surface density, which is the area of flame surface per volume. A value of 0  $[m^{-1}]$  corresponds to no flame existing on the boundary and is appropriate for most inlets or openings.

At wall boundaries an option will be specified controlling how the flame surface interacts with the wall. The following options are available:

- **Wall Quenching:** Enables the wall quenching model
- **Zero Flux:** Disables the wall quenching model
- **Wall Flux in:** Use this parameter in order to implement custom models for flame-wall interaction. Negative values for the **Flame Surface Density Flux** parameter correspond to destruction of the flame at the wall (quenching).

## 9.9.4. Initialization

When using the Extended Coherent Flame Model (ECFM), no initialization data for the library species is required because no transport equations are solved for them. If you are modeling the formation of NO, you will need to set an initialization option for the NO component. For details, see [NO Model \(p. 330\)](#).

### 9.9.4.1. Mixture

You can set values for the mixture fraction mean and variance, but **Automatic** is fine if you do not know of sensible initial values (a value of zero corresponds to 100% oxidizer, and a value of 1 corresponds to 100% fuel).

### 9.9.4.2. Reaction Progress

This parameter is used to specify the reaction progress variable within the domain.  $c = 0$  corresponds to fresh (unburned) gases, whereas  $c = 1$  corresponds to completely burned gases.

### 9.9.4.3. Flame Surface Density

This parameter is used to specify the flame surface density  $\Sigma$  within the domain.  $\Sigma=0$  [m<sup>-1</sup>] corresponds to no reaction present. Unless the reaction is ignited by other means, for example, the [Spark Ignition Model \(p. 315\)](#), it may be necessary to specify non-zero values at least in part of the region in order to start the combustion. When the **Automatic** option is set the default initial values are derived from the gradient of reaction progress,

$$\Sigma = \frac{s_T^{Zimont}}{s_L} \cdot |\nabla \tilde{c}|$$

where  $s_L$  denotes the laminar burning velocity and  $s_T^{Zimont}$  the turbulent burning velocity according to the Zimont correlation.

## 9.9.5. Solver Parameters

The advice given for timestep selection in the EDM model is applicable here. For details, see [Solver Parameters \(p. 306\)](#).

## 9.9.6. Other Parameters

You can turn off the calculation of the reaction progress variable  $c$  by setting the Expert Parameter `solve reaction progress` to `f`. You can turn off the calculation of the flame surface density variable  $\Sigma$  by setting the Expert Parameter `solve fsd` to `f`.

## 9.10. Residual Material Model

The following topics will be discussed:

- [Fluid Models \(p. 318\)](#)
- [Laminar Burning Velocity \(p. 318\)](#)
- [Boundary Settings \(p. 318\)](#)
- [Initialization \(p. 319\)](#)

- [Initialization](#) (p. 317)
- [Other Parameters](#) (p. 319)

### 9.10.1. Fluid Models

The single-mixture fraction approach describes mixing as a two-stream system consisting of fuel and oxidizer. The residual material model extends the mixing model to a three-stream system consisting of fuel, oxidizer and residual material (inert, ballast). The model is available in combination with the partially-premixed combustion models 'BVM (Partially Premixed)' and 'Extended Coherent Flame Model'.

The residual material model accounts for the following effects caused by the presence of ballast material in the mixture:

- Additional degree of freedom for mixture composition (1 extra transport equation)
- Lower peak temperatures because the fuel/air mixture is diluted
- Reduced velocity for flame propagation.

For the **Exhaust Gas** option the residual material is modeled to consist of products originating from the same fuel and oxidizer as for the combustion. This assumption enables calculating the whole mixture composition from a single-mixture fraction flamelet library, that is, the same library that is also used without a residual material model. The details of the component mass fraction calculation are described in the solver theory documentation, see [Mixture Composition in the CFX-Solver Theory Guide](#).

#### 9.10.1.1. Reinitialization

For transient simulations the residual material can be reinitialized at specified times. Under reinitialization all products currently present in the mixture are marked for being treated as residual material from now on. The **Time List** may be specified for applying reinitialization once or several times.

A typical example for use of reinitializing the residual material is the simulation of subsequent cycles of an internal combustion engine. By incomplete load exchange a part of the products generated in one cycle will remain in the combustion chamber, hence serving as residual material for the following engine cycle. This can be modeled by specifying the time for reinitialization at some point after the end of combustion in the first cycle and before the fresh mixture enters the chamber for the next cycle.

### 9.10.2. Laminar Burning Velocity

When the residual material model is enabled, it is recommended to also specify the dependency of the laminar burning velocity. For details, see [Laminar Burning Velocity](#) (p. 328).

### 9.10.3. Boundary Settings

For the residual material model the following additional options are available for **Mixture** boundary conditions:

- **Mixture Fraction and Fuel Tracer:** Use this parameter for direct specification of boundary values for the mean mixture fraction and fuel tracer.
- **Mixture Fraction and Residual Material:** Specification of the residual material mass fraction and the conditional mixture fractions for the fresh and residual fractions.
- **Equivalence Ratio and Residual Material:** Specification of the residual material mass fraction and the conditional equivalence ratios for the fresh and residual fractions.

For options other than the above, the fuel tracer is set equal to mixture fraction, which corresponds to no residual material present in the inlet stream.

### 9.10.4. Initialization

For the residual material model initial values can be specified for the fuel tracer. The default or **Automatic** option initializes the fuel tracer to be equal to mixture fraction, which corresponds to zero residual material.

### 9.10.5. Other Parameters

The transport equation for fuel tracer is solved in the mixture fraction equation group. You can turn off the calculation of the group by setting the Expert Parameter `solve mixture fraction` to `f`.

## 9.11. Flamelet Libraries

The mixture fraction based combustion models in ANSYS CFX (PDF Flamelet, Burning Velocity Model and Extended Coherent Flame Model) require a flamelet library that defines the burnt mixture composition as a function of the combustion scalars solved.

The following topics will be discussed:

- [CFX-RIF \(p. 319\)](#)
- [Flamelet Library Import Filter \(p. 322\)](#)
- [Flamelet Library \(FLL\) File Format \(p. 323\)](#)
- [Stoichiometric Mixture Fraction \(p. 328\)](#)
- [Laminar Burning Velocity \(p. 328\)](#)

Flamelet libraries can be generated using CFX-RIF. For details, see [CFX-RIF \(p. 319\)](#).

It is also possible to use flamelet libraries from other sources, provided that the appropriate file format is used. For details, see [Flamelet Library \(FLL\) File Format \(p. 323\)](#).

### 9.11.1. CFX-RIF

CFX-RIF is a flamelet-library generation tool that offers a range of hydrocarbon fuels and kinetic reaction schemes. For an overview of the built-in fuels and reaction mechanisms, see Basic Settings Tab below.

The user interface for CFX-RIF is integrated into CFX-Pre. The workflow for generating a flamelet library is:

1. Define the CFX-RIF parameters for the flamelet library to be generated.
2. Start the flamelet library calculation (executed in the background).
3. Proceed with setup of the flow simulation.
4. Ensure that flamelet library calculation is finished before starting the flow solver.

Additional information on flamelet libraries is available. For details, see [Flamelet Libraries in the CFX-Solver Theory Guide](#).

### 9.11.1.1. Defining a CFX-RIF Object

To create a new CFX-RIF object in CFX-Pre, select **Insert** > **CFX-RIF** from the menu bar or from the context menu by right-clicking on **Reactions** in the tree view.

### 9.11.1.2. Basic Settings Tab

For **Library File** specify the path and file name to be used for saving the flamelet library when the calculation is finished.

Select the **Fuel Module** for the flamelet library. Choose a module that enables you to represent the fuel, or fuel mixture, as needed for the flow simulation. The mass fractions of the individual components in the 'Fuel' and 'Oxidizer' streams may be specified on the *Boundary Conditions Tab* (p. 321). The available fuel modules are described below:

**Table 9.1 Fuel Modules available in CFX-RIF**

Option	Fuel Description
<b>H2</b>	Hydrogen, using either default reaction mechanisms or Conaire [207] mechanisms
<b>CH4</b>	Methane, using either C1 or C2 reaction mechanisms
<b>C3H8</b>	Propane
<b>C7H16</b>	Heptane
<b>CO-H2 (mixture)</b>	Mixtures of carbon monoxide and hydrogen
<b>CH4-H2 (mixture)</b>	Mixtures of methane and hydrogen, using LCSR mechanism without NO
<b>C1-C4 (mixture)</b>	Mixtures of various hydrocarbon components, such as natural gas or syngas. The complete list of fuel components can be viewed on the Boundary Conditions Tab.
<b>Gasoline (octane-heptane)</b>	Gasoline, modeled as a two-component mixture composed of octane and heptane. The octane to heptane ratio may be customized according to the octane-number for the fuel.
<b>Jet A (surrogate)</b>	Jet-A aviation fuel (kerosene), modeled as a two-component surrogate fuel (by mass 60% n-C10H22 and 40% TMB-C9H12)
<b>Diesel (surrogate)</b>	Diesel fuel, modeled as a two-component surrogate fuel (by mass 62.44% n-C10H22 and 37.56% A2CH3-C11H10)

Choose the **Kinetic Scheme** to be used for calculation of the flamelet library. Reaction mechanisms with different levels of NO<sup>1</sup> modeling are available. It is recommended that you select a scheme without any NO, because better accuracy can be obtained for most flow configurations by solving a transport equation for NO in ANSYS CFX.

In addition to the level of NO modeling, the **H2** and **CH4** fuel modules offer a choice for the principal fuel reaction mechanism. The **H2** fuel module supports a default mechanism and the Conaire [207] mechanism. The latter allows for dilution of fuel and oxidizer by inert gases Argon and Helium. The **CH4** module for methane supports C1 and C2 mechanisms. The C2 mechanism considers a larger number of intermediate species and reaction steps, therefore being potentially more accurate than C1 at the cost of increased table size and calculation times.

<sup>1</sup>For a discussion of the theory of NO formation, see *Thermal NO in the CFX-Solver Theory Guide*.

### 9.11.1.3. Boundary Conditions Tab

The compositions of the fuel and oxidizer streams are defined under **Fuel Composition** and **Oxidizer Composition**, respectively. The available fuel components depend on the fuel module selection made earlier. All fuels may be diluted with nitrogen. The default oxidizer composition is air, where the mass fraction of O<sub>2</sub> is 0.233 and the mass fraction of N<sub>2</sub> is 0.767.

Fuel and oxidizer streams may be diluted with product species, which are CO<sub>2</sub> and H<sub>2</sub>O for hydrocarbon fuels, and just H<sub>2</sub>O for Hydrogen fuel. The Conaire [207] mechanism for hydrogen additionally allows for dilution with the inert gases Argon (Ar) and Helium (He).

The **Fuel Temperature** and **Oxidizer Temperature** should be consistent with the boundary values applied in the CFD simulation. Small differences are acceptable, such as if the values in the CFD simulation are non-constant.

Set the **Reference Pressure** to the pressure level in the CFD simulation. As with temperature, differences are acceptable in case the values in the CFD simulation are non-constant. In this case you should use an average or 'typical' pressure level from the CFD simulation.

### 9.11.1.4. Table Size Tab

The table size, table point distribution, range of scalar dissipation rate, and material list reduction are controlled on the **Table Size** tab. The default settings in this section are appropriate for the majority of cases. The exception is the **Maximum Scalar Dissipation Rate**, which may need to be increased for flows with high scalar dissipation rates in a relevant region of the domain.

Under **Mixture Fraction** choose the **Option** defining how the table points are to be distributed over the interval [0, 1]. **Uniform** creates an equidistant spacing, while **Non Uniform** clusters the table points around the stoichiometric mixture fraction. Because the mixture composition typically shows strong variation around stoichiometry, choosing **Non Uniform** is likely to be more accurate at a given number of table points. The default number of **Table Points** (100) is appropriate in most cases, but it may be decreased in order to reduce the size of the flamelet library generated. The maximum number of table points allowed for **Mixture Fraction** is 200.

**Mixture Fraction Variance** controls the table points for the normalized variance, as defined in [Equation 9–15](#) (p. 324) below. The default is **Uniform Normalized Variance** with 10 **Table Points**, which is appropriate for most cases. The number may be decreased in order to reduce the size of the flamelet library generated. Changing the option to **Value List** allows for direct specification of the table points in the **Normalized Variance List**. When doing so, the size of the list should be in the range of from 2 to 10 values. The maximum number of table points allowed for **Mixture Fraction Variance** is 40.

The range and sample point distribution for **Scalar Dissipation Rate** may be specified either as **Logarithmic** or as **Value List**. For the latter, the list should contain from 2 to 20 values. For **Logarithmic** distribution, the **Lower Scalar Dissipation Rate** specifies the smallest non-zero sample point and the **Maximum Scalar Dissipation Rate** defines the highest value included in the flamelet library. The size and the calculation time for the flamelet library will be roughly proportional to the number of **Table Points** (default=20). The maximum number of table points allowed for **Scalar Dissipation Rate** is 60.

The **Materials List Reduction** setting currently only allows the setting `None`, which implies that all the species present in the Flamelet libraries generated by CFX-RIF are taken into account in the CFD simulation.

### 9.11.1.5. Flamelet Library Calculation

The generation of a flamelet library is started by right-clicking a CFX-RIF object under **Reactions** in the tree view and selecting **Start CFX-RIF Generation** from the context menu. After starting the calculation, the reaction and material objects associated with the flamelet library are loaded into CFX-Pre and the library generation process is executed in the background. The name of the reaction object associated with the flamelet library is derived from the base name of Flamelet Library file by replacing special characters with blanks.

You may proceed with the setup of the case while the flamelet library is being calculated. An error message will appear initially in the physics message window, stating that the Flamelet Library file cannot be opened (because it does not yet exist).

The progress of the library generation can be monitored by opening the run directory or the `out` file in the CFX-Solver Manager. The names of the run directory and out file are derived from the Flamelet Library file name by removing the `.fl1` suffix and appending a run number similar as for a solver run. For example, when the Flamelet Library file name is `Flamelet.fl1` the run directory and out file names will be `Flamelet_{nnn}.dir` and `Flamelet_{nnn}.out` (where `{nnn}` is the smallest available three digit number counting from 001).

The duration of the calculation depends on the fuel, the kinetic scheme and the number of sample points for the library. Calculation times will be longer for higher hydrocarbon fuels with complex reaction mechanisms.

Two files are created as the result of the flamelet library generation: the flamelet library file (`.fl1`) and a corresponding `.ccl` file containing the material and reaction objects. The `.fl1` file is required for running the simulation in the CFX-Solver. The `.ccl` file can be kept for future use of the flamelet library without having to repeat running CFX-RIF.

### 9.11.2. Flamelet Library Import Filter

Flamelet libraries for CFX-TASCflow or libraries generated using the previous stand-alone version of CFX-RIF use a different format for material properties. These files can be converted for use with ANSYS CFX by running the `cfx5fl1import` tool. The program reads the following input files:

- `'fld'`  
flamelet library description file
- `'<lib>.fl1'`  
flamelet libraries
- `'<lib>.prp'`  
material properties for library `'<lib>.fl1'`

and writes the following output files:

- `'<lib>_cfx5.fl1'`  
imported flamelet library
- `'<lib>.ccl'`  
CCL for imported library (reaction and material objects)

After the import, the original `fld`, `<lib>.fll` and `<lib>.prp` files are no longer needed for use with CFX and may be deleted. However, the original files are still required for using the flamelet library with CFX-TASCFlow.

To run the import utility from the operating system, change to the directory that contains the 'fld' file. The following script should then be run:

```
<CFXROOT>\bin\cfx5fllimport
```

This script will run the import utility `<CFXROOT>\bin\<arch>\fllimport_rif.exe`, where `<CFXROOT>` is the installation directory and `<arch>` is the operating system specific directory. While the import program runs, information on the import progress and the created CCL and library files are printed to standard output.

For details on the command line options for running the `cfx5fllimport` script, run the following command:

```
<CFXROOT>\bin\cfx5fllimport -help
```

---

### Note

UNIX paths have forward slashes instead of backslashes. The executable `fllimport_rif.exe` does have the `.exe` extension on both Windows and UNIX systems.

## 9.11.2.1. Loading Flamelet Libraries

To use a particular flamelet library in CFX, simply load the corresponding `<lib>.ccl` file into CFX-Pre. You can do so by selecting:

1. **File > Import > CCL ...** from the menu bar
2. *Import Library Data/File to Import*  in the **Materials** workspace, or
3. *Import Library Data/File to Import*  in the **Reactions** workspace.

Each of these methods leads to the same **Import CCL** dialog box. Loading the `<lib>.ccl` file defines the material properties for all required species and creates a reaction object for the flamelet library. When importing from the **Materials** workspace or the **Reactions** workspace, you should select all materials and reactions in the file for import. Edit the reaction to define the laminar burning velocity (laminar flame speed) and the stoichiometric mixture fraction.

The flamelet library reaction object contains the path name of the flamelet library file (`.fll` file) in the **Library File** setting. If the path name is specified by a relative path, it will be interpreted as being relative to the working directory. If the `.fll` file cannot be found there, the relative path will be interpreted as being relative to `<CFXROOT>/etc/reactions-extra`. The **Reaction** details view can be used to change the "Library File" setting of the flamelet library reaction object as required.

## 9.11.3. Flamelet Library (FLL) File Format

### 9.11.3.1. Flamelet Library (FLL) File Contents

The Flamelet Library (FLL) file contains a flamelet library that can be used with the 'PDF Flamelet' model or with partially premixed combustion models such as Burning Velocity Model (BVM) and the Extended Coherent Flame Model (ECFM).

The flamelet library file defines the component mass fractions in the mixture in tabulated form. For the unburnt solution (inert mixing), the mass fractions are a function of the mean mixture fraction (Favre-average):

$$\tilde{Y}_\alpha^u = \tilde{Y}_\alpha^u(\tilde{Z}) \quad (9-12)$$

For the burnt mixture, the mass fractions depend on the mean mixture fraction, the variance of mixture fraction, and scalar dissipation rate:

$$\tilde{Y}_\alpha^b = \tilde{Y}_\alpha^{flamelet}(\tilde{Z}, \overline{Z''^2}, \chi) \quad (9-13)$$

In order to improve the efficiency of the tabulation, the burnt solution is not tabulated directly as a function of the variance. Instead, a normalized variance is used as the input variable:

$$\tilde{Y}_\alpha^b = \tilde{Y}_\alpha^{flamelet}(\tilde{Z}, z \text{ var norm}, \chi) \quad (9-14)$$

The variance is normalized according to the equation:

$$z \text{ var norm} = \frac{\sqrt{\overline{Z''^2}}}{\min(\tilde{Z}, (1 - \tilde{Z}))} \quad (9-15)$$

The mass fractions are stored in the FLL file as multidimensional tables over the input variables.

### 9.11.3.2. Flamelet Library (FLL) File Format

The FLL file is organized into the following sections:

1. Comments at the beginning of the file (for example, descriptions of library parameters (optional)).
2. A header defining the library dimensions and the sample points for tabulation.
3. Component mass fractions for the unburnt solution (that is, inert mixing).
4. Component mass fractions for the burnt flamelet solutions.

#### 9.11.3.2.1. Detailed FLL File Format

Each line in the FLL file may be up to 80 characters long.

##### 9.11.3.2.1.1. Comment Section

The comment section at the beginning of the file may consist of any number of lines, whose contents is ignored. The end of the comments section is identified by the keyword `DIMENSIONS` at the beginning of the line.

##### 9.11.3.2.1.2. Header

The relevant file contents start below a line beginning with the `DIMENSIONS` keyword. First the library dimensions are defined, followed by the table points for the input quantities. The values given under

STRAIN are currently not used by the CFX-Solver, so the actual values do not matter (provided that the correct count of values given).

```

DIMENSIONS :
MSTZ, MSPEC, MSTRN, MSVAR (I3,I3,I3,I3)
nmean nmat nchi nvar   integer
-----
STRAIN - STEPS
write (iunit,*) (strain(i),i=1,nchi) | all following real
SCALAR DISSIPATION RATE - STEPS
write (iunit,*) (chi(i),i=1,nchi)   |
VARIANCE - STEPS
write (iunit,*) (zvarnorm(i),i=1,nvar) |
Z
write (iunit,*) (zmean(i),i=1,nmean) |

```

### 9.11.3.2.1.3. Unburnt Flamelet

For each component the material name is given on a line by its own. Each material name is followed by several lines with the mass fraction values corresponding to the mean mixture fraction tabulation points.

```

Unburnt Flamelet
do j=1,nmat
  cmat(j)  character*(*)
  write (iunit,*) (mfinert(i,j),i=1,nmean) | all following real

```

### 9.11.3.2.1.4. Burnt Flamelet Solution

For each sample point of the normalized variance and the scalar dissipation rate, the component mass fractions are specified as 1D tables over mixture fraction. The order of the components must be the same as for the unburnt flamelet.

```

do l=1,nvar
do k=1,nchi
  chi(k) zvarnorm(l)  real
  do j=1,nmat
    cmat(j)  character*(*)
    write (iunit,*) (mfflm(i,j,k,l),i=1,nmean) | all following real

```

### 9.11.3.2.2. Example FLL File

```

C      Flamelet Library
C
C      Pressure      [bar]:      1.0000
C      Temp Oxidizer [K] :      300.0000
C      Temp Fuel     [K] :      300.0000
C      Scalar Diss Rate [1/s]:  0 - 10
C      Z-Variance factor :      0 - 0.99
C
C      Composition oxidizer side:
C      N2           :      0.767000
C      O2           :      0.233000
C
C      Composition fuel side :
C      H2           :      1.000000
C

```

```

-----
DIMENSIONS :
MSTZ, MSPEC, MSTRN, MSVAR (I3,I3,I3,I3)
 10 9 2 2
-----

```

```

STRAIN - STEPS (unused)
 0.00000E+00  0.00000E+00
SCALAR DISSIPATION RATE - STEPS
 0.00000E+00  0.10000E+02
VARIANCE - STEPS
 0.00000E+00  0.99000E+00

```

Z					
0.00000E+00	0.25000E-01	0.50000E-01	0.75000E-01	0.10000E+00	
0.48571E+00	0.61429E+00	0.74286E+00	0.87143E+00	0.10000E+01	
Unburnt Flamelet					
H2					
0.00000E+00	0.25000E-01	0.50000E-01	0.75000E-01	0.10000E+00	
0.48571E+00	0.61429E+00	0.74286E+00	0.87143E+00	0.10000E+01	
O2					
0.23300E+00	0.22718E+00	0.22135E+00	0.21553E+00	0.20970E+00	
0.11983E+00	0.89871E-01	0.59914E-01	0.29957E-01	0.10408E-15	
H2O					
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
OH					
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
H					
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
O					
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
HO2					
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
H2O2					
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	
N2					
0.76700E+00	0.74782E+00	0.72865E+00	0.70947E+00	0.69030E+00	
0.39446E+00	0.29584E+00	0.19723E+00	0.98613E-01	0.00000E+00	
0.00000E+00	0.00000E+00				
H2					
0.10000E-24	0.32167E-03	0.22257E-01	0.48043E-01	0.73785E-01	
0.47074E+00	0.60305E+00	0.73537E+00	0.86768E+00	0.10000E+01	
O2					
0.23300E+00	0.26938E-01	0.13402E-05	0.30433E-08	0.12735E-10	
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.10000E-24	
H2O					
0.10000E-24	0.21966E+00	0.24896E+00	0.24267E+00	0.23612E+00	
0.13493E+00	0.10120E+00	0.67463E-01	0.33732E-01	0.11623E-15	
OH					
0.10000E-24	0.50470E-02	0.26098E-03	0.13152E-04	0.75212E-06	
0.38811E-24	0.77449E-29	0.00000E+00	0.00000E+00	0.10000E-24	
H					
0.10000E-24	0.22525E-04	0.89601E-04	0.17580E-04	0.28243E-05	
0.12612E-18	0.10053E-21	0.60974E-22	0.16296E-21	0.10000E-24	
O					
0.10000E-24	0.41505E-03	0.12661E-05	0.61760E-08	0.39353E-10	
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.10000E-24	
HO2					
0.10000E-24	0.30968E-05	0.11313E-08	0.31681E-11	0.13934E-13	
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.10000E-24	
H2O2					
0.10000E-24	0.25535E-06	0.12105E-08	0.18292E-10	0.38118E-12	
0.00000E+00	0.00000E+00	0.00000E+00	0.00000E+00	0.10000E-24	
N2					
0.76700E+00	0.74759E+00	0.72843E+00	0.70926E+00	0.69009E+00	
0.39433E+00	0.29575E+00	0.19717E+00	0.98588E-01	0.00000E+00	
0.10000E+02	0.00000E+00				
H2					
0.10000E-24	0.25063E-02	0.20492E-01	0.46255E-01	0.72274E-01	
0.47042E+00	0.60285E+00	0.73524E+00	0.86763E+00	0.10000E+01	
O2					
0.23300E+00	0.45440E-01	0.12583E-02	0.85114E-04	0.20097E-04	
0.55737E-06	0.28727E-06	0.14271E-06	0.57107E-07	0.00000E+00	
H2O					
0.10000E-24	0.18711E+00	0.24295E+00	0.24161E+00	0.23582E+00	
0.13493E+00	0.10119E+00	0.67463E-01	0.33732E-01	0.21684E-18	
OH					
0.10000E-24	0.10782E-01	0.40147E-02	0.87590E-03	0.25608E-03	
0.18801E-08	0.11176E-08	0.72679E-09	0.28904E-09	0.10017E-24	

H					
0.10000E-24	0.91966E-03	0.20853E-02	0.16570E-02	0.13228E-02	
0.19559E-03	0.11600E-03	0.64313E-04	0.27968E-04	0.00000E+00	
O					
0.10000E-24	0.53884E-02	0.55758E-03	0.43811E-04	0.69272E-05	
0.25113E-08	0.31153E-08	0.27801E-08	0.16103E-08	0.10340E-24	
HO2					
0.10000E-24	0.17485E-04	0.63262E-06	0.50986E-07	0.14220E-07	
0.28498E-08	0.23780E-08	0.18064E-08	0.10560E-08	0.10340E-24	
H2O2					
0.10000E-24	0.16932E-04	0.15026E-05	0.27677E-06	0.10599E-06	
0.10852E-09	0.67381E-10	0.42146E-10	0.20608E-10	0.10017E-24	
N2					
0.76700E+00	0.74782E+00	0.72864E+00	0.70947E+00	0.69030E+00	
0.39445E+00	0.29584E+00	0.19723E+00	0.98610E-01	0.00000E+00	
0.00000E+00	0.99000E+00				
H2					
0.10000E-24	0.83488E-02	0.29476E-01	0.53419E-01	0.78272E-01	
0.48332E+00	0.60536E+00	0.73540E+00	0.86768E+00	0.10000E+01	
O2					
0.23300E+00	0.93664E-01	0.56982E-01	0.42752E-01	0.35775E-01	
0.10067E+00	0.18453E-01	0.24171E-03	0.00000E+00	0.10000E-24	
H2O					
0.10000E-24	0.14918E+00	0.18411E+00	0.19377E+00	0.19520E+00	
0.21515E-01	0.80278E-01	0.67179E-01	0.33732E-01	0.11623E-15	
OH					
0.10000E-24	0.10223E-02	0.86039E-03	0.68068E-03	0.55922E-03	
0.44316E-04	0.12687E-03	0.92239E-05	0.32532E-09	0.10000E-24	
H					
0.10000E-24	0.30313E-04	0.33528E-04	0.28895E-04	0.27175E-04	
0.20180E-05	0.55100E-05	0.73005E-06	0.86118E-10	0.10000E-24	
O					
0.10000E-24	0.38721E-04	0.31603E-04	0.24800E-04	0.20325E-04	
0.19873E-05	0.44947E-05	0.35796E-06	0.56847E-11	0.10000E-24	
HO2					
0.10000E-24	0.51104E-06	0.37260E-06	0.28331E-06	0.23001E-06	
0.26906E-07	0.54387E-07	0.32524E-08	0.00000E+00	0.10000E-24	
H2O2					
0.10000E-24	0.47490E-07	0.34747E-07	0.26623E-07	0.21759E-07	
0.32576E-08	0.55969E-08	0.30967E-09	0.00000E+00	0.10000E-24	
N2					
0.76700E+00	0.74772E+00	0.72851E+00	0.70932E+00	0.69015E+00	
0.39445E+00	0.29577E+00	0.19717E+00	0.98588E-01	0.00000E+00	
0.10000E+02	0.99000E+00				
H2					
0.10000E-24	0.85312E-02	0.29186E-01	0.52917E-01	0.77691E-01	
0.48328E+00	0.60515E+00	0.73521E+00	0.86762E+00	0.10000E+01	
O2					
0.23300E+00	0.98319E-01	0.60926E-01	0.45884E-01	0.38370E-01	
0.10092E+00	0.19024E-01	0.28950E-03	0.82501E-07	0.00000E+00	
H2O					
0.10000E-24	0.13837E+00	0.17493E+00	0.18644E+00	0.18914E+00	
0.20926E-01	0.78935E-01	0.67061E-01	0.33732E-01	0.21684E-18	
OH					
0.10000E-24	0.42102E-02	0.37067E-02	0.29900E-02	0.24882E-02	
0.23040E-03	0.54292E-03	0.54105E-04	0.84910E-08	0.10017E-24	
H					
0.10000E-24	0.73407E-03	0.10170E-02	0.10398E-02	0.99514E-03	
0.78870E-04	0.27180E-03	0.13554E-03	0.34183E-04	0.00000E+00	
O					
0.10000E-24	0.20086E-02	0.15792E-02	0.12333E-02	0.10115E-02	
0.10873E-03	0.23342E-03	0.17181E-04	0.16711E-08	0.10340E-24	
HO2					
0.10000E-24	0.27321E-04	0.17375E-04	0.12985E-04	0.10659E-04	
0.25423E-05	0.34829E-05	0.10183E-06	0.93590E-09	0.10340E-24	
H2O2					
0.10000E-24	0.25316E-04	0.16404E-04	0.12302E-04	0.10084E-04	
0.20839E-05	0.30995E-05	0.10509E-06	0.28831E-10	0.10017E-24	
N2					
0.76700E+00	0.74777E+00	0.72862E+00	0.70947E+00	0.69028E+00	
0.39445E+00	0.29584E+00	0.19723E+00	0.98614E-01	0.00000E+00	

### 9.11.4. Stoichiometric Mixture Fraction

The stoichiometric mixture fraction for the flamelet library is required for computing the local equivalence ratio of the mixture, which is an important input parameter for the laminar burning velocity.

#### 9.11.4.1. Value

Specify the value for stoichiometric mixture fraction,  $0 < Z_{st} < 1$ .

#### 9.11.4.2. Reactants

Specify the reactants and their stoichiometric coefficients for the global reaction. The setup is the same as if it were for the reactants of an equivalent global single-step reaction. For example, if the flamelet library is a single component fuel burnt with air,  $\nu_F \text{Fuel} + \nu_{O_2} \text{O}_2 \rightarrow (\text{products})$ , then the stoichiometric coefficient for Fuel would be set to  $\nu_F$ , and for component  $\text{O}_2$ , the value would be set to  $\nu_{O_2}$ .

#### 9.11.4.3. Automatic

Select the automatic option to let the solver determine the stoichiometric mixture fraction from the flamelet library. This is an approximate method; when used, you should check the calculated value reported to the solver output file. For details, see [CFX-Solver Output File \(Combustion Runs\) in the CFX-Solver Manager User's Guide](#).

### 9.11.5. Laminar Burning Velocity

The laminar burning velocity is an input parameter for the burning velocity combustion model (partially premixed model).

#### 9.11.5.1. Value

Specify the laminar burning velocity. It is recommended that you use an expression that accounts for dependency of the burning velocity on equivalence ratio or mixture fraction. Properties of the unburnt mixture, such as temperature, density, specific heat capacity, and thermal conductivity may be used in order to account for preheating and mixture dependency.

#### 9.11.5.2. Metghalchi and Keck

Built-in correlation fitted for the laminar burning velocities of simple hydrocarbon fuels. The type of fuel is indicated by its carbon index, that is, the number of carbon elements in the fuel molecule:

Molecule	Carbon Index
Methane $\text{CH}_4$	1
Propane $\text{C}_3\text{H}_8$	3
Iso-octane $\text{C}_8\text{H}_{18}$ (gasoline)	8

The correlation accounts for preheat temperature and pressure. However, the flammability limits are assumed to be the same as at (25 [C], 1 [atm]) for all temperatures and pressure. Therefore, the correlation is expected to show its best accuracy at near-standard conditions.

### 9.11.5.3. Equivalence Ratio Correlation

Laminar burning velocity specified as the product of the burning velocity at reference conditions multiplied by corrections for preheat and pressure dependency. For details, see [Equivalence Ratio Correlation in the CFX-Solver Theory Guide](#).

#### 9.11.5.3.1. Reference Burning Velocity

Define the correlation for the laminar burning velocity at reference conditions as a function of the local equivalence ratio of the mixture.

- [Beta Function in the CFX-Solver Theory Guide](#)
- [Quadratic Decay in the CFX-Solver Theory Guide](#)
- [Fifth Order Polynomial in the CFX-Solver Theory Guide](#)

For the quadratic decay and fifth order polynomial options, the fit range defines the range of equivalence ratio for which the polynomials are valid. For equivalence ratios outside the fit range, the reference burning velocity is assumed to decay linearly until it becomes zero at the flammability limit.

#### 9.11.5.3.2. Flammability Limits

Specify the range for equivalence ratio in which the mixture is flammable. The laminar burning velocity becomes zero if the local equivalence ratio is less than the lean flammability limit or larger than the rich flammability limit.

#### 9.11.5.3.3. Preheat Temperature Dependency

Specify the reference temperature and the coefficients  $b_i$  for the temperature exponent. When all coefficients  $b_i$  are set to zero, there will be no dependency on preheat temperature.

#### 9.11.5.3.4. Pressure Dependency

Specify the reference pressure and the coefficients  $b_i$  for the pressure exponent. When all coefficients  $b_i$  are set to zero, there will be no dependency on pressure.

#### 9.11.5.3.5. Residual Material Dependency

Specify the coefficients  $c_i$  for the residual material dependency of the laminar burning velocity. The residual material dependency is optional. If unspecified or when all coefficients  $c_i$  are set to zero, there will be no dependency on the residual material concentration.

## 9.12. Autoignition Model

A flammable mixture residing at sufficiently high temperature will ignite without further interaction after some temporal delay. This phenomenon is called 'autoignition' or 'selfignition'. Depending on the application this may be either desired or adverse behavior. For example, it is an essential feature for compression-ignition (CI, Diesel, HCCI) engines. For spark-ignition (SI) engines autoignition is usually unwanted, and its occurrence is known as engine knock. A third example where autoignition may need to be considered is designing the length of a premixing section, for example, for a gas turbine combustor.

Classical combustion models like Eddy Dissipation, Flamelets, Burning Velocity Model or Extended Coherent Flame Model have been developed for high temperature combustion. The purpose of the autoignition model is to extend the primary combustion model with a special treatment for the lower temperature regime, thereby providing a combined model that is applicable over the combined range.

The low temperature regime is characterized by initial breakdown of fuel molecules and buildup of radical species. When the concentration of radicals is sufficiently high, they begin to feed the oxidation and the rate of heat release will increase. The combustion then transitions to the high temperature regime. The net effect of autoignition (or selfignition) is that significant heat release due to combustion occurs if, and only if, a certain delay time has expired. This is modeled by applying an 'Ignition Delay Time' to the combustion model.

Depending on the behavior of the principal combustion model, the reaction either needs to be suppressed for the delay time, or reaction needs to be enforced after the delay time has expired. This establishes the two kinds of autoignition models:

1. **Ignition Delay:** suppress combustion until delay time has expired; this is available for non-premixed models (Eddy Dissipation, Flamelet)
2. **Knock:** enforce combustion after delay time has expired; this is available for premixed or partially premixed models (BVM, ECFM).

### 9.12.1. Ignition Delay Time

The **Ignition Delay Time** defines the time to expire before autoignition occurs. The following options are available:

- **Douaud and Eyzat:** correlation for Gasoline
- **Hardenberg and Hase:** correlation for Diesel
- **Value:** user-defined correlation for ignition delay time (CEL)

### 9.12.2. Customize Knock Reaction Rate

When autoignition is detected for the **Knock** model, the fuel burns locally according to the **Knock Reaction Rate**. If unspecified the solver assumes a first-order Arrhenius rate with default coefficients. You may customize the coefficients by enabling the **Customize Knock Reaction Rate** option. The following options are available:

- **Arrhenius:** first-order reaction rate proportional to fuel available
- **Value:** specify custom reaction rate (to be applied locally when knock occurs).

The **Solution Change Factor** may be specified in order to limit the fraction of fuel consumed per time step (default=0.6 or 60%). Using this setting ensures that the fuel combustion is resolved by at least few timesteps; this can improve robustness significantly.

## 9.13. NO Model

The following topics will be discussed:

- [Introduction to the NO Model \(p. 331\)](#)
- [Fluid Models \(p. 332\)](#)
- [Initialization \(p. 332\)](#)

- [Solver Parameters](#) (p. 333)

### 9.13.1. Introduction to the NO Model

The NO model calculates mass fractions of NO (with user extensions) formed in the combustion process. It solves additional transport equations for these variables but does not affect the main combustion calculation. NO is treated as a regular component, but because NO concentrations are typically very low, the effect on the global flow and combustion is negligible.

The NO is created or destroyed through four mechanisms: thermal NO, prompt NO, fuel nitrogen, and NO reburn. The fuel nitrogen mechanism only affects coal and oil combustion. In CFX, the temperature variance and NO are solved together with the other equations. NO is treated as a regular component.

In CFX, the NO model is implemented by means of generic reactions with Arrhenius Temperature PDF reaction rates. Control for these reactions is the same as for Arrhenius rates, but with the following extensions:

- Temperature Limit List: The Upper and Lower Bounds should be specified for temperature integration range (2 values).
- Control for temperature variance transport equation currently is for expert users (editing the CCL in CFX-Solver input files)

The NO formation model consists of several parts:

- Predefined reaction schemes for NO formation that are provided by the REACTIONS database (available in CFX-Pre) and that are user-adjustable and extensible.
- Integration of the reaction rates for NO formation over a presumed Probability Density Function (PDF) in order to account for turbulent fluctuations of temperature.
- Solving a transport equation for temperature variance.

#### 9.13.1.1. NO Model with Eddy Dissipation / Finite Rate Chemistry / Combined Model

To model NO, select the reaction scheme with the suffix NO PDF (for example, Methane Air WD1 NO PDF) when creating your reacting mixture material. This will introduce NO as an additional component and add reactions for thermal and prompt NO.

The fuel nitrogen mechanism can be added by additionally selecting the HCN NO PDF multi step reaction (further adding HCN and HCO to the components).

When the fuel is methane, NO reburn can be enabled by adding the Reburn NO Methane PDF reaction. For other fuels the corresponding reaction is not predefined in the REACTIONS database. However, for a given fuel the reaction may be created by copying from the Reburn NO Methane PDF reaction, and changing the fuel and stoichiometry as appropriate.

#### 9.13.1.2. NO Model with Flamelet Model

When using the Flamelet model, you will need to define a new multi-step reaction scheme before you create your variable composition mixture, as the reaction is a multi-step reaction.

In the **Reaction** details view, create a new multistep reaction scheme and select the following reactions:

- The flamelet model library (for example, Methane Air Flamelet 298K 1 bar)

- `Thermal NO O Radical PDF` implements NO formation by the thermal NO mechanism using O radical information provided by the Flamelet library. This is in contrast to the standard `Thermal NO PDF` reaction that approximates O radical concentration from O<sub>2</sub> concentration and temperature. There is no need to do this when running the Flamelet model since O is one of the components.
- `Prompt NO <fuel> PDF` (where <fuel> is the name of the fuel; for example, `Prompt NO Methane PDF`). This reaction accounts for NO formation by the `prompt NO` mechanism.

The fuel nitrogen mechanism and the reburn mechanism can be added in the same way as for the Eddy Dissipation / Finite Rate Chemistry / Combined Model as described above.

The fuel nitrogen mechanism or the NO reburn mechanism can be added in the same way as for the Eddy Dissipation / Finite Rate Chemistry / Combined Model described above. For details, see [NO Model with Eddy Dissipation / Finite Rate Chemistry / Combined Model](#) (p. 331).

### 9.13.1.3. NO Model for Coal Combustion / Hydrocarbon Fuel Model

See [Hydrocarbon Fuel Model Setup](#) (p. 291) for a description of how to set up the combustion of a solid hydrocarbon fuel with NO formation.

## 9.13.2. Fluid Models

The models settings described in this section are set when creating a domain in CFX-Pre. For details, see [Domains in the CFX-Pre User's Guide](#).

### 9.13.2.1. Component Details

You should select `Transport Equation` for the NO component. A transport equation is solved for the NO component when NO is modeled, regardless of the combustion model used.

When running the EDM or Finite Rate Chemistry model, setting **Transport Equation** has the same effect as setting `Automatic`.

When running the Flamelet model, the flamelet library could also contain NO. In this case, specifying **Transport Equation** would activate the NO model discussed here. Specifying `Automatic` or `Library` would use NO from the library instead.

When the fuel nitrogen mechanism is added, the components HCN and HCO need to be specified with the same option as for NO. For example, when used in combination with the flamelet model, HCN and HCO should be set to `Transport Equation`.

### 9.13.2.2. Boundary Conditions

For NO, the default value 0 is appropriate in many configurations. When a fuel nitrogen mechanism is used, the HCN component must be set at the boundary according to the nitrogen content in the fuel.

## 9.13.3. Initialization

The same initialization settings as for regular components can be set (that is, the default initial condition for NO of 0 mass fraction is appropriate for many configurations).

---

**Tip**

The NOx model can have problems if it is enabled for the first few iterations of a simulation. For improved robustness, obtain an established flow field first and then turn the NOx model on.

### 9.13.4. Solver Parameters

The solver parameters depend on the type of combustion model you are running. The presence of NO does not affect the timestep or equation class settings.

## 9.14. Chemistry Post-Processing

The Chemistry Post-Processing model calculates material components and reactions one-way coupled to the main simulation. This is appropriate when the component mass fractions and the reaction rates are sufficiently small so that their effect on mixture properties and flow field may be neglected. This is the case for tracer materials or pollutants and their corresponding formation and destruction reactions (for example, the NO model).

Solving materials with post processing has the advantage that the corresponding transport equations are solved under the final flow and temperature fields from the beginning and, therefore, fewer iterations are required before convergence is reached. Further, post-processing allows for running different variations of the pollutant formation models based on the same (frozen) main solution.

The following topics will be discussed:

- [Fluid Models](#) (p. 333)
- [Solver Parameters](#) (p. 334)

### 9.14.1. Fluid Models

The model settings described in this section are set under the **Combustion Model** section when creating a domain in CFX-Pre. For details, see [Reaction or Combustion Model](#).

#### 9.14.1.1. Chemistry Post-Processing

Set the check box for chemistry post-processing to enable the model.

#### 9.14.1.2. Materials List

Specify the materials for post-processing. When a material is defined simultaneously as a component of the reacting mixture and is under chemistry post-processing, then the component will be post processed.

#### 9.14.1.3. Reactions List

Set the reactions for post-processing. It is allowed to specify reactions for post processing that are also defined in the reacting mixture material, in which case the reactions will be post processed. The result will be identical as if the reactions were only specified under chemistry post-processing.

## 9.14.2. Boundary and Initial Conditions

For post-processing materials, the same boundary conditions and initial conditions apply as for regular components.

## 9.14.3. Solver Parameters

The solver parameters depend on the type of combustion model you are running. The presence of chemistry post-processing does not affect the timestep or equation class settings.

## 9.15. Soot Model

The formation of soot in gaseous flames can result both in significantly enhanced radiative heat transfer, and in particulate pollution. Soot is important in flames in which the carbon to oxygen mole ratio is approaching unity, and its formation can be calculated using the model of Magnussen. For details, see [Soot Model in the CFX-Solver Theory Guide](#).

The following topics will be discussed in this section:

- [Fluid Models](#) (p. 334)
- [Boundary Settings](#) (p. 336)
- [Initialization](#) (p. 336)

A material describing soot must be created in the **Material** details view. The effect of soot on radiation can then be specified in the **Radiation Properties** section, as well as its density. For details, see [Material Properties Tab in the CFX-Pre User's Guide](#).

### 9.15.1. Fluid Models

The models settings described in this section are set under the **Combustion Model** section when creating a domain in CFX-Pre. For details, see [Domains in the CFX-Pre User's Guide](#).

#### 9.15.1.1. Soot Model

Set the **Soot Model** to `Magnussen` to enable the soot model.

#### 9.15.1.2. Fuel Material

The **Fuel Material** is a required parameter and should be set to the name of the fuel. In this release of CFX, only a single fuel is assumed to generate soot. If there are several fuel components, choose the one with the largest mass fraction and carbon content) and increase model coefficients accordingly. For example, set the **Fuel Carbon Mass Fraction** and **Nuclei Formation Pre Exponential Factor** such that the correct value for the following product is obtained:

*Fuel Carbon Mass Fraction \* Nuclei Formation Pre Exponential Factor \* Fuel Mass Fraction.*

#### 9.15.1.3. Soot Material

The **Soot Material** is a required parameter indicating which material in the Library contains its properties description for Density, Absorption Coefficient, and so on.

### 9.15.1.4. Fuel Consumption Reaction

This is an optional parameter, but you are strongly recommended to set an appropriate value for it. When using the EDM or Finite Rate Chemistry model, select the fuel break-up reaction. This reaction must be a single-step reaction.

The component specified for **Fuel Material** must be among the reactants of The Fuel Consumption Reaction and only those reactions are offered in the user interface.

If no Fuel Consumption Reaction is specified, a simplified version of the Magnussen model will be applied that is lacking some physical aspects (turbulence effects, soot combustion).

For the Flamelet or related combustion models (Burning Velocity Model, Extended Coherent Flame Model), the Fuel Consumption Reaction parameter is not available in the user interface. This is because these models define the fuel consumption by means of a Flamelet library, in contrast to a single reaction step. However, in this case the Fuel Consumption Reaction may be specified using CCL functionality (expert use), thereby enabling all features of the soot model in combination with models that do not use a single step for the primary combustion:

1. From the CFX-Pre user interface, create a separate Single Step reaction as follows:
  - a. Reactants and products corresponding to the global reaction that is represented by the Flamelet library.
  - b. All components of the new reaction should already exist in the Flamelet library.
  - c. Set the combustion model under the reaction definition to **Eddy Dissipation** and/or **Finite Rate Chemistry**. Additionally, **Finite Rate Chemistry** requires specification of the **Forward Reaction Rate**.
2. From the CFX-Pre user interface, add the newly created reaction to the list of reactions that define the reacting mixture.
3. From the Command Editor in CFX-Pre, use CCL to set the parameter Fuel Consumption Reaction under Soot Model so that it references the new reaction. The following is an example of the CCL for a single phase case:

```
FLOW:
  DOMAIN: <domain name>
  FLUID MODELS:
  COMBUSTION MODEL:
  SOOT MODEL:
    Option = Magnussen
    Fuel Material = CH4
    Soot Material = Soot
    Fuel Carbon Mass Fraction = 0.75
    Fuel Consumption Reaction = <reaction name>
  END
END
END
END
END
```

where *<domain name>* and *<reaction name>* are the names of the domain and new reaction, respectively.

### 9.15.1.5. Fuel Carbon Mass Fraction

The mass fraction of carbon in the fuel should be entered (for example, for methane enter 0.75 or 12/16).

### 9.15.1.6. Soot Particle Mean Diameter

This is also an optional parameter. The default value is 178.5 angstrom (where 1 angstrom =  $1.0 \times 10^{-10}$  m).

## 9.15.2. Boundary Settings

You can set the amount of soot at inlet and opening boundaries using one of the following two methods.

### 9.15.2.1. Mass Concentration and Nuclei Concentration

Specify the boundary condition data in volumetric concentrations (for example, soot in  $\text{kg}/\text{m}^3$  and soot nuclei in  $\text{mol}/\text{m}^3$ ).

### 9.15.2.2. Mass Fraction and Specific Nuclei Specific Concentration

Specify the boundary condition data in specific concentrations (for example, soot in  $\text{kg}/\text{kg}$  and soot nuclei in  $\text{mol}/\text{kg}$ ).

## 9.15.3. Initialization

Default initial conditions are zero for soot and soot nuclei. This is appropriate for most situations. You can optionally specify the volumetric or specific concentration.

## 9.16. Phasic Combustion

Combustion within different phases can be set up using different models with different phases. Refer to the relevant modeling doc for each type of combustion model for advice.

There is no mass transfer between phases for this release of CFX when setting up the default combustion models. You may set this up using interphase mass transfer, but the rates should be sufficiently small that there is no significant mass source.

## 9.17. General Advice for Modeling Combusting Flows in CFX

The following topics will be discussed:

- [General Procedure for Running Simulations](#) (p. 336)
- [Advantages and Disadvantages of Multistep Reaction Mechanisms](#) (p. 337)
- [Tips for Improving Convergence](#) (p. 337)
- [Advanced Combustion Controls](#) (p. 338)

### 9.17.1. General Procedure for Running Simulations

For many cases, such as the Combustion Tutorial, the run can be started using automatic initial guesses for most fields and the choice of model in the first part of the tutorial, (EDM) is the most robust of the combustion models. If you are having trouble getting a complex problem to converge, the following steps may aid convergence:

- Begin by specifying a single step reaction using the Eddy Dissipation Model.

- For initial conditions, specify **Oxygen** with a mass fraction of 0.232 and set each of the other species to `Automatic`.
- Allow the problem to converge to a reasonable level.
- Restart the problem with Finite Rate Chemistry or Finite Rate Chemistry/Eddy Dissipation Model using the results from the previous problem as an initial guess.
- Restarting the flamelet model from EDM does not work well because of the different model approach. This is because a previous EDM run would not provide mixture fraction mean and variance fields. Instead, it would be better to reduce the timestep for a few iterations.

Combustion introduces a strong coupling between scalars, energy and momentum. In difficult problems, you may find it helps to calculate a cold flow solution before turning on combustion.

In general for the Finite Rate Chemistry Model, the time scale of the combustion process is smaller, so you may have to continue with a smaller timestep to force the mass fraction and energy equations to converge. The time scale for the Eddy Dissipation Model is equal to the turbulence time scale ( $k/\varepsilon$ ).

In some cases, it may be appropriate to use a larger time scale for the mass fraction equations. This is particularly true when there are regions of small flow velocity in the domain. In these cases, the time needed to convect the components into all areas of the domain may be relatively large.

### 9.17.2. Advantages and Disadvantages of Multistep Reaction Mechanisms

Multi-step schemes allow for predicting a larger number of species and intermediate species like CO. They also apply if the fuel is a mixture of several species (for example, when modeling natural gas as a mixture of CH<sub>4</sub>, CO, and H<sub>2</sub>).

For multi-step schemes, the products limiter in the Eddy Dissipation model should not be turned on, because global extinction of the flame would happen with the commonly used value  $B = 0.5$ . Because of this, when applying multi-step schemes to premixed or partially-premixed systems it is recommended that you use the combined FRC/EDM model.

It is important to keep in mind that Finite Rate Chemistry does not account for turbulent fluctuations of temperature when computing temperature dependent reaction rates, unless the **Arrhenius with Temperature PDF** is used for the reaction rates.

Another consideration is that even though several reactions steps can be modeled, this usually remains a strong simplification from reality where dozens of species may be involved in hundreds of reactions simultaneously.

### 9.17.3. Tips for Improving Convergence

It is often useful to apply a larger timestep to temperature and species than the remaining equations. Try starting with a relatively large timestep to let the material sweep through the domain. You can reduce the timestep later to achieve better resolution of the simulation conditions and, therefore, convergence.

When using the Finite Rate Chemistry model, using a timestep that is too large at the beginning may cause the solver to fail due to reaction rates not converging. Under these circumstances, the timestep must be reduced.

Selecting the expert parameter `monitor_ranges` enables you to monitor species mass fractions and temperature. This is useful to check that the reaction has started, in particular when using Finite Rate Chemistry of the combined EDM/Finite Rate Chemistry model.

Additional information on expert parameters is available. For details, see [CFX-Solver Expert Control Parameters](#) (p. 465).

### 9.17.4. Advanced Combustion Controls

Global Dynamic Model Control for combustion takes effect when the EDM product limiter is enabled by setting **Eddy Dissipation Model Coefficient B** to positive. Global Dynamic Model Control for combustion disables the product limiter for the EDM model until after the Transition Iteration. This allows the specification of no products in the domain as a valid initial condition. Global Dynamic Model Control is always selected for combustion, regardless of the choice selected in CFX-Pre, as it provides the most appropriate solver behavior.

You can disable this feature by setting the **Transition Iteration** to 0 on the **Advanced Options** of the **Solver Control** form in CFX-Pre. Select **Combustion Control** and enter a number for the transition iteration.

---

## Chapter 10: Radiation Modeling

---

This chapter describes:

- 10.1. Comparison of the Radiation Models
- 10.2. Terminology
- 10.3. Material Properties for Radiation
- 10.4. Rosseland Model
- 10.5. The P1 Model
- 10.6. The Discrete Transfer Model
- 10.7. The Monte Carlo Model
- 10.8. General Radiation Considerations

CFX includes several radiation modeling options: The Rosseland model (or Diffusion Approximation model), the P-1 model (also known as the Gibb's model or Spherical Harmonics model), the Discrete Transfer model and the Monte Carlo model.

Many fluid flows of practical interest occur in situations where the fluid and/or the enclosing boundaries are hot. In such situations, the effect of radiant heat transfer may become important. A typical environment where radiation plays a significant role is a furnace or other such combustion chamber.

Two limits can be identified in the way that radiation interacts with a fluid or solid medium. One extreme is the situation where the medium is transparent to radiation at wavelengths in which the majority of the heat transfer occurs. In this case, the radiation only affects the medium by heating or cooling the surfaces of the domain, with no radiant energy transfer directly to the medium. Only the Monte Carlo model should be used for this limiting case. The Discrete Transfer model has also been used in this limit, but with limited success.

The opposite extreme is the situation in which the medium is optically dense, and radiation interacts with the medium throughout the interior of the domain, as well as at surfaces. If the medium is optically dense, radiant energy is either scattered, or absorbed and re-emitted in all directions with a small length scale compared to the size of the domain. This situation is known as the "diffusion limit," because radiant intensity is independent of direction. (Note that there is no assumption that the radiation is "diffuse," in the sense of "rarefied.") In this limit, the Rosseland and P1 models are an attractive alternative to the Discrete Transfer and Monte Carlo models because of their simplicity.

For general cases, ranging from optically thin (transparent) to optically thick (diffusion) regions, like combustion, the Discrete Transfer and the Monte Carlo models more accurately represent the solution of the radiative transfer equation.

The Thermal Radiation Model can be selected from the Fluids/Solids Models form on the Domains tab whenever a heat transfer model has been set to Thermal Energy or Total Energy. The default for the Thermal Radiation Model is `None`.

Once a thermal radiation model has been selected, two additional submodels must also be chosen: the spectral model and the scattering model. For details, see [Spectral Model](#) (p. 351) and [Scattering Model](#) (p. 352).

The radiation modeling options in CFX allow you to:

- Setup a gray/non-gray media enclosed by opaque diffuse surfaces, except at openings (inlets, outlets and openings), which are considered fully transparent. Symmetry planes and periodic boundaries are treated as specular surfaces when using the Discrete Transfer or Monte Carlo models.
- Select any of the thermal radiation models in any fluid or porous domains<sup>1</sup>. For solid domains, only the Monte Carlo option is available.
- Set up spectral dependent radiation quantities (material properties, radiation sources, directions, surface properties) via CEL expressions by using any of the available spectral variables: frequency, wavelength in vacuum, or wavenumber in vacuum.
- Setting of boundary conditions at walls, domain interfaces, and open boundaries: inlets, outlets and openings.

## 10.1. Comparison of the Radiation Models

In problems where thermal radiation is significant, the proper choice of the thermal radiation will affect not only the quality of the solution, but also the computational time it requires. Detailed thermal radiation calculations are time consuming, so proper selection must be made from physical considerations.

For problems in the diffusion or thick limit ( $\tau > 5$ ), all the modeling options will produce nearly the same results. Then, the best alternative is a balance between Rosseland and P1 models. As the optical thickness decreases and approaches 1, the P1 model becomes the least expensive alternative. Finally, in the thin limit and for purely transparent cases only the Monte Carlo and Discrete Transfer model should be used. For details, see [Optical Thickness in the CFX-Solver Theory Guide](#).

For gray models, where the radiation field is expected to be reasonably homogeneous everywhere (at least on a local basis), and high spatial resolution is required, the discrete transfer method is much more efficient and provides very accurate results if sufficient angular resolution is used.

A major advantage of the discrete transfer method is its fixed sampling in situations where the same mesh is to be used again and again, as in the case of a combined flow-radiation calculation for modeling a combustion chamber. In this case, the ray paths can be calculated once and stored giving a large improvement in efficiency. This is impossible with Monte Carlo because the photon trajectories depend on the absorption coefficient and walls emissivity.

A major problem with discrete transfer is the lack of error information. It is possible to perform angular sub-sampling for surface fluxes, for example, but this does not help with ray effects. If a source contribution has been missed by the complete ray sample, it will also be missed by the sub-sample. This can be dealt with by running a crude Monte Carlo simulation to detect any large errors.

The actual computational time needed by the discrete transfer method can also be very difficult to assess if iterations are needed to converge to the solution, as will be the case if scattering is present. The efficiency advantage of discrete transfer over Monte Carlo also rapidly disappears when non-gray models with a large number of spectral bands are to be computed. Discrete transfer treats each band independently and so the computational time increases in proportion to the number of bands used. Effectively N separate models are computed for an N-band model. The ray tracking is only done once, however. Because it is the radiative heat transfer that is computed, and the actual spectrum is of no interest, a Monte Carlo simulation is hardly affected by the number of bands as the spectrum is just another independent parameter to be sampled.

---

<sup>1</sup>As long as radiation does not travel through the solid separating two fluid domains, you may have different radiation models on each side of the solid.

Unlike Monte Carlo, all the physical quantities of interest are found at fixed points (due to the fixed sampling and ray discretization), not as surface or volume averages.

## 10.2. Terminology

The terms in this section include:

- *Absorptivity* (p. 341)
- *Diffuse* (p. 341)
- *Gray* (p. 341)
- *Opaque* (p. 341)
- *Reflectivity* (p. 341)
- *Spectral* (p. 341)
- *Transmissivity* (p. 341)

### 10.2.1. Absorptivity

Refers to the fraction of incoming energy that is absorbed at the surface.

### 10.2.2. Diffuse

Refers to quantities that do not depend on incoming or outgoing direction; however, they might be functions of temperature as well as location.

### 10.2.3. Gray

Refers to quantities that do not have spectral dependency (that is, they are not a function of frequency, wavelength, or wavenumber).

### 10.2.4. Opaque

Refers to a surface through which radiation cannot travel (that is, radiation is reflected and/or absorbed at the surface).

### 10.2.5. Reflectivity

Refers to the fraction of incoming energy that is reflected at a surface, and is a function of direction and frequency.

### 10.2.6. Spectral

Refers to a quantity that is a function of any of the spectrum variables: frequency, wavelength and wavenumber. The preferred variable is frequency, but to avoid inconsistencies when dealing with non-unitary refractive index materials, the wavelength or wavenumber in a vacuum are also supported.

### 10.2.7. Transmissivity

Transmissivity,  $\tau$ , refers to the fraction of incoming energy that travels through the surface; that is, the surface is semi-transparent when  $0 < \tau < 1$ , transparent when  $\tau = 1$  and opaque when  $\tau = 0$ .

## 10.3. Material Properties for Radiation

There are three material properties that must be defined in the **Material** details view for radiation simulations: absorption coefficient, scattering coefficient and refractive index. For details, see [Material Details View: Pure Substance in the CFX-Pre User's Guide](#). For multicomponent flows, set the properties in the **Mixture Properties** section of the **Material** details view because this can save substantial CPU time. For details, see [Mixture Properties Tab in the CFX-Pre User's Guide](#) and [Radiation Properties \(p. 46\)](#).

Absorption coefficient, scattering coefficient and refractive index may be a function of intensive thermodynamic variables such as temperature and pressure, as well as composition. In some applications, the radiative properties are not uniform in the whole spectrum (that is, non-gray media). In this situation, you may specify these properties as a function of the CEL spectral variables: frequency, wavelength in vacuum, or wavenumber in vacuum. The spectral variable is evaluated at the midpoint of the spectral band in frequency space.

## 10.4. Rosseland Model

The Rosseland approximation assumes that the media is optically thick and that radiant energy emitted from other locations in the domain are quickly absorbed and have no influence in the local transport. This implies that the approximation is not valid near walls. In CFX, special treatment is applied to wall boundaries to overcome this limitation. Other boundaries are not given any special treatment.

The Rosseland approximation is extremely convenient to use because it does not solve for an additional transport equation. It is usually valid for an optical thickness/depth greater than 5. It should not be used whenever the optical thickness is below 1 because it will affect robustness of the flow solver.

For details, see [General Radiation Considerations \(p. 346\)](#).

### 10.4.1. Fluid Models

Information on radiation modeling in multiple domains is available in [Domain Considerations \(p. 346\)](#).

#### 10.4.1.1. Include Boundary Temperature Slip

Optional parameter. For simulations where thermal radiation is by far the most dominant mode of heat transfer, a temperature slip must be allowed at physical boundaries (Siegel and Howell). By default, the temperature slip is not included.

Information on the mathematical implementation of this is available. For details, see [Rosseland Model \(p. 342\)](#).

#### 10.4.1.2. Spectral Model

See [Spectral Model \(p. 351\)](#).

#### 10.4.1.3. Scattering Model

See [Scattering Model \(p. 352\)](#).

### 10.4.2. Initial Conditions

Because the Rosseland model does not solve for any additional transport quantity, no initial guess or condition is required.

### 10.4.3. Solver Control

No specific advice is required for this model.

## 10.5. The P1 Model

The Differential Approximation or P1 adds an additional transport equation to the simulation, consequently it is more costly. The P1 model is valid for an optical thickness greater than 1. For example, the model has proved adequate for the study of pulverized fuel (PF) flames, in regions away from the immediate vicinity of the flame. However, it has been used for lower values with varying success.

The P1 model implementation in CFX only allows for opaque diffuse walls. That is, the diffuse fraction setting would then be ignored.

Open boundaries: Inlets, outlets and openings are treated as fully transparent boundaries. That is, they absorb all outgoing energy, and the incoming energy is computed as a blackbody at either the local temperature or at a user specified external blackbody temperature. For details, see [General Radiation Considerations](#) (p. 346).

### 10.5.1. Fluid Models

Information on radiation modeling in multiple domains is available. For details, see [Domain Considerations](#) (p. 346).

#### 10.5.1.1. Spectral Model

See [Spectral Model](#) (p. 351).

#### 10.5.1.2. Scattering Model

See [Scattering Model](#) (p. 352).

### 10.5.2. Initial Conditions

The radiation model is an additional energy transport mechanism; it does not create any additional sources of energy (except where the model provides for increased heat flow at boundaries). However, it does not follow that switching on the radiation model results in conservation of total energy within the system. The difference between the incident radiation and emitted radiation represents a heating or cooling effect. There is, therefore, a quantifiable energy “storage” (either positive or negative).

Suppose, for example, a combusting flow is solved with the radiation model initially set to `None`, and then radiation is turned on. Where the fluid is already hot (for example, owing to combustion), the default initial guess introduces a large amount of radiant energy into the domain. Note that incident radiation scales with the fourth power of the local temperature. This extra energy can take a long time to diffuse out of the domain. The default initial guess can therefore be poor for combusting flows.

By its nature, the incident radiation is more uniform throughout the domain than the medium temperature  $T_f$ . Thus, a uniform value of incident radiation everywhere might be a better initial guess. It is recommended that the chosen value for the incident radiation result in as small a change as possible in the energy storage within the flow domain. A suitable level can be obtained by integrating the radiant energy equation over the entire flow domain ( $\Omega$ ): For details, see [The P1 Model in the CFX-Solver Theory Guide](#).

$$4 \sigma \int_{\Omega} K_a (T_f^4 - T_r^4) dV = \int_{\partial\Omega} \frac{2 \sigma \varepsilon_w}{(2 - \varepsilon_w)} \left[ T_w^4 - T_r^4 \right] dA \quad (10-1)$$

where  $\partial\Omega$  is that part of the boundary where an “emissivity-specified” boundary condition is applied. Hence, an average constant value of  $T_r^4$  may be evaluated from:

$$\overline{T_r^4} \left\{ \int_{\Omega} K_a dV + \int_{\partial\Omega} \frac{\varepsilon_w}{2(2 - \varepsilon_w)} dA \right\} = \int_{\Omega} \left[ K_a T_f^4 \right] dV + \int_{\partial\Omega} \frac{\varepsilon_w}{2(2 - \varepsilon_w)} T_w^4 dA \quad (10-2)$$

where:

$$T_r^4 = \frac{1}{V} \int_{\Omega} T_f^4 dV \quad (10-3)$$

and  $V$  is the total volume.

### 10.5.3. Solver Control

No specific advice is required for this model.

## 10.6. The Discrete Transfer Model

This model is based on tracing the domain by multiple rays leaving from the bounding surfaces. The technique was developed by Shah (1979) and depends upon the discretization of the equation of transfer along rays. The path along a ray is discretized by using the sections formed from breaking the path at element boundaries. The physical quantities in each element are assumed to be uniform.

These rays have to be traced through the domain in the same way that the photons would be tracked in the Monte Carlo model. Therefore, the model description for both Monte Carlo and Discrete Transfer is identical.

For the results to be accurate the elements must be chosen so that the radiation field is reasonably homogeneous inside them. This means, for example, that they must be small enough that the scattering optical depth is less than unity across each element.

Non-gray models are dealt with by treating each band as a separate calculation (possible because scattering and reflection are assumed to be coherent). Tracking is done only once, and the results for the bands are combined to give the total radiative heat transfer.

For details, see *General Radiation Considerations* (p. 346).

### 10.6.1. Fluid Models

Information on radiation modeling in multiple domains is available. For details, see *Domain Considerations* (p. 346).

### 10.6.1.1. Number of Rays

To determine the direction of the rays, the unitary hemisphere over the face of a parametric element is discretized using spherical coordinates. The span is divided into angles by the number of rays, and rays directions are computed to pass through the center of the angles. In total, the square of the number of rays is traced from an element surface. The default is set to 8.

### 10.6.1.2. Transfer Mode

The **Transfer Mode** setting defines which radiative transfer mode is enabled. The default value is `Participating Media`; that is, the domain material emits, absorbs, and/or scatters radiation. The `Surface to Surface` option implies that volumetric emission, absorption and scattering are ignored regardless of the specified material properties.

### 10.6.1.3. Spectral Model

See [Spectral Model](#) (p. 351).

### 10.6.1.4. Scattering Model

See [Scattering Model](#) (p. 352).

## 10.6.2. Initial Conditions

Because this model is not solving a transport equation, no initial guess or condition is required. However, if a value is needed to properly evaluate the initial radiation term in the energy equation, the advice given for the P1 model should be considered.

### 10.6.3. Solver Control

See [Thermal Radiation Control](#) (p. 349).

## 10.7. The Monte Carlo Model

The Monte Carlo method simulates the underlying processes that govern the system of interest (that is, the physical interactions between photons and their environment). A photon is selected from a photon source and tracked through the system until its weight falls below some minimum at which point it 'dies.' Each time the photon experiences an 'event,' a surface intersection, scattering or absorption for example, the physical quantities of interest are updated. This process generates a complete 'history' of that photon in the system. Many photon histories need to be generated to get good estimates of the physical quantities of interest in a system. Photon sources are selected (that is, 'sampled') on the basis of emitted radiation, each band being treated independently for non-gray models.

In CFX, the main computational overhead in generating a history is in tracking the photons across the domain. It is therefore essential to produce a balanced description of the domain to efficiently track the photons. This is done by using a coarser mesh for the radiation field than for the flow field under the assumption that the radiation field has less sharp changes than any other transport variables. When the domain material does not emit, absorb, and scatter radiation, there is no need for a mesh in the volume because the radiation transfer is between the boundary surfaces only (see [Transfer Mode](#) (p. 346)). For details on mesh coarsening controls, see [Thermal Radiation Control](#) (p. 349).

## 10.7.1. Fluid Models

Information on radiation modeling in solid/multiple domains is available in [Domain Considerations](#) (p. 346).

### 10.7.1.1. Number of Histories

Optional parameter to indicate the total number of histories to be tracked for the simulation. The default value is 10000. For details, see [Monte Carlo Statistics](#).

### 10.7.1.2. Transfer Mode

The **Transfer Mode** setting defines which radiative transfer mode is enabled. The default value is `Participating Media` (that is, the domain material emits, absorbs, and/or scatters radiation). The `Surface to Surface` option implies that volumetric emission, absorption and scattering are ignored regardless of the specified material properties.

### 10.7.1.3. Spectral Model

See [Spectral Model](#) (p. 351).

### 10.7.1.4. Scattering Model

See [Scattering Model](#) (p. 352).

## 10.7.2. Initial Conditions

Similar to the Discrete Transfer model. For details, see [Initial Conditions](#) (p. 345).

## 10.7.3. Solver Control

See [Thermal Radiation Control](#) (p. 349).

## 10.8. General Radiation Considerations

This section contains advice on the topic of setting up radiation modeling in CFX-Pre.

- 10.8.1. Domain Considerations
- 10.8.2. Domain Interface Considerations
- 10.8.3. Boundary Details
- 10.8.4. Sources
- 10.8.5. Thermal Radiation Control
- 10.8.6. Spectral Model
- 10.8.7. Scattering Model

### 10.8.1. Domain Considerations

Whenever a domain material does not emit, absorb or scatter radiation, the `Surface to Surface` transfer mode option should be chosen. This option reduces the computational time without any changes in the results.

The following set of rules applies when modeling radiation in solid domains and in simulations with more than one domain:

- For solid domains where thermal radiation is important, the Monte Carlo model is the only available option.
- For domain interfaces using the Conservative Interface Flux option, the radiation model must be the same on both sides of the interface. That is, for Fluid-Solid, Solid-Solid, or Porous-Solid domain interfaces, the Monte Carlo model is the only available option.
- For a simulation with multiple solid domains, the radiation model can be set independently for each solid domain, subject to the previous rule.

## 10.8.2. Domain Interface Considerations

The following set of rules applies when modeling radiation through domain interfaces:

- For domain interfaces using the Conservative Interface Flux option, the radiation model must be the same on both sides of the interface.
- For a simulation with radiation and MFR interfaces, the two sides of the interface must be aligned and must have the same shape; no pitch change or orientation change is supported.
- For the Discrete Transfer and Monte Carlo radiation models, rotational periodic GGI interfaces are treated as symmetry conditions.

## 10.8.3. Boundary Details

The boundary condition options which appear will depend on the type of model you are using. Choices will come from the following:

### 10.8.3.1. External Blackbody Temperature

This setting represents the effective blackbody temperature of any bodies beyond that boundary. For example, in the instance that a body has a wall temperature of  $T_w$  and an emissivity of  $\varepsilon_w$  in the absence of any attenuation, the effective blackbody temperature is given by  $[\varepsilon_w T_w^4]^{0.25}$ . This temperature is not necessarily the same as the local temperature.

### 10.8.3.2. Local Temperature

The local fluid temperature must be used to account for the incoming radiation energy. It is extremely useful for outlets or openings when the external blackbody temperature is either unknown or much lower than the expected outlet temperature.

### 10.8.3.3. Radiation Intensity

Specify the mean radiation intensity only, and it is only supported by the P1 model.

### 10.8.3.4. Radiative Heat Flux

You can specify the radiative heat flux directly, and it is only supported by the P1 model.

### 10.8.3.5. Emissivity

At opaque boundaries, the emissivity must be supplied. It can be set as a function of spectral variables using CEL expressions when using the Multiband spectral modeling option.

### **10.8.3.6. Diffuse Fraction**

Diffuse fraction represents the ratio between the diffuse reflected energy and the total reflected energy at an opaque boundary. If the boundary is black (that is, unitary emissivity), this value has no meaning because no energy is reflected.

### **10.8.4. Sources**

Non-thermal radiation sources can be set when using either the Discrete Transfer or Monte Carlo radiation models.

These non-thermal radiation sources (fluxes at boundaries) are divided into 2 groups: isotropic and directional. The Directional Radiation Source and Directional Radiation Flux is only supported when using the Monte Carlo model.

The strength of the source or flux can be a function of the spectral variables: frequency, wavelength in vacuum, or wavenumber in vacuum when using the Multiband spectral modeling option.

#### **10.8.4.1. Directional Radiation Source**

It allows the specification of the source strength and its direction. The direction can be specified by either Cartesian Components or Cylindrical Components using a local axis.

#### **10.8.4.2. Isotropic Radiation Source**

This allows the setting of a single source strength when the source strength is uniform in all directions.

#### **10.8.4.3. Directional Radiation Flux**

Specifies collimated non-thermal radiation flux at boundaries. The direction can be set by using Cartesian Components, Cylindrical Components using a local axis, or Normal to Boundary. The external refractive index can be set. If the value is set, the refraction at the boundary is calculated automatically in a manner similar to that for radiation through domain interfaces; see [Radiation Through Domain Interfaces in the CFX-Solver Theory Guide](#). If the external refractive index is left unspecified it is assumed to have the same value as the material in the domain and the radiation will pass through the boundary without any refraction or reflection.

#### **10.8.4.4. Combining Radiation Sources**

The following combinations of directional radiation sources (available with the Monte Carlo Model) give incorrect answers with the current implementation:

- A directional radiation source and an isotropic radiation source within the same spectral band
- More than one directional radiation source at the same boundary within the same spectral band

For the Gray model (single band) these combinations can be set up in CFX-Pre and run in the CFX-Solver without generating any errors. However, the results will be incorrect.

#### **10.8.4.5. Isotropic Radiation Flux**

Specifies a directionally uniform, non-thermal radiation flux.

## 10.8.5. Thermal Radiation Control

The radiation modeling options based on ray tracing, Discrete Transfer and Monte Carlo, require additional controls. These controls are found on the **Advanced Options** tab of the **Solver Control** form.

Because these radiation models require considerable time, there are several ways to strike a balance between accuracy and computer time. This can be done by coarsening the fine mesh used for the flow field, or calculating the radiation field at a different frequency than the other transport equations.

### 10.8.5.1. Iteration Interval

It sets the frequency of the radiation calculation respect to the flow solver. If left unset, radiation will be calculated at each flow solver iteration (that is, 1).

### 10.8.5.2. Diagnostic Output Level

When performing the ray tracing calculation, either Discrete Transfer or Monte Carlo, several diagnostics can be written to the output file. The output is controlled as follows:

0 - Quiet. No output is reported to the output file even if minor problems have occurred. If the solver encounters a fatal error, it will stop automatically.

1 - Minimal. A diagnostic results file is written and warnings are reported. The diagnostic results file includes radiation quantities for each radiation element.

2 - Verbose. A diagnostic results file is written each radiation iteration and the solver will stop even for some warnings. This level is meant for debugging purposes only.

Information about the diagnostic results file is available. For details, see [CFX Radiation File in the CFX-Solver Manager User's Guide](#).

### 10.8.5.3. Ray Reflection Control

When modeling specular boundaries, a ray may be reflected multiple times. When the energy content of the original ray has dropped below the [Ray Reflection Threshold](#) (p. 350), the tracing is halted.

Increasing the threshold may reduce accuracy. In this case, energy residuals and imbalances may not be smooth over a restart, in particular when the radiation properties have evolved during the initial run.

Decreasing the threshold will result in longer traces. Because the energy content of the original ray decays along the trace, after a certain run length its contribution becomes negligible. Reducing the threshold below a certain level, thus excessively prolonging the traces, will then have no significant influence on results.

### 10.8.5.4. Coarsening Control

#### 10.8.5.4.1. Target Coarsening Rate

This represents the target ratio between elements in the fine mesh and radiation elements in the coarser mesh. The default value is 64; that is, the number of radiation elements is 64 times smaller than the number of elements in the fine mesh. The actual coarsening could be smaller than the target specified. A summary is presented in the Radiation Coarsening section of the output file.

#### **10.8.5.4.2. Minimum Blocking Factor**

This represents the minimum number of elements within a coarser element at a given coarsening level.

#### **10.8.5.4.3. Maximum Blocking Factor**

This represents the maximum number of elements within a coarser element at a given coarsening level.

#### **10.8.5.4.4. Small Coarse Grid Size**

It is the minimum number of radiation elements in the coarser mesh. The coarsening algorithm will stop when either this value or the target coarsening rate is achieved.

#### **10.8.5.4.5. Diagnostic Output Level**

Control the diagnostic information of the coarsening algorithm that is written to the output file.

### ***10.8.5.5. Ray Tracing Control***

This section only applies for the Discrete Transfer model.

#### **10.8.5.5.1. Iteration Interval**

Sets the frequency for the calculation of the ray tracks. Because the ray tracing is time-consuming and disk-intensive, it is rarely used. The default value is zero; that is, the tracks are computed only once and stored permanently.

#### **10.8.5.5.2. Maximum Buffer Size**

To minimize total memory usage and maximize disk throughput, information for the tracks is stored in a memory buffer before being written to disk. The **Maximum Buffer Size** parameter sets the maximum allowed buffer storage in words. The default value is 6000 words.

#### **10.8.5.5.3. Maximum Number of Tracks**

A single ray is made of tracks, the fraction of ray within a radiation element. In certain cases, highly specular surfaces with a small spacing, the rays may have infinite number of reflections before being totally absorbed. Whenever the number of tracks reaches this maximum, the tracing for this ray is halted, and the next ray is started. Default value is 4500.

#### **10.8.5.5.4. Maximum Number of Iterations**

Limits the inner loop when there are reflecting boundaries; otherwise, the first iteration usually satisfies the convergence tolerance (1%).

#### **10.8.5.5.5. Ray Reflection Threshold**

When modeling specular boundaries, a ray may get reflected multiple times. When the energy content of the original ray has dropped below this threshold, the tracing is halted.

#### **10.8.5.5.6. File Path**

Specifies the location to store the track files. This is only required when the local disk space is not large enough to store the track files, or a slave in a parallel run does not have access to the run directory.

## 10.8.6. Spectral Model

In CFX, three different spectral models are supported: Gray, Multiband, and Multigray or Weighted Sum of Gray Gases. Each of radiation modeling option can use the following spectral models:

### 10.8.6.1. Gray

The Gray model assumes that all radiation quantities are uniform throughout the spectrum. This simplifies the radiation calculation considerably because fewer equations should be solved. For combustion calculations, where certain gases are absorbing in finite regions of the spectrum and transparent for rest, it will introduce errors in the total radiative heat flux.

### 10.8.6.2. Multiband

The Multiband model discretizes the spectrum into bands of finite width and assumes that radiation quantities are nearly uniform within the band. The total radiative heat flux is computed by adding the results within each band. Each spectral band can be defined by different means: Frequency, Wavelength in Vacuum, or Wavenumber in Vacuum.

At least two different spectral bands must be set. The solver will check that the union of all spectral bands fully covers the thermal radiation part of spectrum and that they do not overlap. The wavenumber range should cover at least the range between 100 [cm<sup>-1</sup>] and 100,000 [cm<sup>-1</sup>] to cover the full thermal spectrum. A warning message will be written to the output file otherwise.

When using CEL expressions to describe the spectral variation of any radiation quantity, the solver will use the frequency for the spectral band.

### 10.8.6.3. Multigray/Weighted Sum of Gray Gases

This model assumes that gas absorption can be represented by a weighted sum of gray media. The weights and absorption coefficients have been correlated in the literature for a variety of gases (see Modest [8]). The current implementation does not provide a specific set of weights or coefficients, though there is a CFX-Pre template available. Therefore, you must specify the weights/amplitudes and the absorption coefficients for each gray gas.

Caution should be taken when specifying the set of coefficients:

1. There must be one clear gas.
2. Weights must add up to 1 at all times.


A Multigray CCL Template is available in the Library mode of CFX-Pre. For details, see [Multigray Radiation in the CFX-Pre User's Guide](#).

### 10.8.6.4. When is a Non-Gray Spectral Model Appropriate?

Although it is convenient to average radiation properties over the whole spectrum (Gray model), real gases only absorb and emit in discrete bands. Upon diffuse reflection at walls, radiation emitted by the gases within discrete bands is re-emitted at all wavelengths as thermal radiation with the characteristic blackbody spectrum. Although much of this reflected radiation will be reabsorbed by the gases, some will now lie outside the absorption bands of any of the gases present and will therefore pass through the gas volume without absorption.

This effect can be significant when it is important to distinguish between emission from gases and wall reflection, for example, in a reheat furnace, see [Figure 10.1 \(p. 352\)](#), where a thermal load is being heated directly by a gaseous flame (R1) and indirectly by a refractory wall (R2). If the emissivity of the refractory wall is increased (for example, by a special coating), the proportion of radiation with wavelengths outside the gaseous absorption bands increases and the intensity of radiation reaching the load becomes higher. If the radiative heat transfer in the reheat furnace is modeled using a Gray spectral model, then this effect would not be correctly predicted. The Multiband, and Multigray/Weighted Sum of Gray Gases models include a clear band and correctly predict an increase of radiative heat transfer to the load, as wall emissivity increases in the reheat furnace example.

**Figure 10.1 Example of a Reheat Furnace**



A more obvious limitation of the Gray model in combustion calculations is that a single absorption coefficient is set, independent of the local gas composition. This implies that the combustion air has the same radiative properties as the combustion products, although the latter contains a high percentage of  $\text{CO}_2$  and  $\text{H}_2\text{O}$ , which are highly efficient emitters of thermal radiation. The actual error caused by this approximation is not usually large because combustion air is usually at much lower temperatures than the products but, nevertheless, it leads to an overestimate of the absorption due to the air.

### 10.8.7. Scattering Model

The radiative transfer equation includes two terms due to scattering: attenuation by scattering or out-scattering and augmentation by scattering or in-scattering.

In CFX, the scattering term can be controlled independently in several ways. When using the Monte Carlo radiation model, you can optionally specify a scattering model. If you are using an option other than None, you must specify a **Scattering Coefficient** on the **Material Properties** form. If you specify a **Scattering Coefficient**, this does not automatically imply that a scattering model will be used, you must also select either the Gray or Linear Anisotropy models. For details, see [Material Details View: Pure Substance in the CFX-Pre User's Guide](#).

#### 10.8.7.1. Option = None

The scattering coefficient is ignored, even if a non-zero coefficient has been set for the medium. This option could be used, for example, for cases with clean participating gases, without particles, where the absorption coefficient is much larger than the scattering coefficient.

### **10.8.7.2. Option = Isotropic**

It assumes that in-scattering is uniform in all directions.

### **10.8.7.3. Option = Linear Anisotropy**

CFX includes support for the linear anisotropic phase function

$$\Phi = 1 + A (s \cdot s') \quad (10-4)$$

The anisotropy coefficient  $A$  must be supplied. If the coefficient has spectral dependency, it can be evaluated using CEL expressions using any of the spectral variables: `frequency`, `wavelength`, or `wavenumber`. By default, the coefficient  $A$  is set to zero.



---

## Chapter 11: Rigid Body Modeling

---

This chapter describes:

- 11.1. Introduction to Rigid Body Modeling
- 11.2. Rigid Body Motion
- 11.3. Modeling a Rigid Body
- 11.4. CEL Access of the Rigid Body State Variables
- 11.5. Monitor Plots related to Rigid Bodies
- 11.6. Solver Control of Rigid Bodies
- 11.7. Limitations to using Rigid Bodies

### 11.1. Introduction to Rigid Body Modeling

A rigid body is a solid object that moves through a fluid without itself deforming. Its motion is dictated by the fluid forces and torques acting upon it, plus any external forces (such as gravity) and external torques.

Within ANSYS CFX, a rigid body can be modeled in two ways:

- A rigid body can be defined by a collection of 2D regions that form its faces. When a rigid body is modeled in this way, the rigid body itself does not need to be meshed. Mesh motion is used to move the mesh on the rigid body faces in accordance with the solution of the rigid body equations of motion.
- Alternatively, an immersed solid can be defined to be a rigid body. In this case the motion of the immersed solid is dictated by the solution of the rigid body equations of motion.

### 11.2. Rigid Body Motion

ANSYS CFX computes the position and orientation of a rigid body using equations of motion. These equations can provide up to six degrees of freedom (“6 DOF”): up to three translational and up to three rotational degrees of freedom. You have full control over which degrees of freedom are allowed in a given simulation.


In the context of rigid bodies in ANSYS CFX, an orientation is represented by a collection of three *Euler angles* that follow the ZYX convention. Under this convention, a reference coordinate frame is reoriented so that it acquires the orientation of interest as follows:


- **Euler Angle Z** modifies the initial orientation by a rotation about the Z-axis (using the right-hand rule to determine the direction).
- **Euler Angle Y** then further modifies the orientation by a rotation about the (modified) Y-axis (using the right-hand rule to determine the direction).
- **Euler Angle X** then further modifies the orientation by a rotation about the (twice modified) X-axis (using the right-hand rule to determine the direction).

*Figure 11.1* (p. 356) shows a rigid body in an unmodified position. *Figure 11.2* (p. 357) shows the same rigid body after being reoriented. The mounting system has pairs of pins at each pivot location. The angle

that develops between a pair of pins at a given pivot is the Euler angle associated with the axis on which the pivot was initially located.

**Figure 11.1 Rigid Body with Initial Orientation**



**Figure 11.2 Rigid Body Reoriented with Euler Angles Shown**

For theoretical details about the rigid body implementations in ANSYS CFX, see [Rigid Body Theory in the CFX-Solver Theory Guide](#).

## 11.3. Modeling a Rigid Body

As stated in the introduction, there are two kinds of rigid bodies: those implemented as a collection of 2D faces and those implemented as an immersed solid.

The following sections describe how to model each type of rigid body:

11.3.1. [Modeling a Rigid Body as a Collection of 2D Regions](#)

11.3.2. [Modeling a Rigid Body using an Immersed Solid](#)

### 11.3.1. Modeling a Rigid Body as a Collection of 2D Regions

To set up a rigid body as a collection of 2D regions:

1. Insert and define a rigid body object.

The rigid body object holds settings that define: the rigid body characteristics, information about external forces and torques, which degrees of freedom are to be allowed, and initialization settings for the rigid body. Many of the settings are with respect to the *rigid body coordinate frame*, described in [Coord Frame in the CFX-Pre User's Guide](#). For details on the parts of the user interface relevant to this step, see [Rigid Body User Interface in the CFX-Pre User's Guide](#). The rigid body object, once created, is listed in the **Outline** tree view.

2. Ensure that the mesh motion in the related domain(s) reflects the motion of the rigid body by setting the **Mesh Motion** option for the boundaries that contain the rigid body faces to `Rigid Body Solution`. (Mesh motion requires, as a prerequisite, the **Mesh Deformation** setting of `Regions of Motion Specified` for the domain. For details, see [Mesh Deformation in the CFX-Pre User's Guide](#).)
3. As required, apply the **Mesh Motion** option `Rigid Body Solution` to other boundaries (**Boundary Details** tab) and subdomains (**Mesh Motion** tab) in order to move (consistently with the rigid body) parts of the mesh not on the rigid body faces. Properly done, this can help to maintain the mesh quality as the rigid body moves.
4. As required, apply motion constraints to any of the boundaries/subdomains that are governed by the rigid body solution.

The **Motion Constraints** setting is found in the **Mesh Motion** group of settings, which is found in the **Boundary Details** tab for boundaries and the **Mesh Motion** tab for subdomains.

As an example of applying a motion constraint, you might have a circular mesh interface surrounding the rigid body, and you might want the mesh on the outside of that interface to not rotate but still translate to follow the rigid body. In this case, you would apply the `Ignore Rotations` constraint on the outer boundary of the interface. This technique is demonstrated in [Editing the Domain Interfaces in Modeling a Buoy using the CFX Rigid Body Solver in the CFX Tutorials](#).

5. As required, adjust the settings that govern the rigid body solver. For a description of these settings, see [Rigid Body Control Tab in the CFX-Pre User's Guide](#).

### 11.3.2. Modeling a Rigid Body using an Immersed Solid

To set up a rigid body using an immersed solid:

1. Define an immersed solid using a **Domain Motion** option of `Rigid Body Solution`.  
For information about modeling immersed solids, see [Immersed Solids \(p. 14\)](#).
2. Configure the rigid body settings found on the **Basic Settings** tab for the immersed solid domain.

These settings are essentially the same as those on the **Basic Settings** and **Dynamics** tabs in the details view for the rigid body object; those tabs are described in [CFX-Pre User's Guide](#) at:

- [Basic Settings Tab](#)
- [Dynamics Tab](#).

### 11.4. CEL Access of the Rigid Body State Variables

The rigid body state variables hold the position, orientation, and the first and second derivatives of position and orientation, of a rigid body object or an immersed solid domain that is governed by a rigid body solution. The rigid body state variables can be accessed through CEL in CFX-Pre and CFX-Solver

Manager (but not in CFD-Post) via the `rbstate` function. For details on the `rbstate` function, see [Quantitative Function List in the CFX Reference Guide](#).

## 11.5. Monitor Plots related to Rigid Bodies

Using CFX-Pre, you can set up monitors that track the rigid body state by using CEL expressions that access the rigid body state variables. For details, see [CEL Access of the Rigid Body State Variables \(p. 358\)](#), [Setting up Monitors in the CFX-Pre User's Guide](#), and [Convergence History Plots and User Point Plots in the CFX-Solver Manager User's Guide](#). When you run the simulation, these monitors will be plotted on the **User Points** tab in CFX-Solver Manager.

When you run a simulation that involves a rigid body, you can see the following built-in monitor plots (in addition to any user point plots you have set up in CFX-Pre):

- Rigid Body Convergence

This plot appears on the **Rigid Body Convergence** tab. If this tab is not available, select the following menu item in CFX-Solver Manager: **Monitors > Rigid Body > Rigid Body Convergence**.

- Rigid Body Euler Angles

This plot shows, by default, the Euler angles describing the orientation of the rigid body with respect to the global coordinate frame.

This plot appears on the **Rigid Body Euler Angles** tab. To see this plot, select the following menu item in CFX-Solver Manager: **Monitors > Rigid Body > Rigid Body Euler Angles**.

- Rigid Body Position

This plot shows the position of the center of mass of the rigid body with respect to the global coordinate frame.

This plot appears on the **Rigid Body Position** tab. To see this plot, select the following menu item in CFX-Solver Manager: **Monitors > Rigid Body > Rigid Body Position**.

In each of these plots, you can edit the monitor properties (for example, by right-clicking in the plot and selecting **Monitor Properties** from the shortcut menu) to change which plot line variables are plotted. Not all of the variables pertaining to rigid bodies appear in the built-in plots by default; some plot line variables must be manually selected in order for them to appear in a plot. For example to plot the components of angular acceleration, angular velocity, linear acceleration, or linear velocity of a rigid body, you would have to edit the monitor properties of a plot and select the corresponding plot line variables.

---

### Note

All of the plot line variables pertaining to a rigid body are with respect to the global coordinate frame.

## 11.6. Solver Control of Rigid Bodies

The rigid body motion is controlled by the rigid body solver, which is called by the main flow solver. Each call to the rigid body solver is made immediately before the step of processing mesh motion.

You can choose when the rigid body solver is called. You can also change the convergence criteria and amount of under relaxation applied by the rigid body solver. For details, see [Rigid Body Control Tab](#) in the *CFX-Pre User's Guide*.

## 11.7. Limitations to using Rigid Bodies

The following is a list of limitations that apply when using rigid bodies:

- When modeling an immersed solid governed by the rigid body solver, you cannot set initial conditions (as you can for the rigid body object).
- Rigid bodies cannot be modeled in an ANSYS Multi-field (MFX) simulation.
- There is no collision modeling to detect when a rigid body contacts a solid wall or another rigid body.
- Rigid bodies cannot be modeled in a rotating domain.
- The built-in spring models are limited. However, you may be able to use CEL expressions to apply forces and torques that simulate a general spring. When working with CEL, you can use the `rbstate` function to get information about the rigid body position and orientation. For details, see [rbstate](#) in the *CFX Reference Guide*.
- Only simple motion constraints are possible. For example, there is no straightforward way to constrain the motion of a rigid body so that it rotates about a point other than its own center of mass.
- The rigid body coordinate frame definition should not be changed when a case is restarted.

---

## Chapter 12: Real Fluid Properties

---

This chapter describes:

- 12.1. Setting up a Dry Real Gas Simulation
- 12.2. Table Interpolation and Saturation Curve Clipping
- 12.3. Equilibrium Phase Change Model
- 12.4. Setting up an Equilibrium Phase Change Simulation
- 12.5. Important Considerations
- 12.6. Real Gas Property (RGP) File Contents
- 12.7. Real Gas Property (RGP) File Format
- 12.8. Parameters in the .rgp File Controlling the Real Gas Model

For many classes of problems, the thermodynamic properties for a gaseous pure substance are closely approximated by the ideal gas equation of state. The assumptions associated with an ideal gas are especially suited for compressible gas flows at low density, which in practical terms can be stated to be appropriate under the following conditions:

1. At very low pressures, ideal gas equations of state can be used, regardless of temperature, with good accuracy as long as no phase change occurs.
2. When the pressure is low relative to the critical pressure and the temperature is high relative to the critical temperature.

For flows where the pressure and temperature ranges vary, such that the density approaches a significant fraction of the critical density, molecular interactions start to become significant and the ideal gas equation of state is no longer appropriate. In this case, a real gas equation of state may be required to give a better representation of the fluid behavior. This includes regimes with flows of dense gases, or liquids at high pressures above the critical point, or, possibly flows with phase change.

Within CFX, you can use real gas equations of state that are appropriate for this type of regime. CFX has the capability to deal with flows of both superheated vapors and subcooled liquids, while at the same time using equilibrium or non-equilibrium models for phase change mass transfer rates.

This documentation describes the real fluid model capabilities within CFX. It describes material property setup, model setup and modeling considerations for performing calculations that do not involve phase change (vapors or liquids only) and also calculations which do involve phase change (condensing vapors or liquids with evaporation, cavitation or boiling).

The most general setup in CFX allows both equilibrium and non-equilibrium phase change models to be run, and there are specific, built-in models which apply to both kinds of phase change modeling. From a modeling standpoint, this document mainly focuses on how to set up and run the homogeneous equilibrium phase change model, however much of the advice is equally applicable to the non-equilibrium models as well.

Non-equilibrium phase change models are available when using Eulerian multiphase and Particle Transport. The physical properties of the two phases undergoing phase change are set up in a manner similar to what is described here for both of those approaches. For details, see:

- [Thermal Phase Change Model \(p. 213\)](#)

- [Mass Transfer](#) (p. 254).

## 12.1. Setting up a Dry Real Gas Simulation

There are several methods available to model real gases in CFX:

- Using a real gas cubic equation of state.
- Using the IAPWS equation of state (for water).
- Using Real Gas Property tables (in CFX-TASCflow format).
- Using a general, user supplied, equation of state.

### 12.1.1. Using a Real Gas Equation of State

It is recommended that one of the Real Gas equations of state (Aungier Redlich Kwong or Peng Robinson) is used as this is the most flexible option in terms of allowing different temperature and pressure ranges. There is no need to deal with `.rgp` files (discussed below) because the flow solver automatically calculates properties. The implementation of real gas cubic equations of state are discussed in the flow solver theory documentation. For details, see [Real Gas Properties in the CFX-Solver Theory Guide](#). To use cubic equations of state, the following substance dependent quantities are required:

- Critical Temperature
- Critical Pressure
- Critical Volume
- Boiling Temperature
- Acentric Factor
- Zero pressure (Ideal Gas) specific heat capacity

The default pressure range for this option is 0.01 bar to 10 bar and the default temperature range is 100 K to 1000 K.

Many presupplied materials which use the Real Gas equation of state are contained in the `MATERIALS-redkw.ccl` and `MATERIALS-pengrob.ccl` files and are grouped into a few different categories. The materials are suitable for dry gas flows or flows with change of phase.

#### 12.1.1.1. Redlich Kwong Dry Steam

Only water vapor appears in this group. This material is suitable for real gas flows of steam.

#### 12.1.1.2. Redlich Kwong Dry Refrigerants

This group contains several refrigerants including R11, R12, R123, R124, R125, R134, R134a, R141b, R143, R143a, R152a, R22, R23, R32, R410a, CO<sub>2</sub>, and NH<sub>3</sub>.

R410a is modeled using critical point properties, acentric factor and ideal gas specific heat coefficients obtained from NIST REFPROP V7.0 assuming a fixed composition of 50% R32 and 50% R125 by mass

### 12.1.1.3. Redlich Kwong Dry Hydrocarbons

This group contains a variety of common hydrocarbons including Methane ( $\text{CH}_4$ ), Acetylene ( $\text{C}_2\text{H}_2$ ), Ethene ( $\text{C}_2\text{H}_4$ ), Ethane ( $\text{C}_2\text{H}_6$ ), Ethanol ( $\text{C}_2\text{H}_6\text{O}$ ), Propene ( $\text{C}_3\text{H}_6$ ), Propane ( $\text{C}_3\text{H}_8$ ), 1-Butyne ( $\text{C}_4\text{H}_6$ ), Cyclobutane ( $\text{C}_4\text{H}_8$ ), Butane ( $\text{C}_4\text{H}_{10}$ ), Pentane ( $\text{C}_5\text{H}_{12}$ ), Benzene ( $\text{C}_6\text{H}_6$ ), Hexane ( $\text{C}_6\text{H}_{14}$ ), Toluene ( $\text{C}_7\text{H}_8$ ), Octane ( $\text{C}_8\text{H}_{18}$ ), Nonane ( $\text{C}_9\text{H}_{20}$ ), and Decane ( $\text{C}_{10}\text{H}_{22}$ ).

### 12.1.1.4. Dry Redlich Kwong

This group contains various pure fluids which do not appear in any of the other groups and includes Argon, Carbon Monoxide, Carbon Dioxide, Chlorine, Deuterium, Fluorine, Hydrogen, Hydrogen Sulfide, Helium, Nitrogen, Neon, Oxygen, Para-Hydrogen, Sulfur Dioxide and Ozone.

## 12.1.2. Metastable States and Saturation Curve Clipping


When you use a cubic equation of state for a dry vapor calculation or for non-equilibrium phase change calculations (using the thermal phase change model or small droplet phase change model), the flow solver allows the vapor and liquid states to go inside the saturation dome locally. The properties are clipped at the vapor or liquid spinodal curve. The spinodal curve defines the boundary beyond which the equation of state is no longer valid because the local derivative of pressure with respect to volume becomes positive. State points predicted inside the dome, up to the spinodal curve, are called "metastable" because normally they only exist temporarily in small local regions until phase change occurs.

For example, metastable states may occur during the calculation when the vapor cools below the local saturation temperature due to rapid flow expansion (called supercooling) or the liquid temperature locally rises above saturation due to rapid heating or compression (called superheating). For cases without phase change these states can occur and continue to persist depending on the problem setup.

As an example, the following diagrams illustrate what the spinodal curves look like on a pressure-volume diagram and pressure-temperature diagram for water.


## Pressure Volume Diagram For Water

Redlich Kwong Equation of State



## Vapour Pressure Diagram for Water

Redlich Kwong Equation of State



As you can see, the spinodal states for water vapor allow the vapor to cool below the saturation temperature, and similarly for liquid water heat above the saturation temperature. Normally, though, these states do not remain stable for long before phase change happens.

When you run an equilibrium phase change calculation, it is not necessary to predict metastable states inside the saturation dome, so the vapor and liquid properties are clipped at the saturation curve instead of the spinodal curves.

The spinodal curves are derived directly from the equation of state by finding where  $(dp/dv)|_T = 0$ . The vapor pressure curve can be derived from a general equation of state by Gibbs energy minimization. However, to reduce computational cost, the cubic equation of state models assume the saturation curve is given by an equation from Poling et al. [84]:

$$\log_{10} \left( \frac{p_v}{p_c} \right) = \frac{7}{3} (1 + \omega) \left( 1 - \frac{T_c}{T} \right) \quad (12-1)$$

where  $\omega$  is the acentric factor. The acentric factor is a property of a pure fluid and is tabulated in many different thermodynamics references (see, for example, [84]). This equation accurately predicts the saturation curve for most cubic equations of state. If the acentric factor is not tabulated it can easily be estimated using an alternative form of the vapor pressure curve (for example, the Antoine equation) and the following equation:

$$\omega = -\log_{10} \left( \frac{p_v}{p_c} \right) - 1.0$$

where  $p_c$  is the critical pressure and the vapor pressure,  $p_v$ , is evaluated from the Antoine equation, with the temperature set equal to  $T = 0.7 T_c$ . However, using the Antoine equation also requires that the Antoine coefficients be known.

### 12.1.3. Additional Comments

As mentioned above, the flow solver also requires that you supply the ideal gas specific heat capacity coefficients. These coefficients allow the flow solver to calculate the specific heat capacity as a function of both temperature and pressure. The **Real Gas Zero Pressure Coefficients** option is used for this purpose and is described in the modeling documentation. For details, see *Real Gas* (p. 42).

When running this equation of state it is highly recommended that you select the **Rigid Non Interacting Sphere or Interacting Sphere Model** for dynamic viscosity and the **Modified Eucken Model** for thermal conductivity.

The use of the Redlich Kwong cubic state equation model for flows of almost entirely pure liquid (eg: single phase liquid problem, boiling, cavitation) is highly discouraged. If you want to use one of the cubic equations of state for this type of problem then you should use the Peng Robinson equation of state instead, which, by default will force the liquid phase properties to be dependent on temperature and pressure fully consistent with that equation of state.

### 12.1.4. Using the IAPWS Equation of State

The IAPWS Equation of State is recommended for water calculations. For details, see *IAPWS Equation of State in the CFX-Solver Theory Guide*. There are several predefined IAPWS material definitions available for use, which differ only in the pressure and temperature ranges they cover. If you need to operate outside of these ranges, it is recommended that you choose one of the predefined materials and change the table generation details to cover the required range

## 12.1.5. Using Real Gas Property (RGP) Tables

### 12.1.5.1. Loading .rgp files

If you have created your own .rgp file, you just create a new material in CFX-Pre in the materials tab. On the **Material Properties** form, set the **Option** to `Table` and fill in the file name and component name fields. For details, see [Table](#).

### 12.1.5.2. Comments on Pressure and Temperature Ranges

If you use an .rgp file for material properties, you must ensure that your application falls within the temperature and pressure ranges used to generate the tables. .rgp tables can be generated using your own table generator or, if you have the latest version of CFX-TASCflow, you can create an .rgp file using the Real Gas Properties generator. If you do not have CFX-TASCflow, then the built in Real Gas or IAPWS equations of state are a convenient option because the flow solver automatically calculates all necessary properties.

### 12.1.5.3. Saturation Curve Clipping

Even when you run a dry vapor calculation with an .rgp file the flow solver automatically clips the vapor properties at the saturation curve provided in the .rgp file. If you create your own .rgp file you must ensure that the one dimensional saturation curves stored with each two dimensional table and the critical point have correct values. Note that, if desired, these curves can also be filled in with spinodal data so that an .rgp file can be used for modeling non-equilibrium phase change applications. Either way, if these data are not filled in with valid values then the clipping will not work. The correct way to fill in these values is described in a later section. For details, see [Real Gas Property \(RGP\) File Format](#) (p. 378).

## 12.1.6. Using a General Setup (CEL or User Fortran)

For any other real fluid calculation, you only need to set up a pure substance, set the **Thermodynamic State** to `Gas` or `Liquid`, set the properties option to `General Material`, then provide your own equation of state, by supplying an expression (CEL or User Fortran) for the fluid density and specific heat capacity. The flow solver automatically builds tables for both enthalpy and entropy

If you are unsure or not concerned about the real behavior of the specific heat capacity, then you can select the `Zero Pressure Polynomial` option, although keep in mind that this makes both specific heat and enthalpy a function of temperature only. For details, see [Zero Pressure Polynomial](#) (p. 42).

In addition, when you set the density or specific heat capacity using expressions or User Fortran, you must be careful to ensure that the values are consistent. Because the flow solver uses exact differentials of enthalpy and entropy to calculate tables, the coefficients of the differential terms for both enthalpy and entropy must obey the exact differential property. For details, see [Static Enthalpy in the CFX-Solver Theory Guide](#).

For transport properties of real gases, like dynamic viscosity and thermal conductivity, it is recommended that you use one of the built in temperature dependent models based on the kinetic theory of gases. For example, `Sutherlands Formula` for both properties or, like the Real Gas equations, simply combine the `Rigid Non Interacting Sphere Model` or `Interacting Sphere Model` and `Modified Eucken Model`. For details, see [Transport Properties](#) (p. 44). For real liquids, none of the presupplied transport property models are appropriate and another selection should be used.


### 12.1.6.1. Saturation Curve Clipping

When using a general setup, the flow solver makes no assumption about the form of the vapor pressure curve so it does not clip any properties at saturation. You will have to be careful to ensure that your equation of state is well-behaved if it approaches or crosses the vapor pressure curve to predict meta-stable states. Many equations of state are not well behaved inside the dome and robustness problems may result if the enthalpy and pressure (solved for by the flow solver) go past the spinodal curves.

## 12.2. Table Interpolation and Saturation Curve Clipping

As was mentioned in the previous sections, when running with the Redlich Kwong equation of state or a user supplied .xgp file, the flow solver clips two dimensional property tables at the spinodal or saturation curves. For any other definition of properties, no clipping is performed.

Because all properties stored inside the flow solver are in terms of pressure and temperature, the clipping process can be understood by analyzing it on a pressure-temperature diagram, which separates the liquid and vapor regions. The two dimensional tables typically span a given temperature and pressure range and are resolved with a number of points in both directions. The figure drawn below shows a rectangular region where the pressure and temperature range span across the critical point.



Below the critical point, the liquid and vapor regions are separated by the saturation curve and above the critical point, say for  $p > p_{\text{critical}}$ , there is no difference between the liquid and vapor states.

One problem with evaluating liquid properties is that not all equations of state accurately predict properties in the subcooled liquid region where  $T > T_{\text{critical}}$ . When using the Redlich Kwong equation of state the flow solver generates vapor property tables which cover the entire pressure and temperature range except for the subcooled liquid region below the critical pressure and temperature. In the vapor region below the critical temperature, the flow solver will automatically clip vapor properties along the spinodal curve or saturation curve as necessary.

When using an .xgp file, the one-dimensional saturation tables which are used for clipping the two-dimensional tables must be properly filled in with saturation or spinodal data as required by the model being run. So, for example, if you want to run the equilibrium phase change model, then the vapor values of  $h_{\text{sat}}(p) = h(T_{\text{sat}}(p), p)$  for  $p < p_{\text{critical}}$  and  $h_{\text{sat}}(p) = h(T_{\text{critical}}, p)$  for  $p > p_{\text{critical}}$  must be supplied. If you generate your own .xgp files, you should always generate the saturation table data in this manner.

## 12.2.1. Table Interpolation

When the flow solver needs to interpolate a value of  $\varphi$  at a given temperature,  $T$ , and pressure,  $p$ , (for example, the common calculation of  $h(T, p)$ ) there are three possible regions for the interpolation to happen: supercritical (point 1), vapor (point 2) and liquid (point 3).

For any of these regions there are three possible interpolation options available in the flow solver available by setting the following expert parameter:

```
EXPERT PARAMETER:
  prop interp option = 1, 2, or 3 (default)
END
```

Option 1 tells the flow solver to use no saturation clipping, option 2 always uses saturation clipping assuming that saturation data has been extended along the critical isotherm, and option 3 (Default) uses no saturation clipping above the critical pressure.

### $\varphi(T_1, p_1)$ : Interpolation in the supercritical region

For this region there is a slight difference between option 2 and option 3 interpolation.

Option 2: Interpolation for vapors or liquids is performed the same as if the point were below the critical point.

Option 3: First the solver checks if  $p < p_{\text{critical}}$  and  $T < T_{\text{critical}}$ . If this condition is met, then the procedures given below are used. If not, then a standard bilinear interpolation is used from the four table values which enclose the desired point. This would correspond to point 1 on the figure.

### $\varphi(T_2, p_2)$ : Vapor side interpolation below the critical point

Option 2 and option 3 are equivalent in this case.

If  $p < p_{\text{critical}}$  and  $T < T_{\text{critical}}$  then the flow solver detects if the interpolated value must be clipped to the saturation value. This is done by first looking up the table location where the value of  $p$  is located and then calculating  $T_{\text{sat}}(p)$  and  $\varphi_{\text{sat}}(p)$ . If  $T > T_{\text{sat}}(p)$  then the solver does not need to clip to saturation and standard bilinear interpolation is used. If  $T < T_{\text{sat}}(p)$  then the solver simply sets the interpolated value of  $\varphi$  to  $\varphi_{\text{sat}}(p)$ .

### $\varphi(T_3, p_3)$ : Liquid side interpolation below the critical point

---

#### Important

This feature is unsupported for .rgp files and the Real Gas equation of state, but is fully supported for the IAPWS equation of state. It can be accessed only when using an additional expert parameter with the Redlich Kwong equation of state or an .rgp file and some custom flow solver CCL that forces the flow solver to read the two dimensional tables for a liquid. In a future release this feature will be superseded.

For liquids the recipe is almost the same as for a vapor. First the solver looks up the table location where the value of  $p$  is located and calculates  $T_{\text{sat}}(p)$  and  $\varphi_{\text{sat}}(p)$ . If  $T < T_{\text{sat}}(p)$  then the solver does not need to clip to saturation and standard bilinear interpolation is used. If  $T > T_{\text{sat}}(p)$  then the solver simply sets the interpolated value of  $\varphi$  to  $\varphi_{\text{sat}}(p)$ .

### 12.2.2. Table Inversion

There are many cases where the flow solver must calculate one of the table independent variables when given the dependent variable and the other independent variable. For example, the flow solver calculates static enthalpy and pressure from the flow solution. To calculate static temperature, you take those values and invert the  $h(T, p)$  table. This is the most common example of table inversion used by the flow solver. The table inversion algorithm that includes saturation clipping, is similar to the interpolation algorithm. The `prop interp option` expert parameter also applies to table inversion.

The following two examples assume that  $p$  and  $\varphi$  are given and you need to compute  $T$  ( $\varphi$  in this case is usually enthalpy).

$\varphi(T_1, p_1)$ : **Supercritical table inversion**

Option 2: Table inversion is performed in the same way as for below the critical point.

Option 3: Standard table inversion, without saturation clipping is used if  $p > p_{\text{critical}}$ . If  $p < p_{\text{critical}}$  then saturation clipping is used.

An example of standard table inversion is calculating the value of temperature, given enthalpy and pressure. First the location of the value of  $p$  is located along the pressure axis. At that location, the solver searches along the two adjacent isobars for the enthalpy values which bound the given value of  $h$ . Once the table location is found (both  $p$  and  $h$  ordinates) the temperature is backed out using bilinear interpolation.

$\varphi(T_2, p_2)$ : **Vapor side table inversion**

Option 2 and option 3 are equivalent in this region.


The recipe is slightly different when you include saturation clipping. First the flow solver looks up the table location where the value of  $p$  occurs and calculates  $T_{\text{sat}}(p)$  and  $h_{\text{sat}}(p)$ . If  $h > h_{\text{sat}}(p)$  then the flow solver searches for the table location where  $h$  occurs starting at the saturation curve rather than at  $T_{\text{min}}$ , ignoring the liquid region to the left. Once the flow solver finds both table locations ( $p$  and  $h$  ordinates) the temperature is backed out using bilinear interpolation. Alternatively, if  $h < h_{\text{sat}}(p)$  then temperature is simply set to  $T_{\text{sat}}(p)$ . (Liquid side inversion works the same way but in the opposite sense.)

## 12.3. Equilibrium Phase Change Model

The equilibrium phase change model is a single fluid, multicomponent phase change model. The model is especially suitable for flows of condensing vapors (e.g., wet steam or refrigerants) with small liquid mass fractions but it can also be used for some melting or solidification problems as well.

This model assumes that the mixture of the two phases is in local thermodynamic equilibrium. This means that the two phases have the same temperature and that the phase change occurs very rapidly, such that the mass fractions may be determined directly from the phase diagram.

In addition to the superheat region, the equilibrium phase change model requires knowledge of the phase diagram of the material being modeled. Consider the following diagram that shows two lines of constant pressure that go through the saturation dome on a temperature-entropy diagram for a vapor-liquid mixture.



To the left of the dome, the entropy is lower than the saturation entropy of the liquid, and the mixture is all liquid. To the right, the entropy is greater than the saturation entropy of the vapor, and the mixture is all vapor. In the remaining region, underneath the saturation dome, the mixture contains both liquid and vapor.

To determine the mass fraction of the vapor, or quality ( $x$ ), the flow solver uses the lever rule:

$$x = \frac{h_{\text{mix}} - h_{\text{sat},l}(p)}{h_{\text{sat},v}(p) - h_{\text{sat},l}(p)} \quad (12-2)$$

where  $h_{\text{mix}}$  is the mixture static enthalpy calculated by the flow solver (either directly or from total enthalpy), and  $h_{\text{sat},l}(p)$  and  $h_{\text{sat},v}(p)$  are the saturation enthalpies of the liquid and vapor respectively as a function of pressure. The following observations can be made about the quality:

- When  $x < 0$ , the mixture is 100% subcooled liquid so the liquid properties are selected.
- When  $x > 1$ , the mixture is 100% superheated vapor so the vapor properties are selected.
- When  $0 \leq x \leq 1$ , the mixture contains liquid and vapor. The bulk mixture properties are calculated using the lever rule. Using the mass fraction of vapor and the saturated liquid and vapor properties this gives:

$$\varphi_{\text{mix}}(p) = (1 - x_v) \varphi_{\text{sat},l}(p) + x_v \varphi_{\text{sat},v}(p) \quad (12-3)$$

where  $\varphi$  is a property such as entropy, enthalpy, specific heat, thermal conductivity or dynamic viscosity. Because density is volumetric, saturated density is calculated using harmonic averaging instead:

$$\frac{1}{\rho_{\text{mix}}} = \frac{1 - x_v}{\rho_{\text{sat},l}} + \frac{x_v}{\rho_{\text{sat},v}} \quad (12-4)$$

Derivatives of density with respect to pressure along the saturation line are derived from the harmonic average expression using the chain rule:

$$\left( \frac{\partial \rho_{\text{mix}}}{\partial p} \right)_X = \rho_{\text{mix}}^2 \left( \frac{1 - x_v}{\rho_{\text{sat},l}^2} \left( \frac{\partial \rho_{\text{sat},l}}{\partial p} \right)_X + \frac{x_v}{\rho_{\text{sat},v}^2} \left( \frac{\partial \rho_{\text{sat},v}}{\partial p} \right)_X \right) \quad (12-5)$$

where we have not yet decided which variable,  $X$ , is held constant. If the densities are a function of pressure, which they usually are, expressions for the speed of sound can be derived using [Equation 12-5 \(p. 371\)](#), and the standard thermodynamic relationship:

$$\frac{1}{c_{\text{mix}}^2} = \left( \frac{\partial \rho_{\text{mix}}}{\partial p} \right)_X \quad (12-6)$$

For the purposes of the equilibrium phase change model the isentropic speed of sound is output as the variable "Local Speed of Sound" and is computed as follows:

$$\frac{1}{c_{\text{mix}}^2} = \left( \frac{\partial \rho_{\text{mix}}}{\partial p} \right)_s = \frac{c_{v,\text{mix}}}{c_{p,\text{mix}}} \left( \frac{\partial \rho_{\text{mix}}}{\partial p} \right)_T \quad (12-7)$$

substituting [Equation 12-5 \(p. 371\)](#) held at constant temperature. The mixture specific heat capacities are evaluated using [Equation 12-3 \(p. 371\)](#). [Equation 12-7 \(p. 371\)](#) is applied in all regions, however, the mixing rule for the isothermal derivative, [Equation 12-5 \(p. 371\)](#), is only applied in regions where the equilibrium fraction is non-zero or unity.

While the formulas just presented assume that you are modeling a mixture of liquid and vapor, the same algorithm also holds for other types of phase change, such as the melting and solidification of solid and liquid water, respectively.

## 12.4. Setting up an Equilibrium Phase Change Simulation

The Equilibrium Phase Change model requires that consistent material properties be supplied for the two pure substance states involved in the phase change, as well as the saturation curve (vaporization curve for vapor-liquid phase change, fusion line for liquid-solid phase change or the sublimation line for solid-vapor phase change). Although general material properties can be used with this model, in general, it is best practice to use this model with a real gas equation of state for the liquid, vapor and

saturation properties. Saturation properties are defined by using a Homogeneous Binary Mixture. A Homogeneous Binary Mixture is a mixture of two states (solid, liquid or vapor) of the same pure substance.

There are three methods available to set up saturation properties in CFX:

- Using a pre-calculated Real Gas Property .rgp file.
- Using the Real Gas equation of state library.
- Using a general setup, by incorporating two consistent materials (representing the two thermodynamic states) into your own homogeneous binary mixture.

For details, see [Saturation Properties Tab in the CFX-Pre User's Guide](#).

### 12.4.1. Using a Real Gas Equation of State

This method is only appropriate for vapor-liquid phase change and cannot be used for other types of phase change. It is required that each material in the mixture uses the same Real Gas equation of state with all the appropriate data set. CFX presupplies a number of suitable materials which are categorized into several groups which contain three materials for each pure substance. In each group the vapor material has a "v" at the end of the material name, the liquid has an "l" and the homogeneous binary mixture has a "vl" at the end.

#### 12.4.1.1. Redlich Kwong Wet Steam

Only water vapor, liquid water and the homogeneous binary mixture of the two phases appear in this group. Material is suitable for condensing steam flows with small liquid mass fractions.

#### 12.4.1.2. Redlich Kwong Wet Refrigerants

This group contains several refrigerants including R11, R12, R123, R124, R125, R134, R134a, R141b, R143, R143a, R152a, R22, R23, R32, R410a, CO<sub>2</sub>, and NH<sub>3</sub>.

R410a is modeled using critical point properties, acentric factor and ideal gas specific heat coefficients obtained from NIST REFPROP V7.0 assuming a fixed composition of 50% R32 and 50% R125 by mass.

#### 12.4.1.3. Redlich Kwong Wet Hydrocarbons

This group contains a variety of common hydrocarbons including Methane (CH<sub>4</sub>), Acetylene (C<sub>2</sub>H<sub>2</sub>), Ethene (C<sub>2</sub>H<sub>4</sub>), Ethane (C<sub>2</sub>H<sub>6</sub>), Ethanol (C<sub>2</sub>H<sub>6</sub>O), Propene (C<sub>3</sub>H<sub>6</sub>), Propane (C<sub>3</sub>H<sub>8</sub>), 1-Butyne (C<sub>4</sub>H<sub>6</sub>), Cyclobutane (C<sub>4</sub>H<sub>8</sub>), Butane (C<sub>4</sub>H<sub>10</sub>), Pentane (C<sub>5</sub>H<sub>12</sub>), Benzene (C<sub>6</sub>H<sub>6</sub>), Hexane (C<sub>6</sub>H<sub>14</sub>), Toluene (C<sub>7</sub>H<sub>8</sub>), Octane (C<sub>8</sub>H<sub>18</sub>), Nonane (C<sub>9</sub>H<sub>20</sub>), and Decane (C<sub>10</sub>H<sub>22</sub>).

#### 12.4.1.4. Wet Redlich Kwong

This group contains various pure fluids which do not appear in the other groups and includes Argon, Carbon Monoxide, Carbon Dioxide, Chlorine, Deuterium, Fluorine, Hydrogen, Hydrogen Sulfide, Helium, Nitrogen, Neon, Oxygen, Para-Hydrogen, Sulfur Dioxide and Ozone.

### 12.4.1.5. Creating a Liquid Phase Material

If you have already created a vapor phase material, then an easy way to set the data for the liquid phase material is to make a copy of the vapor phase material, change the name to something appropriate, and then simply update the **Thermodynamic State** to **Liquid** instead of **Gas**.

### 12.4.1.6. Creating the Homogeneous Binary Mixture

When creating the Homogeneous Binary Mixture, select the two materials that make up the mixture in the **Material 1** and **Material 2** fields. The thermodynamic state of one fluid should be liquid and the thermodynamic state of the other should be gas. Under **Saturation Properties**, set the **Option** to Redlich Kwong. No other option is available or valid.

## 12.4.2. Using Real Gas Property (.rgp) table files

### 12.4.2.1. Loading an .rgp file

Create the liquid and vapor phase materials as described in the dry RGP section. .rgp files can only be used for liquid-vapor phase change calculations.

### 12.4.2.2. Creating the Homogeneous Binary Mixture

When creating the Homogeneous Binary Mixture, select the two materials that make up the mixture in the **Material1** and **Material2** fields. The thermodynamic states must be Liquid-Gas. Under **Saturation Properties**, set the **Option** to Table and provide the table name (which will be the same as the table for the two components already referenced). The **Component Name** is a required field, because .rgp files can hold data for more than one pure substance. The saturation data must exist in the .rgp file.

## 12.4.3. Using a General Setup

You may also combine two materials together to create your own homogeneous binary mixture. To do this, first set up the two materials representing the two thermodynamic states.

It is very important that the two material definitions use consistent reference states for the enthalpy and entropy. The difference between the two material enthalpies must equal the latent heat at the selected reference temperature and pressure. To make this easier, CFX-Pre allows homogeneous binary mixtures to be created only from materials within the same material group.

When creating the Homogeneous Binary Mixture, select the two materials that make up the mixture in the **Material1** and **Material2** fields. The thermodynamic state of one fluid should be liquid and the thermodynamic state of the other should be gas.

Under **Saturation Properties**, set the **Option** to General. You must then set the saturation properties (vapor pressure as a function of temperature) for the mixture. This may be done in one of two ways.

### 12.4.3.1. Constants or Expressions

If you choose to use constant saturation conditions, then, because they are dependent, you should set values for saturation pressure and temperature which are consistent. For example, for a mixture of saturated liquid and water vapor at 1 atm, the saturation temperature is 100 °C; for a mixture of saturated liquid and water vapor at 100 °C, the saturation pressure is 1 atm.

If you use CEL expressions or User Fortran for both pressure and temperature, you should ensure that your function or expression guarantees that  $T_{\text{sat}}(p_{\text{sat}}(T)) = T$  for all  $T$  on the saturation curve.

### 12.4.3.2. Antoine Equation

You can choose to use this equation for the saturation pressure and supply the flow solver with the necessary model constants. These are tabulated in several thermodynamics texts, see, for example, [84]. Automatic is the only option allowed for temperature in this case because the flow solver calculates saturation temperature from the Antoine equation.

The Antoine Equation correlates vapor pressure as a function of temperature using three coefficients as follows:

$$p_{\text{sat}} = p_{\text{scale}} \exp\left(A - \frac{B}{T + C}\right) \quad (12-8)$$

where  $p_{\text{scale}}$  is the Pressure Scale used to scale the units for the vapor pressure,  $A$  is the Antoine Reference State Constant,  $B$  is the Antoine Enthalpic Coefficient and  $C$  is the Antoine Temperature Coefficient. Depending on the reference you use to obtain the constants, Equation 12-8 (p. 374) can also be written in different forms, so some care should be taken when entering coefficients from the literature. For example, the tables in [84] assume that the Antoine equation is written as follows:

$$\log_{10} p_{\text{sat}} = A - \frac{B}{T + C - 273.15 \text{ K}} \quad (12-9)$$

where  $p_{\text{sat}}$  is in bars and  $p_{\text{scale}}$  is 1.0 bar. So, if you are running the flow solver in the SI unit system, this requires that you add 5.0 to  $A$  and multiply that result by the natural logarithm of 10.0, multiply  $B$  by the natural logarithm of 10 and subtract 273.15 K from the tabulated values of  $C$ . If you are running in a non-SI unit system this would require that you also convert the constants to return the right units of pressure.

### 12.4.4. CFX-Pre Domain Models Setup

The equilibrium phase change model is setup like any other multi-component fluid (MCF) mixture calculation.

1. You should select the **Homogeneous Binary Mixture** as your domain fluid.
2. On the Fluid Models form, you should select one of the mixture components to be the **Equilibrium Fraction** and the other to be the **Equilibrium Constraint**.
3. Now proceed to set up initial and boundary conditions just as you would for a standard MCF model.

**Hint:** For liquid-vapor calculations, if you chose the vapor phase, then the equilibrium fraction is the “quality.” If you chose the liquid phase, then the equilibrium fraction is the “wetness.”

## 12.5. Important Considerations

The following topics will be discussed:

- [Properties \(p. 375\)](#)

- [Inlet Boundary Conditions](#) (p. 375)

### 12.5.1. Properties

If you use your own RGP table and at any point during the solution, the temperature or pressure falls outside of the range in the table, you will receive a notice from the CFX-Solver that it has clipped or extrapolated the value and that the calculation will continue. For example, this may occur during the first few iterations as the solution begins to settle down from the initial guess. If the messages do not persist then you can safely continue with the solution. If these message do persist, then you should generate a table with a larger pressure and/or temperature range.

Pure substances that use real equations of state (non-ideal or non-constant density) can be used in the same way as any other material in CFX. They can form components in multicomponent fluids or be used in multiphase simulations.

You cannot specify mixture properties for homogeneous binary mixtures.

All boundary condition specifications use real fluid relations for conversions from total to static conditions.

### 12.5.2. Inlet Boundary Conditions

If you are using the total pressure and total enthalpy boundary condition with the equilibrium phase change model then you do not have to set the equilibrium fraction, this is automatically derived for you by the flow solver. If the value is set, then the flow solver will ignore it.

Alternatively, if you are using the total pressure and total temperature boundary condition with the equilibrium phase change model, you have the option to enter the value of the equilibrium fraction.

The flow solver applies the specified value of equilibrium fraction as a “total” equilibrium fraction value. If the total conditions are dry vapor, this does not necessarily mean that the static conditions are also dry. For example, if the inlet equilibrium fraction is set to be all vapor (total quality is 1), then the flow solver uses the specified total temperature and pressure, as a starting point to determine the static conditions. If the total conditions were just above the saturation dome, then it is very likely that the final static condition is under the dome and the inlet condition will be a bit wet.

If you specify a value for quality between zero and unity then you are saying that the inlet total conditions are under the dome, and total temperature and pressure are no longer independent. In this case, to ensure consistency with the properties, the flow solver ignores the specified total temperature and evaluates total temperature from the vapor pressure curve instead, i.e.,  $T_{\text{total}} = T_{\text{sat}}(P_{\text{total}})$ .

## 12.6. Real Gas Property (RGP) File Contents

Evaluating fluid properties through a complex equation of state during a solution can lead to significant computing overhead. To avoid this computational expense, CFX uses a number of data tables during the CFD solution. Accessing these tables is much faster than evaluating properties directly from the equation of state.

### 12.6.1. Superheat Region

The superheat region in [Figure 12.1](#) (p. 376) is represented through the following nine tables as functions of temperature and pressure:


1.  $h(P, T)$  : Specific enthalpy.



2.  $c(P, T)$  : Speed of sound.
3.  $v(P, T)$  : Specific volume.
4.  $c_v(P, T)$  : Specific heat at constant volume.
5.  $c_p(P, T)$  : Specific heat at constant pressure.
6.  $(\partial P / \partial v)_T(P, T)$  : Partial derivative of pressure with respect to specific volume at constant temperature.
7.  $s(P, T)$  : Specific entropy.
8.  $\mu(P, T)$  : Dynamic viscosity.
9.  $k(P, T)$  : Thermal conductivity.

All of the tables, with the exception of dynamic viscosity and thermal conductivity are required. Dynamic viscosity and thermal conductivity can also be specified with constant values in the `.rgp` file header and as constants or CEL expressions in the CCL material definition. Constant values of dynamic viscosity and thermal conductivity are often acceptable in turbulent flows because turbulent diffusion normally dominates molecular diffusion processes.

The superheat tables, in a discrete manner, represent functions dependent on  $p$  and  $T$  and are shown in graphic form in [Figure 12.1 \(p. 376\)](#), where  $\phi$  represents any one of the properties  $h, c, v, c_v, c_p, (\partial P / \partial v)_T, s, \mu$  and  $k$ . As indicated in [Figure 12.1 \(p. 376\)](#), for a given material, saturation conditions may run through all of the superheat tables. To handle this case, associated 1D tables (for each 2D superheat table) must be included in the `.rgp` file and represent  $\phi_{\text{sat}}(P)$  and  $T_{\text{sat}}(P)$ , which are shown as graphs in [Figure 12.2 \(p. 377\)](#). With these 1D tables, property evaluations near saturation can be consistently handled using bi-linear interpolation. If the pressure range of the two-dimensional table goes above the critical pressure then the one-dimensional  $\phi_{\text{sat}}(P)$  and  $T_{\text{sat}}(P)$  curves should be clipped at  $\phi_{\text{crit}}$  and  $T_{\text{crit}}$ , respectively. It is very important to get this right because the flow solver relies on these data being correct in order to accurately interpolate values from your tables.

**Figure 12.1 Representation of Superheat Tables Associated with a Material**



**Figure 12.2 Representation of 1D Tables for a Saturation Property in Terms of Pressure****Figure 12.3 Representation of 1D Tables for Saturation Temperature in Terms of Pressure**

### 12.6.2. Saturated Region

Up to this point, the description of the data tables has been directed toward the superheat tables. For the wet/dry equilibrium real fluid model, however, data tables for equilibrium saturation information (as functions of saturation pressure) are also required.

These tables hold property information related to the saturated liquid and vapor lines of the material, as shown in *Figure 12.4* (p. 378), and can be classified as either single valued or dual valued. Single valued information contains saturation properties that are required along the saturated vapor line or along the saturated liquid line (not both). The properties of this type used in CFX, are:


1. Saturation pressure.
2. Saturation temperature.

Dual valued information contains saturation properties that are required along both the saturated vapor and liquid lines as a function of saturation pressure. Properties of this type required for CFX are:

1. Saturated liquid and vapor enthalpy,  $h_l$  and  $h_g$ .
2. Saturated liquid and vapor specific heat at constant pressure,  $c_{pl}$  and  $c_{pg}$ .
3. Saturated liquid and vapor density,  $\rho_l$  and  $\rho_g$ .

4. Saturated liquid and vapor change in density with pressure at constant temperature.
5. Saturated liquid and vapor entropy,  $s_l$  and  $s_g$ .
6. Saturated liquid and vapor specific heat at constant volume,  $c_{vl}$  and  $c_{vg}$ .
7. Saturated liquid and vapor speed of sound,  $c_l$  and  $c_g$ .
8. Saturated liquid and vapor molecular viscosity,  $\mu_l$  and  $\mu_g$ .
9. Saturated liquid and vapor thermal conductivity,  $k_l$  and  $k_g$ .

**Figure 12.4 Representation of a Saturation Table Associated with a Given Material**



## 12.7. Real Gas Property (RGP) File Format

The following provides a description of the real gas property (.rgp) file format. The .rgp file enables you to input your own specialized real fluid properties into a CFD calculation. The .rgp file can be used in conjunction with all models available in CFX.

An .rgp file can contain properties for any number of pure component materials. However, the .rgp files supplied with CFX only contain one pure component each. Once you load the CCL for a particular equation of state, all materials that use that equation of state are loaded into CFX-Pre.


If you want to maintain your own .rgp file which contains multiple pure components, then each new material in the .rgp file begins with the \$\$\$<component> access key, where <component> is the name of the material. Any number of these access keys may exist in the file.

For each fluid associated with an access key, several blocks of information are available which include parameter definition, superheat table, and saturation table information. However, because many calculations do not require all of this information, a less complete set of property information can be included in the .rgp file. In this release of CFX, only the dry superheated vapor model is supported, corresponding to MODEL=3 in the .rgp file. Other settings of this parameter are ignored by the CFX-Solver, so all the saturation data that would normally be read when using the non-equilibrium (MODEL=1) or equilibrium (MODEL=2) models will be ignored. This means that the \$\$\$SAT\_TABLE section does not have to exist under a \$\$\$Database access key, that the SUPERCOOLING parameter can be zero and that only the \$\$\$SUPER\_TABLE section is necessary.

### 12.7.1. Organization of an .rgp File

Figure 12.5 (p. 379) is a schematic representation of the .rgp file organization. The .rgp file is divided into HEADER and DATA sections. The first section begins with the line \$\$\$\$HEADER in the .rgp file, and contains all the parameter information for each material found in the DATA section of the .rgp file. The DATA section begins with the line \$\$\$\$DATA and contains parameter, superheat and saturation information for a given material. Within both of these major sections, all of the available materials are identified by an access key of the type \$\$\$<component>, where <component> is the name of the material. This is also the name that the user will see when selecting a material from CFX-Pre. The purpose of the HEADER section is to allow quick access to material information from CFX-Pre. Information on the order in which the property information is written to the .rgp file is available in Real Gas Property (RGP) File Contents (p. 375).

Figure 12.5 Schematic of the .rgp File Contents



#### 12.7.1.1. Detailed .rgp File Format

Type	Description
----	-----

```

$$$$HEADER
See NOTES 1 and 2
$$$$DATA
$$$<component>      character*8      (key into the .rgp file see NOTE 3)
  nn                integer      (this line is ignored in CFX)
$$PARAM              See NOTE 4
  nn                integer      (number of parameters)
DESCRIPTION
aa                  character*50  (description of the material)
NAME
aa                  character*8   (material name, same as $$$<component>)
INDEX
aa                  character*50  (index into clients RGDB program)
MODEL
  nn                integer      (level of property info available 1,2,or 3)
UNITS
  nn                integer      (unit system of 1,2,3,4 or 5)
PMIN_SUPERHEAT      See NOTE 5
  rr                real
PMAX_SUPERHEAT      See NOTE 5
  rr                real
TMIN_SUPERHEAT      See NOTE 5
  rr                real
TMAX_SUPERHEAT      See NOTE 5
  rr                real
TMIN_SATURATION      See NOTE 6
  rr                real
TMAX_SATURATION      See NOTE 6
  rr                real
SUPERCOOLING        (supercooling level in superheat tables)
  rr                real
P_TRIPLE             See NOTE 7
  rr                real
P_CRITICAL           See NOTE 7
  rr                real
T_TRIPLE             See NOTE 7
  rr                real
T_CRITICAL           See NOTE 7
  rr                real
GAS_CONSTANT        See NOTE 7
  rr                real
TABLE_1              See NOTE 8
  np nt              integer
TABLE_2              See NOTE 8
  np nt              integer
TABLE_3              See NOTE 8
  np nt              integer
TABLE_4              See NOTE 8
  np nt              integer
TABLE_5              See NOTE 8
  np nt              integer
TABLE_6              See NOTE 8
  np nt              integer
TABLE_7              See NOTE 8
  np nt              integer
TABLE_8              See NOTE 9
  np nt              integer
TABLE_9              See NOTE 9
  np nt              integer
SAT_TABLE
npsat nmaxp1 nmaxp2 integer
$$$$SUPER_TABLE
  nn                integer      (number of superheat tables, nn = 9)

```

(The following is repeated for each superheat table, currently at 9. This section relates to [Figure 12.1 \(p. 376\)](#).)

```

$TABLE_nn
  nt np              integer      (size of superheat arrays, See NOTE 10)
write (iunit,*) (t(i),i=1,nt)    |all following real
write (iunit,*) (p(i),i=1,np)    |

```

```

write (iunit,*) ((phi(i,j),i=1,nt),j=1,np) |
write (iunit,*) (tsat(i),i=1,np) |
write (iunit,*) (phisat(i),i=1,np) |

```

(This section writes out the saturation information described by [Figure 12.4 \(p. 378\)](#))

```

$$SAT_TABLE
npsat nmaxp1 nmaxp2          integer          (size of saturation arrays, see NOTE 11)
do j=1,nmaxp1                |all following real
write(iunit,*) (prop1(i,j),i=1,npsat) |
do k=1,2                      |
do j=1,nmaxp2                |j=1 loop writes sat. liquid data
write(iunit,*) (prop2(i,j,k),i=1,npsat) |j=2 loop writes sat. vapour data

```

### Notes:

- Information between `$$$$HEADER` and `$$$$DATA` is a “stripped down” version of all the property information following the `$$$$DATA` header. The `$$$$DATA` section of the `.rgp` file contains all of the property information relative to the material. This may become a very large file. The `$$$$HEADER` was added to the top of the `.rgp` file to allow rapid selection of materials. CFX-Pre reads in and lists this information for the user during selection of a material.
- The `$$$$HEADER` section contains everything that is in the `$$$$DATA` section for a given material except data following the `$$SUPER_TABLE` and `$$SAT_TABLE` headers.
- `$$$<component>` must be an 8 character or less name identifying the material in the `.rgp` file. For example, for refrigerant R134A, the key may read `$$R134A` so that the material can be easily identified in the `.rgp` file.
- The `$$PARAM` parameters may be listed in any order.
- The parameters `PMIN_SUPERHEAT`, `PMAX_SUPERHEAT`, `TMIN_SUPERHEAT`, and `TMAX_SUPERHEAT` indicate the limits on the superheat tables. All superheat tables are built as functions of pressure and temperature because most users are able to estimate the pressure and temperature limits in their processes. Supercooling can be easily built into these tables if the equations of state allow it.
- The parameters `TMIN_SATURATION` and `TMAX_SATURATION` indicate the limits for building the saturation tables. The limits should cover the range over which wetness is expected in the solution. The saturation properties should be written to the `.rgp` file, in equal increments of pressure, starting at `TMIN_SATURATION` and ending at `TMAX_SATURATION`.
- The parameters `P_TRIPLE`, `P_CRITICAL`, `T_TRIPLE` and `T_CRITICAL` refer to the pressure and temperature triple and critical point values for the substance. The critical pressure and temperature must be supplied to the flow solver and, therefore, must be accurate. If they are not, then the table interpolation will not work correctly.
- The `GAS_CONSTANT` for the pure fluid should be supplied and is required if the fluid is to be used in a multi-component fluid calculation.
- The parameters `TABLE_1`, `TABLE_2`, `TABLE_3`, `TABLE_4`, `TABLE_5`, `TABLE_6`, `TABLE_7`, `TABLE_8` and `TABLE_9` refer to the size of the superheat tables for materials found in the `$$SUPER_TABLE` section. The parameter `SAT_TABLE` refers to the size of the saturation table for a material found in the `$$SAT_TABLE` section.
- The superheat tables 8 and 9 contain information on molecular (dynamic) viscosity and thermal conductivity, respectively. Note that these tables are not required if they are set as constants or CEL expressions in CFX-Pre. This allows the omission of these tables in the `.rgp` file if superheat information for these transport properties (as functions of pressure and temperature) is unknown.
- The order in which the superheat tables is written to the `.rgp` file is the same as the order shown in Real Gas Property (RGP) File Contents. For details, see [Real Gas Property \(RGP\) File Contents \(p. 375\)](#).

12. The values for `nmaxp1` and `nmaxp2` are 4 and 9, respectively. The integer `nmaxp1` refers to the number of single valued properties in the saturation tables, and `nmaxp2` to the number of dual valued properties in the saturation tables. The order that the saturation tables are written to the `.rgp` file is the same as the order shown in the Real Gas Property (RGP) File Contents. For details, see [Real Gas Property \(RGP\) File Contents \(p. 375\)](#). For the dual valued properties, the saturated liquid properties are written first (`j=1`) and the saturated vapor properties are written last (`j=2`) to the `.rgp` file.

### 12.7.1.2. Example .rgp File

```

$$$$HEADER
$$$$R134
    1
$$PARAM
    26
DESCRIPTION
Refrigerant R134a from NIST
NAME
134
INDEX
R134A
MODEL
    2
UNITS
    1
PMIN_SUPERHEAT
    55000.000000000000
PMAX_SUPERHEAT
    400000.000000000000
TMIN_SUPERHEAT
    240.00000000000000
TMAX_SUPERHEAT
    400.00000000000000
TMIN_SATURATION
    240.00000000000000
TMAX_SATURATION
    350.00000000000000
SUPERCOOLING
    0.0000000000000000E+00
P_CRITICAL
    0.00000000E+00
P_TRIPLE
    0.00000000E+00
T_CRITICAL
    0.00000000E+00
T_TRIPLE
    0.00000000E+00
TABLE_1
    5      5
TABLE_2
    5      5
TABLE_3
    5      5
TABLE_4
    5      5
TABLE_5
    5      5
TABLE_6
    5      5
TABLE_7
    5      5
TABLE_8
    5      5
TABLE_9
    5      5
SAT_TABLE
    5      4      9
$$$$DATA
$$$$R134

```

```

1
$$PARAM
  26
DESCRIPTION
Refrigerant R134a from NIST
NAME
134
INDEX
R134A
MODEL
  2
UNITS
  1
PMIN_SUPERHEAT
  55000.000000000000
PMAX_SUPERHEAT
  400000.000000000000
TMIN_SUPERHEAT
  240.00000000000000
TMAX_SUPERHEAT
  400.00000000000000
TMIN_SATURATION
  240.00000000000000
TMAX_SATURATION
  350.00000000000000
SUPERCOOLING
  0.0000000000000000E+00
P_CRITICAL
  0.00000000E+00
P_TRIPLE
  0.00000000E+00
T_CRITICAL
  0.00000000E+00
T_TRIPLE
  0.00000000E+00
TABLE_1
  5      5
TABLE_2
  5      5
TABLE_3
  5      5
TABLE_4
  5      5
TABLE_5
  5      5
TABLE_6
  5      5
TABLE_7
  5      5
TABLE_8
  5      5
TABLE_9
  5      5
SAT_TABLE
  5      4      9
$$SUPER_TABLE
  9
$TABLE_1
  5      5
    240.00000000000000      280.00000000000000      320.00000000000000
    360.00000000000000      400.00000000000000
    55000.000000000000      141250.000000000000      227500.000000000000
    313750.000000000000      400000.000000000000
    380537.4694438053      411338.2663531548      444977.3409773413
    481319.1776109927      520216.5694145825      389653.7412125674
    409809.2455431806      443799.3654908382      480400.4939131565
    519497.1970340972      397134.4582379403      408220.8885809304
    442595.4896125616      479470.0507244235      518772.4705830857
    402478.8117714382      406565.3815292667      441363.8343756341
    478527.3570462614      518042.2612321422      406650.5418732642
    406650.5418732642      440102.2828142202      477571.8870479560
    517306.4350445317

```

234.5147959861216	254.6474401194407	266.4385386783982
275.1224493134379	282.1192618430768	
376541.6333194062	389653.7412125674	397134.4582379403
402478.8117714382	406650.5418732642	
\$TABLE_2		
5	5	
240.0000000000000	280.0000000000000	320.0000000000000
360.0000000000000	400.0000000000000	
55000.00000000000	141250.0000000000	227500.0000000000
313750.0000000000	400000.0000000000	
146.0231331684759	157.8078814382528	168.5506303571756
178.5170722927099	187.8737728104760	147.0869026517344
155.2427165817653	166.8523505651282	177.3642207508735
187.0763724397798	147.8329014568262	152.5632728477825
165.1148711540457	176.1977255190386	186.2743889887011
147.9104560214784	149.7535601390501	163.3352394640403
175.0170180126285	185.4677211216712	147.6607838596043
147.6607838596043	161.5101241729302	173.8214905237701
184.6562641923786		
234.5147959861216	254.6474401194407	266.4385386783982
275.1224493134379	282.1192618430768	
144.3034887320350	147.0869026517344	147.8329014568262
147.9104560214784	147.6607838596043	
\$TABLE_3		
5	5	
240.0000000000000	280.0000000000000	320.0000000000000
360.0000000000000	400.0000000000000	
55000.00000000000	141250.0000000000	227500.0000000000
313750.0000000000	400000.0000000000	
0.3481914037990427	0.4095738848363432	0.4702915495291079
0.5305832630019515	0.5905860753062941	0.1402248442644343
0.1561641066947830	0.1807449135220719	0.2048688905909286
0.2286916876895624	8.9273098371410883E-02	444320344302E-02
0.1107157321741076	0.1261131151219874	0.1411960889105597
6.5633087958005529E-02	6.7151770525718760E-02	7.9166190580894386E-02
9.0648541948697259E-02	0.1018021936800781	5.1900452073168755E-02
5.1900452073168755E-02	6.1203439903817498E-02	7.0470885355410795E-02
7.9394150509035255E-02		
234.5147959861216	254.6474401194407	266.4385386783982
275.1224493134379	282.1192618430768	
0.3397008120139503	0.1402248442644343	8.9273098371410883E-02
6.5633087958005529E-02	5.1900452073168755E-02	
\$TABLE_4		
5	5	
240.0000000000000	280.0000000000000	320.0000000000000
360.0000000000000	400.0000000000000	
55000.00000000000	141250.0000000000	227500.0000000000
313750.0000000000	400000.0000000000	
644.8541874954598	719.7151797641214	790.5095338665236
857.2366695715677	919.8970271275263	674.7791960407488
721.6690087704523	792.3443057727616	858.9628531024553
921.5203908806476	698.8825060917976	723.6988581975571
794.2197800381258	860.7115954107751	923.1563593500967
716.9720727393429	725.8148416296926	796.1389707941393
862.4838781958006	924.8052629190319	731.8370306406068
731.8370306406068	798.1052760769886	864.2807537481988
926.4674455748727		
234.5147959861216	254.6474401194407	266.4385386783982
275.1224493134379	282.1192618430768	
634.2715599484291	674.7791960407488	698.8825060917976
716.9720727393429	731.8370306406068	
\$TABLE_5		
5	5	
240.0000000000000	280.0000000000000	320.0000000000000
360.0000000000000	400.0000000000000	
55000.00000000000	141250.0000000000	227500.0000000000
313750.0000000000	400000.0000000000	
733.5432454120784	806.0266427729431	875.3572680256013
941.1190584653727	1003.111496904734	773.6370689985604
816.3711389524509	882.8108960718668	946.7561020285661
1007.512627818587	807.0628915610768	827.9980795292242
890.7840080089826	952.6232673331618	1012.020341520216

834.4867573220491	841.2008081815245	899.3408892587429
958.7368554939568	1016.639020749522	858.8621950799120
858.8621950799120	908.5575294975291	965.1148207606369
1021.373299533599		
234.5147959861216	254.6474401194407	266.4385386783982
275.1224493134379	282.1192618430768	
723.4007165554241	773.6370689985604	807.0628915610768
834.4867573220491	858.8621950799120	

\$TABLE\_6

5	5	
240.0000000000000	280.0000000000000	320.0000000000000
360.0000000000000	400.0000000000000	
55000.00000000000	141250.00000000000	227500.00000000000
313750.00000000000	400000.00000000000	
-154611.9428101669	-132557.4464307218	-115997.3804840207
-103111.8528686964	-92801.69633261529	-959671.2544114459
-873595.5996881851	-764854.3591592711	-680011.5179211511
-612056.5815781737	-2374639.983863590	-2262401.182121443
-1982996.713344134	-1763666.875581090	-1587621.548245155
-4363498.860521937	-4291069.408039705	-3768294.493979145
-3353439.511168068	-3019297.561697437	-6897297.389986640
-6897297.389986640	-6117240.959939656	-5448329.203176694
-4906781.742740840		
234.5147959861216	254.6474401194407	266.4385386783982
275.1224493134379	282.1192618430768	
-158218.3298083634	-959671.2544114459	-2374639.983863590
-4363498.860521937	-6897297.389986640	

\$TABLE\_7

5	5	
240.0000000000000	280.0000000000000	320.0000000000000
360.0000000000000	400.0000000000000	
55000.00000000000	141250.00000000000	227500.00000000000
313750.00000000000	400000.00000000000	
1786.030158361605	1904.585719752846	2016.779512855124
2123.714780772325	2226.113661461630	1748.483241728080
1823.905112007991	1937.275071424368	2044.975937996867
2147.900948384664	1740.481415370240	1781.062492767768
1895.721351626920	2004.229786438356	2107.697911720815
1735.932309549977	1750.655644805153	1866.736275194941
1976.098388594144	2080.127578672003	1732.877658407725
1732.877658407725	1844.072019825660	1954.338672102516
2058.947921108171		
234.5147959861216	254.6474401194407	266.4385386783982
275.1224493134379	282.1192618430768	
1769.188083636742	1748.483241728080	1740.481415370240
1735.932309549977	1732.877658407725	

\$TABLE\_8

5	5	
240.0000000000000	280.0000000000000	320.0000000000000
360.0000000000000	400.0000000000000	
55000.00000000000	141250.00000000000	227500.00000000000
313750.00000000000	400000.00000000000	
9.4859076076546339E-06	1.1098072605476093E-05	1.2682727526284134E-05
1.4225406873221409E-05	1.5718844908709814E-05	1.0113426130489583E-05
1.1128384712488209E-05	1.2707428862857411E-05	1.4246015436604838E-05
1.5736277818145713E-05	1.0622849104772714E-05	1.1161623164463395E-05
1.2733802630234965E-05	1.4267707066828921E-05	1.5754472822231917E-05
1.1006164112931968E-05	1.1198285735280963E-05	1.2761997824348757E-05
1.4290540551654799E-05	1.5773456592676736E-05	1.1321670531250205E-05
1.1321670531250205E-05	1.2792178337213511E-05	1.4314589371365448E-05
1.5793272119540815E-05		
234.5147959861216	254.6474401194407	266.4385386783982
275.1224493134379	282.1192618430768	
9.2638729380455867E-06	1.0113426130489583E-05	1.0622849104772714E-05
1.1006164112931968E-05	1.1321670531250205E-05	

\$TABLE\_9

5	5	
240.0000000000000	280.0000000000000	320.0000000000000
360.0000000000000	400.0000000000000	
55000.00000000000	141250.00000000000	227500.00000000000
313750.00000000000	400000.00000000000	
8.7318132315962922E-03	1.2367010749671227E-02	1.5479028969457832E-02

```

1.8065003454933646E-02      2.0123880410625419E-02      1.0144646731520802E-02
1.2375365154798446E-02      1.5478277206731493E-02      1.8061024664563677E-02
2.0119085407073307E-02      1.1241534315205219E-02      1.2399427073087721E-02
1.5485543810413213E-02      1.8061449100116474E-02      2.0116675809444373E-02
1.2033532782386015E-02      1.2438788590707257E-02      1.5500573740125312E-02
1.8066241345977847E-02      2.0116840814255434E-02      1.2665788438301477E-02
1.2665788438301477E-02      1.5523214978202122E-02      1.8075268343013946E-02
2.0119597534766078E-02
234.5147959861216          254.6474401194407          266.4385386783982
275.1224493134379          282.1192618430768
8.1928902502712009E-03      1.0144646731520802E-02      1.1241534315205219E-02
1.2033532782386015E-02      1.2665788438301477E-02
$$$$SAT_TABLE
      5      4      9
72429.02057212396          669962.0863334293          1267495.152094735
1865028.217856040          2462561.283617346
239.9999762675480          298.3735220799146          321.5184369582214
337.4761886205648          349.9999999385916
0.0000000000000000E+00      0.0000000000000000E+00      0.0000000000000000E+00
0.0000000000000000E+00      0.0000000000000000E+00
0.0000000000000000E+00      0.0000000000000000E+00      0.0000000000000000E+00
0.0000000000000000E+00      0.0000000000000000E+00
157792.0768617229          234423.4028017849          268281.8836128900
293391.1384832433          314607.4539245256
1226.028409346856          1411.621580596332          1538.623093445163
1688.584812454093          1901.162632743923
1394.714486693549          1204.132429873541          1105.717252974825
1023.909256983076          947.2617335591748
7.3133047353247582E-06      1.5554466347974513E-05      2.3546196865974526E-05
3.4054173679783401E-05      4.9653987218547186E-05
836.0313698668695          1119.425611702024          1226.996801517600
1301.491841955899          1361.442808503099
1087.583619605917          1180.740355522880          1205.127882782043
1215.472691163284          1218.190684502114
0.0000000000000000E+00      0.0000000000000000E+00      0.0000000000000000E+00
0.0000000000000000E+00      0.0000000000000000E+00
4.5254108276952397E-04      2.0762809729902491E-04      1.5172962190515123E-04
1.1920087721741867E-04      9.5575862436921458E-05
0.1106897637097442          8.1042418175005723E-02      6.9512380598733353E-02
6.1769627812551062E-02      5.5819411652293066E-02
380136.7395374610          415734.4668987678          426586.7644804174
431942.8510520858          434298.6702392859
736.4416185000921          926.5982109988553          1070.936300636404
1242.721436965689          1480.769140200031
3.808368423257648          32.02662176918217          61.85130414931603
94.90868505077478          132.4954540908795
5.4108323518481296E-05      5.6676277290207862E-05      6.5936536523112708E-05
7.9426352920085037E-05      9.9732676665902821E-05
1762.467546546392          1727.090336441192          1719.363218938642
1712.044400273131          1703.417712356647
645.2669936904850          767.7650176481674          824.1454305224304
868.8335090051181          909.2881576124906
145.2336985804320          145.9254060428890          140.3837459659026
134.1949902861215          127.7833214614285
9.4933329019507708E-06      1.2087890198389884E-05      1.3328835395482605E-05
1.4417814786729988E-05      1.5601940814775012E-05
8.7357640893468182E-03      1.4138793457254478E-02      1.6414352714865677E-02
1.8434500108658915E-02      2.0797428027421110E-02

```

## 12.8. Parameters in the .rgp File Controlling the Real Gas Model

The following topics will be discussed:

- [REAL\\_GAS\\_MODEL](#) (p. 387)
- [P\\_CRITICAL, T\\_CRITICAL](#) (p. 387)
- [UNITS](#) (p. 387)
- [MIN\\_PROPERTY\\_T, MAX\\_PROPERTY\\_T, MIN\\_PROPERTY\\_P and MAX\\_PROPERTY\\_P](#) (p. 387)

- *MOLECULAR\_VISCOSITY, MOLECULAR\_CONDUCTIVITY* (p. 388)
- *GAS\_CONSTANT* (p. 388)
- *TMIN\_SATURATION, TMAX\_SATURATION* (p. 388)
- *P\_TRIPLE, T\_TRIPLE* (p. 388)
- *SUPERCOOLING* (p. 388)

### 12.8.1. REAL\_GAS\_MODEL

This parameter, normally specified in the CFX-TASCflow PRM file, is ignored by the CFX-Solver because the real gas model in CFX is automatically enabled as soon as you set material properties as functions of pressure and temperature, or select a homogeneous binary mixture as the fluid for your domain.

### 12.8.2. P\_CRITICAL, T\_CRITICAL

These two values are required and must be accurate. If they are not, then the table interpolation will not work because the flow solver uses knowledge of the critical point to determine where interpolation is being carried out (above or below the critical point).

### 12.8.3. UNITS

The equations of state for a real gas are normally formulated in a particular unit system and, therefore, it is necessary to know the unit system being used for the RGP properties so that the CFX-Solver can automatically convert the properties to solution units. Five unit systems are available when using an .rgp file as follows:

1. UNITS=1 (kg, m, s, K)
2. UNITS=2 (g, cm, s, K)
3. UNITS=3 (lbm, in, s, R)
4. UNITS=4 (slugs, ft, s, R)
5. UNITS=5 (slugs, in, s, R)

If desired, the solver solution units can be set to the same units as the .rgp file in CFX-Pre. For details, see [Setting the Solution Units in the CFX-Pre User's Guide](#).

### 12.8.4. MIN\_PROPERTY\_T, MAX\_PROPERTY\_T, MIN\_PROPERTY\_P and MAX\_PROPERTY\_P

These parameters correspond to the minimum and maximum temperature and pressure limits used for the superheat tables. Pressure and temperature are used to establish the limits because in most instances you will have an idea of the operating range of these quantities in your problem. It is important to make sure that the MIN\_PROPERTY\_T and MIN\_PROPERTY\_P parameters (when combined) do not represent a thermodynamic state below the saturated vapor curve for the substance (i.e., represent a subcooled liquid). It is also advisable to determine, prior to running the Real Fluid capability, the expected variation in temperature and pressure for the problem and set the table limit parameters accordingly. This will avoid wasting computational time with an unnecessarily large table.

### **12.8.5. MOLECULAR\_VISCOSITY, MOLECULAR\_CONDUCTIVITY**

If no superheat tables are given for these two properties, constant values can be specified instead in the parameter section with these two parameters. The CFX-Solver reads and use these values.

### **12.8.6. GAS\_CONSTANT**

The material gas constant is used, along with the universal gas constant to compute the molar mass. This is required by the flow solver.

### **12.8.7. TMIN\_SATURATION, TMAX\_SATURATION**

These are read by the CFX-Solver and can be used for both equilibrium phase change model.

### **12.8.8. P\_TRIPLE, T\_TRIPLE**

These parameters are not yet used by the flow solver.

### **12.8.9. SUPERCOOLING**

This parameter is not used by the flow solver.

---

## Chapter 13: Coupling CFX to an External Solver: ANSYS Multi-field Simulations

---

Some simulations require the coupling of CFX-Solver to other solvers in order to take account of physics that cannot be readily simulated within CFX. For example, bidirectional (that is, two-way) fluid-structure interaction (FSI) requires CFX to couple to an FEA (structural) solver when the structural physics is more complex than CFX can simulate with its CHT capability. Examples of when this is appropriate are described in [Reference Guide for Mesh Deformation and Fluid-Structure Interaction in the CFX Reference Guide](#).

Coupled simulations follow a timestep/iteration structure that is similar to the one within the CFX-Solver. During coupled simulations, the ANSYS CFX and any external field solvers (such as the Mechanical application solver) execute the simulation through a sequence of multi-field timesteps, each of which consists of one or more "stagger" (or coupling) iterations. During every stagger iteration, each field solver gathers the data it requires from the other solver, and solves its field equations for the current multi-field timestep. Stagger iterations are repeated until a maximum number of stagger iterations is reached or until the data transferred between solvers and all field equations have converged. The latter guarantees an implicit solution of all solution fields for each multi-field timestep.

The only coupling capability that is currently available enables CFX to couple to the Mechanical application solver within an ANSYS Multi-field simulation. The MFX solver is a version of the ANSYS Multi-field solver that enables the coupling of CFX with ANSYS Mechanical or ANSYS Multiphysics. It allows simulations where it is necessary to couple the fluid physics and structural physics throughout the solution process, rather than just by passing data from one solver to the other at the end of the simulation. Some examples of such simulations are given in [Using CFX and the Mechanical Application in the CFX Reference Guide](#).

Data is communicated between the CFX and Mechanical application field solvers through standard internet sockets using a custom client-server communication protocol. This implies that no third-party coupling software is required, and maximizes execution robustness.

The ANSYS Multi-field requires the setup of the fluid physics in CFX, the setup of the structural physics for the Mechanical application, and the specification of the MFX coupling settings. This is described in [Pre-Processing](#) (p. 389).

An example of an ANSYS Multi-field simulation can be found in [Oscillating Plate with Two-Way Fluid-Structure Interaction in the CFX Tutorials](#).

This chapter describes:

- 13.1. Pre-Processing
- 13.2. Running an MFX Simulation
- 13.3. Post-Processing
- 13.4. General Information

### 13.1. Pre-Processing

The topics in this section include:

- *Overview of Pre-Processing for ANSYS Multi-field Simulations* (p. 390)
- *Pre-Processing in ANSYS Workbench Using the Mechanical Application and CFX* (p. 390)
- *Pre-Processing in ANSYS Workbench Using the Mechanical APDL Application* (p. 391)
- *Using CFX-Pre in ANSYS Multi-field Mode* (p. 392)
  - *Input File Specification for the Mechanical Application* (p. 392)
  - *Coupling Time Control* (p. 393)
  - *Boundary Conditions in ANSYS Multi-field Mode* (p. 394)
  - *Solver Controls, External Coupling Tab* (p. 396)
- *Using CFX-Pre in ANSYS MultiField via Prep7 (Mechanical APDL) Mode* (p. 397)
  - *Boundary Conditions in ANSYS MultiField via Prep7 (Mechanical APDL) Mode* (p. 397)

### 13.1.1. Overview of Pre-Processing for ANSYS Multi-field Simulations

For an ANSYS Multi-field MFX calculation to run, two input files are needed. The CFX-Solver needs to have a valid CFX-Solver input file containing the setup for the fluid component of the simulation. The Mechanical application solver needs to have a valid Mechanical application input file containing the setup for the structural component of the simulation, plus the appropriate multi-field commands to control the interaction between the two solvers (the MFX controls). This pair of files can be prepared in two different ways, as described in the following sections.

### 13.1.2. Pre-Processing in ANSYS Workbench Using the Mechanical Application and CFX

Using this method, the required input files are automatically created and utilized. This method involves the following steps:

1. Lay out the ANSYS Workbench project setup for the Multi-field Simulation. A structural analysis system is introduced into the project by double-clicking on the desired Static Structural or Transient Structural entry in the **Analysis Systems** in the ANSYS Workbench toolbox. A fluid flow analysis system is introduced by right-clicking the Setup cell in the structural system and selecting **Transfer Data to New > Fluid Flow (CFX)**. This automatically couples both the geometry and setup cells in the structural and fluid flow systems. Note that the Solution and Results cells may be deleted from structural system because solution control and post-processing are handled as part of the fluid flow system. At this point, the resulting project schematic will appear similar to the one shown in [Figure 23.1: "Project setup for two-way FSI analysis", Oscillating Plate with Two-Way Fluid-Structure Interaction in the CFX Tutorials](#).
2. The structural component of the simulation is setup by editing the Engineering Data, Geometry, Model and Setup cells in the structural system. In particular, **Fluid Solid Interface** type Load/Support(s) are introduced in the Mechanical application by editing the structural system's Setup cell as described in the ANSYS Workbench documentation, in **Mechanical Help > Mechanical Objects Reference > Page Listings > Loads and Supports (Group)**. The Mechanical application input file is automatically generated when the Setup cell is brought to an up-to-date state. By default, this file is named `ds.dat`, and its location is reported in the **Files** view of ANSYS Workbench.
3. The fluid component of the simulation is setup by editing the Geometry, Mesh and Setup cells in the fluid flow system. Use CFX-Pre, as described in [Using CFX-Pre in ANSYS Multi-field Mode](#) (p. 392), to complete the fluid flow physics, and CFX and MFX solver controls.

4. The coupled simulation is executed by editing or updating the Solution cell within the fluid flow system. In each case, the required CFX-Solver input file is automatically generated before running both the CFX-Solver input and CFX solvers. Note, as well, that MFX settings completed in CFX-Pre are automatically translated into appropriate multi-field control commands and merged into the Mechanical application Input file. For more information, see [ANSYS Multi-field Run in the CFX-Solver Manager User's Guide](#).

This method is recommended for all users who do not have prior familiarity with the Mechanical APDL application user interface.

### 13.1.3. Pre-Processing in ANSYS Workbench Using the Mechanical APDL Application

Using this method to prepare the two input files involves the following steps:

1. Lay out the ANSYS Workbench project setup for the Multi-field Simulation. A Mechanical APDL analysis system is introduced into the project by double-clicking on the Mechanical APDL entry in the **Component Systems** option of the ANSYS Workbench toolbox. A fluid flow analysis system is introduced by double-clicking on the Fluid Flow (CFX) entry in the **Analysis Systems** option in the toolbox.
2. If you would like to partially complete the structural setup using the Mechanical application before entering the Mechanical APDL application, then right-click the Analysis cell in the Mechanical APDL application component, and select one of the **Static Structural** or **Transient Structural** Setup entries within the **Transfer Data From New** option. A Static Structural or Transient Structural analysis system is then introduced into the project, and a coupling is drawn between the Setup cell in that system and the Analysis cell in the Mechanical APDL application component. Edit the Data, Geometry, Model and Setup cells, as required, in the structural system before proceeding. A partially complete Mechanical application input file is automatically written once the Setup cell in this system is up-to-date. Its location is reported in the **Files** view of ANSYS Workbench. You may also manually write the partially complete input file from the Mechanical application by selecting the analysis in the Project tree, and picking **Write Input File...** within the **Tools** pull-down menu.
3. Prepare (or complete) the structural setup in the Mechanical APDL application by right-clicking on Analysis cell in the Mechanical APDL application component, and selecting **Edit in Mechanical APDL....** Use the Mechanical APDL application interface to generate the multi-field commands and create the required Mechanical application input file. In particular, use the Pre-processing section of that interface for setting MFX controls as presented in the *MFX Solution Procedure* discussion of the [Mechanical APDL Coupled-Field Analysis Guide](#).
4. Use CFX-Pre in ANSYS MultiField via Prep7 mode to set up the CFX physics. In this case, the Mechanical application input file created within the Mechanical APDL application must be manually selected. Note that its location is reported in the Files view within ANSYS Workbench. Proceed to define the boundary conditions for which the Mechanical application will provide the data via MFX. Defining the boundary conditions in this manner is described in [Using CFX-Pre in ANSYS MultiField via Prep7 \(Mechanical APDL\) Mode](#) (p. 397).

This method is particularly useful for experienced users of the Mechanical APDL application, and/or for simulations that require more complex structural setups than those available within the Mechanical application alone. Many of the steps identified within this method may also be executed outside of the ANSYS Workbench environment.

**Note**

If the Mechanical application input file contains any commands that refer to external files (such as "/INPUT" or "/CDREAD"), then these commands should use a full path specification rather than just the filename itself. For the project to be robust when transferred to, or executed on, a different system, commands that refer to external files should be avoided.

---

**Note**

The Mechanical application input file (written by the Mechanical APDL application and used by CFX-Pre) must be manually updated whenever changes to the structural model are made. This is because updates are not automatically performed by ANSYS Workbench when this method of pre-processing is used.

### 13.1.4. Using CFX-Pre in ANSYS Multi-field Mode

To use CFX-Pre to prepare a CFX-Solver input file containing the CFX setup and the MFX control settings, the ANSYS Multi-field mode must be enabled. This is done by setting **External Solver Coupling** to `ANSYS MultiField` on the **Analysis Type** form (see [External Solver Coupling Settings in the CFX-Pre User's Guide](#)). Once this mode has been enabled, a number of settings that are relevant for setting up an MFX case are enabled as described in the following sections.

#### 13.1.4.1. Input File Specification for the Mechanical Application

This specification is made on the **Analysis Type** pane in CFX-Pre. When using the workflow described above in *Pre-Processing in ANSYS Workbench Using the Mechanical Application and CFX* (p. 390), the correct Mechanical application input file is automatically specified. When using any other workflow, you will need to manually specify a Mechanical application input file that contains the structural setup (including the identification of the Fluid Solid Interfaces) for the MFX problem. This will be used by CFX-Pre to determine the valid interfaces for selection later on, and will also be used by default as the Mechanical application input file when the solver run is started from CFX-Solver Manager.

If the Mechanical application input file comes directly from the Mechanical application then CFX-Pre and CFX-Solver Manager will be able to read it without any user modification. However, if the Mechanical application input file has been transferred between DOS and UNIX file systems, manually modified, or was originally created in the Mechanical APDL application or by hand, you must ensure that it satisfies the following conditions:

- Mechanical application input files are ASCII text files, and must be converted between DOS and UNIX formats appropriately using the utilities such as `dos2unix` and `unix2dos`.
- CFX-Pre will read the Mechanical application input file in order to determine what fluid solid interfaces are defined on the structural model. It will pick up any interfaces defined by the `SF`, `SFE` or `SFA` commands that reference named components (commands that reference specific nodes or elements are not picked up). If the interfaces are defined on nodal or element components using commands of the form "`SF,component_name,FSIN,interface_number`", then CFX-Pre will display the component name to identify the interface; otherwise it will display the interface number.
- When CFX-Solver Manager processes a non-Mechanical application input file, it will effectively remove all commands after (and including) the first `SOLVE` command that is present in the file and then add the multi-field commands and a new `SOLVE` command to the end of the provided Mechanical application input file. If no `SOLVE` command is present then the multi-field commands and new `SOLVE` command

are added to the end of the file. Therefore you must ensure that the provided file has no important commands after any SOLVE command (otherwise these will be stripped out). In addition, if the provided Mechanical application input file already contains multi-field commands, then these will be superseded (or, in the case of the MFLC commands, add extra loads in addition to the ones defined in CFX-Pre). If you already have a complete Mechanical application input file including multi-field commands and SOLVE command, then you can avoid this requirement by using CFX-Pre in ANSYS MultiField via Prep7 mode (see [Using CFX-Pre in ANSYS MultiField via Prep7 \(Mechanical APDL\) Mode](#) (p. 397)) and ensuring that CFX-Solver Manager starts the MFX run using the option to start CFX-Solver without processing the Mechanical application input file (see [ANSYS Multi-field Run in the CFX-Solver Manager User's Guide](#)).

### 13.1.4.2. Coupling Time Control

The specification of the multi-field timestep and time duration for the ANSYS Multi-field simulation is made on the **Analysis Type** panel as **Coupling Time Steps** and **Coupling Time Duration**. **Coupling Initial Time** is also specified on this panel.

- **Coupling Time Duration:** This specifies the total time for a transient MFX simulation. For a steady-state MFX simulation, where the multi-field timesteps represent load steps, the total number of load steps in the simulation is determined by the Coupling Time Duration divided by the Coupling Time Step. Coupling Time Duration must be specified as a single number (it cannot be a CEL expression).
- **Coupling Time Steps:** This control determines the size of the multi-field timestep.
  1. If the option is set to **Timesteps**, then you can set the multi-field timestep directly. You must set a single value for the Timesteps (not a CEL expression). The Coupling Time Duration and the Coupling Time Steps must be set so that the Coupling Time Duration is an exact multiple of Coupling Time Steps.
  2. If you set the option to **Adaptive**, then you enable the multi-field auto time-stepping option. In this case, the Mechanical application will automatically adjust the timestep size for the next multi-field step, based on whether the current multi-field step has converged and how many stagger iterations it took, in order to try to meet a target number of stagger iterations for the next multi-field step. The only option for how the timestep is adjusted is **Scale with Iterations**. When this option is selected, the timestep for the next multi-field step is calculated by multiplying the timestep used for the current iteration by the ratio of how many stagger iterations were performed in the current step to the target number of iterations. You must enter the **Initial Timestep** value (which is used for the first multi-field step), the **Target Iterations**, and a **Maximum** and **Minimum Timestep**, which are used to bound how large and how small the multi-field step is allowed to get.
- **Coupling Initial Time:** This is the initial time for the multi-field simulation. If the multi-field simulation is not a restart, then this can be left set to **Automatic**, and the simulation will always start from a time value of zero. If the multi-field simulation being defined is a restarted run, then two scenarios are possible:
  1. If the restart is a continuation of a previous simulation, then leave **Coupling Initial Time** set to **Automatic**.
  2. If the simulation is a restart from an intermediate time value (for example, the original simulation ran until a time value of 10 [s], but you want to restart from the intermediate time value such as 5 [s]), then set **Coupling Initial Time** to the time value from which you want to start.

For a transient simulation, the multi-field timestep and time duration are also used by CFX-Solver; that is, you cannot specify the CFX **Time Steps** and **Time Duration** independently. In this circumstance, you should set the CFX **Time Steps** option to **Coupling Timesteps**, and **Time Duration** to **Coupling Time Duration** and these are the only available options. The CFX **Initial Time** option should be set

to `Coupling Initial Time` in general, so that time values in the CFX and Mechanical application results files are synchronized for convenient post-processing.

### 13.1.4.3. Boundary Conditions in ANSYS Multi-field Mode

The Boundary Conditions form is where you specify all information relating to a particular boundary, including (for ANSYS Multi-field simulations) if a boundary is to be used for exchanging data with the Mechanical application, and if so, all the details of that data transfer. Only wall boundary conditions can participate in data exchange. There are three different ways of specifying data exchange with the Mechanical application:

- Mesh Motion setting for a model with mesh motion enabled.

For details, see [Mesh Motion Setting](#) (p. 394).

- Heat Transfer setting for a model with heat transfer enabled.

For details, see [Heat Transfer Setting](#) (p. 394).

- Additional Coupling Sent Data for specifying data sent to the Mechanical application that is not covered by the previous two options.

For details, see [Additional Coupling Sent Data](#) (p. 395).

In each case, you will have to select the ANSYS Interface that corresponds to this CFX boundary so that the MFX solver can match the two up. If you created your Fluid Solid Interfaces in the Mechanical application, then the names will appear in CFX-Pre as "FSIN\_X", where X is the interface number defined in the Mechanical application. If you created your Fluid Solid Interfaces outside of the Mechanical application by using a component and a command of the form "SF,<component\_name>,FSIN,<interface\_number>", then CFX-Pre will display the component name to identify the interface. Otherwise CFX-Pre will display the interface number in the drop-down selector.

ANSYS Multi-field settings for multiphase CFX cases are described in [Boundary Conditions for ANSYS Multi-field CFX Multiphase Cases](#) (p. 395).

#### 13.1.4.3.1. Mesh Motion Setting

If the model has **Mesh Motion** set to `Regions of Motion Specified` as part of the Domain specification, and CFX-Pre is in `ANSYS MultiField` mode, then the Mesh Motion setting on the boundary condition form for a Wall can be set to `ANSYS MultiField`. This automatically sets up the CFX simulation to receive its mesh displacement from the Mechanical application solver. You must select the ANSYS Interface that matches this CFX boundary. Additionally, by default you will also get CFX passing forces to the Mechanical application on this boundary; this can be turned off by setting **Send to ANSYS** to `None`.

#### 13.1.4.3.2. Heat Transfer Setting

If the model has a heat transfer model specified as part of the Domain specification, and CFX-Pre is in `ANSYS MultiField` mode, then the Heat Transfer setting on the boundary condition form for a Wall can be set to `ANSYS MultiField`. This automatically sets up the CFX simulation to receive its temperature or heat flow from the Mechanical application solver (which one is determined by how you set the **Receive from ANSYS** option). You must select the ANSYS Interface that matches this CFX boundary. Additionally, by default you will also get CFX passing temperatures to the Mechanical application on this boundary, if you selected to receive heat flows, or passing heat flows to the Mechanical application if you selected to receive temperatures; this can be turned off by setting **Send to ANSYS** to `None`.

### 13.1.4.3.3. Additional Coupling Sent Data

If you need to send data to the Mechanical application that is not covered by the two settings above, then you can create one or more **Additional Coupling Sent Data** objects, also on the **Boundary Details** panel. This is mainly useful in one of the following two situations:

- You want to send data to the Mechanical application without receiving data back, for example if you want to use the Mechanical application solver to calculate thermal stress, but the resulting mesh displacements are too small to be significant enough to consider.
- You have a multi-phase simulation and want to send phase-dependent temperatures to the Mechanical application, or you want to send some custom data to the Mechanical application that has perhaps been defined using an Additional Variable.

Existing **Additional Coupling Sent Data** objects are listed on the **Boundary Details** panel. To create or delete an **Additional Coupling Sent Data** object, use the icons to the right of the list. When creating a new object, you need to specify the following items:

- **ANSYS Variable:** This must be one of FORC (force), DISP (displacement), TEMP (temperature) or HFLU (heat flux). The choice determines how the Mechanical application uses the data sent to it.
- **Coupling Data Transfer Type:** This must be one of Profile Preserving or Conservative. This choice is described in [Interpolation \(p. 399\)](#).
- **CFX Variable:** This must be a CFX Variable of the correct dimensions, given the ANSYS Variable and the Coupling Data Transfer Type. Again, this choice is described in [Interpolation \(p. 399\)](#).
- **ANSYS Interface:** Select the ANSYS Interface from the drop-down list.

### 13.1.4.3.4. Boundary Conditions for ANSYS Multi-field CFX Multiphase Cases

If you have a CFX setup that includes more than one fluid, then heat transfer boundary conditions can be set up either across all fluids (that is, for the boundary as a whole), or on a fluid-by-fluid basis.

If you choose to set up the heat transfer boundary condition for the boundary as a whole, then the ANSYS Multi-field setting is available just as it would be for a single-phase case. Where you choose to have CFX receive Heat Flow from the Mechanical application, then it is divided between the fluids according to the **Wall Contact Model** setting on the boundary. For details, see [Wall Boundaries in Multiphase \(p. 225\)](#). If you are in ANSYS MultiField mode, you can choose to transfer either bulk Temperature or bulk Heat Flow to Mechanical.

If you choose to set up the heat transfer boundary condition on a fluid-by-fluid basis, then you can choose (for example) to have an adiabatic wall for one fluid (such as the dispersed fluid) and an ANSYS Multi-field setting for the other fluid (for example, the continuous fluid). In this case, a temperature provided by the Mechanical application is applied only to the continuous fluid, and any heat flow provided by the Mechanical application goes all into the continuous phase.

If you are setting a heat transfer boundary condition on a fluid-by-fluid basis, and you have more than one fluid-specific heat transfer setting of ANSYS MultiField, then you must be careful to avoid unphysical situations. For example, if you have more than one fluid set to receive heat flow from the Mechanical application, each fluid will get the full heat flow from the Mechanical application, not some proportion of it. You cannot have one fluid receiving heat flow from the Mechanical application, and another receiving temperature. In general, the only sensible combination in this circumstance is to have all the fluids with ANSYS Multi-field settings receiving temperature from the Mechanical application.

Note that if you are in ANSYS MultiField mode, and are specifying heat transfer boundary conditions on a fluid-by-fluid basis, then you cannot choose to send any data from CFX to the Mechanical application when you set up an ANSYS Multi-field boundary condition: this is because of the ambiguity of whether fluid-specific or bulk quantities would be implied in this context. Instead, you can create an Additional Coupling Sent Data object (see [Additional Coupling Sent Data \(p. 395\)](#)) to explicitly send the Mechanical application whatever data you require, whether this is a fluid-specific temperature, bulk temperature, etc.

### 13.1.4.3.5. Solver Controls, External Coupling Tab

The **Solver Control** panel, **External Coupling** tab, is where the solver settings for the Multi-field solver are made. Various settings can be made:

- **Maximum Iterations:** This is the maximum number of stagger iterations allowed in a coupling step (timestep for transient MFX simulations, load step for steady-state MFX simulations).
- **Minimum Iterations:** This is the minimum number of stagger iterations allowed in a coupling step.
- **Solution Sequence Control:** This determines whether the Mechanical application or CFX solves first within each stagger iteration. This does not affect the converged solution, but may affect how many stagger iterations are required to reach convergence. The choice is determined by which physical phenomenon is driving the MFX simulation, and whether it comes from the CFX (fluid) side or the Mechanical application (structural) side. For example, if the simulation is driven by a time-dependent force applied to the structural model, then the simulation is likely to run a little more efficiently if the Mechanical application runs first within each stagger iteration. If the simulation is driven by a time-dependent temperature on the fluid inlet, then it is likely to be slightly more efficient to solve CFX first.

In a small number of cases, it may be desired to have the Mechanical application and CFX solve at the same time during each stagger iteration. However, in general, any wall-clock speed up gained from doing this may well be smaller than the time penalty of having to perform more stagger iterations, due to the more unstable nature of the simulation under these circumstances. In general, this mode of operation is recommended only for advanced users who have simulations that require only a weak coupling between the Mechanical application and CFX, and where the CPU time taken by the CFX and Mechanical application solvers is likely to be similar. This option is not available in the CFX-Pre user interface but can be set in CCL by using the parameter "Solve ANSYS Fields = At Same Time as CFX Fields" instead of "Solve ANSYS Fields = After CFX Fields" or "Solve ANSYS Fields = Before CFX Fields".

- **Under Relaxation Factor:** This is the under-relaxation applied to the data transferred between the two solvers (the Mechanical application and CFX). The value set here is for all quantities. It is also possible to specify overrides for specific variables by using the variable-specific Under Relaxation Factor settings described below.
- **Convergence Target:** This is the convergence target applied to the data transferred between the two solvers (the Mechanical application and CFX). The value set here is for all quantities. It is also possible to specify overrides for specific variables by using the variable-specific **Convergence Target** settings described below. What is meant by convergence for the transferred data is described in [Checking Convergence \(p. 404\)](#).
- **Variable-specific Under Relaxation Factors and Convergence Targets:** For both under-relaxation factors and convergence targets, it is possible to override the global settings for each appropriate Mechanical application variable separately. This is done by selecting the appropriate ANSYS Variable in the list under the Coupling Data Transfer Control box, setting the variable name to be on, and setting one or both of the **Under Relaxation** or **Convergence Target** parameters. **Under Relaxation** can be set for DISP, FORC, TEMP, and HFLU. **Convergence Target** can be set for UX, UY, UZ, FX, FY, FZ, TEMP, and HFLU, that is, it can be set on the components of displacement and force, unlike the under relaxation factor.

### 13.1.5. Using CFX-Pre in ANSYS MultiField via Prep7 (Mechanical APDL) Mode

To use CFX-Pre to prepare a CFX-Solver input file containing the CFX setup only (with no MFX control settings), the ANSYS MultiField via Prep7 mode must be enabled. This is done by setting **External Solver Coupling** to ANSYS MultiField via Prep7 on the **Analysis Type** panel (see [External Solver Coupling Settings in the CFX-Pre User's Guide](#)).

Once this mode has been enabled, only the boundary condition settings that are relevant for providing CFX with boundary information are enabled. No other ANSYS Multi-field settings can be made, and it is assumed that the multi-field settings required for the run have been made within the Mechanical APDL7 User Interface. See [Pre-Processing in ANSYS Workbench Using the Mechanical APDL Application \(p. 391\)](#) for a description on when this mode is appropriate.

#### 13.1.5.1. Boundary Conditions in ANSYS MultiField via Prep7 (Mechanical APDL) Mode

The Boundary Conditions form is where you specify all information relating to a particular boundary, including (for ANSYS Multi-field simulations) if a boundary condition information is to be supplied by the Multi-field solver. ANSYS Multi-field can provide boundary condition information for Mesh Motion and Heat Transfer boundary settings on Wall boundary conditions only.

- Mesh Motion setting for a model with mesh motion enabled.

[Mesh Motion Setting \(p. 397\)](#)

- Heat Transfer setting for a model with heat transfer enabled.

[Heat Transfer Setting \(p. 397\)](#)

ANSYS Multi-field settings for multiphase CFX cases are described in [Boundary Conditions for ANSYS Multi-field CFX Multiphase Cases \(p. 395\)](#).

##### 13.1.5.1.1. Mesh Motion Setting

If the model has **Mesh Motion** set to `Regions of Motion Specified` as part of the Domain specification, and CFX-Pre is in ANSYS MultiField via Prep7 mode, then the **Mesh Motion** setting on the boundary condition form for a Wall can be set to ANSYS MultiField. This automatically sets up the CFX simulation to receive its mesh displacement from the Mechanical application solver.

##### 13.1.5.1.2. Heat Transfer Setting

If the model has a heat transfer model specified as part of the Domain specification, and CFX-Pre is in ANSYS MultiField via Prep7 mode, then the Heat Transfer setting on the boundary condition form for a Wall can be set to ANSYS MultiField. This automatically sets up the CFX simulation to receive its temperature, wall heat flow or wall heat flux from the Mechanical application solver (which one is determined by how you set the **Receive from ANSYS** option). If you want ANSYS Multi-field to provide the heat flux/flow, then you should select the Wall Heat Flow option: the Wall Heat Flux option is available only for backwards-compatibility to earlier releases. The difference between the two settings is that if you select Wall Heat Flow, then the data transfer is automatically "conservative" that is, is guaranteed to preserve the total heat flow across the boundary. If you select Wall Heat Flux then the total heat flow across the boundary will be only approximately preserved, depending on factors such as mesh resolution on the boundary. Both settings preserve the heat flow profile across the boundary.

## 13.2. Running an MFX Simulation

If ANSYS MultiField mode has been used to prepare a CFX-Solver input file, then CFX-Solver Manager can launch the resulting simulation, including starting both CFX and the Mechanical application solvers, and plotting residuals for CFX, the Mechanical application, and the data exchanged between the two. Relevant information can be found as follows:

- See [ANSYS Multi-field Run in the CFX-Solver Manager User's Guide](#) for information on launching an ANSYS Multi-field run.
- See [Residual Plotting for ANSYS Multi-field Runs in the CFX-Solver Manager User's Guide](#) for information on plotting residuals for the Mechanical application and the exchanged data quantities.

If a CFX-Solver input file has been prepared in ANSYS MultiField via Prep7 mode, the Mechanical application input file must contain all multi-field commands in order for the simulation to run properly.

## 13.3. Post-Processing

A successful ANSYS Multi-field run produces a CFX results file and a Mechanical application `rst` or `rth` file, which can be used to post-process results. Both of these files can be post-processed together by CFD-Post.

Specific information on CFD-Post's capabilities to read and use the Mechanical application results data can be found in [ANSYS Files in the CFD-Post User's Guide](#).

The Mechanical application Post1 post-processor can also be used to post-process the Mechanical application results only.

## 13.4. General Information

The information in this section includes:

- [Solver Technology](#) (p. 398)
- [Interpolation](#) (p. 399)
- [Two-Way and One-Way Data Transfer](#) (p. 400)
- [Transient and Steady-state MFX Simulations](#) (p. 401)
- [Multiple Load Steps](#) (p. 402)
- [Units](#) (p. 403)
- [ANSYS Multi-field Simulations with Lagrangian Particle Tracking](#) (p. 403)
- [Best Practices for ANSYS Multi-field Simulations](#) (p. 403)

### 13.4.1. Solver Technology

A detailed description of the MFX solver is given in the Mechanical application user documentation, in "Multi-field Analysis Using Code Coupling", and in particular, the solver technology behind the coupling process is described in the Mechanical application user documentation, in "How MFX Works".

## 13.4.2. Interpolation

ANSYS Multi-field simulations can and usually do run with a mismatched mesh between the Mechanical application and CFX on the interface between them. In such cases, an interpolation method must be used to map data from one mesh onto the other. Detailed technical information on how the MFX solver deals with meshes that do not match on the coupling interface is given in the Mechanical application user documentation, in "Load Transfer" and "Mapping" (although note that the MFMAP command does not apply to MFX).

There are two basic types of interpolation: "Profile Preserving" and "Conservative":

- A profile preserving interpolation simply take the profile of the variable (for example, temperature) on one mesh, and matches or maps it to the other mesh as best as it can.
- A conservative interpolation ensures that the profile is interpolated in such a way as to ensure that a total quantity passing across the interface is conserved that is, the same total passes out of one mesh and into the other. For example, a conservative interpolation for the heat flow variable ensures that the total heat flowing out of one mesh is identical to the total heat flowing into the other mesh, even if the mesh resolution is poor. A conservative interpolation of force ensures that the total force on one side of the boundary exactly matches the total force received by the other side of the boundary. Conservative interpolation does not make sense for a variable such as temperature where there is no corresponding physical quantity to conserve.

In general, you do not need to understand the details of the interpolation types as this is mostly taken care of behind the scenes. If you use CFX-Pre in ANSYS MultiField mode and only ever specify data transfers as part of a **Mesh Motion** or **Heat Transfer** boundary condition setting, or if you prepare your multi-field commands for the Mechanical application input file using the Mechanical APDL application, and only ever set **Load Type** to be `Thermal` or `Mechanical`, then you never need to set interpolation type explicitly. In these cases, CFX and the Mechanical application know which variables are being transferred and can set the interpolation type accordingly (it will be set to `Profile Preserving` for temperatures and displacements, and `Conservative` for forces and heat flows).

However, if you use the **Custom** option for **Load Type** in the Mechanical APDL application, or if you use the **Additional Coupling Sent Data** panel in CFX-Pre, then you can explicitly choose to send any CFX variable to the Mechanical application. For example, in a multi-fluid CFX case, you may want to send the Mechanical application the fluid-specific temperature (called for example, "Water.Temperature") rather than the bulk temperature ("Temperature"), if you are trying to model a particular physical effect. In this case you need to tell MFX which type of quantity you are sending and what type of interpolation type to use, as it will not necessarily be able to work it out for itself. The interpolation method is set as the Coupling Data Transfer Type in CFX-Pre if you are preparing a CFX-Solver input file in ANSYS MultiField mode.

In general, temperatures and displacements must be sent using Profile Preserving interpolation. You should send heat flows and forces using Conservative interpolation. The Mechanical application makes certain assumptions about what type of quantity you send given the ANSYS Variable name and the interpolation method specified, so you must ensure that the dimensions of the variable you send match what it is expecting. For example, if you want to send forces to the Mechanical application, you must send the variable "Total Force Density" (or equivalent) if you use Profile Preserving interpolation, but "Total Force" (or equivalent) if you use Conservative interpolation.

If you are using the **Additional Coupling Sent Data** panel in CFX-Pre, then CFX-Pre will make some checks and limit variable availability to ensure that your variable dimensions are correct, given the CFX variable dimensions and the type of interpolation and ANSYS Variable specified. The required dimensions for each combination of settings are listed in the table below.

<b>ANSYS Variable</b>	<b>Coupling Data Transfer Type</b>	<b>Required dimensions of Data Sent to ANSYS variable</b>	<b>Examples of Suitable CFX Variables</b>
DISP	Profile Preserving	Length	Total Mesh Displacement
TEMP	Profile Preserving	Temperature	Temperature, <i>Fluid-Name</i> .Temperature
FORC	Profile Preserving	Pressure	Total Force Density
HFLU	Profile Preserving	Heat Flux	Wall Heat Flux
DISP	Conservative	Not valid	-
TEMP	Conservative	Not valid	-
FORC	Conservative	Momentum Source	Total Force
HFLU	Conservative	Energy Source	Wall Heat Flow

You can choose to send other variables (for instance, you can send an Additional Variable), but you must ensure that the dimensions match the appropriate settings.

### 13.4.3. Two-Way and One-Way Data Transfer

The most common applications for ANSYS Multi-field simulations have both data being sent from the Mechanical application to CFX and data sent from CFX to the Mechanical application, on the same interface. This is required for a two-way (or bidirectional) simulation. A typical mechanical example will have the Mechanical application sending displacements to CFX, and CFX sending forces to the Mechanical application. A typical thermal example might have the Mechanical application sending temperatures to CFX, and CFX sending heat flows back to the Mechanical application.

When CFX-Pre is being used in ANSYS MultiField mode, all data transfers from the Mechanical application to CFX must be set up as part of the boundary specification for CFX boundaries. For example, if you want to specify the Mesh Motion on a boundary to be provided by the Mechanical application, you set the Mesh Motion on that boundary to be ANSYS MultiField. Once this setting is made, you will need to specify the name or number of the ANSYS Interface that will matches the CFX boundary. CFX-Pre then provides an easy way for you to send the corresponding data back to the Mechanical application by using the setting **Data Sent to ANSYS**. This allows you to send the most common matching data back to the Mechanical application in a straightforward manner: If you do not want to send the specified data back to the Mechanical application, you can choose None for the **Data Sent to ANSYS** setting.

Sometimes, however, you may want to have CFX send data to the Mechanical application without receiving any data back. This might occur, for example, if you want to transfer forces to the Mechanical application to allow you to calculate a time-dependent stress on the structure, but the resulting mesh displacements are not large enough to affect the fluid flow in any significant way.

For these cases, the **Additional Coupling Sent Data** section of the **Boundary Details** panel is provided. This allows you to send any suitable CFX variable to any ANSYS Interface as required, and so allows you to send data for what is effectively a one-way coupled simulation from CFX to the Mechanical application. Details on this panel can be found in *Additional Coupling Sent Data* (p. 395).

If you are using CFX-Pre in ANSYS MultiField via Prep7 mode, then you can specify only details for data being received by CFX from the Mechanical application. Any definition of data to be send from CFX to the Mechanical application must be made in the Mechanical APDL application user interface.

### 13.4.4. Transient and Steady-state MFX Simulations

Simulations of a physical process can either be transient or steady-state. In a transient simulation, the behavior of a physical system as a function of time is investigated. In a steady-state simulation, it is assumed that the physical system is moving towards an equilibrium or steady-state solution.

In an ANSYS Multi-field simulation, each of the Mechanical application and CFX can be set up to simulate in transient or steady-state mode, independent of the other. Different combinations of these imply different physical situations, which are described below.

All ANSYS Multi-field simulations, regardless of whether they are transient or steady-state, are controlled by a "multi-field timestep". This has different meanings depending upon the physical setup.

- **Mechanical transient, CFX transient.** In this case, the physical process is being modeled as transient. Both the Mechanical application and CFX show transient effects. The elapsed time of the simulation is given by the multi-field timestep, as well as the variable "time" in both the Mechanical application and CFX. The timestep for the CFX solution is the same as the multi-field timestep in all cases. However, the Mechanical application can be set to run with a smaller timestep (using the DELTIM command) if this is required for stability reasons, although data will be exchanged with CFX only after each multi-field timestep: this is known as "sub-cycling".
- **Mechanical steady-state, CFX steady-state.** In this case, the physical process is being modeled as steady-state. There is no concept of elapsed time during the simulation. CFX still uses a false timestep (or "pseudo-timestep") as the solution progresses (see *Steady State Time Scale Control* (p. 424)) but this is not an elapsed time and it is not shared in any way with the Mechanical application solver. For single steady-state simulations, the multi-field timestep has no particularly useful meaning and it is set equal to the Coupling Total Time for the simulation. However, ANSYS Multi-field has the concept of doing multiple steady-state simulations or load steps in one setup, and in this context the multi-field timestep is effectively a counter and does become useful again. For details, see *Multiple Load Steps* (p. 402).
- **Mechanical steady-state, CFX transient.** In this case, the physical process is being modeled as transient. The CFX solution shows real transient effects as the flow field evolves with time. However, the structure being modeled in the Mechanical application responds to variations in the fluid fields on a timescale that is much faster than the timescale on which the fluid field evolves, and so it is assumed to be unnecessary to retain transient effects or a history of how the structure evolves over time to get accurate results. In effect the Mechanical application performs multiple steady-state simulations of the structural physics at time intervals corresponding to the multi-field timestep. It would not be wrong to model this situation with the Mechanical application running in transient mode, but the results would be the same as for the steady-state simulation. The elapsed time of the simulation is given by the multi-field timestep, as well as the variable "time" in both the Mechanical application and CFX. The timestep for the CFX solution is the same as the multi-field timestep in all cases.
- **Mechanical transient, CFX steady-state.** This is effectively a reversal of the previous case. In this case, the physical process is being modeled as transient. The Mechanical application solution shows real transient effects as the structural fields evolve with time. However, the fluid being modeled in CFX responds to variations in the structural fields on a timescale that is much faster than the timescale on

which the structure fields evolve, and so it is assumed to be not necessary to retain transient effects or a history of how the fluid evolves over time to get accurate results. The elapsed time of the simulation is given by the multi-field timestep, as well as the variable "time" in the Mechanical application. There is no concept of real elapsed time in CFX, although CFX will still use a false timestep (unrelated to the elapsed time) for solution purposes. Note that in this case, CFX can be made to write out "coupling step" files at the end of each multi-field timestep: these are described in [Multiple Load Steps \(p. 402\)](#).

Whenever CFX is run in steady-state mode in an ANSYS Multi-field simulation, then the following controls and information apply:

- **Minimum Number of Iterations** and **Maximum Number of Iterations** (set on the **Solver Control** form in CFX-Pre). These control the number of iterations per stagger iteration. In general, the higher this is set, the more iterations CFX performs before exchanging data with the Mechanical application. You should run with a value that is much lower than the default for most steady-state ANSYS Multi-field simulations (a value of 3 may be a sensible default for many runs).
- The reported number of outer loop iterations will continue to increase throughout the steady-state simulation: it will not reset at the start of each multi-field timestep or stagger iteration. This means that if you use the CEL variable `aitern` (see [Variables and Predefined Expressions Available in CEL Expressions in the CFX Reference Guide](#)) in a CEL expression, you may not get what you expect. The CEL variable `t` (time) cannot be usefully used in a steady-state simulation. However, two new CEL variables `Current Stagger Iteration` and `Accumulated Coupling Step` are available for use.

`Accumulated Coupling Step` is useful only for a steady-state simulation if multiple coupling steps or load steps are being performed. For details, see [Multiple Load Steps \(p. 402\)](#).

### 13.4.5. Multiple Load Steps

The Mechanical application has the capability to solve multiple steady-state simulations in one run of the solver, and this capability extends also to ANSYS Multi-field runs. Each steady-state simulation is called a "load step" or "coupling step", and any number of load steps can be performed in a single run.

A multiple load step simulation is controlled by the multi-field timestep. For example, to do five load steps, you could set the total "time" for the simulation to be 5 units, and the multi-field timestep to be 1 unit. In this setup the multi-field timestep acts as a counter and simply counts the number of load steps. In order to change the structural physics (loads and/or constraints) between the each load step, you need to set up the appropriate load or constraint to be a function of time (time corresponds to the multi-field time in this case). In order to change the CFX physics between each load step, you can set up physical quantities to be functions of the CEL variable `Accumulated Coupling Step`.

CFX and the Mechanical application would both be set up as steady-state simulations in this scenario. For each load step, the appropriate loads and constraints would be applied to the structure in the Mechanical application, the appropriate boundary conditions would be applied to the fluid in CFX, and the solution would progress through multiple stagger iterations as usual until all of CFX, the Mechanical application (where appropriate) and the exchanged data quantities have converged to the level specified (or until the maximum number of stagger iterations has been reached). At the end of each load step/multi-field timestep, the Mechanical application writes results to its results file, and CFX can be made to write a "coupling step" file. The solvers then both move onto the next load step, and solve that, using the results from the previous load step as the initial conditions.

To get CFX to write a coupling step file, use the **Output Control** panel in CFX-Pre, and ask to create backup files every coupling step. For details, see [Backup Tab in the CFX-Pre User's Guide](#). These files will appear in the same directory as transient results files and other backup files, with a name such as `2_CS_full.bak`, where the number is the load/coupling step number or multi-field timestep number.

Coupling step files can be full or partial (selected variables only) backup files; if they are full backup files then they can be loaded into CFD-Post directly. Alternatively, you can read the final results file into CFD-Post, and then use the **Timestep Selector** dialog box to make the results for all coupling steps/multi-field timesteps available. For details, see [Timestep Selector in the \*CFD-Post User's Guide\*](#). If this is done, and the Mechanical application results file is loaded into CFD-Post in addition to the CFX results files, then the **Timestep Selector** dialog box can be set to synchronize "By Index" to allow the results for each load step/multi-field timestep to be loaded from both files together.

### 13.4.6. Units

If the Mechanical application solution units specified by `/UNITS` command are consistent with CFX solution units, then no warning (annotated with "!") is given in Pre.

If the Mechanical application solution units specified by `/UNITS` command are inconsistent with CFX solution units but are still a well defined system (for example, SI, MKS, 1/4MKS, CGS, BIN), then the following warning is given in CFX-Pre:

```
The solution units defined in CFX-Pre and the Mechanical input file
are not consistent. Inconsistent solution units systems are being
used for the Mechanical and CFX simulations. All necessary unit
conversions will be applied to data transfers between the solvers.
```

If user-defined solution units are specified for the Mechanical application, using the `/UNITS, USER` command, or if no `/UNITS` command is specified, then the following warning is given in CFX-Pre:

```
Potentially inconsistent solution units systems are being used
for the ANSYS and CFX simulations. Unit conversions will not be applied
to data transferred between the solvers - Please check results carefully."
```

Refer to the following sections for more information:

- [Setting the Solution Units in the \*CFX-Pre User's Guide\*](#)
- [Mechanical APDL Command Reference in the \*Mechanical APDL Command Reference\*](#) for a description of the `/UNITS` command.

### 13.4.7. ANSYS Multi-field Simulations with Lagrangian Particle Tracking

It is possible to combine Lagrangian Particle Tracking with ANSYS Multi-field simulations. For details, see [Particle Transport Modeling \(p. 237\)](#). The following points apply.

- Forces exerted on walls by particles are not included in any forces transferred to the Mechanical application.

### 13.4.8. Best Practices for ANSYS Multi-field Simulations

- [Avoiding Mesh Alignment Errors \(p. 403\)](#)
- [Checking Convergence \(p. 404\)](#)
- [Running the Mechanical Application and CFX Solvers Separately \(p. 405\)](#)
- [Miscellaneous \(p. 405\)](#)

#### 13.4.8.1. Avoiding Mesh Alignment Errors

One of the most common mistakes in setting up an ANSYS Multi-field simulation is to get the Mechanical application mesh and the CFX mesh misaligned, so that they do not meet at a common interface. The meshes do not need to match each other node by node on the interface, but if the geometry is

offset too much then the interpolation algorithm will have difficulty in deciding where the interfaces touch and the quantities transferred between the Mechanical application and CFX may not be as desired.

It is easy to spot this problem after the simulation has completed by loading both the Mechanical application and CFX results into CFD-Post: if there are significant gaps or offsets in the two meshes then this will be readily visible.

You can spot this problem before the run has completed by inspecting the Mechanical application text output and error files. If you make use of Conservative Interpolation (either by choosing to send or receive forces or heat flows as part of an ANSYS Multi-field boundary, or by explicitly choosing a Conservative Interpolation for an Additional Coupling Data Transfer definition), then there will a section in the Mechanical application out file (ANSYS.stdout in the <Run Name>.ansys directory) as follows:

```

CONSERVATIVE INTERPOLATION MAPPING
-----
Sending region name      = interface2
From sending process    = CFX
to receiving process    = ANSYS
Transferring variable   = Wall Heat Flow
  Sending Side:
    Total Area          = 3.60000E-03
    Non-Matching Area Fraction = 0.0000%
    No. of Un-Mapped Nodes = 0
  Receiving Side:
    Total Area          = 3.60000E-03
    Non-Matching Area Fraction = 0.0000%
    No. of Un-Mapped Nodes = 0
Processing complete
-----

```

If significant Non-Matching Area Fraction or Numbers of Un-Mapped Nodes are present unexpectedly, then this shows that you may have a problem with misaligned meshes.

You can also see this problem shortly after the run has started (for all interpolation types) by inspecting the Mechanical application error file (ANSYS.err in the <Run Name>.ansys directory) for warnings of the form:

```

*** WARNING ***                      CP =      2.844   TIME= 17:06:34
The component MFLC_1_1_DISP_2 was created for MFLC,1,1,DISP,2 command
to display improperly mapped nodes. Set /debug,,2 for more
information on improperly mapped nodes.

```

You can view the specified component in the Post1 post-processor, or it will be defined as a mesh region in CFD-Post if the appropriate component file is present (this should be the case if the CFX-Solver script processes the Mechanical application input file at the start of the run). For details, see [ANSYS Files in the CFD-Post User's Guide](#).

If you want to try to pick up mismatched mesh regions before you even attempt to perform the run, then you can temporarily import the Mechanical application mesh into CFX-Pre to see where it is located relative to the CFX mesh. This can be done only if you have a .cdb file or the Mechanical application input file that contains the generated mesh (as it will if it came from the Mechanical application). In this case, simply choose to import a mesh of type the Mechanical application and select the appropriate .cdb file or the Mechanical application input file to import. You can delete the Mechanical application mesh from CFX-Pre before writing the CFX-Solver input file, although if it is not included in any domain definition, it should not appear in the CFX-Solver input file in any case.

### 13.4.8.2. Checking Convergence

If the ANSYS Multi-field run has converged, then it must be the case that the Mechanical application, CFX and the data exchanged across the interface has all converged to the limits specified. For a full transient simulation, convergence should take place for every timestep for the results to be accurate.

Residual plots in CFX-Solver Manager should help to give you a visual feel for the convergence levels of all these quantities. However, if you want a quick way to determine if the run has converged, check the Mechanical application error file (`ANSYS.err` in the `<Run Name>.ansys` directory) for warnings of the form:

```
*** WARNING ***                      CP =      313.600   TIME= 10:44:50
The maximum number of stagger iterations has been reached for
multifield solver but the interface quantities have not yet converged.
The analysis will proceed to the next time step.  Increase number of
stagger iterations using the MFIT command for converged interface
solution.
```

If these warnings are present, then the run did not converge. You may be able to increase the number of stagger iterations if the timestep was converging but did not meet the criteria before the maximum number of stagger iterations was reached. This can be done in CFX-Pre by increasing the **Max. Iterations** parameter on the **External Coupling** tab of the **Solver Control** panel.

If the run was not converging, then you will have to view the residual plots to determine which component (the Mechanical application, CFX or the data exchanged) was not converged and take appropriate action to improve the convergence.

### 13.4.8.3. Running the Mechanical Application and CFX Solvers Separately

If you are having difficulty in getting an ANSYS Multi-field simulation to start up correctly, or want to check your setup before trying an ANSYS Multi-field run, then you should attempt to run the CFX and the Mechanical application components of the simulation separately.

- If you have used the Mechanical application to set up the Mechanical application component of the simulation, then add a pressure load to the same location where you have defined the fluid solid interfaces, of roughly the sort of magnitude that you might expect to result from the CFX fluid forces. Then you can use the **Solve** button to get the Mechanical application to solve just the Mechanical application component of the simulation with this dummy pressure load. If this is not successful, then it is likely to be easier to get this simplified simulation working than debugging the full ANSYS Multi-field setup.
- If you have used the Mechanical APDL application interface to set up the Mechanical application component of the simulation, then the same procedure as recommended for the Mechanical application setups can be used. However, you will also have to turn off the multi-field analysis (MFAN, OFF).
- To test the CFX component of the simulation separately, you will need to replace any ANSYS Multi-field boundaries with an approximate equivalent for example, a fixed or time-dependent mesh displacement rather than a mesh displacement defined by an ANSYS Multi-field setting. You will also need to set **External Solver Coupling** to None to get this to run.

### 13.4.8.4. Miscellaneous

- For cases involving thermal physics in the Mechanical application, ensure that the structural temperature initial condition is set to a sensible value. If you are using the Mechanical application to set up a transient analysis, then this setting is under **Initial Condition** in the tree. If you are using the Mechanical application to set up a static thermal analysis, then it should be sufficient to set **Reference Temperature** (under the relevant environment heading for example, `Transient Thermal` in the tree). If you are preparing the Mechanical application input file by hand or through the Mechanical APDL application interface, then use the command `TUNIF` to set the initial temperature.
- In general, CFX passes forces to the Mechanical application relative to its reference pressure. To include the reference pressure in the forces, use the CFX expert parameter `include pref in forces = t`

This can either be added in CFX-Pre by selecting **Insert > Solver > Expert Parameter** and using the **I/O Control** tab, or added to the CCL directly. For details, see [Expert Control Parameters in the CFX-Pre User's Guide](#).

- If the Mechanical application and CFX processes fail to connect to each other within a certain time, they will "time-out" and fail. The default time (600 seconds) can be changed using the CFX expert parameter `cplg connection timeout = 600`.

This is not available in CFX-Pre and must be set in the CCL directly.

- Ensure that CFX always does at least 2 coefficient loops per stagger iteration. This ensures that solution information that is updated at the end of a coefficient iteration is accounted for in the CFX and the Mechanical application solutions.

If short time scale transient effects need to be predicted accurately for a variable density flow, you should set a minimum of 3 coefficient loops per time step.

- Keeping the maximum number of coefficient loops (transient simulations) or maximum number of outer iterations (steady-state simulations) relatively small in CFX ensures that less CPU is required per stagger iteration, but more stagger iterations are needed for convergence (the optimum balance is problem-specific). Both parameters are specified on the **Basic Settings** tab of the **Solver Control** panel in CFX-Pre.

---

## Chapter 14: Aerodynamic Noise Analysis

---

This chapter describes:

- 14.1. Overview of Aerodynamic Noise Analysis
- 14.2. Types of Noise Sources
- 14.3. Noise Source Strength Estimation in CFX
- 14.4. The CGNS Export Data Format

### 14.1. Overview of Aerodynamic Noise Analysis

Aerodynamic noise results from the propagation of disturbances through a compressible fluid (usually air), caused by the movement of objects or the fluid at some point in time and space. Whether the disturbance is caused by an object or the fluid itself, this results in fluctuations in fluid pressure (or equivalently, density) that propagate outwards from the source at the speed of sound relative to the fluid. The size of the pressure fluctuation relative to the background pressure is called the sound pressure level. Due to the extremely large range, over which the human ear is sensitive, the sound pressure level is given on a logarithmic scale as a function of the pressure fluctuation:

$$SPL = 10 \log \left( \frac{p'}{p_{\text{ref}}} \right) \quad (14-1)$$

where  $p'$  is the pressure fluctuation relative to the background pressure and  $p_{\text{ref}}$  is a reference pressure level, commonly chosen as  $10^{-5}$  Pa. The units of sound pressure level are the Decibel [dB]. When evaluating aerodynamic designs, predicting the sound power per unit area, or sound intensity level, is also important. This is related to the sound pressure level by:

$$I = \frac{p'^2}{2 \rho c} \quad (14-2)$$

where  $\rho$  is the density and  $c$  is the speed of sound in the background fluid. The sound intensity is also usually given on a logarithmic scale and is calculated using an equation of the same form as [Equation 14-1 \(p. 407\)](#) using the intensity level and a reference intensity of  $10^{-12}$  W/m<sup>2</sup>.

In the context of a CFD calculation, aerodynamically generated noise is of primary interest. Ideally, one would like to directly predict the pressure fluctuations at any distance from the device. However, practical considerations limit the ability to make direct predictions with a CFD solution.

Pressure and velocity fluctuations, as well as movement of the simulated components on the CFD mesh, generally result in near field noise, although this may depend on the exact definition of the “near field.” Regardless of its definition, the near field will likely include the locations where the maximum noise levels occur. For most CFD applications, the extent of the computational domain is usually such that near field noise can be both analyzed and predicted.

In contrast, far field noise is the noise level that occurs at some distance from the device, usually outside of the CFD computational domain. The near field pressure and velocity fluctuations play a key role in determining far field noise levels by acting as a localized source of noise for far field noise prediction. Usually far field noise is what most aerodynamic designers are concerned about. For example, it might be desirable to create designs which minimize the sound pressure level at a certain distance from the near field source.

### 14.1.1. Near Field Noise Prediction

Near field noise is of interest when you want to get a feeling for the maximum sound levels occurring directly adjacent to your device, or when designing devices that take advantage of acoustic-flow couplings. For example, maximizing acoustic resonance at a given frequency in some combustor designs is used to enhance combustion efficiency (pulse combustors are a common example). Using a time accurate solution of the compressible Navier-Stokes equations, CFX can directly analyze near field noise and its effects upon the flow field. The CFX expression language can easily be used to calculate the near field sound pressure levels using both [Equation 14–1 \(p. 407\)](#) and [Equation 14–2 \(p. 407\)](#) and algebraic Additional Variables.

### 14.1.2. Far Field Noise Prediction

Direct prediction of mid- to far field noise by a CFD calculation is made somewhat impractical because of the meshing and timestep requirements. Firstly, you must solve the time-accurate, compressible Navier-Stokes equations. Accurately resolving the propagation of acoustic waves imposes timestep restrictions such that the Courant number is in the range of 1-2 at most. This restriction can be highly costly. Secondly, the CFD mesh must span all the way to the reception points with enough spatial resolution to directly resolve acoustic waves over the propagation distance with minimal to no numerical damping. These requirements do not make practical sense for many industrial applications.

Practical predications of far field sound pressure levels are made by first starting with a time accurate CFD calculation of the near field region, usually using URANS, LES, DES, SAS or possibly even DNS. Then, assuming that the fluid is a perfect gas, a forced version of the homogeneous wave equation is solved using models for boundary and interior noise sources taken as input from the transient CFD calculation. This solution strategy decouples the source of the noise from the sound propagation and is called the Lighthill, [178] and [179], *acoustic analogy*.

So, rather than directly predicting far field noise with a time accurate compressible Navier-Stokes solution, you solve for the density fluctuations about a user selected ambient condition:

$$\frac{\partial^2 \rho'}{\partial t^2} - c^2 \frac{\partial^2 \rho'}{\partial x_i^2} = \frac{\partial^2 T_{ij}}{\partial x_i \partial x_j} \quad (14-3)$$

where  $T_{ij}$  is the Lighthill tensor and  $\rho'$  is the density fluctuation with respect to the ambient condition. [Equation 14–3 \(p. 408\)](#) is the non-homogeneous (driven) wave equation and sometimes called the Lighthill equation. It assumes that the ambient fluid is an isothermal polytropic gas so that the pressure fluctuation is directly proportional to the density fluctuation. As a result, the equation can be written in terms of either pressure or density variation. The Lighthill tensor has three components and is given by:

$$T_{ij} = \rho u_i u_j + \tau_{ij} - c^2 \rho' \delta_{ij} \quad (14-4)$$

where the first term is the instantaneous Reynolds stress and  $\tau_{ij}$  is the stress tensor (normal, including pressure, and shear components). Solutions of the Lighthill equation give the spatial and temporal magnitude and distribution of density fluctuations due to interior noise sources generated by the Lighthill tensor. Interior sources result from flow structures such as wakes and shear layers. Surface based sources, not shown in [Equation 14-3 \(p. 408\)](#), can also contribute to density fluctuations and are further discussed in the following section.

One approach to solving the Lighthill equation would be to predict the noise source strength on a separate acoustic mesh which is normally much coarser than the original CFD mesh, and may cover a much larger spatial extent. This approach significantly reduces the cost of solving for the far field noise over that of a full solution of the compressible Navier-Stokes equations but can still account for complex effects such as reflections, diffraction or absorption by boundary conditions. Other, less computationally expensive approaches are also possible.

Any method that one uses to solve the Lighthill equation is a one-way approach that ignores coupling between acoustics and the flow field. Hence, processes which consider that coupling cannot be analyzed with this approach. As a result, the one way methodology is limited to predicting noise mainly for far field regions around aerodynamic devices. Prediction of noise using this approach for a confined, internal flow applications will be of limited usefulness because the flow tends to be more strongly coupled with the acoustics.

Additionally, without even solving the Lighthill equation in some way, it is valuable to evaluate the strength of the various noise sources. This is the approach that can be directly used within CFX to compare designs, as well as to analyze the relative strengths of the noise sources. In addition, the surface noise sources can be written from the flow solver and post processed using software which solves the Lighthill equation.

## 14.2. Types of Noise Sources

As mentioned in the last section, noise sources for the Lighthill equation can arise from several sources. These include displacement of the fluid by a moving boundary, pressure fluctuations on surfaces within the CFD calculation (these may or may not be wall boundary conditions), as well as interior flow features. The first of these sources is called a monopole source. The second is called a dipole source, if the surface is stationary, or it is called a rotating dipole source, if the surface is rotating at a fixed angular velocity about an axis. Finally, interior sources are usually referred to as quadrupole sources.

A generalized version of the Lighthill equation that represents the three possible noise sources was first presented by Williams and Hawkins [180] as follows:

$$\frac{\partial^2 \rho'}{\partial t^2} - c^2 \frac{\partial^2 \rho'}{\partial x_i^2} = \frac{\partial}{\partial t} \left\{ \rho_0 v_n \delta(f) \right\} - \frac{\partial}{\partial x_i} \left\{ \tau_{ij} \delta(f) \right\} + \frac{\partial^2 T_{ij}}{\partial x_i \partial x_j} \quad (14-5)$$

where  $\delta(f)$  is the Dirac delta function describing the moving surface geometry ( $f$  is non-zero in the fluid region and zero at the moving boundary),  $v_n$  is the normal velocity of the surface, and  $\tau_{ij}$  is the fluid stress tensor given by:

$$\tau_{ij} = p \delta_{ij} + \mu_{\text{eff}} \left( \frac{\partial u_i}{\partial x_j} + \frac{\partial u_j}{\partial x_i} \right) - \frac{2}{3} \mu_{\text{eff}} \frac{\partial u_k}{\partial x_k} \delta_{ij} \quad (14-6)$$

The first term on the right hand side of [Equation 14-5 \(p. 409\)](#) represents the monopole source. The second term represent the dipole sources (possibly rotating). The third term represents the quadrupole sources.

### 14.2.1. Monopole Sources

This is a source that occurs as a result of fluid being displaced by the swept volume of a moving boundary as it propagates through its range of motion. Sometimes this noise source is also called the “self noise” or the “thickness noise” of the device. Monopole source strength is a function of the normal velocity of the surface.

### 14.2.2. Dipole and Rotating Dipole Sources

Dipoles and rotating dipole sources arise from the fluctuation of forces on the surface. Sometimes these sources are also referred to as “loading noise.” Strictly speaking, these forces cannot be evaluated without knowledge of the acoustic field. However, the Lighthill analogy neglects any two-way coupling, and the forces due to acoustic fluctuations are much smaller than the dynamic forces. Hence, it is perfectly valid to only consider the dynamic forces created by the bulk fluid flow.

In addition, it is common to neglect the viscous component of the force because that is usually a smaller fraction of the normal (static pressure based) component of the force.

### 14.2.3. Quadrupole Sources

Quadrupole sources arise in the interior of the flow and result from turbulence fluctuations in wakes, shear layers, or interaction of flow features. Because many of these features are three-dimensional in nature, quadrupole sources are very expensive to evaluate and store. This is mainly because transient data for a symmetric tensor is needed over some three dimensional region of the CFD calculation.

Usually the density fluctuation term in the Lighthill tensor [Equation 14-4 \(p. 409\)](#) is neglected because for turbulent flows, it is much smaller than the combined instantaneous Reynolds and compressive stresses.

## 14.3. Noise Source Strength Estimation in CFX

Without directly solving either the Lighthill or FW-H equation to predict the sound pressure levels or power at some distance from the source, it is still useful to analyze the four types of sources (monopole, dipole, rotating dipole, and quadrupole). Analysis of the various source terms allows comparative evaluations of different designs, as well as comparison of the relative strengths of the various types of source terms. The main objectives of analysis of the various noise sources are:

- Comparison of the relative noise source strengths for a given configuration. This type of comparison will allow you to determine which type of noise source dominates in your problem (monopole, dipole, or quadrupole). Once the dominant noise source is known, this reduces the cost of far field noise predictions because less overall data can be written.
- Designs can be compared against one another to determine which produces less noise.
- The maximum noise source level can be deduced by post processing the noise sources.

- The noise source strengths can be written to files and used for input into any far field noise prediction software (for example, LMS Sysnoise or Virtual Lab Acoustics, or your own model).

There are various approaches for analysis of noise sources in CFX discussed in the following sections. Near field noise can be analyzed using CEL expressions and flow solver monitor points to create plots of sound pressure levels within the computational domain. While far field noise cannot be directly predicted, the common sources can be post processed and can also be written as transient solution fields from the flow solver on selected boundary conditions. You can control the data export using the **Export Results** tab on the **Output Control** dialog box in CFX-Pre. All files are written in a binary format called CGNS (<http://www.cgns.org>). The CGNS exported data is described in a later section.

## 14.3.1. Monopole Sources

### 14.3.1.1. Monopole Data in the CFX-Solver Manager

Monopole sources are related to the movement of the surface of the sources. Averaged values, as well as minimum and maximum values, of the monopole sources can be monitored in the CFX-Solver Manager using monitor points created in CFX-Pre. The monitor point data will appear in the **User Points** tab in the CFX-Solver Manager. These data can be exported from within the CFX-Solver Manager, if desired. For details, see [Exporting Plot Data in the CFX-Solver Manager User's Guide](#).

### 14.3.1.2. Exporting Surface Monopole Data

For a rotating device, the monopole source strength depends on the component of the rotation velocity normal to the rotating surface.

Monopole source output is a built-in option for the results export. To export the data, you need to create an export results object with an export surface that uses the `Acoustic Monopole` option. In this case, the CFX-Solver writes out the acoustic monopole data on the selected boundaries to a file in the requested file format.

Acoustic monopole data is available for both steady-state and transient simulations.

## 14.3.2. Dipole or Rotating Dipole Sources

### 14.3.2.1. Dipole Data in the CFX-Solver Manager

Dipole and rotating dipole sources result from the fluctuation of the fluid pressure and shear stress field at the boundaries of the CFD domain. Averaged, minimum or maximum values of the pressure or wall shear stress can be monitored in the CFX-Solver Manager using monitor points created in CFX-Pre. The monitor point data will appear in the **User Points** tab in the CFX-Solver Manager. These data can be exported for external analysis if so desired. For details, see [Working with Monitors in the CFX-Pre User's Guide](#) and [Exporting Plot Data in the CFX-Solver Manager User's Guide](#).

### 14.3.2.2. Exporting Surface Dipole Data

Dipole and rotating dipole source output are built in options for the results export. You simply create an export results object, again with an export surface that uses either the `Acoustic Dipole` or `Acoustic Rotating Dipole` options. For these two options, the flow solver automatically writes the necessary data to CGNS files during the run. A single mesh file is written at the beginning of the run, which contains the surface grid coordinates and mesh topology. For rotating dipole sources, the mesh file also includes the normal area vectors in addition to the surface grid and topology.

In both cases, the solver writes the static pressure on the selected boundaries to a file for each timestep. It is important to note that the shear stress contribution to the force on the boundaries is neglected in this case. The second and third terms in [Equation 14–6 \(p. 410\)](#) are ignored. This is normally a reasonable assumption, especially for aerodynamic flows, because the normal force will dominate the noise source.

### 14.3.3. Important Boundary Results Export Notes

- The mesh file is written once at the beginning of the run and contains the surface grid coordinates, the element topology (element to node connectivity) and, for some sources, the nodal area vectors.
- When multiple boundary conditions are selected the flow solver will concatenate these together to form one large region, as long as the boundaries do not span CFX domains. When the selected boundary conditions span CFX domains, they are broken up into one export surface per CFX domain.
- Multiple export surfaces can be used for each export object and each export surface can be of a different type.
- The file name for the export will be set to the name of the export results object. This can be overridden using the `Filename Prefix` parameter.

### 14.3.4. Quadrupole Sources

Quadrupole sources are related to turbulence fluctuations in the flow field. The Lighthill stress tensor [Equation 14–4 \(p. 409\)](#), neglecting the pressure fluctuation term, is available from the CFX-Solver and can be monitored in the CFX-Solver Manager. It is not only possible to monitor averaged or minimum and maximum values of the quadrupole sources, but also to monitor individual components of the Lighthill stress tensor. These values can be monitored using monitor points created in CFX-Pre. The monitor point data will appear in the **User Points** tab in the CFX-Solver Manager. These data can be exported if desired.

#### 14.3.4.1. Exporting Acoustic Quadrupole Data

Quadrupole source data is available for transient simulations only. The Lighthill stress tensor and its components are available to export to results, backup and transient results files. To write the data to file, selecting the Lighthill stress tensor from the list of selected variables is required.

## 14.4. The CGNS Export Data Format

By default, all boundary results export files are written in CGNS V2.4 format. This is a completely open format and the source code for the library can be downloaded from <http://www.sourceforge.net>. Examples and documentation are also available from the official CGNS website at <http://www.cgns.org>. You might also find it useful to download and compile the CGNS Tools from the source forge site as well. The ADF Viewer in particular is useful for inspecting the CGNS files written by the flow solver.

Even though the format is fully open, there is still considerable room for picking various options such as how files are named and exactly how they are internally structured. This section documents most of that information.

### 14.4.1. File Naming Conventions

During the run, the flow solver writes the mesh and the solution data to the temporary run directory using the following naming conventions:

```
<prefix>_mesh.cgns mesh file
```

<prefix>\_<timestep>.cgns solution file

where:

- <prefix> is the filename prefix. By default, this is set to the export results object name. The default can be overridden by the user during pre-processing.
- <timestep> is the timestep number. This is a six character string containing the timestep number. The string is formatted and right justified. For example, 000010, 000020, 000030, ... This allows files to show up in order when displayed using a directory listing. It also makes batch post processing the files easier.

At the end of the run, the files are stored in a saved version of the temporary directory called:

<filename>\_<run number>

where <filename> is the basename of the CFX-Solver input file or results file from which the run was started and <run number> is the three character string indicating how many runs have been performed for this case. The run number is accumulated across restarts so that directories over a sequence of two or more runs might be labelled:

lescylinder\_001/, lescylinder\_002/, lescylinder\_003/, ...

where the flow solver, in this case, was originally started using a CFX-Solver input file named lescylinder.def. For each run, an independent set of CGNS files will be stored separately in each directory.

#### 14.4.1.1. Important Notes

- The flow solver makes no attempt to keep track of previously written source files across restarts. Files are simply written out during each run and it is up to the user to keep track of the sequence.
- The mesh data is written only once at the beginning of the run to minimize the data output. For rotating dipole results, the normal area vectors are also stored in the initial mesh file.

#### 14.4.2. CGNS File Structure

The generic details of how to read CGNS files and the file structure are fully documented in the documentation available from the CGNS website.

In the following sections, it may be useful to work from an example of the CFX pre-processing setup in this case. The following flow solver CCL was created using a transient version of the CFX axial turbine MFR tutorial:

```

OUTPUT CONTROL:
  EXPORT RESULTS: export1
    Option = Surface Data
  EXPORT FORMAT:
    Filename Prefix = trouser
    Option = CGNS
  END
  EXPORT FREQUENCY:
    Option = Time Interval
    Time Interval = 2.124E-5 [s]
  END
  EXPORT SURFACE: rotating dipole
    Option = Acoustic Rotating Dipole
    Output Boundary List = Blade
  END
  EXPORT SURFACE: regularities

```

```
    Option = Acoustic Dipole
    Output Boundary List = Shroud,Shroud 2
END
EXPORT RESULTS: export2
    Option = Surface Data
    EXPORT FREQUENCY:
        Option = Time Interval
        Time Interval = 2.124E-5 [s]
    END
    EXPORT SURFACE: dipole
        Option = Acoustic Dipole
        Output Boundary List = Blade 2
    END
END
END
```


In this example, the user has selected to output two different groups of files corresponding to the two objects, `export1` and `export2`, at the same time interval. The object names could be any string and by default the object name is used as the file prefix unless the user overrides that by setting the `File-name Prefix` option under `EXPORT FORMAT`.

For `export1`, the user has selected to output a rotating dipole surface source called `rotatingdipole` on the boundary called `Blade` (which happens to be in a rotating domain). In addition, a regular dipole source, called `regulardipole`, will be written on boundaries `Shroud` and `Shroud 2`. In this example, `Shroud` is in a rotating domain and `Shroud 2` is in a stationary domain. This is an example of where the flow solver will split the surface source into two different regions because the surface spans across two CFX domains.

For `export2`, they have selected to output a dipole source, called `dipole`, on `Blade 2`, which is in a stationary domain.

The export surface names in both cases are also provided by the user, in addition to the export results names, during CFX pre-processing.

The tree structure of the `export2` results output looks as follows:



On the left is the grid file and on the right is a solution file. All CGNS files contain a root node called "/" and are set up like a file system below that root node. Below the root node is CGNSLibraryVersion which gives the CGNS version used to write the file. Both mesh and solution files contain a base node called `export2` which corresponds to the results object name and the file prefix. Below that node, the following nodes are defined:

#### 14.4.2.1. Common Nodes for Mesh and Solution Files

`SimulationType` simply contains a string stating that the solution is written from a time-accurate or nontime-accurate simulation. Acoustic output will always be from a time-accurate simulation in CFX.

`TimeIterValues` is a `BaseIterativeData_t` node that contains the time values and timestep data for the solutions in the file.

`TimeIterValues/TimeValues` is a `DataArray_t` node that contains a list of real values corresponding to the simulation times stored in the file. In our case, there is only ever one time value inside a single CGNS file.

`TimeIterValues/IterationValues` is also a `DataArray_t` node that contains the integer value corresponding to the timestep number. This number is exactly the same as that encoded in the file name.

`dipole` is a `CGNS Zone_t` node and contains the grid coordinates and nodal area vectors in the mesh file. The solution file contains the boundary pressures and links back to the grid coordinates and the element to vertex map.

`ZoneType` is a `processor_t` node that contains the type of grid written to the file and is always set to `Unstructured`. This is a default CGNS name.

`Export Option` is written for all regions and contains a string which tells what kind of surface export option was used to create the data. In the two examples, this string will be either `Acoustic Dipole` or `Acoustic Rotating Dipole`.

`Flow Solution` is a `FlowSolution_t` node which contains the solution values below it written on the element nodes. In the mesh file, this directory contains nothing for this case because the file only contains data for a dipole source. For rotating dipole source cases, this directory contains the nodal area vector components called `Nodal Area VectorX`, `Nodal Area VectorY`, `Nodal Area VectorZ`. (Normally, the CGNS documentation has a suggested naming convention for variables written to `FlowSolution_t` nodes. There is no suggested name for `Nodal Area Vectors` but this format follows the suggested naming convention for vectors.)

`ZoneIterativeData` is a `ZoneIterativeData_t` node that contains a single node below it called `FlowSolutionPointers`. This node is a `DataArray_t` node that contains an array of character strings pointing to the directory names for flow solutions at different timestep values. Because only one timestep is written to each CGNS file, this node only holds one character string called `Flow Solution`.

#### 14.4.2.2. Mesh File Specific Nodes

`GridCoordinates` is a `GridCoordinates_t` node which contains the surface mesh  $\langle x,y,z \rangle$  coordinates in the flow solver coordinate system.

`CoordinateX/Y/Z` are just `DataArray_t` nodes with the grid coordinate components.

`Face to Vertex Map` is an `Elements_t` directory node that contains the element range and connectivity.

`Face to Vertex Map/ElementRange` is an `IndexRange_t` node that gives the range of elements assigned to the region. In all cases, this node gives two numbers 1 and N, where N is the number of surface elements written for the region. `Face to Vertex Map / ElementConnectivity` is a `DataArray_t` node which contains the face to vertex map for each boundary face (2D `QUAD_4`) element. An example of this array with both triangular and quadrilateral faces is as follows:

```
465 152 155 155
459 176 178 178
579 154 157 157
579 156 154 154
465 157 152 152
2 32 31 1
1 31 462 461
3 33 32 2
4 34 33 3
5 35 34 4
6 36 35 5
7 37 36 6
8 38 37 7
9 39 38 8
```

The first five elements on this boundary are actually triangular faces written as degenerate quadrilaterals. The remaining elements are real quadrilaterals. The elements are always written to the file with the CGNS element type QUAD\_4.


### **14.4.2.3. Solution File Specific Nodes**

GridCoordinates is only a link node which gives the filename of the mesh file corresponding to the solution.

Face to Vertex Map is another link node which gives the filename of the mesh file corresponding to the solution.

FlowSolution/Pressure is a DataArray\_t node which contains the boundary pressures on element vertices.

The last example shows a case where the dipole export surface has been broken into two regions because the boundary list spans across more than one CFX domain. In this case, one domain is rotating (R1) and the other is stationary (S2):



The main difference between this example and the last one is that the split regions have been prefixed with the corresponding CFX domain name and a period character. All other nodes contain the exact data as the simple case previously described.

---

## Chapter 15: Advice on Flow Modeling

---

This chapter describes:

- 15.1. Solving Problems with ANSYS CFX
- 15.2. Modeling 2D Problems
- 15.3. Mesh Issues
- 15.4. Timestep Selection
- 15.5. Advection Scheme Selection
- 15.6. Advanced Options: Dynamic Model Control
- 15.7. Pressure Level Information
- 15.8. Interpolation Scheme
- 15.9. Temperature Damping
- 15.10. Monitoring and Obtaining Convergence
- 15.11. Solver Issues
- 15.12. How CEL Interacts with the CFX-Solver
- 15.13. Best Practice Guides

### 15.1. Solving Problems with ANSYS CFX

CFX-Solver is extremely robust and can reliably give solutions to a wide range of complex flow problems. However, there are some situations where obtaining a converged solution is not straightforward.

This section provides advice on setting appropriate solver parameters and on identifying, diagnosing and solving potential problems quickly and easily.

Issues associated with multi-component or multiphase flow are available in [Multicomponent Flow](#) (p. 18) and [Multiphase Flow Modeling](#) (p. 189).

Modeling advice for free surface flow is available in [Modeling Advice for Free Surface Flow](#) (p. 233).

### 15.2. Modeling 2D Problems

The following is advice for modeling 2D problems:

- Make the mesh only 1 element thick. More elements will slow computational time and require more memory.
- For planar 2D geometries, apply symmetry conditions to the front and back planes. Free Surface Flow Over a Bump is one example of a case that uses this setup. Do not use free slip walls; doing so will hurt accuracy because control volume gradients will not be computed. The extrusion distance should be on the order of the smallest mesh dimension.
- For axisymmetric 2D geometries, apply symmetry conditions to the high-theta and low-theta planes unless there is swirl anticipated in the flow, in which case, 1:1 periodic connections should be applied instead. Do not use GGI periodic connections; doing so will hurt accuracy. The extrusion rotation angle for axisymmetric geometries should be small (for example, 1 to 5 degrees).

## 15.3. Mesh Issues

The ability to obtain accurate results is significantly affected by the mesh distribution. In the discussion that follows, the relationship between the mesh distribution and the following topics is addressed:

- [Physical Modeling Errors: YPLUS and Mesh Resolution Near the Wall](#) (p. 420)
- [Measures of Mesh Quality](#) (p. 420)

### 15.3.1. Physical Modeling Errors: YPLUS and Mesh Resolution Near the Wall

Unless you are specifically interested in resolving the boundary layer profile in your simulation, ANSYS CFX will use wall functions to model the near wall region in a turbulent flow simulation.

Wall functions are extremely useful in reducing computational load, but you should be aware of their limitations. These limitations are best understood in terms of the parameter  $y^+$  (Yplus), which is a non-dimensional variable representing the distance from the wall to the first node away from the wall. It is therefore dependent on the size of the mesh in the wall region. If the value of  $y^+$  is too large, then the wall function will impose wall type conditions further from the wall than would normally be physically appropriate. The use of scalable wall functions in ANSYS CFX has removed problems associated with the lower valid limit for  $y^+$ .

You can plot the values of  $y^+$  at the wall in CFD-Post to see where the mesh needs refining (or coarsening) to reduce (or increase) the value of  $y^+$  in that region.

For more information see [Scalable Wall Functions in the CFX-Solver Theory Guide](#) and [Solver Yplus and Yplus in the CFX-Solver Theory Guide](#).

### 15.3.2. Measures of Mesh Quality

Using a mesh of adequate geometrical mesh quality is an important part of controlling discretization error. For details, see [Discretization Errors in the CFX-Solver Theory Guide](#). It is also important for avoiding round-off errors during, for example, the solution of the linear equations that are produced by the discretization process. Significant measures of mesh quality may be broadly categorized as measures of mesh orthogonality, expansion and aspect ratio (or stretching).


Various forms of these measures are presented during different stages of the simulation process (for example, mesh generation, physics pre-processing, solution, and so on). It is important to realize, however, that the most relevant form of the orthogonality, expansion and aspect ratio measures is intimately related to the discrete approximations employed by the field solver being used. Moreover, acceptable ranges for the values of these measures also depend heavily upon the discretizations used.

The discussion that follows focuses on the measures that are most relevant to the CFX-Solver. The relationship between these measures and some of the values that are available in mesh generators or physics pre- or post-processors is also noted.

#### 15.3.2.1. Mesh Orthogonality

The concept of mesh orthogonality relates to how close the angles between adjacent element faces or adjacent element edges are to some optimal angle (for example, 90° for quadrilateral faced elements and 60° for triangular faces elements). The most relevant measure of mesh orthogonality for the CFX-Solver is illustrated below. It involves the angle between the vector that joins two mesh (or control

volume) nodes (s) and the normal vector for each integration point surface (n) associated with that edge. Significant orthogonality and non-orthogonality are illustrated at ip1 and ip2, respectively.



The orthogonality angle, three related measures, and acceptable ranges are tabulated below with other measures that are available through the CFD-Post post-processor and ANSYS ICEM CFD meshing tools. Values outside of the suggested acceptable range will increase both sources and the amplification of discretization error. Poor convergence and divergence can be expected under these conditions.


Orthogonality Measure	Acceptable Range	Description and Notes
Orthogonality Angle	$>20^\circ$	Area weighted average of $90^\circ - a \cos(n \cdot s)$ for all integration point surfaces of a control volume <ul style="list-style-type: none"> <li>• Large values indicate good orthogonality</li> <li>• One of the best indicators of how and where poor orthogonality will adversely affect general solution accuracy and robustness</li> </ul>
Orthogonality Factor	$>\frac{1}{3}$	Area weighted average of all integration point surface scalar products of unit n and s vectors (that is, n·s) associated with each control volume <ul style="list-style-type: none"> <li>• Large values indicate good orthogonality</li> <li>• One of the best indicators of how and where poor orthogonality will adversely affect general solution accuracy and robustness</li> </ul>
Orthogonality Angle Minimum	$>10^\circ$	Minimum of $90^\circ - a \cos(n \cdot s)$ for all integration point surfaces of a control volume <ul style="list-style-type: none"> <li>• Similar to orthogonality angle, but adverse effects are likely to be less globally significant</li> </ul>
Orthogonality	$>\frac{1}{6}$	Minimum of all integration point surface scalar products of unit n and s vectors (that is, n·s) associated with each control volume

Orthogonal-ity Measure	Acceptable Range	Description and Notes
Factor Minimum		<ul style="list-style-type: none"> <li>Similar to orthogonality angle, but adverse effects are likely to be less globally significant</li> </ul>
Minimum/Maximum Face Angle (CFD-Post)	$>10^\circ / <170^\circ$	<p>Minimum/maximum angle between edges of each face that touches a node</p> <ul style="list-style-type: none"> <li>Usefulness of this orthogonality measure is limited by its two-dimensional nature</li> <li>Acceptable minimum/maximum values do not ensure acceptable orthogonality (for example, a flattened tetrahedron can have minimum angles of <math>30^\circ</math>)</li> </ul>
Minimum/Maximum Dihedral Angle (ANSYS ICEM CFD)	$>10^\circ / <170^\circ$	<p>Minimum/maximum angle between element faces</p> <ul style="list-style-type: none"> <li>Inherent three-dimensional nature increases the usefulness of this measure</li> <li>Most similar measure to orthogonality angle minimum</li> </ul>

### 15.3.2.2. Mesh Expansion

The concept of mesh expansion relates to rate of change in the magnitude of adjacent element face areas or volumes.

The most relevant measure of mesh expansion for the CFX-Solver is illustrated below. It involves the ratio of the maximum to minimum distance between the control volume node and the control volume boundaries. Because this measure is relatively expensive to calculate for arbitrarily shaped control volumes, an alternative formulation, the ratio of maximum to minimum sector volumes, is used.




This measure and its acceptable values are tabulated below, along with a measure that is available through the CFD-Post post-processor. Values outside of the suggested acceptable range will increase sources of error that are due to the discretization of transient and body force terms.

Mesh Expansion Measure	Acceptable Range	Description and Notes
Mesh Expansion Factor	<20	Ratio of largest to smallest sector volumes for each control volume
Element Volume Ratio (CFD-Post)	<20	Ratio of largest to smallest element volumes that surround a node

### 15.3.2.3. Mesh Aspect Ratio

The concept of the mesh aspect ratio relates to the degree that mesh elements are stretched. The most relevant measure of aspect ratio for the CFX-Solver is illustrated below. It involves the ratio of the maximum to minimum integration point surface areas in all elements. Nodal (that is, control volume) values are calculated as the maximum of all element aspect ratios that are adjacent to the node.



The area based measure is tabulated below along with another measure that is available through the CFD-Post post-processor. Values outside of the suggested acceptable range will lead to round-off errors and associated difficulties converging the discretized equations.

Mesh Aspect Ratio Measure	Acceptable Range	Description and Notes
Aspect Ratio	<100 <sup>a</sup>	Largest ratio of maximum to minimum integration point surface areas for all elements adjacent to a node
Edge Length Ratio (CFD-Post)	<100	Largest ratio of maximum to minimum integration edge lengths for all edges of element faces that touch a node

<sup>a</sup>The acceptable range for both measurements is less than 1000 if running double precision.

## 15.4. Timestep Selection

The selection of an appropriate timestep size is essential in order to obtain good convergence rates for your simulation. A general discussion on when a steady state or a transient solution should be attempted is available in *Steady State and Transient Flows* (p. 3).

### 15.4.1. Steady State Time Scale Control

For steady-state problems, the CFX-Solver applies a false timestep as a means of under-relaxing the equations as they iterate towards the final solution. Because the solver formulation is robust and fully implicit, a relatively large time scale can typically be selected, so that the convergence to steady-state is as fast as possible.

A steady-state calculation will typically require between 50 and 100 outer loop iterations to achieve convergence. If you expect that the actual flow being simulated would take a long time to reach a steady-state condition, given the initial conditions you have specified, then a greater number of outer loop iterations may be required. In this case, you can usually reduce the number of iterations required by setting initial conditions that more closely resemble the steady state flow.

Although a relatively large time scale can be used, if the time scale is too large the resulting convergence behavior will be “bouncy.” If this is observed, then the first thing you should try is to reduce the time scale, say, by a factor of four. If there is no noticeable improvement, then the convergence problem may be caused by another factor. If the time scale is too small, then the convergence will be very slow.

In addition to the advice in the following sections, you will probably require a small physical time scale for the following situations:

- Poor mesh quality
- Transonic flow
- Large regions of separated flow
- Openings with simultaneous inflow and outflow
- Free Surface flows: In these cases it is often sufficient to use a smaller timestep only for the Volume Fraction equations
- Multiphase flows

#### 15.4.1.1. Max. Iterations

This sets the number of outer loop iterations for the CFX-Solver. The CFX-Solver will terminate the run after this number of iterations, even if specified convergence criteria have not been reached. Most simulations will require between 50 and 100 iterations for adequate convergence. After a solver run, you should always check the reason why the CFX-Solver finished; that is, has the convergence criteria been met or has the maximum number of iterations been reached? If the CFX-Solver finished because the maximum number of iterations was reached, you may want to continue the run until the convergence criteria is achieved.

If you are using Mesh Adaption, the maximum number of iterations specified is the maximum number of iterations in the final adaption step. The total maximum number of iterations will depend on the number of adaption steps and the maximum number of iterations per adaption step.

If the run is an ANSYS Multi-field run, then the maximum number of iterations specified is the maximum number of iterations per stagger iteration. In general, you should set this to be rather smaller number (for example, 5) for efficient solution of most ANSYS Multi-field simulations.

#### 15.4.1.2. Minimum Number of Iterations

The minimum number of iterations the CFX-Solver will run.

### 15.4.1.3. Time Scale Control

The time scale used by the CFX-Solver can be controlled using one of three methods:

- [Auto Timescale](#) (p. 425)
- [Local Time Scale Factor](#) (p. 426)
- [Physical Time Scale](#) (p. 426)

You can control these settings from CFX-Pre by going to the **Outline** tree view and right-clicking **Solver Control** > **Edit**. Alternatively, you can use the **CFX-Solver File Editor** to achieve more control over the ANSYS CFX-Solver. (See [Controlling the Time Scale with the CFX-Solver File Editor](#) (p. 426) for details.)

#### 15.4.1.3.1. Auto Timescale

**Auto Timescale** is a fluid timescale control option that uses an internally calculated physical time scale based on the boundary conditions, flow conditions, physics, and domain geometry. Information on how the CFX-Solver calculates the **Auto Timescale** is available in [Automatic Time Scale Calculation in the CFX-Solver Theory Guide](#)

**Auto Timescale** is the default timescale control setting. However, be aware that the **Auto Timescale** calculated by the solver is often conservative. This is usually robust, but faster convergence is often possible using a more aggressive setting. This can be done by:

- Setting **Length Scale Option** to **Aggressive** (see [Length Scale Option](#) (p. 425))
- Increasing the **Time Scale Factor** (see [Timescale Factor](#) (p. 425))
- Changing to an appropriate **Physical Time Scale** (see [Physical Time Scale](#) (p. 426))

It is also worth noting that, in some instances, the internal time scale calculation fails to find an appropriate velocity or length scale on which to base the time scale. For example, a buoyancy-driven flow problem can be specified using a Subdomain heat source in a cavity. If no velocity field or temperature difference is specified, a very large time scale (several orders of magnitude) can result. If this is the case, then you should try either:

- Specifying a small fixed physical time scale and follow the general guidelines about increasing or decreasing time scale accordingly
- Specifying an initial guess for velocity and/or temperature.

##### 15.4.1.3.1.1. Length Scale Option

When using the **Auto Timescale** option for fluid domains in a steady-state simulation, the **Length Scale Option** may also be set. The length scale is used by the solver to evaluate a time scale based on  $L/U$ . The options are:

- **Conservative:** The cube root of the domain volume is used. This is the default.
- **Aggressive:** The maximum extent of the domain volume is used.
- **Specified Length Scale:** Uses a user-specified value.

##### 15.4.1.3.1.2. Timescale Factor

The **Timescale Factor** option, set automatically to a default value of 1, can be used to multiply the **Auto Timescale** value calculated by the solver.

### 15.4.1.3.1.3. Maximum Timescale

The **Maximum Timescale** can be used to bound the internally-calculated time scale. The ANSYS CFX-Solver uses the smaller of the internally calculated time scale and the user maximum value.

#### 15.4.1.3.1.4. Controlling the Time Scale with the CFX-Solver File Editor

Advanced control over the auto timestepping algorithm is available using CCL directly or using the CFX-Solver File Editor. The following additional parameters are available:

- **Timescale Update Frequency:** Controls the frequency with which a new timescale is updated (default is every 5 iterations)
- **Number of Timescale Updates:** Controls the number of times that a new timescale is calculated (unbounded by default)
- **Timescale Ramping Factor:** If the Number of Timescale Updates has been passed, and the Maximum Timescale is larger than the internally-calculated timescale, the solver increases the timescale every iteration by a factor of the Timescale Ramping Factor until the Maximum Timescale is reached. The default is 1.2.

In the CCL example that follows, the solver starts with an internally calculated timescale multiplied by the Timescale Factor of 1.5. The internally calculated timescale is updated every 7 iterations, but is not permitted to exceed the Maximum Timescale of 5 [s]. The timescale is updated every 7 iterations for a total number of 12 updates. After this period, the timescale increases every iteration by a factor of 1.3 until it reaches the Maximum Timescale.

```
SOLVER CONTROL:
CONVERGENCE CONTROL:
  Maximum Number of Iterations = 300
  Timescale Control = Auto Timescale
  Timescale Factor = 1.5
  Number of Timescale Updates = 12
  Timescale Update Frequency = 7
  Maximum Timescale = 5 [s]
  Timescale Ramping Factor = 1.3
END
END
```

### 15.4.1.3.2. Local Time Scale Factor

The **Local Timescale Factor** option enables different time scales to be used in different regions of the calculation domain. The value you enter is a multiplier of a local element-based time scale. Smaller time scales are applied to regions of the flow where the local time scale is very short (such as fast flow), and larger time scales to those regions where the time scale is locally large (such as slow flow). The default value is 5. Any value less than this can be considered a “small” timestep.

This option is very useful when there are widely varying velocity scales in the simulation, for example, jet flow into a plenum chamber. The main disadvantage of this method is that very small timescales may locally result for small elements or large aspect ratio elements, which may in turn reduce the overall convergence rate. For this reason, it is best used on meshes of uniform element size and moderate aspect ratios.

### 15.4.1.3.3. Physical Time Scale

The **Physical Timescale** option enables a fixed time scale to be used for the selected equations over the entire flow domain.

In general, there are two situations in which you would use a physical time scale:

- To provide sufficient relaxation of the equation nonlinearities so that a converged steady-state solution is obtained, or,
- To evolve the solution through time in order to provide transient information about a time-dependent simulation.

For advection dominated flows, the physical time scale should be some fraction of a length scale divided by a velocity scale. A good approximation is the Dynamical Time for the flow. This is the time taken for a point in the flow to make its way through the fluid domain. For many simulations, a reasonable time estimate  $t$  is easy to make based on the length of the fluid domain  $L$ , and the mean velocity  $U$ , for example:

$$\Delta t \approx \frac{L}{U} \quad (15-1)$$

For external flow,  $L$  should be based upon a characteristic geometric length (for example, chord length).

If the domain contains largely varying velocity and length scales, you should try to estimate an average value. If you get divergence, check in the output file that your time scale is not larger than the **Advection Time Scale** value given in the **Average Scale Information** at the end of the run. A “small” time scale can be considered to be less than 1/3 the smallest length / velocity scale in the simulation. Values higher than this can be considered a “large” time scale.

It is often necessary to alter the physical time scale for buoyancy driven flows in order to achieve convergence. The maximum physical time scale may be estimated using the following relationship:

$$\Delta t_{\max} \approx \sqrt{\frac{dl}{\beta g \Delta T}} \quad (15-2)$$

where:

- $l$  is a length scale associated with the vertical temperature gradient
- $\Delta T$  is the temperature variation in the fluid
- $\beta$  is the thermal expansivity of the fluid
- $g$  is the gravitational acceleration.

Physical time scales that are too large are characterized by bouncy convergence or results that do not converge. Time scales that are too small are characterized by very slow, steady convergence.

Depending on your initial guess, a significantly smaller time scale may be required for the first few iterations of a problem.

A judicious physical time scale value usually gives faster convergence than specifying a **Local Timescale Factor** value.

If you use an expression for the physical time scale, it must evaluate to a constant value. CEL variables are available to control the time scale depending on the iteration. For details, see [Timestep, Timestep Interval, and Iteration Number Variables in the CFX Reference Guide](#).

### 15.4.1.4. Solid Time Scale Control

The **Solid Timescale Control** option is available if you have a solid domain and are performing a steady-state calculation. Because there is no flow in a solid domain, the relevant time scale for the solution in the solid part of the domain may be very much longer than the time scale in the fluid domain. It is usually safe to set a much larger time scale in a solid domain than would be used in a fluid domain. You can also set a time scale for the energy equation class in a solid domain (see [Controlling the Timescale for Each Equation](#) (p. 428)).

#### 15.4.1.4.1. Solid Timescale Factor

When using the **Auto Timescale** option for the **Solid Timescale Control**, a **Solid Timescale Factor** is used. The default value is 1. For instructions on how this value is used when calculating a solid time scale is available in [Solid Time Scale Estimate in the CFX-Solver Theory Guide](#).

### 15.4.1.5. Controlling the Timescale for Each Equation

CFX gives you great flexibility in controlling the timescale used for each equation solved. You can specify a timescale on a global basis, a domain basis, a fluid basis, an equation-class basis, or an individual equation basis.

When setting timesteps like this, there will often be more than one timescale defined for any given equation. For example, you could define both a global timescale and a timescale for a single fluid in one domain. The different ways in which a timescale can be set are outlined below in decreasing order of precedence below. For a given equation, the option with highest precedence will always be used:

1. For a specific equation, in a specific phase, in a specific domain.
2. For a specific equation in a specific domain.
3. For a specific equation in a specific phase, in all domains.
4. For a specific equation in all domains.
5. For a specific equation class, in a specific phase, in a specific domain.
6. For a specific equation class in a specific domain.
7. For a specific equation class, in a specific phase, in all domains.
8. For a specific equation class in all domains.
9. For all equations, in a specific phase, in a specific domain.
10. For all equations in a specific domain.
11. For a specific phase in all domains.
12. For all equations globally.
13. For solid domains that use the global **Solid Timescale Factor** option (when **Solid Timescale Control** is set to **Auto Timescale**).

---

#### Note

**Solid Timescale** and **Solid Timescale Control** are not allowed outside the global level. Options 1 to 11 can only be specified using the **Auto Timescale** or **Physical Timescale**.

An equation is a single-solved equation. This could be the momentum, continuity, or energy equation for a single fluid; the mass fraction equation for a single component; the volume fraction equation for a single fluid; one of the turbulence equations for a single fluid; or a single Additional Variable equation.

An equation class can include more than one equation. The equation classes are `momentum`, `continuity`, `energy`, `rs` (Reynolds stress), `ke` (turbulent kinetic energy), `ed` (turbulent eddy dissipation), `tef` (turbulent eddy frequency), `meshdisp` (mesh displacement), `mf` (mass fraction), `vf` (volume fraction) and `av` (Additional Variable). The first eight of these will include more than one equation only in a multiphase and/or multi-domain simulation. The `mf` class will include as many equations as there are components, the `vf` class will include as many equations as there are fluids, and the `av` class will include as many equations as there are Additional Variables.

The CFX-Pre user interface supports options 8, 12, and 13. To use other options, you must edit the CCL file.

The default approach for solid domains is thus the lowest priority option. If you want to set a special timescale control for the energy equations in the fluid domain but not affect the solid domains, then you must use one of options 1, 2, 5, or 6. If you use options 1 to 8 for the energy equation and also specify a **Solid Timescale Factor**, the **Solid Timescale Factor** will be ignored.

## 15.4.2. Transient Timestep Control

Time dependent behavior for transient simulations in ANSYS CFX is specified through time duration and timestep. The **Timesteps** option provides a way for ANSYS CFX to track the progress of real time during the simulation, whereas **Time Duration** is a user-specified limit on the length of real time the simulation is to run.

The CFX-Solver uses the timestep and time duration specifications to determine whether to continue the simulation using the next timestep. For example, if the following are set:

- **Timesteps** is set to a single value of  $\Delta t$ .
- **Time Duration** is set to **Total Time** option with a value of  $T$ .

then the CFX-Solver will continue to compute solutions at each timestep iteration until  $N \Delta t \geq T$ , where  $N$  is the number of timesteps actually performed by the CFX-Solver. Note that the final simulation time may slightly exceed the specified time duration (for example, if adaptive timestepping is used or if the specified  $\Delta t$  does not divide evenly into  $T$ ).

The following options can be set to control the time duration and timestep size in a transient simulation. Information on specifying these options in CFX-Pre is available; for details, see [Analysis Type in the CFX-Pre User's Guide](#).

### 15.4.2.1. Time Duration

This is where the duration of the simulation in real time is specified. It is used to determine when to finish the transient run. It can be set to one of:

- **Total Time** - The real time, relative to the initial time for the analysis, at which to end the transient analysis. This should be greater than the initial time for a given run. Note that the initial time for the analysis is not automatically reset when continuing from a previous transient analysis.
- **Time per Run** - The real time, relative to the initial time for a given run, at which to end the transient analysis. Note that the initial time for the run is automatically reset when continuing from a previous

transient analysis (for example, after a user-defined solver interrupt condition is triggered and remeshing is performed).

- **Maximum Number of Timesteps** - The timestep counter value at which to end the transient analysis. Note that the timestep counter value is not automatically reset when continuing from either a previous steady state or transient analysis. Further, when continuing from steady state analyses, the final outer loop iteration value is used to initialize the timestep counter value.
- **Number of Timesteps per Run** - The timestep counter value, relative to the initial value for a given run, at which to end the transient analysis.
- **Coupling Time Duration** - This can only be specified for simulations which have **External Solver Coupling** set to ANSYS MultiField or ANSYS MultiField via Prep7 on the **Analysis Type** panel. When **External Solver Coupling** is set to ANSYS MultiField, this is the only allowed option, and the time duration for the simulation is read from the **Coupling Time Duration** setting made under the **External Solver Coupling** settings. When **External Solver Coupling** is set to ANSYS MultiField via Prep7, a full range of options is available; however, the time duration for the simulation is always read from the MFTI setting in the ANSYS input file regardless of what is set. For this reason, it is recommended that you use the **Coupling Time Duration** option to avoid specifying unused information.

### 15.4.2.2. Timesteps: Timesteps List

The **Timesteps** list is where you set the actual real time intervals at which the CFX-Solver solves for the flow field. The timesteps you select need to be based on the time scale of the transient behavior that you want to resolve in your flow simulation. The timesteps can be:

- A single timestep value, for example, 2.3
- A comma separated list of timestep values, for example, 2.3, 3.0, 3.5, 0.1
- Either of the above as a CEL expression, in which case units must be included. For example: 2.3 [s], 3.0 [s], 3.5 [s], 0.1 [s]

When *not* entering the list as an expression, you can also specify a comma separated list of timestep values with multiple timesteps per item in the list. For example, specifying 5\*0.1, 2\*0.5, 10\*1, with the units [s] specified separately, would result in the following CCL:

```
0.1 [s], 0.1 [s], 0.1 [s], 0.1 [s], 0.1 [s], 0.5 [s], 0.5 [s], 1 [s],
1 [s], 1 [s], 1 [s], 1 [s], 1 [s], 1 [s], 1 [s], 1 [s], 1 [s]
```

If you accidentally enter 5\*0.1 [s], 2\*0.5 [s], 10\*1 [s] as an expression, the multiplication would be carried out, and the corresponding CCL that would be generated would be:

```
0.5 [s], 1.0 [s], 10.0 [s]
```

If a single value or expression is set, this timestep size is used to move forward in real time from the initial time to the end of the transient run. The end of the transient run is determined by the **Time Duration: Option** setting (see [Time Duration \(p. 429\)](#)).

If a list is set, each timestep size is used in turn to move forward in real time from the initial time to the end of the transient run. The end of the transient run is still determined by the **Time Duration: Option** setting. The end of the run can be reached before all timesteps in the list have been used, in which case the remaining timesteps are ignored. If all timesteps in the list are used before the end of the run is reached, then the last timestep in the list continues to be used repeatedly until the end of the transient run.

When restarting a transient run, the time completed in previous runs is considered. For example, if a list is specified and the first three timesteps in the list were completed in the initial run, then the run will restart at the fourth timestep in the list.

A simple timestep dependence study is useful to determine the effect of the timestep size on the accuracy of the results. You should initially choose a timestep size of the order of the time scales of interest, and then running a fixed but small period of the simulation in physical time. The same period is then re-run using double and half this timestep size, and the results compared. Significant differences between the initial and smaller timestep mean that an even smaller timestep is required, and this process can be repeated until the similarity in results is within some acceptable solution tolerance. Even if your timestep selection for the run is not the limiting case, this kind of analysis provides a good feel for the level of error introduced by your selection of timestep size. For details, see *Max. Iter. Per Step* (p. 432).

### 15.4.2.3. Timesteps: Timesteps for the Run List

This is the same as the **Timesteps** list described above, except that when restarting a run, the time completed in previous runs is ignored. When CCL is used to set both **Timesteps** and **Timesteps for the Run** lists, the **Timesteps** list takes precedence (see *Timesteps: Timesteps List* (p. 430)).

### 15.4.2.4. Timesteps: Adaptive

Adaptive timestepping automates the process of adapting the timestep size according to one of the following three options:

- **Num. Coeff. Loops** (Number of Coefficient Loops): a target minimum/maximum number of coefficient loops is specified. If the actual number of coefficient loops used is less than the **Target Minimum Coefficient Loops**, the timestep size is increased. If the actual number of coefficient loops used is greater than the **Target Maximum Coefficient Loops**, the timestep size is decreased. The increase and decrease factors for the timestep must also be provided by specifying values for **Timestep Increase Factor** and **Timestep Decrease Factor**. The actual min/max number of coefficient loops set in SOLVER CONTROL must encompass the range specified by **Target Minimum Coefficient Loops** and **Target Maximum Coefficient Loops**.

---

#### Note

If short time scale transient effects need to be predicted accurately for a variable density flow, you should set a minimum of 3 coefficient loops per time step.

- **RMS Courant Number**: the timestep size is adjusted such that the specified **RMS Courant Number** condition is satisfied. The relaxation factors for the timestep must also be provided.
- **MAX Courant Number**: the timestep size is adjusted such that the specified **Maximum Courant Number** condition is satisfied. The relaxation factors for the timestep must also be provided.

In addition, each condition requires specification of following parameters:

- **First Update Time**: The timestep adaption algorithm is initiated when the simulation time reaches the specified first update time.
- **Timestep Update Frequency**: The adaptive timestep is updated with this frequency. A value of 1 means that it is updated every timestep.
- **Initial Timestep**: The adaptive timestepping algorithm is initialized with this timestep size. It is also used with the first update time is reached.

- **Minimum Timestep:** The adaptive timestep is not permitted to drop below this value.
- **Maximum Timestep:** The adaptive timestep is not permitted to rise above this value.

If adaptive timestepping is used, the final simulation time may slightly exceed the specified time duration.

#### 15.4.2.5. Timesteps: Coupling Timesteps

Coupling timesteps can only be specified for simulations which have **External Solver Coupling** set to ANSYS MultiField or ANSYS MultiField via Prep7 on the **Analysis Type** panel. When **External Solver Coupling** is set to ANSYS MultiField, this is the only allowed option, and the size of the timestep for the simulation is read from the **Coupling Timesteps** setting made under the **External Solver Coupling** settings. When **External Solver Coupling** is set to ANSYS MultiField via Prep7, a full range of options is available; however, the timestep for the simulation is always read from the MFDT setting in the ANSYS input file regardless of what is set. For this reason, it is recommended that you use the **Coupling Timesteps** option to avoid specifying unused information.

#### 15.4.2.6. Initial Time

The **Initial Time** for a transient simulation corresponds to the time before beginning the first timestep in the current simulation. The following options can be set to control the initial time:

- **Automatic:** automatically reads the **Initial Time** from an initial values file if one can be found; otherwise, it uses a default value of zero.
- **Automatic with Value:** automatically reads the **Initial Time** from an initial values file if one can be found; otherwise, it uses the specified value.
- **Value:** Always uses the specified value for the **Initial Time**. You should only use this option to reset the initial time to a specified value for a restarted run.
- **Coupling Initial Time:** This can only be specified for simulations which have **External Solver Coupling** set to ANSYS MultiField or ANSYS MultiField via Prep7 on the **Analysis Type** panel. When **External Solver Coupling** is set to ANSYS MultiField, this is the only allowed option, and the initial time for the simulation is read from the **Coupling Timesteps** setting made under the **External Solver Coupling** settings. When **External Solver Coupling** is set to ANSYS MultiField via Prep7, a full range of options is available; however, the initial time is always read from the MFRS setting in the ANSYS input file (it is 0 [s] if no MFRS command is specified) regardless of what is set. For this reason it is recommended that you use the **Coupling Initial Time** option to avoid specifying unused information

If the **Initial Time** is read from an initial values file, it is set to the last timestep value read from the results file. Information on specifying this option in CFX-Pre is specific.

#### 15.4.2.7. Max. Iter. Per Step

At each timestep in a transient simulation, the CFX-Solver performs several coefficient iterations or loops, either to a specified maximum number or to the predefined residual tolerance. These settings are controlled on the Solver Control panel in CFX-Pre. The maximum number of iterations per timestep may not always be reached if the residual target level is achieved first.

Using a large number of coefficient iterations for transient runs is not recommended. Improved accuracy is much more efficiently achieved by reducing the timestep size. If the solution is not converging within each timestep, which is required to maintain a conservative discretization, it may signify that the timestep is too large for good transient accuracy. Decreasing the timestep size typically makes convergence within a timestep easier to achieve, and also improves the transient accuracy of the solution.

Actual behavior is, of course, problem dependent. For your particular application, you need to make a compromise between timestep size, number of coefficient iterations and residual tolerance to get the most cost effective solution.

A value of 3 iterations per timestep should be sufficient for most single phase simulations, and values higher than 5 are unlikely to improve accuracy. In multiphase cases, the default value of 10 iterations per timestep may be more appropriate. Initially, you should use these values and then adjust the timesteps to control the balance between accuracy and solution time.

Long transient simulations can obviously end up being very computationally expensive. It is easy to define a problem that could potentially take weeks to compute, even with the coupled solution capability of ANSYS CFX. It is very important, therefore, to balance the need for accuracy against runtime cost when performing these types of analyses.

- [Timesteps: Timesteps List \(p. 430\)](#)
- [Steady State and Transient Flows \(p. 3\)](#)

The maximum number of coefficient iterations is also significant in ANSYS Multi-field simulations. In this context, there are two levels of iteration within each timestep: the inner-most level consists of the coefficient iterations within the CFX-Solver and the outer-most level consists of the stagger iterations used to couple the ANSYS CFX and ANSYS field solvers. The maximum number of iterations specified in the ANSYS CFX setup determines the number of coefficient iterations performed by ANSYS CFX per stagger/coupling iteration; reducing this number will force a tighter coupling between the ANSYS CFX and ANSYS field solvers. A value of 1 to 3 coefficient iterations is recommended. Note that the number of stagger/coupling iterations per timestep is specified as **Max. Iterations** under **External Coupling** on the **Solver Control** panel.

### 15.4.2.8. Transient Scheme

The transient scheme defines the discretization algorithm for the transient term. Options available are [First Order Backward Euler \(p. 433\)](#), [Second Order Backward Euler \(p. 433\)](#), and [High Resolution \(p. 434\)](#). More information on theory is available in [Transient Term in the CFX-Solver Theory Guide](#).

#### 15.4.2.8.1. First Order Backward Euler

The `First Order Backward Euler` scheme is an implicit time-stepping scheme that is first-order accurate. Its behavior is analogous to the `Upwind` differencing scheme for advection terms, and suffers from similar numerical diffusion. Although it is useful for initial studies, its use is not recommended for production runs except for turbulence equations.

#### 15.4.2.8.2. Second Order Backward Euler

The **Second Order Backward Euler** scheme is also an implicit time-stepping scheme, but is second-order accurate, and is the default in ANSYS CFX. It is applicable for constant and variable timestep sizes. Like second-order advection schemes, however, it is not monotonic and is therefore inappropriate for some quantities that must remain bounded, such as turbulence quantities and volume fractions. When running the **Second Order Backward Euler** scheme, the transient scheme for turbulence equations will remain First Order, and the transient scheme for volume fraction equations will be set to a bounded second-order scheme, similar to the High Resolution scheme for advection. This scheme is generally recommended for most transient runs.

### 15.4.2.8.2.1. Timestep Initialization

When performing a transient run using the **Second Order Backward Euler** scheme, there are three options for initializing the solution within a timestep:

- **Previous Timestep:** The solution from the end of the previous timestep is used.
- **Extrapolation:** The solutions from the previous timesteps are extrapolated to the new timestep.
- **Automatic:** This option is a blend of the **Previous Timestep** and **Extrapolation** options:
  - If the local Courant number is below the specified **Lower Courant Number** (5 by default), then **Previous Timestep** is used.
  - If the local Courant number is above the specified **Upper Courant Number** (10 by default), then **Extrapolation** is used.

For compressible cases, the local Courant number used is the so called "acoustic" Courant number, which is based on the speed of sound. For more details, see [Courant Number in the CFX-Solver Theory Guide](#).

### 15.4.2.8.3. High Resolution

The High Resolution transient scheme uses the second order backward Euler scheme wherever and whenever possible and reverts to the first order backward Euler scheme when required to maintain a bounded solution.

## 15.5. Advection Scheme Selection

This section describes the **Basic Settings** tab in the **Solver Control** panel in ANSYS CFX-Pre and how to choose these settings for your simulation.

You can select to use `Upwind`, `High Resolution`, or specify a blend factor to blend between first and second order advection schemes to calculate the advection terms in the discrete finite volume equations. Different schemes can be applied to each equation class by setting the **Equation Class Settings** in CFX-Pre.

The **CDS Blending** settings are available for the DES and SAS turbulence models only. They control the Courant-number-based blending between the specified advection scheme and the central difference scheme (CDS).

Additional information on the advection schemes used in ANSYS CFX is available; for details, see [Advection Term in the CFX-Solver Theory Guide](#).

### 15.5.1. Upwind

With this setting, advection terms are first-order accurate. This is equivalent to specifying a blend factor of 0.0. This setting gives the most robust performance of the CFX-Solver but suffers from numerical diffusion. Using this advection scheme is not recommended to obtain final results (except for the turbulence equations).

### 15.5.2. High Resolution

With this setting, the blend factor values vary throughout the domain based on the local solution field in order to enforce a boundedness criterion. In flow regions with low variable gradients, the blend factor

will be close to 1.0 for accuracy. In areas where the gradients change sharply, the blend factor will be closer to 0.0 to prevent overshoots and undershoots and maintain robustness.

Note that for vector quantities it is the components that are bounded between 0 and 1. Therefore, the magnitude of  $\beta$  for a vector quantity can be as large as  $\sqrt{3}$ .

### 15.5.3. Specified Blend Factor

This selection enables you to set a blend factor between 0.0 and 1.0 for the advection scheme. A value of 0.0 is equivalent to using the first order advection scheme and is the most robust option. A value of 1.0 uses second order differencing for the advection terms; this is *not* the same as the high resolution advection scheme. This setting is more accurate but less robust. Values between 0.0 and 1.0 blend first and second order differencing, with increased accuracy and reduced robustness as you approach 1.0. At the higher values, overshoots and undershoots can appear. At lower values, excessive diffusivity can occur.

---

#### Important

If you are using `High Resolution` or a high blend factor value, it will be necessary to use a smaller timestep. It is recommended that you use a timestep of approximately 1/4 to 1/3 the physical timestep. For details, see *Time Scale Control* (p. 425).

You cannot use this advection scheme for the volume fraction equation in a multiphase simulation.

### 15.5.4. Central Difference

This option is available when using the large eddy simulation turbulence model and is recommended for these cases.

### 15.5.5. Advection Scheme for Turbulence Equations

All turbulence equations always use the first order upwind advection scheme, irrespective of the **Advection Scheme** setting. This can be overridden on the **Equation Class Settings** panel in CFX-Pre.

### 15.5.6. Advection Schemes for Multiphase Volume Fractions

If you set the global advection scheme (that is, if you do not specify equation-class advection schemes) to upwind or high resolution, then the volume fraction equation will also be solved using upwind or high resolution. This differs from ANSYS CFX-5.5.1 where upwind was always used for the volume fraction equations. However, if you set the global advection scheme to a specified blend, then the volume fraction equations will actually use the high resolution advection scheme but the maximum blend factor will be limited to the specified value instead of 1.

### 15.5.7. Comparisons to CFX-TASCflow

For users of CFX-TASCflow, the following settings approximate the common advection schemes used in CFX-TASCflow:

- The **Upwind** scheme is equivalent to `ISKEW=1` with `LPAC=F` in CFX-TASCflow.
- A **Specified Blend Factor** value of 0.75 is approximately equivalent to `ISKEW=3` with `LPAC=T` in CFX-TASCflow.

- A **Specified Blend Factor** value of 1.0 is approximately equivalent to `ISKEW=4` with `LPAC=T` in CFX-TASCflow.
- The **High Resolution** scheme is usually close to `ISKEW=3` with `LPAC=T`, but may be slightly better in some cases. It is always better for all equations other than the hydrodynamic system of equations. It is always smoother than `ISKEW=4` with `LPAC=T`, but never as accurate.

## 15.6. Advanced Options: Dynamic Model Control

Dynamic Model Control is designed to improve robustness during the first few iterations or timesteps of a simulation. Often when the CFX-Solver fails, it is during the first few iterations or timesteps. This can be caused by difficult initial guesses, a mismatch between the initial guess values and boundary condition specifications, and so on.

### 15.6.1. Global Dynamic Model Control

This option should generally be left selected. By itself, the only change made during the first few iterations is to turn off a product limiter for combusting/reacting flows. The product limiter is disabled for the first five iterations, after which it is turned back on. This behavior can be overridden by adding the following lines to the CCL in your CFX-Solver input file (which must first be converted to an editable text file). For details, see [Editing the Command Language \(CCL\) File in the CFX-Solver Manager User's Guide](#).

```
DYNAMIC MODEL CONTROL:
  COMBUSTION CONTROL:
    Transition Iteration = 0
  END
END # DYNAMIC MODEL CONTROL
```

This would cause the product limiter to be on all the time.

Specific controls to the turbulence and hydrodynamic equations are described next; however, the **Global Dynamic Model Control** toggle must be selected for these to have any effect.

---

#### Note

For each of the turbulence, combustion and hydro controls, the transition iteration is the iteration at which the change from the starting model to the model chosen for the simulation is made. The fifth iteration is often a reasonable choice. The default transition iteration is zero; that is, the starting model is not used unless you set a transition iteration.

### 15.6.2. Turbulence Control

This option enables specification of a different turbulence model to be used from the first iteration through to the transition iteration. The idea is to solve a simpler and more robust turbulence model for the first few iterations. In the order of increasing complexity, the turbulence models are laminar, zero equation, dispersed phase zero equation, k epsilon, and then RNG k epsilon. You should use this option when startup with the desired turbulence model is not possible.

### 15.6.3. Combustion Control

Combustion Control is described in [Advanced Combustion Controls](#) (p. 338).

## 15.6.4. Hydro Control

These settings become active from the first iteration through to the specified transition iteration. The default transition iteration is zero; that is, the settings are not used unless you set a transition iteration.

**Sum Continuity Coefficients** is only applicable to compressible flows. This forces/enhances diagonal dominance in the solution matrices for more robust startup. It has no effect on the steady solution, but should be turned off using the transition iteration after a few iterations as it would begin to retard convergence.

**Free Surface Harmonic Averaging** has the same effect as the **Harmonic Body Force Averaging** option (see below), but enables you to use harmonic averaging (more robust) during startup and then revert back to the default body force treatment after the transition iteration is reached.

## 15.7. Pressure Level Information

Sometimes a simulation does not have a pressure specification set through the boundary conditions. In this case, the solver automatically sets a pressure level at a reference location. By default, the reference value is zero, and the reference location is at the first finite volume number. There are two methods to override this default behavior if necessary.

The first (and recommended) method is to set a pressure level using the **Pressure Level Information** option on the **Solver Control** form in CFX-Pre. The Cartesian coordinates option enables you to specify an X, Y, Z location for the reference pressure location. The nearest node to this location is used as the pressure reference location. A value for the reference pressure can also be entered.

The **Compressible Transient Option** determines whether the pressure field is shifted to accelerate mass conservation for compressible transient simulations that have no pressure boundaries.

## 15.8. Interpolation Scheme

The following topics will be discussed:

- [Pressure Interpolation Type](#) (p. 437)
- [Velocity Interpolation Type](#) (p. 437)
- [Shape Function Option](#) (p. 438)

### 15.8.1. Pressure Interpolation Type

Pressure Interpolation Type refers to the method of interpolating nodal pressures to integration points for the pressure gradient term of the momentum equation. Trilinear is more accurate, especially for large pressure gradients, but may have robustness problems on highly stretched meshes. Trilinear is the default for buoyant flows, otherwise the default is linear-linear.

### 15.8.2. Velocity Interpolation Type

Velocity Interpolation Type refers to the method of interpolating nodal velocities to integration points for the velocity divergence term in the continuity equation. The default is trilinear, and should not need to be changed.

### 15.8.3. Shape Function Option

For tets, wedges, and pyramids, using trilinear shape functions for value interpolation may not be linearly exact because the trilinear integration point location may not lie at the geometric centroid of the face on which the integration point is located. In such situations, interpolation accuracy may be improved by using geometric shape functions. The default behavior is to use geometric shape functions for buoyant problems and the standard parametric shape functions otherwise.

## 15.9. Temperature Damping

Temperature Damping provides advanced control for temperature relaxation and becomes available when a transport equation for heat transfer is solved (thermal or total energy).

### 15.9.1. Option

The available options are:

- `Automatic`  
Tells the solver to use the option believed to be most appropriate for each fluid, depending on the physical setup. This is the default option.
- `None`  
Disables temperature damping.
- `Temperature Damping`  
Enables temperature relaxation. Two parameters are available for controlling the amount of relaxation applied: *Temperature Damping Limit* (p. 438) and *Under Relaxation Factor* (p. 438).

### 15.9.2. Temperature Damping Limit

This option is available when **Option** is set to `Temperature Damping`. The default value for this option is 0 K.

Temperature damping is equivalent to classical relaxation when the temperature damping limit is set to zero.

### 15.9.3. Under Relaxation Factor

This option is available when **Option** is set to `Temperature Damping`. The default value for this option is 0.2.

The **Under Relaxation Factor** is applied only if the absolute change in temperature is larger than the value specified as the *Temperature Damping Limit* (p. 438).

## 15.10. Monitoring and Obtaining Convergence

The following topics will be discussed:

- *The Residual* (p. 439)
- *Residual Type and Target* (p. 439)
- *Judging Convergence* (p. 439)

- [Global Balances and Integrated Quantities](#) (p. 440)
- [Convergence Rate](#) (p. 441)
- [Problems with Convergence](#) (p. 441)

### 15.10.1. The Residual

The residual is a measure of the local imbalance of each conservative control volume equation. It is the most important measure of convergence as it relates directly to whether the equations have been solved. Additional information on how the residual is calculated is available. For details, see [Linear Equation Solution in the CFX-Solver Theory Guide](#).

CFX presents the normalized residuals to judge convergence. For details, see [Residual Normalization Procedure in the CFX-Solver Theory Guide](#). By normalizing the residuals, you are presented with a relatively consistent means of judging convergence. The Normalized Residual is used to automatically stop the CFX-Solver run when a specified level has been obtained.

In transient simulations, the same target residual is used to control the termination of the coefficient iterations, except that the residual now includes a contribution from the transient term. If the maximum number of coefficient iterations per timestep has been set to a large value, such as 20, then when the coefficient iteration residuals are below the target residual, the coefficient iterations will stop. This method can be used to cause the CFX-Solver to run with many coefficient iterations early in the run (when residuals are relatively high) and fewer coefficient iterations later in the run.

### 15.10.2. Residual Type and Target

You can select to use MAX (maximum) or RMS (root mean square) normalized values of the equation residuals as you check for convergence. The CFX-Solver will terminate the run when the equation residuals calculated using the method specified are below the **Residual Target** value (see below for recommended residual targets).

Note that the residual level for turbulence transport equations (for example,  $k$ ,  $\varepsilon$ , Reynolds stress components, and turbulent heat flux components) are not included by the solver in deciding when convergence is reached.

Note also that for multiphase simulations, the convergence criterion for the volume fraction equations is a factor of 10 higher than the specified target residual.

The default target RMS residual value is  $1e-4$ .

### 15.10.3. Judging Convergence

---

#### Important

You should always check whether your run stopped because your convergence criteria was met or because the maximum number of iterations was reached. In the latter case, your solution has not yet converged to the specified level.

There are a variety of opinions on how to judge convergence. In general, you need to consider the size of the RMS residual, the size of the MAX residual, as well as the overall flow balances (overall conservation). The level of convergence required depends on the purpose of the simulation (whether qualitative or quantitative results are required) and the details of model. When quantitative accuracy is required, it is highly recommended that you test sensitivity of relative quantities (for example, lift, drag, efficiency,

and so on) to the convergence target. These can be monitored during the run in the CFX-Solver Manager using monitor points

Although the required convergence level depends on the model and on your requirements, the following guidelines regarding residual levels may be helpful.

### **15.10.3.1. RMS Residual Level**

- Values larger than  $1e-4$  may be sufficient to obtain a qualitative understanding of the flow field.
- $1e-4$  is relatively loose convergence, but may be sufficient for many engineering applications.
- $1e-5$  is good convergence, and usually sufficient for most engineering applications.
- $1e-6$  or lower is very tight convergence, and occasionally required for geometrically sensitive problems. It is often not possible to achieve this level of convergence, particularly when using a single precision solver.

### **15.10.3.2. MAX Residual Level**

MAX residuals are typically 10 times larger than the RMS residual; The above guidelines for RMS residuals can also be applied to MAX residuals, with the targets increased by a factor of 10.

Sometimes, however, the MAX residuals are much larger (for example, a factor of 100) than the RMS residuals. In this situation, it is very likely that the region of high MAX residuals is isolated to a very small area of the flow, typically where some unstable flow situation exists (for example, a separation or re-attachment point, and so on). It may be the case that this small area of unstable flow / lack of tight convergence of the MAX residuals do not affect the overall prediction. To verify that the solution is acceptable, you should verify that the variation of relevant quantities (for example, lift, drag forces, efficiency of the device, and so on) is small.

## **15.10.4. Global Balances and Integrated Quantities**

At the end of each run, a summary of global balances is reported in the OUT file. For details, see [Global Conservation Statistics in the CFX-Solver Manager User's Guide](#). You can also monitor Flows, Forces and general CEL expressions during the run. In most cases, when the residuals have converged sufficiently, the global balances will be met. However, if there is a process whose time scale is very large relative to other physical processes, it is possible to have converged residuals before the global balances are met. An example might be the dissipation of heat from a cup of coffee into a large room.

Flow balances are evaluated while assembling the conservation equations, and are therefore based on the solution from the previous timestep. For transient runs, if convergence within a timestep is achieved in one coefficient iteration, this can lead to unexpected diagnostics for the accumulation term. By default, the initial guess within a timestep is taken from the end of the previous timestep. For the First Order Backward Euler transient scheme, this leads to an accumulation term of zero, and for the Second Order Backward Euler scheme, the accumulation term has the opposite sign from expectation. However, if the Second Order Backward Euler scheme is used with extrapolation as the initialization option, then the accumulation term is reasonable after one coefficient. Information on initialization setting is available. For details, see [Transient Scheme \(p. 433\)](#).

### **15.10.4.1. Positive and Negative Domain Source Totals**

A quantity may be produced in one region of a domain, and destroyed in another region of a domain. For example, an intermediate combustion species, may have a small overall source resulting from the

difference of significant production and destruction. In order to handle this case appropriately, the positive and negative sources are accumulated separately.

In case a transport equation has production and destruction terms that contribute simultaneously at the same location, details of the implementation determine whether the positive and negative contributions are balanced separately, or whether just the local net source is balanced. In the latter case, the effective local source values are spread into the positive and negative domain source totals.

#### 15.10.4.2. Conservation Target

To ensure the global balances are met, you may additionally apply a target imbalance for the conservation equations (that is, a global balance criterion). In such a case, the solver will only stop before the maximum number of iterations if the residual criteria are met and global balances are also met. The value you specify is the fractional imbalance. The default value is 0.01 (that is, 1%). The global imbalances for the hydrodynamic equations should at least be less than 1% before you can consider a solution converged.

#### 15.10.5. Convergence Rate

A convergence rate can be defined by:

$$\text{convergence rate} = \frac{R_n}{R_{n-1}} \quad (15-3)$$

where  $R_n$  is the Normalized Residual at iteration  $n$ , and  $R_{n-1}$  is the Normalized Residual at an earlier iteration. With two exceptions, the convergence rate is evaluated using the current and previous iterates. The first exception corresponds to evaluating the residuals during the first coefficient iteration for a timestep in transient simulations. In this case, the rate is evaluated using the current residuals and the residuals from the first iteration from the previous timestep. The second exception corresponds to evaluating the residuals of the mesh displacement equations for both steady and transient simulations. In this case, the rate is evaluated using current residuals and the residuals from the first iteration from the previous solution of the displacement equations. In each of these cases, residual reduction values that are less than unity indicate convergence towards a steady state.

A residual reduction rate of 0.95 or smaller is considered typical for most situations, while a rate of 0.85 or smaller is considered to be very good. If your convergence behavior is slower than this (that is, rates are larger than 0.95), but is smooth, you should try increasing the timestep. Once the residuals are dropping monotonically, the timestep can often be safely increased to the characteristic time scale or greater in order to maximize the convergence rate. If there is no improvement, then the source of the convergence problem is probably not the timestep specification. For details, see *Initial Condition Modeling* (p. 95).

#### 15.10.6. Problems with Convergence

This section describes how to solve two classes of convergence problems: *Start-up Problems* (p. 441) and *Later Problems* (p. 442).

##### 15.10.6.1. Start-up Problems

If you are having problems getting your solution started, it will often be due to a poor initial guess. For details, see the following:

- *Initialization Advice* (p. 107)

- *Recommended Configurations of Boundary Conditions* (p. 60)

For some cases, in particular, compressible flow cases, you will need to first solve the case using more robust models and then use this solution as the initial guess for the more complex simulation. The general idea is to solve a simpler problem and use its solution to get the real case going. Below is a list of simulation attributes and their relative robustness. Therefore, on a complex or difficult problem, replacing an attribute with a more robust one will give you a problem more likely to converge which you can then use as the starting point for a complex simulation.

- Liquids and constant property materials are more robust than gases (in other words, incompressible flow is more robust than compressible flow).
- Laminar flow is more robust than turbulent flow with the Zero Equation Model, which in turn is more robust than the  $k - \varepsilon$  and other two-equation turbulence models, which in turn are more robust than Reynolds Stress models. The zero equation model should not be used to obtain final results.
- Pressure specified Openings may be more robust than Static Pressure Outlets.
- The **1st Order** advection scheme or a **Specified Blend = 0** is more robust than the **High Resolution** scheme, which is more robust than a **Specified Blend = 1**. Smaller values of the Blend Factor are more robust than larger ones. Final results should use a Specified Blend of at least 0.75 or the High Resolution scheme. It is also possible that using a Blend Factor of 1.0 will not produce a converged solution no matter what you do. In this case, gradually increasing values of the Blend Factor could be used to get a more accurate solution than the 1st order option. If the flow includes shocks, the High Resolution scheme should be used.
- For transonic and supersonic flows, the most difficult flow regime is around Mach 1. If this is your flow regime of interest, you should first try a flow velocity lower or higher than Mach 1 and see how that converges. If this is successful, you can then modify your problem specification to your requirements and use the previous result as your initial value field.
- Smaller physical timesteps are more robust than larger ones.
- An Isothermal simulation is more robust than modeling heat transfer. The Thermal Energy model is more robust than the Total Energy Model.
- Velocity or mass specified boundary conditions are more robust than pressure specified boundary conditions. A Static pressure boundary is more robust than a total pressure boundary.

### 15.10.6.2. Later Problems

In many cases, global quantities will stabilize within 20 to 30 timesteps, but convergence will not be achieved until approximately 100 timesteps have completed. For most applications, convergence should be achieved (or well on its way) within 200 timesteps.

If you have problems with convergence, you should find the source of the problem rather than taking the results as they are. There are many factors that may lead to poor convergence, including poor mesh quality, improper boundary condition selection and timestep selection to name a few. If you are unable to diagnose the source of your convergence difficulties, contact your technical support representative for advice.

When you are having problems converging, try to determine whether the problem is local or global. Compare the RMS and MAX residuals of the equations having difficulty. If the MAX residual is more than one order of magnitude larger than your RMS residual, it usually indicates that the problem is concentrated to a local region.

If it is a locally high residual, identifying the location of the MAX residual will help in diagnosing the problem. Typically the location of the MAX residual of the momentum equations is the most useful to identify. This may be done by reading the location of the MAX residual from the solver summary at the end of your OUT file, or by setting the Expert Parameter **output eq residuals = true**. For details, see *CFX-Solver Expert Control Parameters* (p. 465).

If the MAX residual is far downstream of your region of interest and far from an outlet boundary, you may determine that it has no effect on your solution. If you write the equation residuals out to your RES file, then it may be useful to create an isovolume equal to your MAX residual criteria and to verify the residuals are low enough in your region of interest.

Once you have determined the location of your high residuals, you will want to determine the source of the local problem and fix it. Because CFD simulations are varied, a comprehensive list is not possible, but the following short list of common problems and solutions should be helpful. If you still cannot resolve your problem, contact your ANSYS CFX technical support representative for advice.

**Table 15.1 Convergence Problems Due to Local Effects**

Local Problem	Description and Solution
Poor grid quality	Small angles or high aspect ratios can lead to round-off errors in the solver. Try to improve grid quality in the problem area.
Free shear layer or wake	<p>These often cause the convergence to stall due to transient effects. In most cases, the transients should be captured by the turbulence model and reflected as a mean velocity and turbulence intensity. A small timestep will resolve the transients, thus causing the convergence problems. A larger timestep should take care of the problem. In some situations, it may also help to apply additional underrelaxation to the advection scheme gradients and blend factors. This can be done by adding the following text to the ADVECTION SCHEME CCL:</p> <pre data-bbox="565 1339 941 1461"> ADVECTION SCHEME : Option = High Resolution Gradient Relaxation = 0.1 Blend Factor Relaxation = 0.1 END </pre> <p>Blend Factor Relaxation is applicable only for the high resolution scheme, while Gradient Relaxation is applicable for both the specified blend and the high resolution schemes. The default values of these parameters are 0.25 for steady-state simulations and 0.5 for transient simulations</p>
MAX residual adjacent to a shock	The solution field can “bounce around” near discontinuities like shocks. Shocks can also be susceptible to a transverse instability called the carbuncle effect, particularly if the mesh is finer in the transverse direction than the flow direction. To resolve these issues, activate <b>High Speed</b>

Local Problem	Description and Solution
	<b>Numerics</b> on the <b>Advanced</b> panel of the <b>Solver Control</b> tab.
MAX residual adjacent to a Stage Domain Interface	A large timestep can cause convergence problems at a Stage Interface. Reduce your timestep by a factor of 2 to 10. For closely coupled components, the <b>Constant Total Pressure</b> option should be considered. Increasing the pressure profile decay above its default of 0.05 may help robustness by adding stiffness to the downstream pressure profile, but can also reduce the natural circumferential pressure variation.
MAX residual adjacent to a flow boundary	Check that the boundary condition is sensible. Try different options for the boundary specification. If you can specify a profile (by equation or data interpolation), it may help. If you are using a profile, check to see that it is correct and sensible.

**Table 15.2 Convergence Problems Due to Global Effects**

Global Problem	Description and Solution
Large time scale effect	<p>If the characteristic time scale is not simply the advection time of the problem, there may be transient effects holding up convergence. Heat transfer or combustion processes may take a long time to convect through the domain or settle out. There may also be vortices caused by the initial guess, which take longer to move through the entire solution domain.</p> <p>In these cases, a larger timestep may be needed to push things through initially, followed by a smaller timestep to ensure convergence on the small time scale physics. If the large timestep results in solver instability, then a small time scale should be used and more iterations may be required.</p>
Turbulence levels	<p>Sometimes the levels of turbulence in the domain can affect convergence. If the level of turbulence is non-physically too low, then the flow might be “too thin” and transient flow effects may be dominating. Conversely if the level of turbulence is non-physically too high then the flow might be “too thick” and cause unrealistic pressure changes in the domain. It is wise to look at the Eddy Viscosity and compare it to the dynamic (molecular) viscosity. Typically the Eddy Viscosity is of the order of 1000 times the dynamic viscosity, for a fully turbulent flow.</p>
Turbulence model selection	When choosing a turbulence model, care must be taken to use a mesh appropriate for the given

Global Problem	Description and Solution
	model. Running a given turbulence model on an inappropriate mesh can cause convergence to stall.
Advection scheme	The 2nd Order High Resolution advection scheme has the desirable property of giving 2nd order accurate gradient resolution while keeping solution variables physically bounded. However, may cause convergence problems for some cases due to the nonlinearity of the Beta value. If you are running High Res and are having convergence difficulty, try reducing your timestep. If you still have problems converging, try switching to a Specified Blend Factor of 0.75 and gradually increasing the Blend Factor to as close to 1.0 as possible.

## 15.11. Solver Issues

The following topics will be discussed:

- [Robustness and Accuracy](#) (p. 445)
- [Linear Solver Failure](#) (p. 445)

### 15.11.1. Robustness and Accuracy

Some comment has already been made about the relative merits of robustness and accuracy, and the need to solve more complex problems by gradually increasing the complexity of the model, but they are worth reiterating here. Generally speaking, higher order discretizations are more accurate but less robust than lower order ones. Increasing the order of discretization by increasing the Blend Factor should be approached in the same way as increasing the complexity of the physical model, that is, gradually, and by starting from a more robust solution.

### 15.11.2. Linear Solver Failure

This is the most catastrophic thing that can go wrong during the solution phase. A fatal failure of the linear solver could look like this:

```

=====
TIME STEP = 6 SIMULATION TIME = 3.00E+11 CPU SECONDS = 1.05E+02
-----
| Equation | Rate | RMS Res | Max Res | Location | Linear Solution |
+-----+-----+-----+-----+-----+-----+
| U - Mom  | 1.36 | 3.7E-02 | 3.5E-01 | 1        | NaN *          |
| V - Mom  | 1.37 | 3.8E-02 | 3.5E-01 | 1        | NaN *          |
| W - Mom  | 0.75 | 1.2E-01 | 1.2E+00 | 26       | NaN *          |
| P - Mass | 1.74 | 2.0E-02 | 6.9E-01 | 1248     | 8.3 Nan *      |
+-----+-----+-----+-----+-----+-----+
| ERROR #004100018 has occurred in subroutine FINMES. |
| Message: |
| Fatal overflow in linear solver. |
+-----+-----+-----+-----+-----+-----+

```

After which the CFX-Solver terminates. The “\*” means that there has been a floating point exception in the linear solver, usually a floating point overflow.

Sometimes a linear solver failure can be less dramatic, such as

```

=====
TIME STEP = 2 SIMULATION TIME = 1.00E+11 CPU SECONDS = 2.52E+01
-----
| Equation | Rate | RMS Res | Max Res | Location | Linear Solution |
+-----+-----+-----+-----+-----+-----+
| U - Mom | 0.00 | 3.7E-05 | 4.9E-04 | 48 | 2.6E+01 F |
| V - Mom | 0.00 | 3.7E-05 | 4.9E-04 | 38 | 2.6E+01 F |
| W - Mom | 0.00 | 2.8E-04 | 7.1E-03 | 37 | 8.4E+01 F |
| P - Mass | 0.00 | 1.3E-07 | 3.8E-06 | 37 | 8.3 1.1E+02 F |
+-----+-----+-----+-----+-----+-----+
| H-Energy | 0.00 | 2.6E-02 | 1.9E-01 | 748 | 10.2 5.0E-04 OK |
+-----+-----+-----+-----+-----+-----+
| K-TurbKE | 0.00 | 0.0E+00 | 5.9E-34 | 1200 | 5.6 0.0E+00 OK |
+-----+-----+-----+-----+-----+-----+
| E-Diss.K | 0.00 | 0.0E+00 | 5.7E-34 | 1200 | 5.6 0.0E+00 OK |
+-----+-----+-----+-----+-----+-----+

```

This time the CFX-Solver continues with mixed results (that is, sometimes it will recover and converge, sometimes not). The "F" in the last column means that the linear solver failed to reduce the residuals of the linearized equations (the solution was diverging).

When the linear solver fails, it can mean that non-physical boundary conditions have been applied, or that the initial values were inappropriately set. For details, see *Boundary Condition Modeling* (p. 57). A good set of initial conditions can be generated by solving a simpler flow. For instance, assume that the flow you want to model is turbulent and compressible. You want to model it using the  $k - \varepsilon$  model, with the most accurate discretization, with several pressure specified opening boundaries and a complex, curved geometry. There is no good initial values guess, and the linear solver might fail no matter what you try. However, if you instead modeled laminar flow, with the most robust discretization, and changed the boundary conditions to be velocity specified inflows with only one pressure-specified opening, the solution will converge with almost any initial value you choose. You could then use this converged result as the much better initial value for the real problem of interest.

## 15.12. How CEL Interacts with the CFX-Solver

At various points in the flow solver operation, the calculation requires information such as the rate of flow at an inlet boundary, or the viscosity in some part of the fluid. This dependence can be specified in a simple manner, but more complex dependencies can be developed by using CEL.

Consider the case of flow through a pipe. You may want to set a velocity profile at the inlet, which will typically be greatest at the center. The profile can be expressed mathematically in terms of a function of  $x$ ,  $y$ , and  $z$ , which are ANSYS CFX system variables known to the CFX-Solver. The mathematical definition of the profile is called an expression, and the value of this expression is a term that is input to the flow solver. You can define many terms in ANSYS CFX by way of expressions: fluid properties, subdomain sources, boundary conditions, and initial values are all ANSYS CFX terms that can be described using expressions.

A key feature of CEL is that it is used dynamically by the CFX-Solver. For example, you can set viscosity to be dependent on temperature using CEL, and the current heat transfer CFD solution will be computed for this relationship.

## 15.13. Best Practice Guides

The following best practice guides are available:

- ["CFX Best Practices Guide for Numerical Accuracy"](#)
- ["CFX Best Practices Guide for Cavitation"](#)
- ["CFX Best Practices Guide for Combustion"](#)

- "CFX Best Practices Guide for HVAC"
- "CFX Best Practices Guide for Multiphase"
- "CFX Best Practices Guide for Turbomachinery"



---

## Chapter 16: Using the Solver in Parallel

---

The parallel implementation of the CFX-Solver is based on the *Single-Program-Multiple-Data* (SPMD) model. This model runs identical versions of the code on one or more processors.

The overall parallel run procedure is divided into two steps:

1. A *partitioning* step, where the mesh is divided into a number of different segments, or partitions.
2. A *running* step, where the mesh partitions are solved using separate processes (a *master* and one or more *slave* processes), often on different machines, with each process working on its own partition.

The CFX-Solver is designed so that all of the numerically intensive tasks can be performed in parallel. Administrative tasks, such as simulation control and user interaction, as well as the input/output phases of a parallel run, are performed serially by the master process. This approach guarantees good parallel performance and scalability of the parallel code, as well as ensuring that the input/output files are like those of a sequential run.

Communication between processes during a parallel run is performed using the PVM (Parallel Virtual Machine) or MPI message-passing libraries. Platform specific versions of MPI are available. In all cases, the processes of a parallel run are distributed among the processors in the specified pool of hosts.

There are several limitations for combining hardware in a parallel run:

- PVM is completely interoperable between platforms and can be used for running parallel jobs on a heterogeneous network. PVM internally takes care of the different hardware architectures, single- and multi-processor environments and shared memory concepts. Additionally, PVM can be used to combine UNIX or Linux hosts with Windows hosts in a parallel run.
- MPICH is interoperable among the various types of UNIX and Linux that are supported by ANSYS CFX, but you cannot mix UNIX or Linux with Windows.
- Platform specific versions of MPI must also be used only on a homogeneous network of the supported platforms.

This chapter describes the ideas behind parallel processing in ANSYS CFX and some provides advice on using it effectively:

[16.1. Partitioning](#)

[16.2. Setup for Parallel Runs](#)

[16.3. Message Passing Interface \(MPI\) for Parallel](#)

[16.4. Advice on Using ANSYS CFX in Parallel](#)


More detailed instructions on how to set up a parallel run are available in [Parallel Run in the CFX-Solver Manager User's Guide](#).

### 16.1. Partitioning

Partitioning is the process of dividing the mesh into a number of 'partitions' each of which may be solved on a separate processor. Several partitioning methods have been developed, but most are based on recursive bisection and differ only in the bisection step. The original mesh is first decomposed into

two meshes of approximately equal size. The decomposition is then repeated recursively until the required number of partitions is obtained. The following diagram shows this process.

**Figure 16.1 The Partitioning Process**



For information about setting up partitioning, see [Partitioner Tab in the CFX-Solver Manager User's Guide](#).


For information about viewing the mesh partitions after running the CFX-Solver in Partition Only mode, see [CFX Partition File in the CFX-Solver Manager User's Guide](#).

For information about optimizing mesh partitioning, see [Optimizing Mesh Partitioning \(p. 458\)](#).

### 16.1.1. Node-based and Element-based Partitioning

Any three-dimensional mesh can be partitioned using either node-based or element-based partitioning. *Node-based partitioning* divides the mesh across element faces; that is, between nodal locations. *Element-based partitioning* divides the mesh along element faces without dividing elements themselves; that is, at nodal locations.

**Figure 16.2 Node-based and Element-based Partitioning**



CFX uses node-based partitioning because this is consistent with the node-based linear solver. The following partitioners are available:

- MeTiS
- Recursive Coordinate Bisection
- Optimized Recursive Coordinate Bisection
- Simple Assignment
- User Defined Direction
- Directional Recursive Coordinate Bisection
- Junction Box
- Radial
- Circumferential.

Not all nodes in a given case require the same amount of computation effort. For example, a node on a GGI boundary requires a larger assembly effort within the solver than a node that is not on a GGI boundary. To take account of this, the CFX-Solver does not weight all nodes equally during partitioning—a partition with a lot of nodes on GGI interfaces will generally be assigned fewer nodes in total than one that does not have many nodes on GGI interfaces. There is an expert control parameter, `ggi vertex weighting value`, that controls the weighting applied to GGI vertices during partitioning. For more information, see *Expert Control Parameters* (p. 465).

### 16.1.2. Multilevel Graph Partitioning Software - MeTiS

The public domain partitioning package MeTiS (Karypis and Kumar, 1996) uses the currently most advanced mesh partitioning algorithm, the Multilevel Graph Partitioning Algorithm. The basic idea behind this algorithm is as follows: a graph is built containing the topology information of the mesh to be partitioned. This graph is first coarsened down to a few hundred vertices. A bisection of the resulting much coarser graph is calculated, and then the resulting partitions are projected back onto the original graph, by consecutively refining the partitions.


The MeTiS partitioner uses a fast algorithm that creates very efficient partitions. The whole process is fully automatic. However, it is unable to take advantage of coordinate direction alignment, and a substantial amount of dynamically allocated memory is required to run it (approximately 250 MB for a mesh containing 1.0E+06 nodes). If memory is a limitation, comparable results can be obtained with Optimized Recursive Coordinate Bisection. For details, see *Optimized Recursive Coordinate Bisection* (p. 452).

MeTiS is the default partitioner used by CFX.

The Multidomain Option setting can be set to partition the mesh for each domain separately (Independent Partitioning) or to partition the mesh ignoring domains (Coupled Partitioning). Note that only domains of the same physical type (fluid/porous and solid) are coupled together for coupled partitioning.

### 16.1.3. Recursive Coordinate Bisection

The Recursive Coordinate Bisection partitioning algorithm is very efficient with respect to CPU time and additional memory. The partitioning is based on the global coordinates of the mesh. Each step of the recursive bisection is performed in the coordinate direction with the largest dimension.

**Figure 16.3 Recursive Coordinate Bisection**

Like MeTiS, the Recursive Coordinate Bisection partitioner uses a fast, fully automatic algorithm, but it has only a small additional memory overhead. A particular disadvantage is that larger overlap regions can exist compared with the MeTiS partitioner, and each partition may contain separate parts.

### 16.1.4. Optimized Recursive Coordinate Bisection

This partitioning method is similar to Recursive Coordinate Bisection, but allows arbitrary directions for each partitioning step. The partitioning quality is comparable to the MeTiS algorithm. The method requires more CPU time to run, but is efficient with respect to memory. You may want to use this algorithm if some very large cases require too much memory for the MeTiS algorithm to function.

### 16.1.5. Simple Assignment


The Simple Assignment provides the fastest possible partitioning method that uses the smallest amount of memory. The vertices are assigned to the partitions simply corresponding to their vertex numbers. Assume a mesh with 1000 vertices that has to be partitioned into 10 partitions. The Simple Assignment produces the following partitions:

```
Partition 1:      Vertices 1-100
Partition 2:      Vertices 101-200
Partition 3:      Vertices 201-300
...
```

This is reasonable for hex meshes because their vertices are generally in topological order. However, this partitioning method can be arbitrarily bad for unstructured meshes and can result in huge overlapping regions.

### 16.1.6. User Specified Direction

The simplest partitioning algorithm is coordinate based in a direction whose vector components can be specified directly. This partitioning method uses the most efficient algorithm, and also has small additional memory overhead.

**Figure 16.4 User Specified Direction**

The partitioning process itself is partially controllable through the direction specification. However, in general, larger overlap regions occur compared with both the MeTiS and recursive coordinate bisection partitioners. This application is generally recommended only for special geometries.

### 16.1.7. Directional Recursive Coordinate Bisection

The *Recursive Coordinate Bisection* (p. 451) method recursively splits the domain into two parts using the x-, y-, or the z-coordinate direction (the choice depends on the biggest extension). This will geometrically lead to “cubic” partitions, but does not take into account the different mesh resolution in the three possible coordinate directions. Only the vertex coordinates are required for the partitioning. The graph (vertex/element connectivity) is not required, which makes this method very efficient.

In order to further improve the Recursive Coordinate Bisection method, there is the *Optimized Recursive Coordinate Bisection* (p. 452) method. Unlike the Recursive Bisection method, this method uses a graph to decide which coordinate direction has to be used for the bisection at each recursion level. The Directional Recursive Coordinate Bisection method is similar to the Optimized Recursive Coordinate Bisection, but is not limited to the three coordinate directions.


With respect to efficiency and partition quality (overlap region minimization), the methods can be ordered as follows, showing decreasing efficiency (increased CPU time and memory requirements) but better partitioning quality:

1. Recursive Coordinate Bisection
2. Optimized Recursive Coordinate Bisection
3. Directional Recursive Coordinate Bisection.

The best (but most expensive) partitioning method (Directional Recursive Coordinate Bisection) is still cheaper than *Multilevel Graph Partitioning Software - MeTiS* (p. 451), but generates partitions of similar quality.

### 16.1.8. Radial


Radial partitioning requires the specification of a rotation axis and partitions the mesh in the radial direction, according to the following diagram.

**Figure 16.5 Radial Partitioning**

The same considerations apply for Radial partitioning as for User Specified direction partitioning.

### 16.1.9. Circumferential

Circumferential partitioning uses the same axis definition as the radial partitioning method and divides the problem in the circumferential direction, according to the diagram.

**Figure 16.6 Circumferential Partitioning**

The same considerations apply for circumferential partitioning as for user specified direction partitioning.

## 16.2. Setup for Parallel Runs

Running CFX-Solver in parallel mode requires:

- Creation of `hostinfo.ccl` file to identify all available hosts that can be used in a parallel run
- Use of the `rsh` (remote shell) protocol to enable communication between hosts without requiring password authentication.

For details, see [Configuring ANSYS CFX Parallel in the Installation and Licensing Documentation](#).

## 16.3. Message Passing Interface (MPI) for Parallel

MPI is available for Windows and UNIX systems as a parallel communication library. Vendor specific versions of MPI are available on some platforms (see following table).

## Important

MPI run modes cannot be used on a mixture of Windows and UNIX machines.

For homogeneous distributed machines and multi-processor machines, MPI has been shown to give improved parallel efficiency over the PVM libraries. However, jobs run with MPI may not run as reliably as with PVM.

### 16.3.1. How to Use MPI Run Modes

Selection of MPI mode is made when defining the Run Mode in the CFX-Solver Manager. The options available in the drop-down list depend on the platform you are running on. The table below shows the versions of MPI that are available for each of the supported platforms.

Platform	MPICH	Platform MPI
winnt-ia32	no / 1.0.7	1.1
winnt-amd64	no / 1.0.7	1.1
linux-ia64	1.2.6 / no	2.3
linux-amd64	1.2.6 / no	2.3

### 16.3.2. When to Use MPI or PVM

- Due to poor performance, PVM run modes are not available from the CFX-Solver Manager on Windows platforms; you must use Platform MPI.
- PVM run modes can still be selected on Windows using the command line. Additionally, Windows hosts can be combined with UNIX or Linux master hosts in a distributed parallel run using PVM. This combination is not supported by other run modes.
- You must use the Platform MPI run modes on Linux and Windows if you want to utilize high speed interconnects (such as Myrinet, Infiniband, and so on) on those platforms.
- Generally PVM mode is superior to MPI in terms of robustness to abnormal situations for network parallel runs (such as an application termination during a run). However, for maximum performance, MPI run modes are usually recommended.
- Local parallel runs will generally perform best when using one of the MPI run modes. Unlike PVM, MPI run modes supports shared memory communication, which is faster than using socket based communication.
- When using MPICH run modes in a shared memory environment you should check that the operating system kernel has a large enough number of "semaphores IDs" and "shared memory segments" available. The sections that follow explain what semaphores IDs are, and what you need to know about them in order to run successfully MPICH on your system.

### 16.3.3. Common MPICH Errors

MPICH communication modes run without a central daemon and, hence, is not robust as PVM at cleaning up processes in error situations. If an error occurs during a parallel MPICH run, the individual solver processes may need to be cleaned up (killed) manually. If errors occur, check that the operating system kernel has a large enough number of "semaphores" or "shared memory segments" available, as described below.

## 16.3.4. Common Problems Encountered While Running MPICH

### 16.3.4.1. Semaphores and Shared Memory Segments

Semaphores are constructs used by MPICH to enable interprocess communication locally on a shared memory multiprocessor. They are the shared-memory equivalent to "sockets" that are used by PVM to enable interprocess communication.

Each parallel process uses its own semaphore. Shared memory access via semaphores is managed by the operating system kernel. Semaphores are created and used by a user-id, but managed by the operating system.

When an ANSYS CFX MPICH parallel job is finished, these semaphores are, by default, deleted. If the job terminated in some abnormal fashion, for example, one of the processes was killed, then the semaphores in use are not deleted and remain in an idle state. This situation consumes free semaphores on your system. There is a maximum limit on the number of semaphores that the operating system will permit. Once this limit is reached, no new semaphores can be created. Software usage may become unstable when the semaphore limit is reached.

### 16.3.4.2. Typical Problems When You Run Out of Semaphores

- You cannot start a new MPI run. Typical error message to console:

```
p0_97244: p4_error: semget failed for setnum=%d: 0
          An error has occurred in cfx5solve:
```

- A new MPI job starts up, but kills an already running MPI job.
- When two MPI jobs are running at the same time, for the same user-id, stopping one MPI job kills the second MPI job.

### 16.3.4.3. Checking How Many Semaphores Are in Use, and by Whom

There is a built-in command for UNIX: "ipcs", or "ipcs -a". Use this command to see what semaphores are owned by your user-id. Typical output is as follows:

```
machine.company.com: ipcs
Message Queues:
T      ID      KEY      MODE      OWNER      GROUP
q      0 0x416d02d8 --rw----- root      system
Shared Memory:
T      ID      KEY      MODE      OWNER      GROUP
m      768 0x7a08e  --rw----- joe       all
m      1409 0x57463  --rw----- moe       all
Semaphores:
T      ID      KEY      MODE      OWNER      GROUP
s      0 0x416d02d8 --ra----- root      system
s      1 0x416d029e --ra----- root      system
s      82 0x7a08e  --ra----- joe       all
s      83 0x7a08f  --ra----- joe       all
s      84 0x7a090  --ra----- joe       all
s      85 0x7a091  --ra----- joe       all
s      214 0x57463  --ra----- moe       all
s      183 0x57464  --ra----- moe       all
s      184 0x57465  --ra----- moe       all
s      185 0x57466  --ra----- moe       all
```

The user `joe` has one shared memory segment and 4 semaphores left over from an abnormally aborted previous CFX computation. These need to be deleted.

### 16.3.4.4. Deleting the Semaphores You Are Using

Once the system limit is hit for semaphores, new MPICH jobs are not possible. Because MPI does not delete these semaphores if a simulation has an abnormal termination, it is up to each user to manually clean up (delete) all such semaphores. It is also a good idea to also delete any remaining shared memory segments owned by your account at the end of an aborted run. This leaves the system free for other users to use for their MPI runs. Continuing from the above example, the user "joe" would issue the UNIX command "ipcrm -m xxx -s yyy" where xxx is shared memory ID number and yyy is a semaphore ID number. For example:

```
machine.company.com: ipcrm -s 82 -s 83 -s 84 -s 85 -m 768
```

This will delete the semaphores and the shared memory segment, leaving the system free for the next user. On some systems, the exact syntax of the ipcrm command may differ from that shown above.

### 16.3.4.5. Shared Memory Segment Size Problems

In some cases, it is possible to encounter the following message:

```
p0_2406: (140.296294) xx_shmalloc: returning NULL; requested 65576 bytes
p0_2406: (140.296337) p4_shmalloc returning NULL; request = 65576 bytes
You can increase the amount of memory by setting the environment
variable P4_GLOBMEMSIZE (in bytes)
p0_2406: p4_error: alloc_p4_msg failed: 0
```

This may occur if ANSYS CFX attempts to allocate a shared memory segment with a size larger than what is allowed by default by MPICH (the default is 4 MBytes). The default size can be adjusted, as mentioned in the error message, by setting the environment variable P4\_GLOBMEMSIZE. For example, to set this variable to 16 MBytes running a C-Shell:

```
setenv P4_GLOBMEMSIZE 16777216
```

You must be careful when you increase the value of this parameter that you do not exceed the maximum size allowed for a shared memory segment. This limit is set by the operating system kernel rather than MPICH.

### 16.3.4.6. Checking Semaphore ID and Shared Memory Segment Limits

In some cases, it may be necessary to increase the maximum number of semaphores IDs, or the maximum size of a shared memory segment on your system, so that several users/jobs can each run in parallel, simultaneously. Once the total number of semaphores are used, then more parallel MPI jobs can be started. You can find out the maximum number of semaphores on your system with the following commands:

#### 16.3.4.6.1. Linux

```
Semaphores: /sbin/sysctl -a | grep -i sem
```

```
Shared Memory segments: /sbin/sysctl -a | grep -i shm
```

### 16.3.4.7. Increasing the Maximum Number of Semaphores for Your System

In general, this is not a simple task, and it varies greatly between different computer vendors and operating systems. It may involve changing a system resource file and rebooting the computer, or it may involve making changes to the system kernel and recompilation of the system kernel. Contact your system administrator if you need to increase the number of semaphores on your system.

## 16.4. Advice on Using ANSYS CFX in Parallel

The following topics will be discussed:

- *Optimizing Mesh Partitioning* (p. 458)
- *Optimizing the Parallel Run* (p. 459)
- *Error Handling* (p. 459)
- *Measuring Parallel Performance* (p. 461)

### 16.4.1. Optimizing Mesh Partitioning

Partitioning in ANSYS CFX Parallel is a pre-processing step. In CFX-Solver Manager, you can choose one of several partitioning methods (see [Partitioner Tab in the CFX-Solver Manager User's Guide](#)), and you can specify the number of partitions (up to a maximum of 512).

In general, you should try to follow these guidelines wherever possible:

#### 16.4.1.1. Do Not Run Small Jobs in Parallel

For tetrahedral meshes, you may want to use a minimum of 30,000 nodes per partition. For partitions smaller than this, you are unlikely to see any significant performance increase and may even see parallel slow down.

For hexahedral meshes, good parallel performance improvements are usually not seen until a minimum of 75,000 nodes per partition is reached.

These numbers are machine dependent and can be higher or lower. Dual CPU PCs usually give poorer performance due to lack of bandwidth in the bus. Essentially the two CPUs can demand more memory access than the memory bus can provide.

#### 16.4.1.2. Always Try to Use the MeTiS Partitioning Method

MeTiS generates the best partitions with respect to the size of the overlap regions between the partitions, and is therefore the favored, and the default, partitioning method in CFX. Use one of the alternative partitioning methods only if MeTiS fails, or if the memory overheads are unacceptably high.

#### 16.4.1.3. Try to Use a Sensible Number of Partitions

The partitioning of a mesh leads to the creation of overlap regions at the partition interfaces. These regions are responsible for communication and memory overhead during a parallel run. During partitioning, ANSYS CFX prints partitioning diagnostic information to the CFX-Solver Manager text window and output file about partition overlaps. The percentage of overlap nodes to the total number of mesh nodes should ideally be less than 10% for efficient partitioning. Values greater than 20% will impair performance and are not recommended.

#### 16.4.1.4. If Necessary, Store the Partition File

As mentioned above, partitioning is a pre-processing step. By default, ANSYS CFX performs mesh partitioning automatically in combination with a parallel run. The creation of a partition file is therefore treated as an intermediate step, and is deleted at the end of a parallel run.

Under certain circumstances, it is advisable to store the partition file permanently, by performing a partition-only run of the CFX-Solver. These are:

- When the machine on which the master process is to be run does not have enough memory to run the partitioner.
- When several parallel runs using the same number of partitions are to be performed.

#### **16.4.1.5. Selection of the Partitioning Mode for Multi-Domain Cases**

For multi-domain cases, you can set up the **Multidomain Option** on the **Partitioner** tab by selecting either `Independent Partitioning` or `Coupled Partitioning`. For details see, [Partitioner Tab in the CFX-Solver Manager User's Guide](#).

`Coupled Partitioning` provides better partitions with respect to the size of overlap regions between partitions and thus exhibits improved parallel performance. However:

- Coupled partitioning requires more memory for the partitioning run. The partitioning memory scales with the size of the largest domain for `Independent Partitioning` and with the total size of all domains for coupled partitioning.
- Performance of particle transport calculations may be made worse when using coupled partitioning.

#### **16.4.2. Optimizing the Parallel Run**

The following is a bulleted list of tips to help you get the most from a parallel run using the CFX-Solver:

- For a single parallel run, try to use machines that have a similar level of performance.
- Avoid using swap space. Try to use machines that can perform their assigned tasks using their own physical memory.
- If you are using a network of workstations, use high speed Ethernet connections (100 Mbit is preferred to 10 Mbit).
- High-speed interconnects are supported only by Platform MPI; these are not supported by PVM.
- Before starting a parallel job, check to see if your selected machines or processors can be used exclusively. If you have to share their use with others, this may increase the CPU static load.
- Using two processors on a multi-processor machine is generally faster than using two processors on different machines. Dual CPU PCs are often the exception to this because the memory bus cannot provide enough memory access for both CPUs.
- Try to avoid assigning more than one process per processor.
- Use a sensible number of partitions. There should always be a balance between the individual partition size and the number of partitions.

#### **16.4.3. Error Handling**

This section gives suggestions on what to do if you encounter problems during a parallel run of the CFX-Solver. Most failures occur during the initial phase of the run as a result of configuration or PVM problems.

### 16.4.3.1. Problems with PVM

- Check to see whether PVM daemon files already exist on the selected hosts. On UNIX systems, these files are usually located in the `/tmp` directory and have the name `pvmd.user_id_number`, where `user_id_number` is your own user id number.
- Avoid using machines that share the same `/tmp` directory in the parallel environment.
- Start the PVM console on the master machine and then **add** the desired hosts.

On a UNIX system, you can start the PVM console by typing the command

```
cfx5parallel -pvm-console
```

in a UNIX terminal window.

The following are some of the main PVM commands:

Command	Description
add	Adds a specified host or list of hosts.
conf	Shows the current host configuration.
quit	Leave the PVM environment and keep PVM running in the background.
halt	Leave and stop the PVM environment.

- Check if the PVM architectures of the selected hosts are supported by your installation of CFX. On a UNIX system, the PVM architecture can be checked by running on each machine

```
CFX/tools/pvm/lib/pvmgetarch
```

- Check that you have a valid account on each of the selected machines. On UNIX systems, each of these accounts must have the same user name.
- The PVMHosts file is read only when the PVM daemon is first started. This means that if you change the PVMHosts file while any parallel run is running, no changes will be noticed until the next time all parallel processes have stopped running.
- On UNIX, you may need to kill the `pvmd` process.

### 16.4.3.2. Problems with the ANSYS CFX Executables

- Check the Hosts File (`hostinfo.ccl`) for syntax errors.
- Check that the specified executables for each host in the Hosts File exist, and that the files have execute permission set.
- Check that the specified executables are correct for the specified hosts (operating system, 32-bit or 64-bit executables, etc.).
- If a slave process is running on a Windows system, and the parallel run complains that it cannot find the solver executable, even though the specified executable exists, you should check to see that the user who is running the `rshd.exe` process (the RSH Service) has appropriate permission to run the specified solver executable.

You can find out which user is running the RSH Service as follows. Log on as `administrator`. Select **Settings** > **Control Panel** from the Start menu, and double-click on the **Services** icon. In the **Services** panel, double-click on the **Remote Shell (RSH) Service** line. A **Service** window pops up. The user running the RSH Service has the username that appears as the **Log On As** setting.

### 16.4.3.3. Problems with ANSYS CFX Licenses

- Check that you have the correct parallel licenses to run a parallel job on the assigned hosts.
- Check that you have enough licenses for the specified number of partitions.

### 16.4.3.4. Windows Problems

- Check to make sure that you are using the right version of `rsh`.
- If you are having trouble with distributed parallel MPI, check that you have installed the MPI daemon and registered a username and password.
- If you see the warning:

```
Your credentials are not cached with the MPI service on the remote host.
This may cause the update to fail. If it does, check the RSM log
for more details.
```

...you should registered a username and password. Note that a change to your password requires that you register that password with the MPI service.

### 16.4.3.5. Linux Problems

- CFX Distributed Parallel Runs Fail

On some SLES machines (typically ones with more than one network card), the default configuration of `/etc/hosts` will cause CFX distributed parallel runs to fail. In such cases, the problem might be solved by editing the `/etc/hosts` file to remove all lines that contain redundant loopback addresses. Do not remove the line with the first loopback address, which is typically 127.0.0.1.

### 16.4.3.6. Convergence Problems

Occasionally you may find that jobs submitted in serial will converge while those in parallel fail. This can be due to the different internal structure of the multigrid solver. The partitioned mesh leads to different coarse mesh blocking than the serial mesh, and if you have selected a timestep size that is close to the critical convergence limit, this can cause convergence problems.

Usually a reduction in the timestep size alleviates this problem.

## 16.4.4. Measuring Parallel Performance

In general, there are two reasons why you might want to run an ANSYS CFX job in parallel:

- Getting results faster by combining the processing power of two or more processors. The performance of this set up is measured by the system speedup.
- Performing simulations that require more memory than can be provided by a single machine. The performance of this feature is best measured using the memory efficiency.

In a real-world computer environment, it is not always easy to measure parallel performance. Measured execution times depend on relative speed of processors, which in turn is limited by the processor architecture, as well as its load. For heterogeneous networks, the parallel performance is directly determined by the speed of the slowest processor.

### 16.4.4.1. Wall Clock Performance

In order to measure wall clock performance, two parameters can be defined:

$$\text{Speedup, } S = \frac{T_s}{T_p} \quad (16-1)$$

$$\text{Efficiency, } E = \frac{T_s}{N T_p} = \frac{S}{N} \quad (16-2)$$

where the subscripts  $s$  and  $p$  refer to the sequential and parallel wall clock execution times respectively, and  $N$  is the number of partitions. The best wall clock performance increase that can be expected is a linear speed up ( $S = N$ ), and this corresponds to an efficiency of 100%.

The performance determination can sometimes not be straightforward due to the fact that only part of the CFX-Solver run is actually performed in parallel. The reading and distributing of the CFX-Solver input file data, and the collecting and writing of results file data are highly I/O dependent and not parallelized. These stages therefore depend on high disk speeds and fast network communication for fast operation, and should be neglected in any parallel performance evaluation. The number of seconds taken for the parallelized calculation stage of CFX-Solver can be found on the following line of the flow solver output file:

```
CFD Solver wall clock seconds: 2.5113E+04
```

This line is found at the end of the outer loop iterations (steady state run) or timesteps (transient run). This number is accurate only if no backup or transient results have been written during this stage of the calculation because file i/o is a serial process.

#### 16.4.4.2. Memory Efficiency

The memory efficiency:

$$E_m = \frac{M_s}{M_p} \quad (16-3)$$

where

$$M_p = \sum_{i=1}^N M_{p,i} \quad (16-4)$$

can be used to compare the total memory required by all processes of a parallel run,  $M_p$ , with the memory required by that of the equivalent serial run,  $M_s$ . The memory efficiency can be used to compare the total memory required by all processes of a parallel run, with the memory required by that of the equivalent serial run. The memory efficiency for ANSYS CFX will always be smaller than 100%, but should generally be in the range of 80-95% for meshes with reasonable partitions. With respect to workstation clusters, it is important to know that all processes (operating on both master and slave machines) use a nearly identical amount of memory.

Detailed information about the memory requirements of a parallel run are written to the output file.

### **16.4.4.3. Visualizing Mesh Partitions**

Partitioning information is appended to the results file during a parallel run of the CFX-Solver. You can view the partitions in CFD-Post by loading the results file and viewing the variable **Real partition number** on a locator to display the partitions of the mesh.



---

## Chapter 17: Expert Control Parameters

---

This chapter describes expert control parameters (sometime referred to as "expert parameters"):

17.1. When to Use Expert Control Parameters

17.2. Modifying Expert Control Parameters

17.3. CFX-Solver Expert Control Parameters

Additional information on expert control parameters is available. For details, see [Expert Control Parameters in the CFX-Pre User's Guide](#).

### 17.1. When to Use Expert Control Parameters

For a small number of cases, convergence difficulties can arise that cannot be resolved in the normal manner of timestep control or judicious setting of initial values. Under these circumstances, modifying control parameters can help when all else fails to bring about a converged solution.

It should be emphasized that the most frequent requirement for access to Expert Control Parameters is to take control of internal CFX-Solver defaults in order to improve or achieve convergence on a difficult case. Before you attempt to change Expert Control Parameter settings, it is important that you have read through the advice section and have taken all the normal steps to address any convergence difficulties.

Advice on Flow Modeling is available so that you can ensure you have done all that you can to obtain a converged solution before proceeding to modify Expert Control Parameters. For details, see [Advice on Flow Modeling](#) (p. 419).

### 17.2. Modifying Expert Control Parameters

You can set and edit Expert Control Parameters in CFX-Pre from the Expert Parameters panel. For details, see [Expert Control Parameters in the CFX-Pre User's Guide](#). The **Command File** editor can also be used. For details, see [Command File Editor Overview in the CFX-Solver Manager User's Guide](#).

### 17.3. CFX-Solver Expert Control Parameters

In the following sections, the name and function of the available Expert Control Parameters for the CFX-Solver is given. Each one is given either a logical, integer or real value. All of the parameters can be inserted using the **Command File** editor and "written" back into the CFX-Solver input file before executing the CFX-Solver.

Note that changing some of the CFX-Solver Control Parameters may affect the output generated by the CFX-Solver.

#### 17.3.1. Discretization Parameters

bounded bnd diffusion tets	
Type	String

Default Value	f
Description	Controls whether or not a bounded diffusion scheme is used at boundaries for tetrahedral elements. The diffusion scheme for other element types is bounded by default through the default setting of 5 for the expert parameters 'cht diffusion scheme' and 'scalar diffusion scheme'. Tetrahedral elements are controlled separately because the bounded scheme may lead to less accurate results.
build artificial wall	
Type	Logical
Default Value	t
Description	Artificial walls are usually built during the solution if the solver detects inflow at an outlet boundary, or outflow at an Inlet boundary. Set this parameter to 'f' to prevent artificial walls from being built.  Setting this to 'f' also enables you to set up a static-pressure to static-pressure flow problem, by allowing flow to be 'sucked' into the domain through an outlet boundary. Very small timestep sizes are usually required (an $L/V$ scale where $L$ approaches the mesh spacing at the inflow), and this method in general is susceptible to severe convergence difficulties.
cht diffusion scheme	
Type	Integer
Default Value	5
Description	Specifies the diffusion scheme for CHT solids:  1=central (interior), central (boundary) 2=positive definite coefficients (interior), central (boundary) 3=positive definite values (interior), positive definite values (boundary) 4=blended scheme (interior), central (boundary) 5=positive definite coefficients (interior), positive definite values (boundary) 6=blended scheme (interior), positive definite values (boundary)
degeneracy check tolerance	
Type	Real
Default Value	1e-4
Description	A face set is considered degenerate if the dimensionless area of the face set is less than this tolerance. The dimensionless area is calculated as the ratio of the area of the domain boundary (summed up over all integration point faces on the domain boundary) to a geometry length scale based on the volume of the elements adjacent to the domain boundary. If the dimensionless area is smaller than the specified tolerance, the whole domain boundary is flagged as degenerate. Note that no-slip wall boundaries that are flagged as degenerate are not allowed and the solver will stop with an error message. Also, when symmetry conditions are applied to a degenerate domain boundary, vectors and tensors on the domain boundary are modified to satisfy the required conditions. For example, all components of vectors that are orthogonal to the degenerate domain boundary are set to zero.
diffusion at inlets	

Type	String
Default Value	f
Description	Indicates whether to include diffusion terms at inlets, openings, and outlets for scalar equations (for example, Additional Variables, species, turbulence, and so on).
<code>fsdamp efficiency scale</code>	
Type	Real
Default Value	0.01
Description	Scaling factor for the free stream damping used in the efficiency calculation. For details, see <a href="#">Isentropic Efficiency and Total Enthalpy</a> .
<code>meshdisp diffusion scheme</code>	
Type	Integer
Default Value	2
Description	Specifies the diffusion scheme for mesh displacement equations:  1=central (interior), central (boundary) 2=positive definite coefficients (interior), central (boundary) 3=positive definite values (interior), positive definite values (boundary) 4=blended scheme (interior), central (boundary)  A value of 3 may improve the mesh quality in some cases, particularly when mesh folding occurs at sharp corners. For details, see <a href="#">Mesh Displacement Diffusion Scheme</a> .
<code>laplacian stresses</code>	
Type	Logical
Default Value	f
Description	When set to 't', causes a Laplacian form of the viscous stresses to be used instead of the strictly-correct stress tensor form.  When there are strong shear layers in regions of high mesh aspect ratio, the full viscous stress tensor can cause convergence slow-down or convergence stalling at a moderate level (for example, maximum residuals at 1.0E-2). The Laplacian form converges better in such cases, but is formally less accurate.
<code>porous cs discretisation option</code>	
Type	Integer
Default Value	2
Description	Specifies how the pressure is treated at interfaces to a porous domain:  1=constant static pressure 2=constant total pressure  Constant total pressure is the preferred and more physical setting. However, when using this setting, in cases where there are sections of the porous interface where there is little or no flow normal to the interface, the CFX-Solver may fail to converge. These convergence difficulties may be overcome by using the less physical constant static pressure setting.

linearly exact numerics	
Type	Logical
Default Value	f
Description	Controls whether numerics are linearly exact (that is, give a zero error in the presence of a linear solution field). This is a feature that has so far been found to be useful when there is quiescent flow in a hydrostatic pressure field and the mesh is a non-orthogonal hexahedral or mixed-element mesh.
pressure diffusion scheme	
Type	Integer
Default Value	2 (tetrahedral)
	1 (hexagonal)
Description	Specifies whether the standard central scheme (default) or the positive definite scheme is applied to the continuity equation.  This parameter may be of use in obtaining convergence with poor quality meshes.  A value of 2 sets the pressure diffusion scheme to be positive definite.
scalar diffusion scheme	
Type	Integer
Default Value	5
Description	Specifies the diffusion scheme for scalars:  1=central (interior), central (boundary) 2=positive definite coefficients (interior), central (boundary) 3=positive definite values (interior), positive definite values (boundary) 4=blended scheme (interior), central (boundary) 5=positive definite coefficients (interior), positive definite values (boundary) 6=blended scheme (interior), positive definite values (boundary)
stress diffusion scheme	
Type	Integer
Default Value	2 (tetrahedral)
	1 (hexagonal)
Description	Specifies the diffusion scheme for scalars:  1=central (interior), central (boundary) 2=positive definite coefficients (interior), central (boundary) 3=positive definite values (interior), positive definite values (boundary) 4=blended scheme (interior), central (boundary) 5=positive definite coefficients (interior), positive definite values (boundary) 6=blended scheme (interior), positive definite values (boundary)
tangential vector tolerance	
Type	Real

Default Value	10.0
Description	The solver will trigger an error message when the angle between the specified direction at a total pressure inlet and the inlet face is smaller than this angle.
<code>tbulk for htc</code>	
Type	Real
Default Value	300 K
Description	<p>When the Heat Transfer Coefficient (HTC) is computed for a temperature specified wall, by default a near-wall fluid temperature is used for a temperature scale. However, for consistency with traditional 1D analyses, you may want to enter a reference bulk temperature to compute the HTC. This parameter is that reference value.</p> <p>Thus the HTC computed when this parameter is provided is equal to the local heat flux calculated by the solver divided by the difference of the specified wall temperature and this specified bulk temperature.</p>
<code>vector parallel tolerance</code>	
Type	Real
Default Value	5.0
Description	<p>The value of this parameter is the number of degrees tolerated by the solver in determining the maximum deviation of any element face normal from the calculated average element face normal in a Symmetry Plane boundary condition. This error may occur when element inflation is used on surfaces adjacent to the Symmetry Plane boundary.</p> <p>Increase this value to relax the tolerance.</p>
<code>highres energy option</code>	
Type	Integer
Default Value	0
Description	<p>This parameter controls how the high resolution blend factor is calculated for the energy equation.</p> <p>Note that the blend factor is always shared with the species equations for multicomponent flow, with the actual blend factor taken as the most conservative of all contributions from the energy and mass fraction group.</p> <p>The information below indicates which variable is used to calculate the energy equation blend factor for single-component flow and the energy equation's contribution to the shared blend factor for multicomponent flow:</p> <p>0 = Enthalpy for single component flow, enthalpy for multicomponent flow.</p> <p>1 = Enthalpy for single component flow, no contribution for multicomponent flow.</p> <p>2 = Enthalpy for single component flow, temperature for multicomponent flow.</p>

	3 = Temperature for single component flow, temperature for multicomponent flow.
<code>ipmt area density clip</code>	
Type	String
Default Value	t
Description	Controls whether the interphase area density is clipped to a non-zero value for interphase mass transfer models. Using a clipped value provides a crude nucleation model, but in some cases prevents mass conservation.
<code>volfrc sumapp</code>	
Type	Logical
Default Value	t
Description	For multiphase calculations, the linear equations for phasic continuity (that is, the volume fraction equations) are not always diagonally dominant. Setting this parameter to true will force the linear equations to be diagonally dominant. This may improve robustness in some situations, but may also considerably slow down the convergence rate.
<code>wallscale diffusion scheme</code>	
Type	Integer
Default Value	5
Description	<p>Wallscale diffusion differencing scheme:</p> <p>1=central (interior), central (boundary)  2=positive definite coefficients (interior), central (boundary)  3=positive definite values (interior), positive definite values (boundary)  4=blended scheme (interior), central (boundary)  5=positive definite coefficients (interior), positive definite values (boundary)  6=blended scheme (interior), positive definite values (boundary)</p>

### 17.3.2. Linear-Solver Parameters

<code>mg solver option</code>	
Type	Integer
Default Value	5 (automatic)
Description	<p>For hydrodynamic equations (u, v, w, p), determines the coarsening algorithm for algebraic multigrid of the fluid coupled equations.</p> <p>A value of 5 (automatic) has the following behavior:</p> <ul style="list-style-type: none"> <li>• If the simulation involves multiphase flow with the free surface model activated, or with coupled volume fractions, option 2 is used.</li> <li>• Otherwise, option 4 is used.</li> </ul> <p>A value of 4 means that the anisotropic coarsening is designed to give robust convergence for the widest possible range of flow conditions.</p> <p>Alternative coarsening algorithms are also available for comparison purposes.</p>

	<p>A value of 3 means that coarsening is based on the velocity coefficient.</p> <p>A value of 2 means that the anisotropic coarsening is based on the pressure coefficient. This was the previous default value.</p> <p>A value of 1 sets an isotropic coarsening based on topology only (similar to conventional geometric multigrid).</p>
multigrid solver	
Type	Logical
Default Value	t
Description	Control whether multigrid is used in CFX-Solver.
overlap relaxation fluids	
Type	Real
Default Value	1.0
Description	Linear solver underrelaxation of overlap equations in a parallel run for hydrodynamics equations.
solver relaxation fluids	
Type	Real
Default Value	0.9
Description	<p>The under-relaxation value for the coupled U, V, W and P linear smoother within the multigrid solver.</p> <p>On a very poor mesh, coupled U, V, W and P linear solver failure can be helped by increasing this under-relaxation to, for example, 0.75.</p>
solver relaxation scalar	
Type	Real
Default Value	0.9
Description	<p>The under-relaxation value for the scalar linear smoother within the multigrid solver.</p> <p>On a very poor mesh, scalar equation linear solver failure can be helped by increasing this under-relaxation to, for example, 0.75.</p>
solver target reduction fluids	
Type	Real
Default Value	0.1
Description	The linear solver for the coupled mass-momentum system iterates until the final RMS residual for the continuity equation is below this number times the initial RMS continuity residual. It is occasionally useful, for testing purposes for instance, to drive the linear solver to a tighter tolerance (for example, to machine round-off).
solver target reduction scalar	
Type	Real
Default Value	0.1
Description	The linear solver for the coupled mass-momentum system iterates until the final RMS residual for the continuity equation is below this number

multiplied by the initial RMS continuity residual. It is occasionally useful, for testing purposes for instance, to drive the linear solver to a tighter tolerance (for example, to machine round-off).

### 17.3.3. I/O Control Parameters

always output post processing	
Type	Logical
Default Value	f
Description	When set to 't', makes the solver output flow summaries, variable ranges, forces, moments and scales to the output file on intermediate adaption steps
backup file at start	
Type	Logical
Default Value	f
Description	Controls whether a backup file is written at the start of every run (that is, showing the initial values field for the run).
backup file at zero	
Type	Logical
Default Value	f
Description	Controls whether a backup file is written after zero timesteps (that is, showing the initial guess field for the run).
delete backup files	
Type	Logical
Default Value	t
Description	When set to 'f', previous backup files are NOT overwritten by the next when using the backup frequency parameter.
include pref in forces	
Type	Logical
Default Value	f
Description	If set to 't', the solver will account for the specified reference pressure in the force and moment calculation.
mcf concentrations output option	
Type	Integer
Default Value	2
Description	Controls the output of mass concentrations, molar concentrations and molar fractions to the results file.
	0 - determine what data to write from the VARIABLES file (or CCL)
	1 - do not write this data
	2 - do not write this data for mixture fraction based models, and do write this data for other combustion models or no combustion model

	3 - always write this data
	To achieve full backwards compatibility with version 10.0, set this parameter to 3. Note that, in the case of a large number of components (>20), the computational cost of writing the data may be unacceptably high.
monitor digits	
Type	Integer
Default Value	5
Description	Controls the number of digits used in the MON file. Increase the value to increase the precision of the results reported.
monitor ftrans	
Type	Logical
Default Value	f
Description	When set to 't', outputs false transient information (steady state only) to the Solver output file (*.out) file for each coefficient loop.
monitor ranges	
Type	Logical
Default Value	f
Description	When set to 't', outputs variable ranges for each coefficient loop in a steady state simulation or for each timestep in a transient simulation.
monitor scales	
Type	Logical
Default Value	f
Description	When set to 't', outputs variable scales for each coefficient loop in a steady state simulation or for each timestep in a transient simulation.
mfloip to trn files	
Type	Logical
Default Value	f
Description	When set to 't', integration point mass flows are written to transient files (*.trn). This will ensure numerically consistent mass flow evaluations when post-processing transient files.
read boundary flows	
Type	Logical
Default Value	f
Description	When set to 't', the solver reads in boundary flows from the initial values when restarting from a previous run. This helps with smooth restart of cases with user function CEL expressions involving forces or boundary flows.
transient initialisation override	
Type	Logical
Default Value	f
Description	When set to 't', enables solver default values to be used for initialization in a transient simulation.

wall clock time	
Type	Logical
Default Value	f
Description	Output wall clock time during the outer loop in a steady state run or timestep loop in a transient run.

### 17.3.4. Convergence-Control Parameters

allow cbck for initcon	
Type	String
Default Value	f
Description	If set to 't', expressions involving callbacks (such as integrated values) can be used to set initial conditions. By default it is not allowed because allowing callbacks introduces the risk of hanging in parallel.
auto turnoff solve eq flag	
Type	Logical
Default Value	f
Description	This flag determines whether to stop solving individual equations when residuals have fallen below their convergence criteria. If either the U, V, W, P, H or $k - \varepsilon$ equations have fallen below their target residual by more than 10%, then each individual equation solution will be stopped in turn and the run completed when the Additional Variable equations have been solved satisfactorily.  This is only functional for steady state models, and when the model contains one or more Additional Variables. It is automatically set to 't' if the Auto Timescale feature is invoked.
check isolated regions	
Type	Logical
Default Value	t
Description	For serial runs, the solver checks if any fluid domain contains volumetric regions that are isolated pockets. This check cannot be performed for parallel solver runs.
ignore solve flag on restart	
Type	Logical
Default Value	f
Description	The solution of the wallscale equation stops after it has converged, even if the other equations have not yet converged. If you perform a restart and reduce the convergence criterion, it will not start solving again because the flag indicating it has converged is still set. To start solving the wallscale equation again on a restart, set this parameter to 't'.
imbalance normalisation type	
Type	Integer
Default Value	2

Description	Specifies how imbalances are normalized:  0 - no normalization  1 - normalize by maximum contribution in domain  2 - normalize by maximum contribution in all connected domains
max continuity loops	
Type	Integer
Default Value	1
Description	Sets the maximum number of continuity loops to perform within a timestep. The continuity loop iterates on the density*velocity nonlinearity in the continuity equation. The default value of 1 is usually appropriate. For high-speed supersonic flows (Mach numbers above 2), increasing the value to 2 may help convergence.
model coefficient relaxation	
Type	Real
Default Value	1.0
Description	Sometimes poor convergence is observed with the $k - \varepsilon$ turbulence model, characterized by bouncy $k$ and $\varepsilon$ residual graphs. Changing this under-relaxation parameter can help, but do not use values lower than 0.1.
outer loop relaxations default	
Type	Real
Default Value	0.75
Description	The default value for several underrelaxation parameters at the timestep loop level.  Bouncy convergence, even with a small timestep, can sometimes be reduced by lowering this value to 0.5 or less. A value below 0.25 is not recommended as that would drastically slow down convergence.
relax mass	
Type	Real
Default Value	0.75
Description	Changing the value of this parameter can aid convergence for problems that show residual oscillations in separation and reattachment regions. As it relaxes, the mass flow calculation procedure, it should not be used for transient problems (or should be set to 1).
require coefloop convergence	
Type	String
Default Value	f
Description	If set to 't' then the solver will stop in a transient run if convergence is not achieved within the coefficient loop
topology estimate factor	
Type	Real

Default Value	1.0
Description	<p><b>Note</b></p> <p>Do not use this parameter unless informed to in a run-time error message.</p> <p>Adjusts an internal factor used to help when the solver is estimating the total memory required to store the control volume equation matrix. Sometimes the internal factor is not sufficient and the solver will stop indicating that the “topology estimate factor” parameter must be increased. If this is the case, supply a number for this parameter that is larger than 1; for example, 1.2 will increase the internal memory estimate by 20%, which is often sufficient.</p>
topology estimate factor zif	
Type	Real
Default Value	1.0
Description	<p><b>Note</b></p> <p>Do not use this parameter unless informed to in a run-time error message.</p> <p>Adjusts an internal factor used to help when the solver is estimating the total memory required to store the matrix coefficients at GGI domain interfaces. Sometimes the internal factor is not sufficient and the solver will stop indicating that the “topology estimate factor” parameter must be increased. If this is the case, supply a number for this parameter that is larger than 1; for example, 1.2 will increase the internal memory estimate by 20%, which is often sufficient.</p>

### 17.3.5. Physical Models Parameters

apply ic fluctuations for les	
Type	Logical
Default Value	f
Description	If set to 't', to force the application of velocity fluctuations when restarting an LES. This is most useful when using a RANS solution as this initial guess. For details, see <a href="#">LES Initialization (p. 140)</a> .
coupled scalars	
Type	Logical
Default Value	t
Description	All combustion models that solve for the mixture fractions of the reactants and products (single or multiple step reaction models), are solved using a coupled multigrid linear solver. This means that all of the mixture fraction equations are solved simultaneously, with the mixture mass transfer source terms linearized in each equation. Under certain conditions, this coupling procedure can fail, leading to oscillatory convergence or divergence. In

	<p>this case, you can disable the coupled solver and switch to a segregated approach to solving the mixture fraction equations. This is achieved by setting this parameter to 'f'.</p>
force intersection	
Type	Logical
Default Value	f
Description	On all GGI interfaces (fluid-fluid attachments, periodicity and frame change interfaces), the solver performs an intersection procedure to connect the two sides of the interface together. This procedure is CPU intensive, so the result of the intersection is stored in the outgoing results file, for future use (for example, upon restart of the simulation). You can force a re-intersection of the GGI interface if desired, upon restart, by setting this parameter to 't'. It is rare that this parameter should be needed, as it generally only results in wasted CPU time upon a restarted simulation.
ggi vertex weighting value	
Type	String
Default Value	2
Description	Weighting applied to GGI vertices during partitioning. A larger value assigns a larger weight to vertices on GGI boundaries to account for the fact that the assembly effort is higher at GGI interfaces. For more information, see <i>Node-based and Element-based Partitioning</i> (p. 450).
mpf ggi force flow balance	
Type	Logical
Default Value	f
Description	Usually flow balance is not enforced at GGI interfaces for multiphase flows. By setting the value of this parameter to 't', the code will enforce flow balance. This can help with the convergence of many inhomogeneous multiphase flows which include such interfaces.
interp single phase treatment	
Type	Logical
Default Value	t
Description	By default, when interpolating from multiple Initial Values files onto a single Solver Input File, if each Initial Values file contains just one fluid, then the CFX-Interpolator regards all of these fluids as being the same fluid, regardless of the Fluid Definition name. This behavior can be turned off by setting the value of this expert parameter to "f" in the Solver Input File. This forces the CFX-Interpolator to use the Fluid Definition names to match each fluid from each Initial Values file with the appropriate fluid in the Solver Input File.
part cvs weighting	
Type	Logical
Default Value	f
Description	This parameter can be used to enable a more complex, experimental algorithm for parallel partitioning. This method attempts to assign different weights to each node/vertex in the domain, depending on the complexity

	of the elements surrounding a vertex. It attempts to make a more balanced partitioning for mixed element grids.
<code>tef numerics option</code>	
Type	Integer
Default Value	0
Description	The $k - \omega$ and SST turbulence models sometimes give convergence difficulties in areas of extremely high gradients in $\omega$ , for example, at a blunt trailing edge or sudden rearward facing surface, in conjunction with a highly refined boundary layer grid (generally resolved into the viscous sub-layer). The SST model is most susceptible to this problem. Symptoms are generally a lack of convergence with residuals stuck at regions of extremely high gradients of omega, sometimes leading to sudden, early total failure of the solver. In these cases, a flux limiting numerics implementation can be used for the $\omega$ equation, activated by setting this parameter to 1. This setting may become the default setting in a future release.
<code>use kolmogorov ts for extinction</code>	
Type	Logical
Default Value	f
Description	This parameter is provided for backwards compatibility with the first release of the extinction model. It is not recommended for use (leave at default setting of 'f', which uses the turbulence time scale for the flame extinction model). When set to 't', the Kolmogorov time scale is used in the extinction model (not recommended).
<code>wallscale relaxation factor</code>	
Type	Real
Default Value	0.75
Description	This is a relaxation factor for the wallscale equation, which is solved for all $k - \omega$ and SST turbulence models.  The wall scale equation is a pure diffusion equation and is therefore very sensitive to non-orthogonal meshes (such as a mesh that is highly skewed at a corner). If convergence problems for a wallscale equation are observed, try reducing the value of the wallscale relaxation factor.

### 17.3.6. Particle-Tracking Parameters

<code>pt distribute trans particles</code>	
Type	Logical
Default Value	t
Description	Uniformly distribute transient particles over the time step in a transient run. If this parameter is set to 'f', all particles are injected at the start of the time step.
<code>pt extrap vel for integ</code>	
Type	Logical
Default Value	f

Description	Use extrapolation of the particle velocity during particle integration. This may be helpful for cases with streamline curvature.
pt linear src coef multiplier	
Type	Real
Default Value	1.0
Description	Defines a factor which multiplies the linearization coefficient of the particle sources.
pt maximum particle temperature	
Type	Real
Default Value	3000.0
Description	Defines upper bound for the particle temperature in units of Kelvin [K].
pt minimum diameter	
Type	Real
Default Value	1.E-8
Description	Defines the minimum allowed particle diameter. Tracking of a particles is stopped if its diameter falls below this value.
pt minimum eddy life time	
Type	Real
Default Value	0.0
Description	Defines the minimum eddy life time for turbulent dispersion of particles.
pt time interpolation	
Type	Integer
Default Value	1
Description	Used in a transient run in order to decide how fluid quantities have to be interpolated to the current particle time. Possible values are:  0=use newest time level  1=linear interpolation between current and previous time levels  2=quadratic interpolation between current and two previous time levels
pt tracks in absolute frame	
Type	Logical
Default Value	f
Description	Output tracks in absolute frame of reference. Important for post-processing of non-transient RFR cases. Not required for transient cases.
pt zone specific tracks	
Type	Logical
Default Value	t
Description	This parameter controls the way how particle tracking information is written out to the results file. By default, this expert parameter is set to 't' and particle tracks will contain domain information. This information enables CFD-Post, for example, to display particle tracks on a user specified domain only.

In a multi-configuration run, where the number of domains may vary across simulations, it can happen that the interpolator can no longer map the source domain to a target domain. In this case, the source particle tracks are not copied to the target domain and are therefore lost. To avoid this problem, it is suggested that you set the `pt zone specific tracks` parameter to 'f' for multi-configuration runs. This enables the interpolator to always copy particle tracks to the target file, regardless of any changes in the number of source to target domains.

---

**Note**

When the `pt zone specific tracks` parameter is set to 'f', no domain filtering will be possible in CFD-Post.

`pt fluid var interpolation option`

Type	Integer
Default Value	1 (for cases that involve particle reactions)
Description	2 (for cases that do not involve particle reactions) This parameter controls whether fluid variables are interpolated to the current particle position.  Values:  0 = No interpolation. All fluid variables are assumed to be constant within a control volume.  1 = Interpolate all fluid variables except those that represent species concentrations.  2 = Interpolate all fluid variables.

`solve particles`

Type	Logical
Default Value	t
Description	Flag for controlling whether or not the controller solves the particle transport equations

### 17.3.7. Override Parameters

`solve emag`

Type	Logical
Default Value	t
Description	Flag for controlling whether or not the solver solves the electromagnetic equations.

`solve energy`

Type	Logical
Default Value	t

Description	Flag for controlling whether or not the controller solves the energy equation.
<code>solve fluids</code>	
Type	Logical
Default Value	t
Description	Flag for controlling whether or not the controller solves the hydrodynamics equations. Use if you have obtained convergence and you need to continue solving other equation groups.
<code>solve fsd</code>	
Type	Logical
Default Value	t
Description	Flag for controlling whether or not the solver solves the flame surface density equation.
<code>solve masfrc</code>	
Type	Logical
Default Value	t
Description	Flag for controlling whether or not the controller solves for mass fraction.
<code>solve mixture fraction</code>	
Type	Logical
Default Value	t
Description	Flag for controlling whether or not the controller solves for mixture fraction mean and variance equations.
<code>solve postproc masfrc</code>	
Type	Logical
Default Value	t
Description	Flag for controlling whether or not the controller solves the mass fraction equations in chemistry post processing. This flag affects only post processed components. The equations for regular components of the mixture are solved in the main iteration and may be controlled using the <code>solve masfrc</code> parameter.
<code>solve postproc tvariance</code>	
Type	Logical
Default Value	t
Description	Flag for controlling whether or not the controller solves the temperature variance equation in chemistry post processing. This flag applies only if the temperature variance equation is solved as part of chemistry post processing. When solved as part of the main iteration, the corresponding <code>solve temperature variance</code> flag applies.
<code>solve radiation</code>	
Type	String
Default Value	t
Description	Flag for controlling whether or not the controller solves the radiation equations

solve reaction progress	
Type	Logical
Default Value	t
Description	Flag for controlling whether or not the controller solves for reaction progress equations. For details, see <a href="#">Other Parameters</a> (p. 314).
solve scalar	
Type	Logical
Default Value	t (if running with Additional Variables)
Description	Flag for controlling whether or not the controller solves equations for Additional Variables.
solve soot	
Type	Logical
Default Value	t
Description	Flag for controlling whether or not the controller solves equations for soot equations.
solve temperature variance	
Type	Logical
Default Value	t
Description	Flag for controlling whether or not the controller solves for the temperature variance equation.
solve turbulence	
Type	Logical
Default Value	t
Description	Flag for controlling whether or not the controller solves the turbulence model equations
solve volfrac	
Type	Logical
Default Value	t
Description	Flag for controlling whether or not the controller solves the volume fraction equations
solve wallscale	
Type	Logical
Default Value	t
Description	Flag for controlling whether or not the controller solves the wall scale and boundary scale equations. Note that these equations must be solved to access the Wall Distance and Boundary Distance variables. Detailed information on the wall scale equation is available at <a href="#">Wall and Boundary Distance Formulation in the CFX-Solver Theory Guide</a> .

---

## Chapter 18: User Fortran

---

This chapter discusses:

- 18.1. User CEL Functions and Routines
- 18.2. User Junction Box Routines
- 18.3. Shared Libraries
- 18.4. User Parameters
- 18.5. Utility Routines for User Functions
- 18.6. CFX Memory Management System (MMS)
- 18.7. User CEL Examples
- 18.8. User Junction Box Examples
- 18.9. Using CFX-4 Routines in CFX
- 18.10. State Point Evaluation
- 18.11. Calculating the Particle Drag Coefficient

To add additional features and physical models to CFX, you can write your own subroutines in Fortran and have the CFX-Solver call these routines through a source code interface. You may also want to implement customized physical models that would never be available in CFX due to confidentiality considerations.

CFX supports user subroutines written in Fortran 77 or Fortran 90. A list of supported compilers for each platform is available. Using Fortran 77 whenever possible is recommended.

Two different kinds of user routines are available in CFX:

- User defined CEL (CFX Expression Language) functions can be used within a CEL expression, following the standard CEL rules. For details, see [User CEL Functions and Routines \(p. 484\)](#).
- Junction box routines can be used at several places in the CFX-Solver to execute user code. For details, see [User Junction Box Routines \(p. 486\)](#).

The following tasks can be accomplished with user subroutines in CFX:

- Input of user data (for example, data required for profile boundary conditions or externally generated sources).
- User-specified boundary conditions (for example, profile boundary conditions).
- User-specified initial conditions (for example, externally generated flow fields, random distribution or disturbance of existing solutions).
- User-specified source terms (for example, externally generated body forces or general additional source terms used to implement new physical models).
- Junction box routines called every timestep, which acts as a general interface between the CFX-Solver and other software (for example, structure mechanic codes). Junction boxes also offer an interface for advanced monitoring and solution output.
- User particle routines are used to specify sources of momentum, heat and mass transfer, and can also be used to specify injection regions for particles. The structure of particle user routines is the same. An example of this functionality is available. For details, see [Structure of User CEL Functions \(p. 485\)](#), [Particle User Sources \(p. 256\)](#), and [User Defined \(p. 272\)](#).


Note that CFX includes features such as advanced monitoring of solution variables or global values and extended CEL functionality, which may reduce your need for user subroutines.

To use junction box routines, you will need to be familiar with the CFX MMS (Memory Management System) to set up and pass around user data for access in any subroutine. For details, see [CFX Memory Management System \(MMS\)](#) (p. 526).

Shared libraries allow subroutines to be reused without recompilation for successive CFX-Solver runs or even for different applications. The location of a shared library is specified in CFX-Pre. During execution of the CFX-Solver, the user subroutines are loaded from the specified shared libraries. For details, see [Shared Libraries](#) (p. 491).

## 18.1. User CEL Functions and Routines

User CEL functions allow you to create your own functions in addition to the predefined CEL functions (such as sin, cos, step, etc.). You can then use these functions in any expression where a CEL function can be used. A user CEL function passes an argument list to a subroutine that you have written, and then uses the returned values from the subroutine to set values for the quantity of interest. The figure below demonstrates the concept.



All variables that are available for use in standard CEL expressions are also available for use in User CEL Expressions. A list of these variables is available in [Variables and Predefined Expressions Available in CEL Expressions in the CFX Reference Guide](#).

Details on creating user CEL functions in CFX-Pre and defining quantities via an expression with an argument list are available. For details, see:

- [User Routine Details View in the CFX-Pre User's Guide](#)

- [User Functions in the CFX-Pre User's Guide.](#)

Details on creating shared libraries and compiling subroutines are available. For details, see [Shared Libraries](#) (p. 491).

Examples of using user CEL functions are available. For details, see [User CEL Examples](#) (p. 542).

### 18.1.1. Structure of User CEL Functions

A User Fortran file may contain several user routines that can be called from the CFX-Solver, as well as any secondary routines that are called only from other routines in this file.

In addition to any comments and declarations that you may want to add, the basic structure of a user CEL function is:

```
#include "cfx5ext.h"
dllexport(<callingname>)
  SUBROUTINE <callingname>(
    & NLOC, NRET, NARG, RET, ARGS, CRESLT, CZ,DZ,IZ,LZ,RZ )
C
  INTEGER NLOC,NARG,NRET
  CHARACTER CRESLT*(*)
  REAL ARGS(NLOC,NARG), RET(NLOC,NRET)
C
  INTEGER IZ(*)
  CHARACTER CZ(*)*(1)
  DOUBLE PRECISION DZ(*)
  LOGICAL LZ(*)
  REAL RZ(*)
C
  .... executable statements
END
```

The `dllexport()` macro is used to ensure that a calling name is known externally on those platforms that require it for successful runtime linking. The macro is defined in an include file so `#include "cfx5ext.h"` should be the first line of the Fortran file.

One `dllexport()` should be specified for every routine that the CFX-Solver can call in the Fortran file, and each `dllexport()` macro must precede the `SUBROUTINE` statement that it refers to and must start in column 1. The argument of the `dllexport` macro should be the name of the subroutine in lower case and should not contain spaces.

User CEL functions have a fixed argument list that contains the following data fields:

- **NLOC:** Number of locations in space over which the calculations have to be performed.
- **NARG:** Number of arguments passed to the function.
- **ARGS(1:NLOC,1:NARG):** Arguments passed to the function (at each point in space).
- **NRET:** Number of return variables. This is always 1 in CFX, but is included to allow future extensions.
- **RET(1:NLOC,1:NRET):** Return variables (at each point in space).
- **CZ(\*), DZ(\*), IZ(\*), LZ(\*), RZ(\*):** CHARACTER, DOUBLE PRECISION, INTEGER, LOGICAL and REAL stacks.

The length (NLOC) of the arguments (ARGS) and the return value (RET) of user CEL functions is determined by the locale for which the routine is called. For example, for a boundary element group, NLOC is the number of faces in the group, and for vertices, NLOC is the number of vertices in the current zone.

Note that, in general, your user CEL function will be called several times during each iteration and the value of NLOC will be different for each call. This is because the CFX-Solver will split the specified region

(for example, a boundary condition region) into a number of smaller 'pieces' and call your function for each piece. Your user subroutine should be coded to deal with this.

The stacks are required if the information specified on the right side of the CEL expression (for example,  $B * C$  and  $D$  in  $A = UR(B * C, D)$ ) is not sufficient to calculate  $A$ . It might be necessary to pick up additional data (such as user input data, data at other locales, gradients, and so on). For details, see [Utility Routines for User Functions](#) (p. 497). This data is accessed from the CFX Memory Management System and requires the global stacks; therefore, the global stacks are added to the argument list. For details, see [CFX Memory Management System \(MMS\)](#) (p. 526).

A template user CEL function Fortran file named `ucf_template.F` can be found in `<CFXROOT>/examples/`.

Note that all strings used in User Fortran are case-sensitive.

### 18.1.2. User CEL Function Units

On entry into a user CEL function routine, the arguments are automatically converted into the units specified in the **Argument List** in the **User Function Editor** (labelled `Argument List` in the definition for the function in the CCL file `LIBRARY` section).

On exit, the results are automatically converted from the **Result Units** into the solution units used by the CFX-Solver.

This ability to choose the working units for the routine with automatic conversion may be useful for creating interfaces between the CFX-Solver and third-party data or applications.

## 18.2. User Junction Box Routines

In addition to defining your own CEL functions, you can call user subroutines at several points during execution of the CFX-Solver; such subroutines are called junction boxes. Junction boxes can be used to accomplish a number of different tasks:

- Input / Output of user data.
- Advanced solution monitoring tasks.
- Coupling of CFX with other software packages.
- Program control (for example, control of the termination criteria of coefficient loops in a transient run by some other means than maximum number of iterations or residual targets).

User defined junction box routines are passed only to the CFX-Solver workspace stacks as arguments. Unlike user CEL functions, there are no user arguments for these routines. However, by using the CFX MMS (Memory Management System) utilities, advanced users have full access to the internal data structures of the CFX-Solver. For details, see [CFX Memory Management System \(MMS\)](#) (p. 526). Some simplified routines have been implemented to allow access to commonly used data in the MMS. For details, see [Utility Routines for User Functions](#) (p. 497).

CEL variables are not available for use in junction box routines.

You can call more than one junction box during a run.

## 18.2.1. Junction Box Routine Options and Parameters


A junction box routine is created in CFX-Pre so that the CFX-Solver knows where to find the Fortran subroutine and when it should be called. The parameters that must be specified are described below. For details, see [Junction Box Routines in the CFX-Pre User's Guide](#).

The parameters that must be set for the `USER ROUTINE CCL` object are similar to the parameters used for User CEL Functions; however, an additional `Junction Box Location CCL` parameter specifies at which point the junction box routine is called during execution of the CFX-Solver.

The following parameters have to be set for the `USER ROUTINE CCL` object to fully declare a junction box routine.

- **Calling Name:** Is the name you use internally in your subroutine (for example, `mysub` for `SUBROUTINE MYSUB( . . . )`). Note that this should be in lower case even when it is in upper case in the Fortran file.
- **Library Name:** Is the shared library name (your Fortran file name by default). For details, see [Shared Libraries \(p. 491\)](#).
- **Library Path:** Is the path to the directory that contains the final shared library in subdirectories for each platform (linux, winnt). For details, see [Shared Libraries \(p. 491\)](#).
- **Junction Box Location:** Is a list of locations in the simulation where a junction box routine has to be called. The locations listed below are possible and are illustrated in the diagram that follows:
  - **First Partitioning Call:** Only applicable if partitioning is performed. Called just before the mesh is read and before partitioning is performed.
  - **Start of Partitioning:** Only applicable if partitioning is performed. Called after reading the mesh but before the partitioning process.
  - **End of Partitioning:** Only applicable if partitioning is performed. Called just after the partitioning has been completed and the `.par` file is written.
  - **First Call:** Called just before the mesh is read and the physics and boundary condition initialization. Called after partitioning has been completed if applicable.
  - **Start of Run:** Called after the problem setup is completed and the mesh has been read in.
  - **End of Run:** Called just after the results file has been written.
  - **User Input:** Called after **Start of Run**. This is the recommended location for your Fortran input code that works in parallel as well as serial runs. For details, see [Reading Data with the User Input Option \(p. 490\)](#).
  - **User Start:** Called after **User Input** on all partitions.
  - **User Output:** Called after **End of Run**. This is the recommended location for your Fortran output code that works in parallel as well as serial runs. For details, see [Writing Data with the User Output Option \(p. 490\)](#).
  - **Start of Timestep:** Called at the start of each timestep. This applies only for transient runs and relates to the outer loop.
  - **User Input Start of Timestep:** Called at the start of each timestep. Works identically to the User Input location but is called at the beginning of each timestep in a transient run.
  - **End of Timestep:** Called at the end of each timestep. This is applicable only for a transient run and relates to the outer loop.
  - **Start of Coefficient Loop:** Called at the start of each iteration loop. For a transient run, this relates to the inner loop.

- **User Input Start of Coefficient Loop:** Called at the start of each coefficient loop. Works identically to the User Input location but is called at the beginning of each coefficient loop in a transient run and steady state run.
- **End of Coefficient Loop:** Called at the end of each iteration loop. For a transient run, this relates to the inner loop.
- **Start of Linear Solution:** Called before the linear solver for a particular set of equations.
- **End of Linear Solution:** Called after the linear solver for a particular set of equations.
- **Abort:** Called if the Solver stops prematurely for some reason.
- **Start of Rigid Body Solution:** Called at the start of the rigid body solution. Only applicable for cases with a rigid body enabled. The rigid body solver is called in accordance with the rigid body solver control settings. For details, see [Rigid Body Control Tab in the CFX-Pre User's Guide](#).
- **End of Rigid Body Solution:** Called at the end of the rigid body solution.



## 18.2.2. Calling Junction Box Routines

Many junction box routines may be defined, but only those selected on the Solver Output Control tab will be called during execution of the CFX-Solver. For details, see [Basic Settings Tab in the CFX-Pre User's Guide](#).

### 18.2.3. Reading Data with the User Input Option

The **User Input** option for Junction Box Location allows you to read in your own data stored in files using arbitrary data formats. An example of data you may want to read in is any kind of data table (for example, profile boundary condition) when the data is read during a CFX-Solver run, a special MMS data area called `/USER_DATA` is created before the user input call. In a parallel run, this call is made only on the master process. After the call, any data found in `/USER_DATA` will be automatically copied from the master to the slave processes, so it becomes available to all subroutines on all processes. Use of this MMS data area requires calls to basic CFX MMS routines. For details, see *CFX Memory Management System (MMS)* (p. 526).

In a parallel run, **Start of Run** calls are made on every partition, while **User Input** calls are made only by the master process.

### 18.2.4. Writing Data with the User Output Option

The **User Output** option for junction box location allows you to write out data at the end of a run (advanced solution monitoring in CFX can be used in many cases to achieve tasks where user output would have previously been needed). For parallel runs, user output becomes more complicated. Unlike the automatic communication on the **User Input** call, the **User Output** location has no built-in facility for collecting data from slaves processes, because it is difficult to anticipate which data will be output. With the exception of integrated quantities (which can be written out with the advanced monitoring facility), all data is stored locally on each partition.

### 18.2.5. Other Junction Box Location Options

Junction box routines called at the beginning or end of timesteps or coefficient loops are expected to be mainly used for custom solution monitoring, program steering or coupling with other applications. A good example application is the coupling of CFX with a structure analysis code to calculate the fluid-structure interaction.

The **Abort** option for Junction Box Location is a special call that occurs just before the CFX-Solver terminates abnormally (for example, if an MMS error occurs). It is designed to allow you to shut down programs that might be running in conjunction with the CFX-Solver or other system level operations required as the CFX-Solver process ends. The CFX-Solver exit status is provided in the common block `/CFXSTATUS/ STATUS`. **STATUS** is an integer.

### 18.2.6. Structure of the User Junction Box Routines

Junction box routines have a fixed argument list that contains only the global stacks; no further arguments can be passed to them. Therefore, the argument and unit information that is required for user CEL functions is not required for junction box routines. Junction box routines always work in base units, as specified in the `FLOW > SOLUTION UNITS` section of a CCL file or on the **Solution Units** form in CFX-Pre. For details, see *Setting the Solution Units in the CFX-Pre User's Guide*.

MMS (Memory Management System) calls can be used in junction box routines to access CFX-Solver data. For details, see *CFX Memory Management System (MMS)* (p. 526).

A template junction box routine, `jcb_template.F` can be found in `<CFXROOT>/examples/`.

## 18.2.7. Which Call

Because the same junction box routine can be called from several locations in the same CFX-Solver run, it may be useful for the routine to know which location currently applies. This can be determined by looking up the variable `Which Call` as if this were a user parameter. For example, a junction box routine may contain:

```
CHARACTER*256 Which Call
CHARACTER*4 CRESLT
CHARACTER*1 CZ(*)
....
....
CALL USER_PEEKCS( 'Which Call', Which Call,
& 'STOP', CRESLT, CZ )
IF( Which Call .EQ. 'USERINPUT' ) THEN
....
END IF
```

Note that the value returned by the enquiry is in upper case even though the junction box locations were specified in lower case. For details, see [User Parameters \(p. 493\)](#).

## 18.3. Shared Libraries

The shared library concept enables you to link to user subroutines during a CFX-Solver run and avoids the need to create custom binaries each time user subroutines are used to extend the functionality of CFX. They also have advantage that:

- Different applications can reuse the same common library or set of libraries.
- One application can use several libraries or alternative libraries.

As has been shown in the previous sections, both user CEL functions and junction box routines declared in the CCL file must specify a library name, a unique calling name and a path to the shared library.

### 18.3.1. Creating the Shared Libraries

A script called `cfx5mkext` is used to create shared libraries. You can run `cfx5mkext -help` for information on the arguments accepted by the script. To create the shared libraries execute:

```
cfx5mkext myroutine1.F myroutine2.F
```

at the command line. This creates an architecture specific directory in the current working directory (for example, `winnt`). This directory contains the shared object library `myroutine1.dll` (Windows). A single library is created for all files passed to `cfx5mkext`. By default, the library is named using the first file specified in the `cfx5mkext` command.

---

### Important

Use a capital F as the file extension for Fortran source to be run through the pre-processor.

If you are using one of the double precision CFX-Solver executables, you should use the `-double` arguments with `cfx5mkext` to compile your subroutines. For details, see [Special Partitioner, Solver and Interpolator Executables in the CFX-Solver Manager User's Guide](#).

You can specify a different name for the shared object library using the `-name` option. The `-dest` option can be used to set the location of the library. For example,

```
cfx5mkext -name UserRoutine -dest /home/user/SharedLibraries myroutine.F
```

creates `UserRoutine.dll` (Windows) in an architecture, specify subdirectory in `/home/user/SharedLibraries`.

When specifying the library name in CFX-Pre (or in a CCL file), any prefix or suffix (`lib`, `.so`, `.sl`, `.dll`) added to the name should not be included.

When specifying the library path in CFX-Pre (or in a CCL file), you should specify an absolute path to the directory that contains the architecture specific subdirectories (for example, `/home/user/SharedLibraries` in the previous example. On Windows systems, this might be `F:\user\SharedLibraries`). Library path lists are supported to allow distributed parallel runs across different architectures. For details, see [Library Name and Library Path in the CFX-Pre User's Guide](#).

A `-double` option is provided with the command to allow you to produce files for use with the double precision CFX-Solver.

---

### Note

The double-precision solver uses 'auto promotion' of REAL data to DOUBLE. Specifically, when you include the `"-double"` option in your `cfx5mkext` command line, this activates auto-promotion and gives you double-precision User Fortran. If you are using Linux, you must have the Portland or gfortran compiler to build double-precision User Fortran.

## 18.3.2. Compiling User Fortran for ANSYS CFX 14.0 on Windows

The Intel Fortran 11.1.060 compiler is the recommended and supported compiler for ANSYS CFX 14.0. A supported linker is required; refer to the *Intel Fortran Release Notes* for details.

## 18.3.3. Compiling User Fortran for use on Linux Machines Without a Compiler Installation

In order to use User FORTRAN on a Linux platform without a compiler installed, you must force static linking with the Portland Group compiler run times (when using the Portland Group compiler). To do this, you first have to make a copy of the file `<CFXROOT>/etc/cfx5mkext.ccl` in the working directory, and then add the Portland Group compiler flag `"-Bstatic_pgi"` to every line which starts with `"ext link ldflags ="`, and which relates to the pgf95 compiler for the applicable operating system (linux-amd64). This flag tells the pgf95 driver to embed the Portland run time libraries within the generated shared object library.

## 18.3.4. Default Fortran Compilers

The `cfx5mkext` command requires a Fortran compiler to be in your path. The commands given in the following table are the defaults used to execute the compiler on each platform. On platforms where multiple Fortran commands are shown they are searched in the listed order.

Platform	Command
winnt	ifort
winnt-amd64	ifort
linux-amd64	pgf95, gfortran, g77
linux-ia64	ifort

If the commands shown do not execute the Fortran compiler on your platform, then you will have to manually edit a copy of the `<CFXROOT>/etc/cfx5mkext.ccl` file and place it in the working directory. The `cfx5mkext` command looks for a copy of `cfx5mkext.ccl` in the current working directory first. Further instructions are provided at the top of the file `cfx5mkext.ccl` file.

## 18.4. User Parameters

User Fortran using shared libraries is more versatile if its key parameters can be changed between runs without the need for recompilation or maintenance of different versions of the routines.

For example, the same User Fortran source code may be run for different applications or for parametric studies, but each run may need to open a different file name for reference data, or use a different value for some model option or a model parameter. Such parameters may be passed to the User Fortran through the command language in the CFX-Solver input file or the results file. In a parallel run, each partition gets a copy of this data. A demonstration on the use of some user parameters is available in [Junction Box Example 1: Profile Boundary Conditions](#) (p. 550).

### 18.4.1. Adding and Modifying User Parameters

There is a `USER:` object in command language for automatically passing user parameters to the solver (for access by User Fortran routines). Any parameter may be defined inside this object by simply adding statements of the form `name = value` within the `USER:` object.

The `USER:` object and parameters can be added to a CFX-Solver input file using `cfx5cmds`. For details, see [Editing the Command Language \(CCL\) File in the CFX-Solver Manager User's Guide](#). Once user parameters have been entered into the problem definition, they can also be seen and modified in the **Command File** editor.

### 18.4.2. Parameter Names

The name of a user parameter can be arbitrary, but subject to certain rules.

- Names in command language should start with an alphabetic character followed by alphanumeric characters.
- They are allowed to contain embedded spaces.
- Underscores are reserved for future syntax and, as such, are not allowed.

However, to allow access to the parameter on the solver side by using the same name, you should ensure that the names of user parameters contain only single spaces and are unique in the first 20 characters.

### 18.4.3. Parameter Values

The value part of the parameter statement is a string that conforms to command language rules (leading and trailing spaces are ignored; a backslash character at the end of a line may be used for continuation) and which can be interpreted by the user routine.

Standard utilities are provided for interpreting a parameter value as a simple Fortran-style INTEGER, REAL, DOUBLE PRECISION, or LOGICAL value, or as a CHAR string, or as a list of any of these types. These utilities expect list items to be separated by commas.

Note that these standard utilities do not support the processing of units.

## 18.4.4. Example of CCL File User Parameters

```

USER:
#
# location of external inlet profiles.
InputFile = /home/cfxuser/u_profile.dat
#
# printing control switch.
User Printing = .FALSE.
#
# model option.
ModelOption = 1
#
# model data.
InletTemperature = 300
#
RadiusList = 0, 0.2, 0.4, 0.6, 0.8, 1
VelocityList = 1, 0.96, 0.84, 0.64, 0.36, 0
END

```

## 18.4.5. Looking up a String Value

A User Fortran routine can pick up any user parameter value as a simple string, by calling the utility:

```
CALL USER_PEEKCS( CDANAM, VALUE, CERACT, CRESLT, CZ )
```

Input Arguments:

- CHARACTER\*(\*) CDANAM - solver name of parameter.
- CHARACTER\*4 CERACT - error action:
  - STOP to stop on error.
  - SKIP to continue silently.
  - WARN to continue after warning.
- CHARACTER\*1(\*) CZ - solver stack for CHARACTER data.

Output Arguments:

- CHARACTER\*(\*) VALUE - value of parameter.
- CHARACTER\*4 CRESLT - result code:
  - GOOD if successful.
  - BIG if data string is longer than length of VALUE variable.

## 18.4.6. String Value Example

```

CHARACTER*(80) InputFile
CHARACTER*4 CRESLT
CHARACTER*1 CZ(*)
C
C Look up command file parameter InputFile
C The run will stop if the data has not been provided.
C
CALL USER_PEEKCS(
& 'InputFile', InputFile, 'STOP', CRESLT, CZ )

```

## 18.4.7. Looking Up List Values

The `USER :` data arriving at the CFX-Solver may be interpreted either as a single value, or as a list of values separated by commas. If there is only a single value, the following utilities regard this as a list that is one item long.

Each individual value of a list may be looked-up as data of type `CHARACTER`, `DOUBLE PRECISION`, `LOGICAL`, `INTEGER` or `REAL` by calling the appropriate utility and specifying the position of the item in the list.

```
CALL USER_PEEKCA(
& CDANAM, JADRES, CVALUE, CERACT, CRESLT, CZ )
CALL USER_PEEKD(
& CDANAM, JADRES, DVALUE, CERACT, CRESLT, CZ )
CALL USER_PEEKL(
& CDANAM, JADRES, DVALUE, CERACT, CRESLT, CZ )
CALL USER_PEEKI(
& CDANAM, JADRES, IVALUE, CERACT, CRESLT, CZ )
CALL USER_PEEKR(
& CDANAM, JADRES, RVALUE, CERACT, CRESLT, CZ )
```

Input arguments:

- `CHARACTER*(*) CDANAM` - name of parameter.
- `INTEGER JADRES` - parameter list index, for example, 1 for a simple value or for the first value in the list.
- `CHARACTER*4 CERACT` - error action.
  - `STOP` to stop on error.
  - `SKIP` to continue silently.
  - `WARN` to continue after warning.
- `CHARACTER*1(*) CZ` - solver stack for `CHARACTER` data.

Output arguments:

- `CHARACTER*(*) CVALUE` - value of string parameter.
- `DOUBLE PRECISION DVALUE` - value of double precision parameter.
- `LOGICAL LVALUE` - value of logical parameter.
- `INTEGER IVALUE` - value of integer parameter.
- `REAL RVALUE` - value of real parameter.
- `CHARACTER*4 CRESLT` - result code.
  - `GOOD` if successful.
  - `ADRS` if `JADRES` is out of bounds.

## 18.4.8. Real Value Example

```
REAL InletTemperature
CHARACTER*4 CRESLT
CHARACTER*1 CZ(*)

C
C Set a default value
  InletTemperature = 298.0

C
C Look up command file parameter InletTemperature
```

```

C but continue with default value if none provided.
C Only one value is expected, so specify JADRES=1.
  CALL USER_PEEKR(
    & 'InletTemperature', 1, InletTemperature, 'SKIP', CRESLT, CZ )

```

### 18.4.9. Looking up Sizes of Lists and Strings

If the length of items or number of items in a list could be variable, then these sizes can be determined by the following utility.

```
CALL USER_PEEK_SIZE(CDANAM, NSIZE, LENVEC, CERACT, CRESLT, CZ )
```

Input arguments:

- CHARACTER\*(\*) CDANAM - solver name of parameter.
- CHARACTER\*4 CERACT - error action.
  - STOP to stop on error.
  - SKIP to continue silently.
  - WARN to continue after warning.
- CHARACTER\*4 CRESLT - result code.
  - GOOD if successful.
- CHARACTER\*1(\*) CZ - solver stack for CHARACTER data.

Output arguments:

- INTEGER NSIZE - number of items in list.
- INTEGER LENVEC - number of characters in the longest item, ignoring any leading spaces

### 18.4.10. Real List Example

```

REAL RadiusList(100), VelocityList(100)
INTEGER NSIZE, LENVEC
CHARACTER*4 CRESLT
CHARACTER*1 CZ(*)
INTEGER ITEM

C
C Initialization
  DO ITEM = 1, NSIZE
    RadiusList(ITEM) = 0.0
    VelocityList(ITEM) = 0.0
  END DO

C
C Assume VelocityList and RadiusList have same,
C but arbitrary, number of items, up to a limit of 100.
C
C Determine number of items, NSIZE
  CALL USER_PEEK_SIZE(
    & 'RadiusList', NSIZE, LENVEC, 'STOP', CRESLT, CZ )
C
C Lookup VelocityList(1:NSIZE) and RadiusList(1:NSIZE)
  DO ITEM = 1, NSIZE
    CALL USER_PEEKR( 'RadiusList',
    & ITEM, RadiusList(ITEM), 'SKIP', CRESLT, CZ )
    CALL USER_PEEKR( 'VelocityList',
    & ITEM, VelocityList(ITEM), 'SKIP', CRESLT, CZ )
  END DO

```

### 18.4.11. Printing Parameters

User Fortran code that needs to output results to file can use normal Fortran output statements, provided that these are coded in junction box routines called from the user output location. This allows the same code to use in serial and parallel.

However, it can also be useful for other user routines to be able to print out key parameters elsewhere during a run. Typical uses might be for checking and recording control settings or for observing run progress.

Some simple printing utilities are provided that are valid for both serial and parallel runs. These send text via the master process to the output file and at the same time to the console.

The following utilities print messages of the form `name = value`

```
CALL USER_PRINT_CHAR( NAME, VALUE )
CALL USER_PRINT_DBLE( NAME, VALUE )
CALL USER_PRINT_INTR( NAME, VALUE )
CALL USER_PRINT_LOGL( NAME, VALUE )
CALL USER_PRINT_REAL( NAME, VALUE )
```

There are two input arguments.

- `NAME` is a label of type `CHARACTER*(*)`.
- `VALUE` is a Fortran constant or variable of type `CHARACTER*(*)`, `DOUBLE PRECISION`, `INTEGER`, `LOGICAL` or `REAL` as indicated by the utility name.

The above utilities make use of the following CFX-Solver routine for outputting a general string

```
CALL MESSAGE( 'WRITE-ASIS', STRING )
```

where `STRING` is data of type `CHARACTER*(*)`.

This `MESSAGE` routine can be used for constructing other forms of message from User Fortran that will also be valid in both parallel and serial runs.

## 18.5. Utility Routines for User Functions

The following topics will be discussed:

- [Introduction to Utility Routines for User Functions](#) (p. 497)
- [Data Acquisition Routines](#) (p. 498)
- [Character Handling](#) (p. 522)
- [Output Routines](#) (p. 525)

### 18.5.1. Introduction to Utility Routines for User Functions

The main memory stacks are passed to both user CEL Functions and junction box routines providing you with full access to the CFX MMS, along with some useful MMS utility routines. For details, see [CFX Memory Management System \(MMS\)](#) (p. 526).

To enable easy access to some of the more frequently used data in the MMS, a set of simplified routines that can be called from within user CEL function and/or user junction box subroutines have been provided.

A routine called `USER_GETVAR` provides easy access to gradients on the given locale of a user CEL function. This is documented below.

Locale information can be accessed from within a user CEL function routine using the subroutine. For details, see [USER\\_CALC\\_INFO](#) (p. 506).

Scalar mesh information (for example, total numbers of vertices and elements) can be accessed using the `USER_GET_MESH_INFO` routine. For details, see [USER\\_GET\\_MESH\\_INFO](#) (p. 507). Arrays describing mesh data, such as vertex coordinates and element volumes, are accessed using the `USER_GET_MESH-DATA` routine. For details, see [USER\\_GET\\_MESHDATA](#) (p. 511).

Physical data can be accessed using the `USER_GET_PHYS_INFO` routine. For details, see [USER\\_GET\\_PHYS\\_INFO](#) (p. 513). This includes, for example, information on numbers and types of fluids and solids, and details on physical models, such as turbulence models. This can be used from within both user CEL function routines and user junction box routines.

Equation assembly information can be accessed using the `USER_ASSEMBLE_INFO` routine. For details, see [USER\\_ASSEMBLE\\_INFO](#) (p. 516).

Parallel information can be accessed using the `GET_PARALLEL_INFO` routine. For details, see [GET\\_PARALLEL\\_INFO](#) (p. 517). This can be used from within both user CEL function routines and user junction box routines.

Throughout, arguments to subroutines are listed, for example as follows

```
CI CZONE      : Solver Zone Name    (blank for global information only)
CV CDIR       : Subdirectory name of /USER into which to put info.
CO CRESLT     : Result = 'GOOD', 'ERR' or 'DIR'.
```

The abbreviations CI, CV, CO refer to input data, modified data, and output data respectively.

## 18.5.2. Data Acquisition Routines

### 18.5.2.1. USER\_GETVAR

The main application for `USER_GETVAR` is to provide derived variables, which are not accessible with CEL or operations on primitive and derived variables, and to provide material properties data. `USER_GETVAR` can be called from within user CEL functions to obtain a pointer to the latest solution fields for the locations on which the subroutine is currently operating. Note that `USER_GETVAR` obtains or computes its own copy of the data, and the returned pointer cannot be used to change the value of the solution fields. Note also that `USER_GETVAR` is not relevant to junction box routines.

Calls to `USER_GETVAR` have the following form:

```
CALL USER_GETVAR( '<VARIABLE_DESCRIPTION>' , CRESLT,
&                <pVAR> , CZ , DZ , IZ , LZ , RZ )
```

where the arguments in the argument list are as follows:

- `<VARIABLE_DESCRIPTION>`: name of the variable for which `USER_GETVAR` is called, following the naming convention:

```
[<Field A>].[<Field B>].<Field C>.[<Field D>]
```

where:

Field	Description
A	A valid name of one of the following objects: FLUID, SOLID, FLUID PAIR, or MUSIG FLUID
B	A valid name of one of the following objects: COMPONENT, SIZE GROUP, REACTION
C	A valid name of one of the following objects: VARIABLE, ADDITIONAL VARIABLE
D	One of the following variable operators: Magnitude, Gradient, Curl, Laplacian, Time Derivative, Transient Minimum, Transient Maximum, Transient Std Deviation, Transient RMS, Transient Average, Boundcon, magnitude, grad, curl, laplacian, dt, Trnmin, Trnmax, Trnsdv, Trnrms, Trnavg, hybrid

You should always add the fluid name even though, in some cases such as for the variable `Pressure`, it is not strictly necessary. The fluid name is required when specifying a phase-specific variable (in a multiphase case) and when specifying an algebraic Additional Variable (even for a single-phase case).

The names are case sensitive. You can use long variable names (for example, **Pressure**) or short names as they appear in CEL (for example, **p**).

You can also request whole vector and tensor entities (for example, `Air at STP.Velocity`) as well as components of these variables (for example, `Air at STP.Velocity u`).

#### Examples:

- `Pressure`: is the fluid pressure. Notice that no fluid tag is required.
  - `Pressure.Gradient`: is the pressure gradient in the fluid.
  - `Water at RTP.Density`: is the density of fluid `Water at RTP`
  - `Air.Nitrogen.Mass Fraction`: is the mass fraction of component `Nitrogen` in the multi-component fluid `Air`
  - `Water.Pollutant.Mass Fraction.Gradient`: is the gradient of the variable `Water.Pollutant.Mass Fraction`
  - `MyMusigFluid.Group1.Size Fraction`: is the size fraction of size group `Group1` in the MUSIG fluid `MyMusigFluid`
  - `Mixture.CO Oxidation.Molar Reaction Rate`: is the molar reaction rate of the reaction `CO Oxidation` in the reacting fluid `Mixture`.
- `CRESLT`: returned result key word containing the status of the `USER_GETVAR` call. After a successful call to `USER_GETVAR`, this variable will be `CRESLT= 'GOOD'`. The possible return codes are:

CRESLT	Description
BADL	Variable cannot be computed on the current LOCALE
CIRC	Variable has a circular reference
CVAR	Variable solver name is not valid
ENTY	Variable cannot be compute on the current ENTITY
GOOD	Variable was successfully computed
NAME	Variable user name is not valid
RECP	Variable is valid but CFX-Solver could not find a formula to evaluate the variable

This variable **MUST** be checked after every call to `USER_GETVAR` and verify that is equal to `GOOD`; otherwise, there has been a failure and the caller should continue or stop at his/her discretion.

- `<pVAR>`: stack pointer to the variable if the call was successful. Otherwise, its value is undefined and will result in a segmentation violation if used.
- `CZ, DZ, IZ, LZ, RZ`: stacks.

For example:

```
CALL USER_GETVAR('Water at RTP.Pressure.Gradient',CRESLT,
&                pPGRADIENT,CZ,DZ,IZ,LZ,RZ)
IF (CRESLT.NE. 'GOOD') STOP
```

Depending on the locale, the gradients are provided as vertex gradients (for example, for initial conditions `LOCALE= 'VERTICES'`), element averaged gradients (for example, for source terms `LOCALE= 'IELGn'`) or face averaged gradients (for example, for boundary conditions `LOCALE= 'BELGn'`). For `'IELGn'` and `'BELGn'`, `USER_GETVAR` gathers the specified variable to the vertices of the `IELG` or `BELG` and then use the shape functions to calculate the gradients.

The following restrictions apply to the use of gradients or curls:

- Gradients (or Curl) on `'VERTICES'` are approximate at wall boundaries. This is because wall values are taken from the interior.
- The normal component of gradients on `'VERTICES'` is always zero on symmetry planes.

### 18.5.2.1.1. Boundcon Operator

The “Boundcon” operator allows you to pick up boundary condition data for transport variables on boundary locales when applicable. By default, `USER_GETVAR` modifies the entity on a boundary locale to ensure that data can be obtained from the solution field, or a recipe if relevant. The use of this operator is targeted at experts as the precise effect is boundary condition, variable and equation dependent.

### 18.5.2.1.2. Variable Shape and Dimensions

The shape of the returned variable depends on the variable type and specified operation. The following syntax is used for non-gradients:

```
VAR (NCOMPT, NLOC)
```

with

- `NCOMPT`: number of tensor components of the variable. This is 1 for a scalar, 3 for a vector and 6 for a symmetric rank two tensor.
- `NLOC`: dimension of the locale.

For gradients and curls, the gradient/curl components appear first, with the tensor components appearing at the end, as follows:

```
VAR (NGRAD, NLOC, NCOMPT)
```

with

- `NGRAD = 3`: number of gradient components in the result.
- `NLOC`: dimension of the locale.
- `NCOMPT`: number of tensor components of the variable. This is 1 for a scalar, 3 for a vector and 6 for a symmetric rank two tensor.

This leads to the following definitions:

- Scalar variable:  $RZ(pVAR)$  points to a variable  $VAR(NLOC)$ .
- Vector variable:  $RZ(pVAR)$  points to a variable  $VAR(3, NLOC)$ .
- Gradient of a scalar variable:  $RZ(pVAR)$  points to a variable  $VAR(3, NLOC)$ .
- Gradient of a vector variable:  $RZ(pVAR)$  points to a variable  $VAR(3, NLOC, 3)$ .

The locale is always the locale for which the User CEL routine is called. It is not possible to call `USER_GETVAR` for non-local information (for example, using the face gradients on `BOUNDARY:Inlet` for the boundary condition specification of a variable on `BOUNDARY:Outlet`).

### 18.5.2.2. *USER\_GET\_GVAR*

This utility enables the integrated global quantities, normally used in CEL, to be used from User Fortran. For example, one could obtain the mean pressure (over all partitions in the case of a parallel run).

---

#### Note

This utility may fail in parallel, if the utility routine is not called on every partition.

The integrated function notation used is similar to that in CEL. `USER_GET_GVAR` may be called from user CEL or junction box routines. However, note the following differences in its operation in these two contexts:

- When called from a junction box, the requested integrated quantity is recalculated.
- When called from a User CEL routine, the requested integrated quantity is recalculated only if it has not previously been calculated and saved. If it has previously been calculated and saved, then the previously calculated value is returned.

These differences in operation are due to parallel processing issues. It is safe to recalculate on junction boxes, as all parallel processes are synchronized in that case. However, user CEL routines are used during local assembly, where it is not possible to recompute global quantities in parallel. If such a quantity is requested from a user CEL routine during a parallel run, the code may hang. For this reason, it is recommended that you call `USER_GET_GVAR` only from junction box routines. For user CEL routines, it is better practice to obtain the required global quantities from call back routines in CEL, and pass these as arguments to the user CEL routine. An alternative workaround is also to call the required global quantity from a junction box that is called once per coefficient loop. It is then safe to request the quantity from user CEL.

Examples of the use of `USER_GET_GVAR` are available in [User Junction Box Examples \(p. 550\)](#).

```

SUBROUTINE USER_GET_GVAR (USER_VAR, USER_LOC, USER_OPER,
&                        CRESLT, VAR, CZ,DZ,IZ,LZ,RZ)
C
CI USER_VAR:  User Name of variable or phase
CI USER_LOC:  User Location.
CI USER_OPER: Operation. e.g. 'maxVal'
C
CO CRESLT: Result, e.g. 'GOOD', 'ERR'

```

Depending on the operation requested, `USER_VAR` may be specified as follows:

- `USER_VAR` = user variable name, for example, 'Water at RTP.Temperature'
- `USER_VAR` = '' (blank), for example, for `USER_OPER` = 'area'

Depending on the operation requested, USER\_LOC may be specified as follows:

- USER\_LOC = domain name, for example, 'duct'
- USER\_LOC = subdomain name, for example, 'heated region'
- USER\_LOC = boundary condition name, for example, 'inlet'.

Allowed operations are tabulated and described below, together with allowed variable and location types.

USER_OPER	Allowed USER_VAR	Allowed USER_LOC	Description
area	blank	Any 2D region (such as a boundary or interface)	Area of a boundary or interface.
area_x area_y area_z	blank	Any 2D region (such as a boundary or interface)	The component of the normal area vector in the x, y or z direction.
areaAve	variable	Any 2D region (such as a boundary or interface)	Area-weighted average of the variable on a 2D region.
areaInt	variable	Any 2D region (such as a boundary or interface)	Area-weighted integral of the variable over a 2D region.
ave	variable	Any 3D region (such as a domain or subdomain)	Arithmetic average of the variable within a 3D region.
force	blank	Any 2D region (such as a wall)	The magnitude of the force vector on a boundary <sup>[1 (p. 505)]</sup> .
force_x force_y force_z	blank	Any 2D region (such as a wall)	The component of the force vector in the x, y or z direction <sup>[1 (p. 505)]</sup> .
mass	blank	Any 3D region (such as a domain or subdomain)	The total mass within a 3D region. This is fluid dependent.
massAve	variable	Any 3D region (such as a domain or subdomain)	Mass-weighted average of the variable on a 3D region.
massInt	variable	Any 3D region (such as a domain or subdomain)	The mass-weighted integration of the variable within a 3D region.
mass-Flow	blank	Any fluid surfaces (such as inlets and outlets)	Mass flow through a fluid surface.
mass-FlowAve	variable	Any fluid surfaces (such as inlets and outlets)	Mass flow weighted average of the variable on a fluid surface.

<b>USER_OPER</b>	<b>Allowed USER_VAR</b>	<b>Allowed USER_LOC</b>	<b>Description</b>
mass-FlowAveAbs	variable	Any fluid surfaces (such as inlets and outlets)	Absolute mass flow weighted average of the variable on a fluid surface.
mass-FlowInt	variable	Any fluid surfaces (such as inlets and outlets)	Mass flow weighted integration of the variable on a fluid surface.
maxVal	variable	Any 3D region (such as a domain or subdomain)	Maximum value of the variable within a 3D region.
minVal	variable	Any 3D region (such as a domain or subdomain)	Minimum value of the variable within a 3D region.
rbstate	variable long name for a rigid body state variable  The rigid body state variables are: <ul style="list-style-type: none"> <li>• Position,               <ul style="list-style-type: none"> <li>Position X,</li> <li>Position Y,</li> <li>Position Z</li> </ul> </li> <li>• Linear Velocity,               <ul style="list-style-type: none"> <li>Linear Velocity X,</li> <li>Linear Velocity Y,</li> <li>Linear Velocity Z</li> </ul> </li> <li>• Linear Acceleration,               <ul style="list-style-type: none"> <li>Linear Acceleration X,</li> <li>Linear Acceleration Y,</li> </ul> </li> </ul>	Any rigid body object or any immersed solid domain that is governed by a rigid body solution.	Returns the position/velocity/acceleration or orientation/angular velocity/angular acceleration (or axis components of these) of a rigid body object or immersed solid that is governed by a rigid body solution. These quantities are with respect to the global coordinate frame.

USER_OPER	Allowed USER_VAR	Allowed USER_LOC	Description
	<p>Linear Acceleration Z</p> <ul style="list-style-type: none"> <li>• Euler Angle X, <p>Euler Angle Y,</p> <p>Euler Angle Z</p> <li>• Angular Velocity, <p>Angular Velocity X,</p> <p>Angular Velocity Y,</p> <p>Angular Velocity Z</p> <li>• Angular Acceleration, <p>Angular Acceleration X,</p> <p>Angular Acceleration Y,</p> <p>Angular Acceleration Z</p> </li></li></li></ul> <p>For variables that do not include an axis name, the magnitude of the vector is returned. For example, if the variable is Position, the distance from the</p>		

USER_OPER	Allowed USER_VAR	Allowed USER_LOC	Description
	origin is returned.		
rmsAve	variable	Any 2D region (such as a boundary or interface)	RMS average of the variable within a 2D region
sum	variable	Any 3D region (such as a domain or subdomain)	Sum of the variable over all 3D region vertices.
torque	blank	Any 2D region (such as a wall)	Magnitude of the torque vector on a 2D region.
torque_x torque_y torque_z	blank	Any 2D region (such as a wall)	Magnitude of the torque vector in the x, y, or z direction.
volume	blank	Any 3D region (such as a domain or subdomain)	The total volume of a 3D region.
volumeAve	variable	Any 3D region (such as a domain or subdomain)	Volume-weighted average of the variable on a domain.
volumeInt	variable	Any 3D region (such as a domain or subdomain)	Volume-weighted integration of the variable within a domain or subdomain.
<p>1. When restarting from an initial value file, USER_GET_GVAR will return only the normal part of the force when called before or at the start of the first iteration (the first coefficient loop of the first timestep for a transient simulation). For all subsequent iterations the force returned will include both the normal and the tangential parts, i.e. the solution converges to the correct result. The restart kink can be resolved by setting expert parameter "read boundary flows = t".</p>			

### 18.5.2.2.1. USER\_GET\_GVAR with Multiphase Flow

If the USER\_OPER is fluid-specific, various behaviors are possible depending on the USER\_OPER type:

- For `massFlow` and `massFlowAve`, if the fluid prefix is not specified for the USER\_OPER, then the bulk mass flows will be used
- For other fluid-specific functions, if a fluid-specific variable is specified and no fluid is specified for the USER\_OPER, then the fluid specified for the variable will be assumed for the USER\_OPER as well.
- For a fluid-specific USER\_OPER that is specified, with a variable that is fluid-specific, and no fluid is specified for the variable, then the fluid specified for the USER\_OPER will be assumed for the variable as well.
- If either the USER\_OPER or variable are fluid-specific, and a prefix is not given for either, the solver will stop with an error.

USER\_GET\_GVAR multiphase examples are shown in the following table:

CEL Function	USER_OPERATOR	USER_VAR	USER_LOC	Behavior
<code>massFlow()@inlet</code>	<code>massFlow</code>	blank	inlet	Bulk mass flow rate through inlet

CEL Function	USER_OPERATOR	USER_VAR	USER_LOC	Behavior
Air.mass-Flow(@inlet)	Air.mass-Flow	blank	inlet	Air mass flow rate through inlet
mass-FlowAve(p)@inlet	mass-FlowAve	p	inlet	Bulk mass flow averaged pressure on inlet
Air.mass-FlowAve(p)@inlet	Air.mass-FlowAve	p	inlet	Air mass flow averaged pressure on inlet
mass-FlowAve(vf)@inlet	mass-FlowAve	vf	inlet	Error because no fluid specified
mass-FlowAve(Air.vf)@inlet	mass-FlowAve	Air.vf	inlet	Bulk mass flow averaged air volume fraction on inlet
Air.mass-FlowAve(Air.vf)@inlet	Air.mass-FlowAve	Air.vf	inlet	Air mass flow averaged air volume fraction on inlet
Air.mass-FlowAve(vf)@inlet	Air.mass-FlowAve	vf	inlet	Same as Air.massFlowAve(Air.vf)@inlet

### 18.5.2.3. USER\_CALC\_INFO

A simple routine, USER\_CALC\_INFO is provided for obtaining mesh locale information from within any user CEL function (it is not available from within junction box routines).

```

SUBROUTINE USER_CALC_INFO (WHO,ACTION,CVAR,LOCALE,ENTITY,WHEN,
& CALIAS,CERACT,CRESLT,
& CZONE,ILOCS,ILOCF,IENTS,IENTF,
& CZ,DZ,IZ,LZ,RZ)
C
CD Controls setting and getting of user data area and locale info.
C
CO WHO          : Name of routine making original call to GETVAR.
CO ACTION       : 'SET', 'GET' & 'RELEASE'
CO CVAR        : Solver Name of variable to be calculated by CEL call.
CO LOCALE      : Solver Locale (vertices, elements, element set etc.)
CO ENTITY      : Solver Entity (for element locales: integration point, etc.)
CO WHEN        : The time & iteration for evaluation.
CO CALIAS      : External variable name. Usually user provided for mass
C               : fractions and additional variables.
CO CERACT      : Action to be taken on an error occurring.
CO CRESLT      : Result of attempt to calculate variable.
CO CZONE       : Zone (if known) as context for AV links.
CO ILOCS       : Number of first item of locale type (e.g. vertex or
C               : element).
CO ILOCF       : Number of last item of locale type.
CO IENTS       : Number of first item of entity type (e.g. integration pt.)
CO IENTF       : Number of last item of entity type.
C               : For vertices, or ALL elements, IENTS=IENTF=1

```

This routine should be called only with ACTION set to 'GET'. Each argument is then set with the data described above. The arguments can be declared as follows in the calling routine:

```

CHARACTER*(MXDNAM) WHO, ACTION, CVAR, LOCALE, ENTITY, WHEN, CZONE
CHARACTER*(120) CALIAS

```

```
CHARACTER*(4) CERACT, CRESLT
INTEGER ILOCS, ILOCF, IENTS, IENTF
```

Note that for ACTION= 'GET', all other arguments are returned with output values, even CERACT, which in all other situations would be expected to be an input argument. Hence, do not attempt to code constant values for any arguments, except for ACTION.

Allowed solver LOCALE names are listed and described in the table below.  $m, n$  denote arbitrary integers:

<b>LOCALE</b>	<b>Description</b>
ZNm	zone $m$ = domain $m$
VLm	volume $m$
VPm	volume patch $m$ = subdomain $m$ = a union of elementary volumes
VERTICES	all vertices on a zone
ELEMENTS	all elements on a zone
ELSm	element set $m$ = set of elements of a fixed logical type
IELGm	interior element group $m$ (a contiguous subset of an element set)
BCPm	boundary condition patch (BCP) $m$ (a set of faces belonging to a boundary condition)
FCSm	face set $m$ (a subset of a BCP consisting of faces of fixed logical type)
BELGm	boundary element group $m$ = (a subset of elements of fixed logical type, coincident with a face set)

Allowed Solver ENTITY names are listed and described in the table below.  $m, n$  denote arbitrary integers:

<b>ENTITY</b>	<b>Description</b>
''	not specified, for example, if LOCALE = 'VERTICES'
CENTRE =	centroids, for example, of elements on an element group, faces on a face set.
CENTER	
VXEL	element vertices, for example, on an interior or boundary element group.
IP	integration points, for example, on an interior or boundary element group.

#### **18.5.2.4. USER\_GET\_MESH\_INFO**

This subroutine stores useful geometric and mesh related scalar data under a directory named '/USER/' //CDIR. It does so by looking inside /FLOW/GEOMETRY/ and /FLOW/MESH/, and copying required data. It is available in user CEL and junction box routines.



Variable Name	Variable Type	Description
NELS	INTEGER	total number of element sets
NIELG	INTEGER	total number of internal element groups
NBELG	INTEGER	total number of boundary element groups

#### 18.5.2.4.2. Zonal Information: **CZONE = 'ZNm', LOCALE = ''**

If you specify a valid solver zone name, and a blank locale name, then it is assumed that you require mesh data specific to that zone. The information stored under CDIR is tabulated below:

Variable Name	Variable Type	Description
PHYTYPE	CHARACTER * (MXD-NAM)	zone physical type = 'FLUID' or 'SOLID'
IZN	INTEGER	zone number
NDIM	INTEGER	number of spatial dimensions
NVL	INTEGER	number of volumes
NVP	INTEGER	number of volume patches = subdomains.
NSF	INTEGER	number of surfaces
NSP	INTEGER	number of surface patches
NBCP	INTEGER	number of boundary condition patches
CB-CP(NBCP)	CHARACTER * (MXD-NAM)	character array containing internal solver names of boundary condition patches.  (These are of the form 'BCPm', m = integer.)
CVP(NVP)	CHARACTER * (MXD-NAM)	character array containing internal solver names of volume patches = subdomains.  (These are of the form 'VPm', m = integer.)
NVX	INTEGER	total number of vertices on this zone
NEL	INTEGER	total number of elements on this zone
NELS	INTEGER	total number of element sets on this zone
NIELG	INTEGER	total number of internal element groups on this zone
NBELG	INTEGER	total number of boundary element groups on this zone

#### 18.5.2.5. Boundary Condition Patch Information: **CZONE = 'ZNm', LOCALE = 'BCPn'**

If you specify a valid solver zone name, and a valid Boundary Condition Patch (BCP) name, then it is assumed that you require mesh data specific to that BCP. The information stored under CDIR is tabulated below:

Variable Name	Variable Type	Description
PHYTYPE	CHARACTER * (MXD-NAM)	BCP physical type = 'INLET' or 'OUTLET'; 'OPENING', 'WALL', 'SYMMETRY', 'PERIODIC', 'INTERFACE'
IBCP	INTEGER	boundary condition patch number

#### 18.5.2.5.1. Face Set Information: CZONE = 'ZNm', LOCALE = 'FCSn'

If you specify a valid solver zone name and a valid face set name, then it is assumed that you require mesh data specific to that face set. The information stored under CDIR is tabulated below:

Variable Name	Variable Type	Description
CBCP	CHARACTER * (MXD-NAM)	name of BCP to which the face set belongs
IBCP	INTEGER	number of BCP to which the face set belongs
ISFC_S	INTEGER	starting set face number for this face set
ISFC_F	INTEGER	finishing set face number for this face set

#### 18.5.2.5.2. Element Set or Element Group Information: CZONE = 'ZNm', LOCALE = 'ELSn' or 'IELGn' or 'BELGn'

If you specify a valid solver zone name, and a valid element set name, or element group name, then it is assumed that you require mesh data specific to that element set or element group. The information stored under CDIR is tabulated below:

Variable Name	Variable Type	Description
IELS	INTEGER	element set number for an element set or interior element group = 0 for a boundary element group
IELG	INTEGER	interior element group number = 0 if not an interior element group
BELG	INTEGER	boundary element group number = 0 if not a boundary element group
NVXEL	INTEGER	number of vertices per element.
NFCEL	INTEGER	number of faces per element
NIPEL	INTEGER	number of integration points per element
IP1	INTEGER	starting integration point number
IP2	INTEGER	finishing integration point number
ISEL_S	INTEGER	starting set element number for an element set or an interior element group
ISEL_F	INTEGER	finishing set element number for an element set or an interior element group

Variable Name	Variable Type	Description
ISFC_S	INTEGER	starting set face number for a boundary element group
ISFC_F	INTEGER	finishing set face number for a boundary element group

### 18.5.2.6. USER\_GET\_MESHDATA

This routine is similar to `USER_GETVAR`, in that it obtains arrays containing mesh related data. The subroutine looks for the requested variable on the `/FLOW/MESH` stack, and returns a pointer to it, and its size.

```

SUBROUTINE USER_GET_MESHDATA (WHAT,WHERE,CACTION,aCERACT,CRESLT,
&
      NVAR,pVAR, CZ,DZ,IZ,LZ,RZ)
CI WHAT      : User name of variable.
CI WHERE     : User name of locale.
CI CACTION   : Action = 'RETURN' or 'RELEASE'
CI CERACT    : Error action = 'STOP', 'SKIP' or 'WARN'
CO CRESLT    : Result of attempt to get variable, e.g. 'GOOD' or 'BADL'
CO pVAR      : Address in stack for the result.
CO NVAR      : Number of words in stack used for the variable.

```

The arguments are of type:

```

CHARACTER*(*) WHAT, WHERE, CACTION, CERACT, CRESLT
INTEGGER NVAR
__stack_point__ pVAR

```

`USER_GET_MESHDATA` is available only in user CEL routines. Also, the range of obtainable arrays depends on the current solver locale, which may be determined by a prior call. For details, see [USER\\_CALC\\_INFO \(p. 506\)](#). If you try to access a variable on an invalid solver locale, then `USER_GET_MESH_INFO` returns `CRESLT = 'BADL'`.

The table below lists permitted user mesh variable names and locations, and the permitted solver locales on which they may be obtained. It also describes the name, type, and shape of the associated solver variable that is returned. A description of the integer variables defining the array shape is available in [USER\\_GET\\_MESH\\_INFO \(p. 507\)](#). The values of these variables may be obtained by a prior call to `USER_GET_MESH_INFO`.

Note that, unlike `USER_GETVAR`, this routine returns a pointer to the actual solver array, not a copy of it.

WHAT	WHERE	Permitted Solver Locales	Solver Array Shape	Variable Type	Description
Coordinates	Vertices	Any	Crdvx (NDIM, NVX)	REAL	Coordinates of mesh vertices
Coordinates	Integration Points	ELS*, IELG*, BELG*	Crdlp (ISEL_S:ISEL_F, NDIM, IP1:IP2)	REAL	Coordinates of integration points
Coordinates	Faces	BELG*	CrdFc	REAL	Coordinates of faces

WHAT	WHERE	Permitted Solver Locales	Solver Array Shape	Variable Type	Description
Volume	Vertices	Any	(ISFC_S:IS-FC_F, NDIM) ContVol (NVX)	REAL	Control cell volumes
Volume	Elements	ELS*, IELG*, BELG*	VolEl (ISEL_S:ISEL_F)	REAL	Element volumes
Volume	Sectors	ELS*, IELG*, BELG*	VolSec (ISEL_S:ISEL_F, NVxEl)	REAL	Control cell sector volumes
Area	Faces	FCS*, BELG*	ArFc (ISFC_S:IS-FC_F)	REAL	Areas of faces
Area	Integration Points	BELG*	ArIp (ISFC_S:IS-FC_F, IP1:IP2)	REAL	Areas of sectors surrounding boundary integration points
Normal Area Vector	Integration Points	ELS*, IELG*, BELG*	NarvIp (ISEL_S:ISEL_F, NDIM, IP1:IP2)	REAL	Inward-directed normal area vectors at integration points
Normal Area Vector	Faces	BELG*	NarvFc (ISFC_S:IS-FC_F, NDIM)	REAL	Inward-directed normal area vectors at faces
Normal Unit Vector	Integration Points	IELS*, IELG*, BELG*	NunvIp (ISEL_S:ISEL_F, NDIM,IP1:IP2)	REAL	Inward-directed normal unit vector at integration points
Normal Unit Vector	Faces	BELG*	NunvIp (ISFC_S:IS-FC_F, NDIM)	REAL	Inward-directed normal unit vector at faces

WHAT	WHERE	Permitted Solver Locales	Solver Array Shape	Variable Type	Description
Near Wall Distance	Elements	BELG*	NWDIST  (ISFC_S:ISFC_F)	REAL	Distance from element centroid to wall
Element-to-vertex Connectivity	Elements	ELS*,  IELG*,  BELG*	KVxEI  (ISEL_S:ISEL_F,  NVxEI)	IN-TEGER	List of vertex numbers connected to each element

### 18.5.2.7. USER\_GET\_PHYS\_INFO

This routine gets physics information on zones and phases, and stores under the /USER data area. This subroutine stores useful physical model data under a directory named '/USER/'//CDIR. It does so by looking inside /FLOW/PHYSICS/, and copying required data. It is available in user CEL and junction box routines.

```

SUBROUTINE USER_GET_PHYS_INFO (WHO,ACTION,CERACT,
&                               WHEN,CZONE,CPHASE,CDIR,CRESLT,
&                               CZ,DZ,IZ,LZ,RZ)
CI WHO          : Name of routine making original call.
CI ACTION       : 'GET' & 'DELETE'
CI CERACT       : Error Action = 'STOP', 'WARN', 'SKIP'.
CI WHEN        : Only 'LATEST' supported at present.
CI CZONE       : Zone Name
CI CPHASE      : Phase Name (blank for zonal information only)
CV CDIR        : Subdirectory name of /USER into which to put info.
CO CRESLT      : Result = 'GOOD', 'ERR' or 'DIR'.

```

The arguments are of type:

```

CHARACTER*(*) WHO,ACTION,CERACT,WHEN,CZONE,CPHASE,CDIR
CHARACTER*(4) CRESLT

```

There are two ways in which you can choose a name for a directory under which to place the data. Either:

- Create a directory named CDIR below /USER, and pass the name down as an argument to USER\_GET\_PHYS\_INFO. In this case, the requested information is placed in the specified directory. For more information, see [CFX Memory Management System \(MMS\) \(p. 526\)](#) and [Directories \(p. 529\)](#).
- Alternatively, if CDIR does not exist under /USER/, for example CDIR = '', when passed down to USER\_GET\_PHYS\_INFO, then the program generates a name for a directory in which to place the data. The generated name is of the form PHYS\_INFO/Czone/Locale/. This directory name will be passed back in the argument CDIR.

If you choose the second alternative, then CDIR must be declared to be sufficiently long to hold this directory name. If not, then an error is generated, and CRESLT = 'DIR' is returned.

Setting ACTION = 'GET' copies required data into the specified directory name. Setting ACTION = 'DELETE' deletes the directory. The data under CDIR can be subsequently obtained using the PEEK facilities. For details, see:

- [CFX Memory Management System \(MMS\) \(p. 526\)](#)

- *Setting and Reading Individual Values* (p. 537).

Examples of use of USER\_GET\_PHYS\_INFO are available in the Junction Box 2 example. For details, see *Junction Box Example 2: Integrated Residence Time Distribution* (p. 558).

The information copied depends on your setting of CZONE and CPHASE, as described below.

#### 18.5.2.7.1. Zonal Information: CZONE = 'ZNm', CPHASE = ''

If you specify a valid solver zone name, and a blank phase name, then it is assumed that you require physical data specific to that zone. The information stored under CDIR is tabulated below:

Variable Names	Variable Type	Description
PHYTYPE	CHARACTER * (MXDNAM)	zone physical type = 'FLUID' or 'SOLID'
IZN	INTEGER	zone number
NPHASE	INTEGER	number of phases defined on the zone
PREF	REAL	reference pressure
TREF	REAL	reference temperature
GX, GY, GZ	REAL	components of gravity vector
CPHASE (NPHASE)	CHARACTER * (MXDNAM)	character array containing internal solver names of phases; of the form 'FLm', or 'SLm', m = integer, for fluid and solid phases respectively
CPP(NPP)	CHARACTER * (MXDNAM)	character array containing internal solver names of phase pairs; of the form 'PPm', m = integer

#### 18.5.2.7.2. Phase Information: CZONE = 'ZNm', CPHASE = 'FLm' or 'SLm'

If you specify a valid solver zone name, and a valid phase name, then it is assumed that you require physical data specific to that phase on that zone. The information stored under CDIR is tabulated below:

Variable Names	Variable Type	Description
IPHASE	INTEGER	phase number
CMAT	CHARACTER * (MXDNAM)	internal solver name of material associated with this phase; of the form 'MTm', m = integer
CTURBM	CHARACTER * (MXDNAM)	internal solver name of turbulence model associated with this phase
CHEATM	CHARACTER * (MXDNAM)	internal solver name of heat transfer model associated with this phase
CBUOYM	CHARACTER * (MXDNAM)	internal solver name of buoyancy model associated with this phase
CCOMBM	CHARACTER * (MXDNAM)	internal solver name of combustion model associated with this phase

Variable Names	Variable Type	Description
MORPHOLOGY	CHARACTER * (MXD-NAM)	internal solver name of morphology associated with this phase

The table below translates internal solver names for physical models

Variable Names	Variable Value	Description
CTURBM	' '	laminar
CTURBM	'EVM:ALG:CX'	Baldwin-Lomax
CTURBM	'EVM:ALG:DIS'	Dispersed Phase Zero Equation model
CTURBM	'EVM:ALG:LES'	LES (Smagorinsky)
CTURBM	'EVM:K-E'	Standard k- $\epsilon$ model
CTURBM	'EVM:K-E:RNG'	RNG $k - \epsilon$ model.
CTURBM	'EVM:K-O'	Wilcox $k - \omega$ model
CTURBM	'EVM:K-O:SST'	Menter Shear Stress Transport (SST) model
CTURBM	'EVM:K-O:SST:DES'	DES=Menter Shear Stress Transport (SST) model
CTURBM	'EVM:K-O:BSL'	Menter Baseline (BSL) model
CTURBM	'EVM:EVT'	Menter Eddy Viscosity Transport model
CTURBM	'RSM:TED'	Reynolds Stress Model (Launder, Reece and Rodi)
CTURBM	'RSM:TED:SSG'	SSG Reynolds Stress model
CTURBM	'RSM:TED:QI'	QI Reynolds Stress model
CTURBM	'RSM:TEF'	Reynolds Stress-Omega model
CTURBM	'RSM:TEF:BSL'	Reynolds Stress-Omega model with BSL Omega equation
CHEATM	'ISOTHERMAL'	isothermal.
CHEATM	'THERMAL_H'	Thermal Energy model
CHEATM	'TOTAL_H'	Total Energy model
CBUOYM	'DEN*G'	buoyancy force = $\rho \mathbf{g}$
CBUOYM	'DENDIF*G'	buoyancy force = $(\rho - \rho_0) \mathbf{g}$
CBUOYM	'BOUSSINESQ'	Boussinesq approximation

### 18.5.2.8. USER\_GET\_TRANS\_INFO

The USER\_GET\_TRANS\_INFO routine provides access to time variables during transient simulations. It stores information in the '/USER'//CDIR data area. It is available in user CEL and junction box routines.

```
SUBROUTINE USER_GET_TRANS_INFO(WHO, ACTION, CDIR, CZ, DZ, IZ, LZ, RZ)
C
```

The last five arguments are the stacks as usual. All the other arguments are character strings and are defined as follows:

```
CI WHO          : Name of routine making original call.
CI ACTION       : 'GET' & 'RELEASE'
```

```

CC
CC
CV CDIR      : Sub-directory name of /USER into which to put info.
CC           If blank on entry, this is set equal to
CC           TRANS_INFO
CC           If non-blank on entry, it is unchanged, and treated
CC           as a user supplied directory name.

```

Calling this routine with ACTION = 'GET' creates and stores the transient information in '/USER/'//CDIR whereas ACTION = 'RELEASE' deletes it. If CDIR is blank, the directory 'TRANS\_INFO' will be used.

After calling USER\_GET\_TRANS\_INFO the following variables will be available in '/USER/'//CDIR:

Variable Names	Description
ATSTEP	Accumulated time step counter
CTSTEP	Current time step counter
ACLOOP	Accumulated coefficient loop counter
NCLOOP	Current coefficient loop counter
DT	Current time step size
ATIME_END	Accumulated simulation time at the end of time step
CTIME_END	Current simulation time at the end of time step
ATIME_MID	Accumulated simulation time at the middle of time step
CTIME_MID	Current simulation time at the middle of time step
ATIME	Accumulated simulation time
CTIME	Current simulation time

By default, ATIME is the same as ATIME\_END and CTIME is the same as CTIME\_END, but they can be changed to the 'middle of timestep' values using the expert parameter 'time value option=2'.

For an example involving USER\_GET\_TRANS\_INFO, see Junction Box Example 3: Timestep Control.

### 18.5.2.9. USER\_ASSEMBLE\_INFO

This is a utility to obtain information about the equation being assembled when a call to a User Fortran routine is made during the computation of a boundary condition or a source. The call is made as follows:

```

CALL USER_ASSEMBLE_INFO (ACTION, CGROUP, CEQN, CTERM, CPVAR,
&                          CLVAR, CPATCH, CRESLT,
&                          CZ, DZ, IZ, LZ, RZ)

```

The last five arguments are the stacks as usual. All the other arguments are character strings and are defined as follows:

```

C -----
C Arguments
C -----
C
CI ACTION      : 'GET' or 'GET_USER'

```

```

C
CO CRESLT      : Result of attempt to return information. See details.
CO CGROUP     : Equation group being assembled.
CO CEQN       : Equation being assembled.
CO CTERM      : Term or term type being assembled.
CO CPVAR      : Principal variable of equation being assembled.
CO CLVAR      : Linearization variable - see details.
CO CPATCH     : Patch name.
C
C -----
C Details
C -----
C
C ACTION:-
C = 'GET'      => Get all the field names that exists returned in
C               internal solver form.
C = 'GET_USER' => As for 'GET' except that user aliases are returned.
C
C CRESLT:-
C If complete information can be provided then CRESLT = 'GOOD'
C If partial information is provided then CRESLT = 'SOME'
C Otherwise CRESLT = 'NONE' if no information can be found.
C CRESLT = 'BIG' if actual argument string lengths are too short to
C hold the data required. This argument should be declared to be *(4).
C Other output arguments:-
C These should be declared to be *(MXDNAM) for ACTION='GET' and they
C must be long enough to hold the user's names, a safe declaration is
C *(MXLEN_XALIAS).

```

CTERM is returned with the term TYPE if ACTION = 'GET\_USER' rather than the term name. Possible term types are: FTRANS.VOL, SOURCE.VOL or TRANS.VOL for volumetric terms and ADVECT.SUR, DIFFUS.SUR, FLUX.SUR, GRAD.SUR, LAPLACE.SUR, MSFLOW.SUR and STRESS.SUR.

CLVAR is the variable on which the term operates, or for a source term, it is the one of the variables used to linearize the term. Generally this will be identical to CPVAR but for coupled systems of equations it might be the principal variable of any of the equations in the system. For a deferred term, for example, the  $dP/dt$  term in the energy equation, it might be ANY variable.

An example of the use of USER\_ASSEMBLE\_INFO is available in [User CEL Example 2: Using Gradients for an Additional Variable Source](#) (p. 545).

### 18.5.2.10. GET\_PARALLEL\_INFO

The GET\_PARALLEL\_INFO routine provides access to information about the parallel run mode and partitioning details from within any user CEL function or from within junction box routines. It can be called in the following ways to look up the variables RUNMOD, PARMOD, OWNPAR and NPARD:

```

CALL GET_PARALLEL_INFO ('RUNMOD', RUN_MODE, CNAME, CRESLT)
CALL GET_PARALLEL_INFO ('PARMOD', PAR_MODE, CNAME, CRESLT)
CALL GET_PARALLEL_INFO ('OWNPAR', OWN_PAR, CNAME, CRESLT)
CALL GET_PARALLEL_INFO ('NPARD', NUM_PAR, CNAME, CRESLT)

```

- RUNMOD describes the run mode as either serial or parallel. It is an integer variable where 0 corresponds to serial and 1 to parallel.
- PARMOD describes the parallel mode and can be master or slave. It is an integer variable where 1 corresponds to the master process and 2 to a slave process.
- OWNPAR is an integer variable that gives the partition number on the current process.
- NPARD is an integer variable that gives the total number of partitions.

The variables RUN\_MODE, PAR\_MODE, OWN\_PAR and NUM\_PAR are used to store the values locally and should be declared as integer variables in your subroutine. They can be named differently to the names



CHARACTER\*(\*) TYPE,USER\_NAME,  
& SOLVER\_ZONE,SOLVER\_NAME,OPER,CRESLT

The character string TYPE denotes the type of entity for which a name conversion is required. Permitted types are tabulated below, together with descriptions of input and output names.

<b>TYPE</b>	<b>Description</b>	<b>Example User Name Format</b>	<b>Solver Name Format</b>
'Domain'	domain name  = zone name	'Pipe'	'ZNn'
'Subdomain'	subdomain name  = volume patch name	'Heated Region'	'VPn'
'Boundary' or 'Bcp'	boundary condition patch name	'Inlet'	'BCPn'
'Material'	material name (library variable)  SOLVER_ZONE may be blank	'O2'	'MTm'
'Monitor Point'	Monitor Point name	'MonitorPoint1'	'MPn'
'Source Point'	Source Point name	SourcePoint1	'SPn'
'Radiometer'	Radiometer name  SOLVER_ZONE may be blank	Radiometer1	'RADMONn'
'Rigid Body'	Rigid Body name  SOLVER_ZONE may be blank	RigidBody1	'Rbn'
'Region'	Region name  SOLVER_ZONE may be blank	Region1	'REGn'
'Additional Variable'	Additional Variable Name	Water.Phi1	for example 'QPU-MASS_AVm_FLn'
'AV'	Additional Variable name (library variable)  SOLVER_ZONE may be blank	'Phi'	'AVm'
'Phase'	phase name  = fluid or solid name	'Water.'  'Copper'	for example, 'FLn'  for example 'SLn'

TYPE	Description	Example User Name Format	Solver Name Format
'Variable'	variable name	'Water.Velocity'	for example 'VEL_FLn'
		'Water.O2.Mass Fraction'	for example 'MAS-FRN_MTm_FLn'
		'Water.Phi1'	for example 'QPU-MASS_AVm_FLn'
		'Copper.Temperature'	for example 'TEMP_SLm'

**Note:**

- The SOLVER\_ZONE name is output for all entity types, *except* for TYPE = 'Variable', in which case it is required as an input variable.
- OPER = 'GRADIENT' is returned if TYPE = 'Variable', and the USER\_NAME is the name of a variable gradient. Otherwise, OPER = '' is returned.
- The format of the name returned using 'Additional Variable' (for example, 'QPUMASS\_AV2\_FL1') is the format accepted by many internal utility routines.

**18.5.3.2. CONVERT\_NAME\_S2U**

Converts solver names to user names, for domains, subdomains, boundary conditions, materials, phases and variables. It is available in both user CEL and junction box routines.

```

SUBROUTINE CONVERT_NAME_S2U (TYPE, SOLVER_NAME, OPER,
& USER_NAME, CRESLT,
& CZ, DZ, IZ, LZ, RZ)
CC TYPE          : Data Type
CI SOLVER_NAME   : Solver Name.
CC OPER          : Operator, if applicable
CO USER_NAME    : User name
CO CRESLT        : ='GOOD' for a successful conversion.

```

The arguments are of type:

```
CHARACTER*(*) CTYPE, SOLVER_NAME, OPER, USER_NAME, CRESLT
```

This performs the reverse operation. For details, see [CONVERT\\_NAME\\_U2S](#) (p. 518). See the table for TYPE name conventions, as well as for full descriptions of input and output names.

Examples of its use are provided in:

- [User CEL Example 2: Using Gradients for an Additional Variable Source](#) (p. 545)
- [Junction Box Example 2: Integrated Residence Time Distribution](#) (p. 558)
- [Junction Box Example 4: Solver Control](#) (p. 567).

**18.5.3.3. VAR\_ALIAS**

This function returns the alias (user name) of the input variable CVAR (solver format).

```
CHARACTER*(*) FUNCTION VAR_ALIAS(CVAR, CZ, DZ, IZ, LZ, RZ)
```

The arguments are of type:

```
CHARACTER*(*) CVAR
```

Its functionality is superseded by [CONVERT\\_NAME\\_S2U](#) (p. 520), but it is retained, as it may be quicker and easier to use in certain circumstances. For details, see [CONVERT\\_NAME\\_S2U](#) (p. 520).

### 18.5.3.4. LOCALE\_ALIAS

Returns the alias (user name) of the input locale LOCALE (solver format).

```
CHARACTER*(*) FUNCTION LOCALE_ALIAS(LOCALE, CZ,DZ,IZ,LZ,RZ)
```

The arguments are of type:

```
CHARACTER*(*) LOCALE
```

Its functionality is superseded by [CONVERT\\_NAME\\_S2U](#) (p. 520), but it is retained, as it may be quicker and easier to use in certain circumstances. For details, see [CONVERT\\_NAME\\_S2U](#) (p. 520).

### 18.5.3.5. CONVERT\_USER\_NAMES

Converts user variable names to solver variable names. The functionality of this routine is superseded, but it is included for back compatibility. For details, see [CONVERT\\_NAME\\_U2S](#) (p. 518).

```

SUBROUTINE CONVERT_USER_NAMES(SOLVERR_ZONE,USER_NAME,SOLVER_NAME,OPER,
&                               CRESLT,CZ,DZ,IZ,LZ,RZ)
CC -----
CC      Input
CC -----
CC SOLVERR_ZONE   : Zone Name (solver format)
CC USER_NAME     : User name
CC -----
CC      Output
CC -----
CC SOLVER_NAME    : Solver name of form Var_Mat_Phase.
CC OPER          : Operator, if applicable.
CC CRESLT        : ='GOOD' for a successful conversion.

```

The arguments are of type:

```
CHARACTER*(*) SOLVERR_ZONE,USER_NAME,SOLVER_NAME,OPER,CRESLT
```

OPER = 'GRADIENT' is returned if the user variable name is a gradient. Otherwise, OPER = '' is returned.

### 18.5.3.6. GET\_PHASE\_FROM\_VAR

Returns the phase name from the input variable name CVAR.

```

SUBROUTINE GET_PHASE_FROM_VAR ( CVAR, PHASE )
CC CVAR Variable Name (Solver Format)
CC PHASE Fluid or solid name (Solver Format. Blank if not present).
The arguments are of type:
CHARACTER*(*) CVAR, PHASE

```

On exit, PHASE = 'FLn' for a fluid phase, or 'SLn' for a solid phase, where *n* is an integer.

Examples of its use are available. For details, see [User CEL Example 2: Using Gradients for an Additional Variable Source](#) (p. 545).

### 18.5.3.7. PARSMP

This subroutine provides the property, material and fluid components of the input variable CVAR.

```

SUBROUTINE PARSMP(WHO,CVAR,CPROP,CMAT,CPHASE,LBULK,
& LNOPHASE,CERACT,CRESLT,CZ,DZ,IZ,LZ,RZ)
CC CVAR      : Target variable name (Solver Format)

```

```
CO CPROP      : Material property (i.e. class) part of name
CO CMAT       : Material (i.e. component) part of name
CO CPHASE     : Fluid part of name
CO LBULK      : True if material name is missing from full name
CO LNOPHASE   : True if phase name is missing from full name
```

The arguments are of type:

```
CHARACTER*(*) WHO,CVAR,CPROP,CMAT,CPHASE,CERACT,CRESLT
LOGICAL LBULK,LNOPHASE
```

## 18.5.4. Character Handling

The following section outlines some useful character handling functions and subroutines that operate on Fortran character variables.

Functions are provided for carrying out internal formatting in a standard manner, without using Fortran format statements. Thus, you can convert numbers (double precision, integer or real) to and from their character representations. Using the string editing facilities it is possible to remove redundant spaces from a character string, find the *active length* of a character string, and split a character string into separate strings by treating spaces as separators.

### 18.5.4.1. CFROMD

```
CHARACTER*(*) FUNCTION CFROMD (DVAL)
DOUBLE PRECISION DVAL (input)
```

This function converts a double precision number DVAL into a character string, of the form ' -1.2345678D+09' (in this case NFIG=8). The number of figures contained in CFROMD is determined by NFIG. In the calling subroutine, CFROMD must be declared EXTERNAL and to be CHARACTER\*n where n is at least of size NFIG+7.

Note that CFROMD produces a right-justified character string (that is, padded with leading blank spaces).

### 18.5.4.2. CFROMI

```
CHARACTER*(*) FUNCTION CFROMI (IVAL)
INTEGER IVAL (input)
```

This function converts an integer IVAL into a character string, of the form ' -123456'. The number of figures contained in CFROMI is chosen purely according to the value of IVAL. In the calling subroutine, CFROMI must be declared EXTERNAL and to be CHARACTER\*n where n is at least of size m+2, where m is the maximum number of figures that will be needed to represent any integer IVAL.

Note that CFROMI produces a right-justified character string (that is, padded with leading blank spaces).

### 18.5.4.3. CFROMR

```
CHARACTER*(*) FUNCTION CFROMR (RVAL)
REAL RVAL (input)
```

This function converts a real number RVAL into a character string, of the form ' -1.2E+05' (in this case NFIG=2). The number of figures contained in CFROMR is determined by NFIG as described above. In the calling subroutine, CFROMR must be declared EXTERNAL and to be CHARACTER\*n where n is at least of size NFIG+7.

Note that CFROMR produces a right-justified character string (that is, padded with leading blank spaces).

### 18.5.4.4. DFROMC

```
DOUBLE PRECISION FUNCTION DFROMC (CVAL)
CHARACTER*(*) CVAL (input)
```

This function converts a character string CVAL into a double precision number. If CVAL is not a valid string for producing a double precision number then the result is 0.

### 18.5.4.5. IFROMC

```
INTEGER FUNCTION IFROMC (CVAL)
CHARACTER*(*) CVAL (input)
```

This function converts a character string CVAL into an integer. If CVAL is not a valid string for producing an integer then the result is 0.

### 18.5.4.6. RFROMC

```
REAL FUNCTION RFROMC (CVAL)
CHARACTER*(*) CVAL (input)
```

This function converts a character string CVAL into a real number. If CVAL is not a valid string for producing a real number then the result is 0.

### 18.5.4.7. LENACT

```
INTEGER FUNCTION LENACT (CSTR)
CHARACTER*(*) CSTR (input)
```

This function gives the position of the last character in the string CSTR, which is *not* a space. Thus, it gives the *active length* of the string.

LENACT must be declared EXTERNAL in any calling subroutine.

### 18.5.4.8. EDIT

```
SUBROUTINE EDIT (CSTR, IL, IU, COM, IAC)
CHARACTER*(*) CSTR (input/output)
INTEGER IL,IU (input)
CHARACTER*(*) COM (input)
INTEGER IAC (output)
```

This subroutine edits a substring of CSTR. The action taken depends on the value of the command string, COM. Four possible actions can be taken:

- COM='U' ⇒ convert to upper case;
- COM='L' ⇒ convert to lower case;
- COM='S' ⇒ remove all spaces;
- COM='C' ⇒ remove leading and trailing spaces and compress all other contiguous spaces to a single space.

The edit is performed on a substring of CSTR determined by the values of IL and IU. The edit starts at character, I1, and ends at character, I2, where these are determined as follows. I1 is the maximum of IL and 1; thus, if IL is less than or equal to zero the first character in CSTR is the beginning character. I2 is the minimum of the string length of CSTR and IU. Additionally, if IU is less than or equal to zero, I2 is set to the length of CSTR. If I2 is less than I1, then no edit is performed.

IAC is returned with the length of the substring edited if COM is 'L' or 'U.' If COM is 'S' or 'C' it is returned with the active length of the substring edited, see LENA CT above.

Note that if COM is not set to a valid character, then EDIT simply returns without taking any action.

Note that MAPCHA must be called before EDIT can be used.

#### 18.5.4.9. IOPNAM

```
SUBROUTINE IOPNAM (CNAME, LENSTR, NCHAR, NNAME, LFULL, MXNAME)
CHARACTER*(*) CNAME (input)
INTEGER LENSTR, MXNAME (input)
INTEGER NCHAR(MXNAME), NNAME (output)
LOGICAL LFULL (output)
```

This subroutine locates words between slashes inside a string, and is useful for parsing data area path names. It takes the path name given in CNAME and returns a pointer to the start of each part of the path name within the string CNAME, in the array NCHAR, starting at the left hand end of the string.

MXNAME is used as the dimension of NCHAR and should be set to the maximum number of names anticipated in the path name

LENSTR is the active length of the string CNAME and should be determined by calling LENA CT for CNAME prior to the call to this routine.

NNAME provides a count of the separate names in the path name.

The logical flag LFULL is set to indicate whether the path name provided is a full one or a relative one. LFULL=.TRUE. if the first character of CNAME is a '/' and .FALSE. otherwise.

For instance, the path name (CNAME) '/TIME0/VEL/UVEL' would return:

LFULL=.TRUE. (It is a full path name.)

NCHAR(1) = 2 (The first name in the path (TIME0) starts at character 2 of CNAME.)

NCHAR(2) = 8 (The second name in the path (VEL) starts at character 8 of CNAME.)

NCHAR(3) = 12 (The third name in the path (UVEL) starts at character 12 of CNAME.)

NNAME=3 (There are 3 names in the path name.)

#### 18.5.4.10. CCATI

```
CHARACTER*(*) FUNCTION CCATI (STRING, NUMBER)
CHARACTER*(*) STRING:- String prefix.
INTEGER NUMER:- Number to be post-fixed as a string.
```

This function is used to concatenate a string and number. CCATI must be declared external in the routine calling it and must be typed to a length sufficient to hold the concatenated string and number. If CCATI is too short to hold the result, then it will be filled with asterisks. If CCATI is longer than necessary then it is padded to the right with blanks. For example, if STRING='FCS' and NUMBER = 4 then CCATI returns 'FCS4.'

## 18.5.5. Output Routines

### 18.5.5.1. MESSAGE

```
SUBROUTINE MESSAGE (COMMAND, MESSAGE)
CHARACTER*(*) COMMAND, MESSAGE (input)
```

This subroutine writes the character string MESSAGE. This character string can be written directly to the output file (that is, to standard output), or it can be written into a buffer, which may later be emptied into the output file.

The character string COMMAND determines exactly what is done with MESSAGE.

Usually, COMMAND will be set to 'WRITE' or 'WRITE-ASIS'. In that case, MESSAGE is written directly to the output file.

**COMMAND = 'WRITE'** indicates that MESSAGE will be rearranged to remove redundant spaces, and (if possible) to ensure that no word is broken at the end of a record.

**COMMAND = 'WRITE-ASIS'** means that MESSAGE will be written without rearrangement, except that an end-of-record is inserted every LENREC characters. Each call to MESSAGE for 'WRITE' or 'WRITE-ASIS' starts a new record in the output file.

The buffer has a capacity of 4096 characters. Once it becomes full, any further writes to the buffer will be ignored, until it has been emptied or written to the output file.

Setting COMMAND to be 'BUFF' or 'BUFF-ASIS' causes MESSAGE to be written into the buffer (and not the output file).

**COMMAND = 'BUFF'** asks for MESSAGE to be rearranged to remove redundant spaces.

**COMMAND = 'BUFF-ASIS'** just writes MESSAGE into the buffer without rearrangement.

Each of these calls to MESSAGE does not generally insert an end-of-record; when the buffer is finally written to the output file, only the LENREC character-record length is used to determine where records end. However, it is possible to forcibly insert an end-of-record into the buffer, by calling MESSAGE with **COMMAND = 'BUFF-NL'**. For this call the contents of MESSAGE are ignored.

To write the buffer contents to the output file, and empty the buffer, just call MESSAGE with **COMMAND = 'BUFF-OUT'**. Wherever possible, spaces will be inserted to ensure that no word is broken by an end-of-record. MESSAGE will be ignored in this call.

To empty the buffer without writing the contents to the output file, simply set **COMMAND = 'BUFF-DEL'**. Again, MESSAGE is ignored for this value of COMMAND.

Any other value for COMMAND is treated as 'WRITE'.

Note that the character handling functions described can be used to put numbers into a message. For example:

```
CALL MESSAGE( 'WRITE', 'Max Temp is '//CFROMR(TMAX)//' at vertex'//
& CFROMI(IVX))
```

For details, see [Character Handling \(p. 522\)](#).

### 18.5.5.2. ERRMSG

This routine is used to print out error messages. Output can be buffered to allow the message to be gathered from various substrings.

```
SUBROUTINE ERRMSG(MESSAGE)
CHARACTER*(*) MESSAGE:- Message string to be output directly or buffered.
```

Simple strings will be written directly. If the first three characters of the message are `'*B*'` then the following calls to ERRMSG will not output any message but will copy the strings into a buffer. The buffer will be output when a string is passed to ERRMSG with the characters `'*E*'` as the last three characters. The following sets of calls all produce the same message:

```
CALL ERRMSG('My name is ' // first_name // last_name)
CALL ERRMSG('*B*My name is ')
CALL ERRMSG(first_name)
CALL ERRMSG(last_name // '*E*')
CALL ERRMSG('*B*')
CALL ERRMSG('My name is ')
CALL ERRMSG(first_name)
CALL ERRMSG(last_name)
CALL ERRMSG('*E*')
```

When using the buffer facility, it is strongly recommended that the `'*B*'` and `'*E*'` strings be passed as separate calls to ERRMSG as in the last example. Note that the first example might be illegal Fortran if either of the string variables `first_name` or `last_name` were declared to be of length `*(*)` and the second would be illegal if `last_name` was declared `*(*)`.

## 18.6. CFX Memory Management System (MMS)

The following topics will be discussed:

- [Introduction to the Memory Management System \(p. 526\)](#)
- [Error Conventions \(p. 527\)](#)
- [Stack Pointers \(p. 529\)](#)
- [Subroutines \(p. 529\)](#)

### 18.6.1. Introduction to the Memory Management System

This introduction to the memory management system, as used in the CFX-Solver, allows you to operate on and pass around your own data structures between user routines.

All arrays (except perhaps for very small local arrays) are stored in global stacks, there being one stack for REAL (RZ), one for DOUBLE PRECISION (DZ), one for INTEGER (IZ), one for CHARACTER (CZ), and one for LOGICAL (LZ). Similarly, any scalar variables that are not local may be stored in a stack. Such sections of the stack (arrays or individual scalars) be referred to as data areas.

The total number of data areas available in the memory management system, also referred to as the **catalogue size**, can be set by the programmer.

Within each stack, data areas can be created and deleted, but each individual data area will be contiguous.

When data areas are deleted, holes appear in the stack, but the stack catalogue is managed so as to ensure that no two holes are adjacent (that is, holes will be merged). A new data area will usually be placed in the smallest hole available, which is large enough to contain it.

Some data areas can be flagged as “vulnerable” so that, when the stack is full, one or more of these will be deleted automatically to make space. However, if the stack does not become full then all vulnerable data areas will remain unchanged.

The naming convention for data areas follows a UNIX-like structure, employing the concept of directories. Thus, a data area can be referred to by its full path name /TIME-0/ GRID2/ VEL, say, or by its local name VEL, provided the current directory is /TIME-0 /GRID2/. It is also possible to refer to data areas and directories using relative path names, GRID2/ VEL, say, if the current directory is /TIME-0/. As in UNIX, the current and parent directories may be referenced by the character strings ‘.’ and ‘..’. Note that ‘/’ is referred to as the *home directory*, and that ‘HOME’ is not allowed as a directory or data area name.

There are utilities available for changing the current directory, pushing and popping to directories, creating new directories, creating new data areas, and so on. It is also possible to link directories and data areas.

Data area and directory names are currently limited to, at most, MXDNAM = 20 characters. Full path names of directories and data areas are currently limited to at most MXPNAM = 200 characters. MXDNAM and MXPNAM are both declared in the include file MMS.h, which should be included in all routines requiring character variables of these lengths to be declared.

Example:

```
#include "MMS.h"
CHARACTER*(MXDNAM)  VARNAME
CHARACTER*(MXPNAM)  PATHNAME
....
....
VARNAME = 'MY_VARIABLE'
PATHNAME = '/USER_DATA/MY_VARIABLE'
```

As some compilers save local variables, the use of character variables of length MXPNAM should be kept to a minimum.

## 18.6.2. Error Conventions

This section summarizes the conventions adopted for announcing and controlling errors in the memory management system, and fully describes the role of the character variables CERACT and CRESLT, which occur in many of the argument lists for subroutines.

A typical memory management subroutine contains two character strings in its argument list: CERACT and CRESLT. CERACT is passed as input to the subroutine, and determines the action to be taken when there is an error. CRESLT is set as output, and indicates the result of the call to the subroutine. If the subroutine call is successful then CRESLT = ‘GOOD’ on exit.

Both CERACT and CRESLT should be declared as CHARACTER\*4 in the calling subroutine.

Below are the standard values that can be set for CERACT.

```
CERACT = `SKIP`
```

In the event of an error, there is no warning message and the program continues (control being returned to the calling subroutine).

```
CERACT = `STOP`
```

In the event of an error, an error message is produced and the program is stopped.

```
CERACT = `WARN`
```

In the event of an error, a warning message is produced and the program continues (control being returned to the calling subroutine).

If any other value is set for CERACT, then this is equivalent to 'STOP'.

There are many values that can be set for CRESLT by the various memory management subroutines, and these are listed below.

<b>CRESLT</b>	<b>Description</b>
ADRS	The address passed for locating an array entry (for example, JADRES in PEEK and POKE subroutines) is out of range.
BIG	When using POKECA or POKECS to set a character string, or even when using PEEKCA to obtain a character string, this value for CRESLT indicates that the character variable passed down is too big for this data area. Conversely, when using PEEKCS, to obtain a character string, this value for CRESLT indicates that the character variable passed to contain it is too small. This error code can also be returned by the subroutine SQZDAT, to show that you are trying to increase the length of a data area (or give it a negative length). Finally, this error code will be returned by subroutine MMSTAT if LENINF is set too small.
BSL	The character string passed down to PEEKCA or POKECA, to contain an entry from a character array, has a length inconsistent with the total length of the character array data area (BSL = Bad String Length).
DAT	The name passed to the subroutine represents a data area, when it should (perhaps) be a directory.
DIR	The name passed to the subroutine represents a directory, when it should be a data area.
END	There are no more data areas or subdirectories to be found.
ERR	There is some unspecified error, not covered elsewhere in this list.
FCAT	The memory management catalogue is full (catalogue size has been exceeded). To increase the catalogue size, see <a href="#">Starting the CFX-Solver from the Command Line in the CFX-Solver Manager User's Guide</a> and <a href="#">Configuring Memory for the CFX-Solver in the CFX-Solver Manager User's Guide</a> .
FULL	The memory management stack is full.
GOOD	The subroutine successfully achieves what was asked of it.
ILEG	The name passed to the subroutine is illegal. This value of CRESLT is returned if one of the directories in the path name does not exist, or if the path name has an illegal character or is too long.
NLNK	The name passed to the subroutine is an existing data area or directory in its own right, when it should have been created by a call to MAKLNK. In the case of MMSTAT, this indicates an internal error within this subroutine.
NONE	The name passed to the subroutine could not be found.
OLD	The name passed to the subroutine is already in use.
SIZE	There is a problem with the size requested.
TEMP	The subroutine cannot find a temporary name for workspace.
TYPE	The data area is of an inappropriate type (integer, real, and so on.) for this particular POKE or PEEK subroutine. In the case of MMSTAT, this error condition implies that the value set for CTYPE has not been recognized.
OPTS	Illegal options passed to FNDFIL.

### 18.6.3. Stack Pointers

Data on the stacks is often first accessed by name then manipulated efficiently by using a pointer. By convention, a stack pointer is a variable with a name starting with a small "p". It is declared as of type `_stack_point_`, for example:

```
_stack_point_ pVAR
```

`_stack_point_` is a pre-processor macro that is currently equivalent to `INTEGER` but allows future extensions for long addresses. It can be accessed in any Fortran routine that contains the statement:

```
#include "stack_point.h"
```

before the macro is first used.

Pointers are returned by routines that create new data areas (`MAKDAT`) or find existing data areas (`LOCDAT`). In each the caller specifies a name for the data, for example, `MY_VAR` and receives a pointer in return, for example, `pMY_VAR`.

It is recommended that stack pointers are used locally within a routine where they are obtained; there is a clear distinction between routines that use pointers and those that do not. These stack points should not be stored for future calls because it is not guaranteed that the referenced item will remain in memory at the same location.

It is common practice to pass a stack location, for example, `RZ(pVAR)`, as an argument down to another subroutine that can manipulate this data as an ordinary Fortran variable or array. For example:

```
CALL MY_SUB( RZ(pMY_ARRAY), LEN_MY_ARRAY)
....
....
SUBROUTINE MY_SUB( A, N )
  REAL A(N)
  DO I = 1, N
    A(I) = 0.0
  END DO
END
```

### 18.6.4. Subroutines

This section describes the subroutines available to a program developer, by giving a specification for each of the subroutines provided by the memory management system. A consistent approach to error handling is adopted, with character variables `CERACT` and `CRESLT` used to control and report errors. For details, see [Error Conventions](#) (p. 527).

#### 18.6.4.1. Directories

##### 18.6.4.1.1. MAKDIR

```
SUBROUTINE MAKDIR (CDRNAM, CERACT, CRESLT)
CHARACTER*(*) CDRNAM, CERACT (input)
CHARACTER*4 CRESLT (output)
```

This creates a new directory `CDRNAM`, where `CDRNAM` can be a full path name (in which case it must start with '/') or it can be a relative path name. Note that the relative path name can include '.' to indicate the current directory or '..' to indicate the parent directory, just as in UNIX. However, you must be careful when using '..' in the presence of linked directories.

### 18.6.4.1.2. DELDIR

```
SUBROUTINE DELDIR (CDRNAM, CERACT, CRESLT)
CHARACTER*(*) CDRNAM, CERACT (input)
CHARACTER*4 CRESLT (output)
```

This deletes the directory CDRNAM, along with all subdirectories and data areas that it contains.

### 18.6.4.1.3. CHGDIR

```
SUBROUTINE CHGDIR (CDRNAM, CERACT, CRESLT)
CHARACTER*(*) CDRNAM, CERACT (input)
CHARACTER*4 CRESLT (output)
```

This changes the current directory to CDRNAM.

Note that linked directories behave like UNIX *hard links* as far as changing directories is concerned. For example, suppose you have two directories 'A1' and 'A2', each with subdirectories 'B1' and 'B2', and that 'B1' is linked to 'B2':

A1/ B1 → A2/ B2

Suppose that 'A1' is the current directory, and you perform the following sequence of commands:

```
CALL CHGDIR ('B1', 'STOP', CRESLT)
CALL CHGDIR ('..', 'STOP', CRESLT)
```

Then you finish up back in 'A1'; unlike UNIX *soft links*, which would finish up in 'A2'.

### 18.6.4.1.4. CHMDIR

```
SUBROUTINE CHMDIR (CDRNAM, CERACT, CRESLT)
CHARACTER*(*) CDRNAM, CERACT (input)
CHARACTER*4 CRESLT (output)
```

This changes the current directory to CDRNAM, if CDRNAM exists; otherwise it first makes the directory CDRNAM and then changes into it.

### 18.6.4.1.5. PSHDIR

```
SUBROUTINE PSHDIR (CDRNAM, CERACT, CRESLT)
CHARACTER*(*) CDRNAM, CERACT (input)
CHARACTER*4 CRESLT (output)
```

This places the name of the current directory on a stack of previous current directories, and then changes the current directory to CDRNAM. It is designed to be used in combination with POPDIR (see below).

### 18.6.4.1.6. PSHDRH

```
SUBROUTINE PSHDRH (CDRNAM, CERACT, CRESLT)
CHARACTER*(*) CDRNAM, CERACT (input)
CHARACTER*4 CRESLT (output)
```

This places the name of the current directory on a stack of previous current directories, and then changes the current directory to CDRNAM. It is designed to be used in combination with POPDIR (see below). This routine behaves the same as PSHDIR if a directory is not a link to another directory. However, if the input directory is a link, this routine follows the link so that '..' is actually the parent directory of CDRNAM. With PSHDIR, '..' follows the original linked directory.

### 18.6.4.1.7. POPDIR

```
SUBROUTINE POPDIR (CERACT, CRESLT)
CHARACTER*(*) CERACT (input)
CHARACTER*4 CRESLT (output)
```

This changes back to the directory stored on the top of the stack of previous current directories, and removes this directory from the stack.

If this directory no longer exists, the current directory remains unchanged, but the top entry on the stack of previous current directories will still be removed. The value of CERACT then determines whether the program continues. Note that the stack is not cleared and any subsequent call to POPDIR attempts to change to the directory given by the new top entry on the stack.

POPDIR is designed to be used in combination with PSHDIR (see above). Note that the stack of current working directories is a last-in-first-out stack, so care must be taken if nesting PSHDIR's and POPDIR's.

### 18.6.4.1.8. LISDAT

```
SUBROUTINE LISDAT
```

All subdirectories and data areas are listed (in the standard output file) for the current directory. The name of this current directory is also printed.

### 18.6.4.1.9. PUTDIR

```
SUBROUTINE PUTDIR (CURDIR, LENCD)
CHARACTER*200 CURDIR (output)
INTEGER LENCD (output)
```

The full path name of the current directory is written into CURDIR (which should be at least of length 200 bytes). The actual number of active bytes in the full path name is returned as LENCD.

### 18.6.4.1.10. FNDFIL

```
SUBROUTINE FNDFIL(CDRNAM, CNAME, COPTS, CFNAME, LFNAME, CLNAME, \
LLNAME, CDTYPE, CERACT, ISIZE, JADRES, CRESLT)
CHARACTER*(*) CDRNAM (input)
CHARACTER*(*) CNAME (input)
CHARACTER*(*) COPTS (input)
CHARACTER*(*) CERACT (input)
CHARACTER*208 CFNAME (output)
CHARACTER*4 CDTYPE, CRESLT (output)
CHARACTER*208 CLNAME (output)
INTEGER ISIZE, JADRES, LFNAME, LLNAME (output)
```

This routine replaces the old TARLIS routine, and its call is done in very much the same way. Much more control over what is returned by this routine is provided than for TARLIS however, and the DEFAULT action is to search only in the directory CDRNAM and *not recursively* through subdirectories of CDRNAM.

CDRNAM is the directory to be searched.

CNAME is the file name to be searched for. The name may contain up to two wild cards for which the '\*' character is used as in Linux. The following are valid examples of CNAME:

**CNAME = 'FRED'**

Returns only files called FRED

**CNAME = '\*DAT'**

Returns only files ending in 'DAT'

**CNAME = 'FCP\*'**

Returns only files beginning in 'FCP'

**CNAME = '\*STR\*'**

Returns only files including the string 'STR'

**CNAME = '\*'**

Returns all file names.

*Note that CNAME should be set only on the first call. FNDFIL is always initialized for a new search whenever CNAME is non-blank.*

COPTS is a string holding the file system type options. All options should be prepended with a '-' character, the minus sign. More than one option can be included, for example, COPTS='-opt1 -opt2 -opt3 .....'. Valid options are:

**R**

Search recursively through all subdirectories

**-ALL**

Return all file types

**-DIR**

Return directory files

**-LINK**

Return link files

**-'DATA' [>lev | <lev]**

Return files of data type 'DATA'.

The optional part in [ ] after the data type option is used to specify a vulnerability level restriction on the data areas. For example:

`-INTR > All integer data areas;`

`-INTR >10 > Integer data areas with a vulnerability >10;`

`-REAL <50 > Real data areas with a vulnerability <50.`

Thus, to specify all vulnerable integer data areas use, '-INTR>0'. For all non-vulnerable logical files, use '-LOGL<1'.

Options are processed in order and so can be modified in the expected manner; thus, '-ALL-INTR<10' => all files but only integer files with a vulnerability less than 10.

Note if the options string is left blank then this is the same as '-ALL'.

CFNAME is returned with the relative path name of the file from the directory being listed, in the form './d1/d2/.../file name'.

If CRESLT = 'END' then there are no more data areas to be found, and so CFNAME will not contain the name of a new directory or data area.

Note that CRESLT = 'END' is treated like CRESLT = 'GOOD' as far as error handling is concerned, so it is not an error condition.

Once a call has produced the result CRESLT = 'END' or CRESLT = 'ERR' the next call to FNDFIL is treated as a first call and a new search begins.

LFNAME contains the length of CFNAME in characters, and CDTYPE contains the data type of CFNAME; this will be one of 'REAL', 'INTR', 'DBLE', 'LOGL' or 'CHAR'.

ISIZE is the size of the data area CFNAME, and JADRES is the start address for this data area in the relevant stack.

If ISIZE = 0 and LLNAME = 0 then CFNAME is actually a directory. But if ISIZE=0 and LLNAME is greater than zero, then CFNAME is a link to another data area or directory, in which case CLNAME and LLNAME are returned containing the name of the link, and the length of this name, respectively. When ISIZE=0, CDTYPE is not defined.

The following illustrates the calling sequence using FNFIL:

First call:

```
CALL FNFIL('Dir. name', '*', '-R -ALL', ...)
```

Subsequent calls:

```
CALL FNFIL(' ', ' ', ' ', ...)
```

For the subsequent calls only the CNAME argument is checked and it must be blank otherwise a new search will be initiated.

```
LOGICAL FUNCTION LDIR(CDIR)
CHARACTER*(*) CDIR (input)
```

This function is true if the directory CDIR exists.

```
LOGICAL FUNCTION LFIL(CFIL)
CHARACTER*(*) CFIL (input) This function is true if the file CFIL exists
```

## 18.6.4.2. Data Areas

### 18.6.4.2.1. MAKDAT

```
SUBROUTINE MAKDAT (CDANAM, CDTYPE, CERACT, ISIZE, JADRES, CRESLT)
CHARACTER*(*) CDANAM, CERACT (input)
CHARACTER*4 CDTYPE (input)
INTEGER ISIZE (input)
INTEGER JADRES (output)
CHARACTER*4 CRESLT (output)
```

CDANAM can be set to either a program name or a data area name. If CDANAM is a program name, then CERACT is also set to 'CODE', and MAKDAT simply initializes the character string CCODE to the program name, and then returns. CCODE is then saved for future calls to MAKDAT. The program name can then be used in user friendly memory error messages.

If CDANAM is a data area name, then MAKDAT creates a new data area called CDANAM, which is of type CDTYPE (CDTYPE='REAL','INTR','DBLE','LOGL' or 'CHAR'). CERACT performs its usual function, and ISIZE defines the size of the new data area (for character arrays, ISIZE is the total number of bytes required).

The start address in the appropriate global stack is returned as JADRES.

Note that MAKDAT may delete vulnerable data areas if there is no room available in the stack for a new data area (see VULDAT below).

If MAKDAT fails due to lack of space on one of the stacks, that is, CRESLT = 'FULL', the following message is sent to standard output, providing CERACT is not set to 'SKIP':

```
*** INSUFFICIENT MEMORY ALLOCATED ***
```

Action required:

Depending on what program is running, there then follows a message relating to what memory stack is full. If the program is CFX-FLOW, then the following message is shown:

```
Re-run CFX-Pre and increase the CDTYPE stack memory factor. Use the
Workspace Sizes menu under Advanced Control of CFX-Flow Parameters.
```

Where CDTYPE is one of 'CHAR', 'DBLE', 'INTR', 'LOGL', or 'REAL', to indicate for which data type MAKDAT has failed. Otherwise, for other programs, the following message is shown:

```
Contact the CFDS Customer Helpline giving the following details
```

If MAKDAT fails due to the file catalogue being full, that is, CRESLT = 'FCAT', the following message is sent to standard output, providing CERACT is not set to 'SKIP':

```
>> Insufficient memory allocated. Try increasing file catalogue size.
```

To increase the catalogue size, see [Starting the CFX-Solver from the Command Line in the CFX-Solver Manager User's Guide](#) and [Configuring Memory for the CFX-Solver in the CFX-Solver Manager User's Guide](#).

#### 18.6.4.2.2. MAKVEC

```
SUBROUTINE MAKVEC (CDANAM, CDTYPE, CERACT, LENVEC, ISIZE, JADRES, CRESLT)
CHARACTER*(*) CDANAM, CERACT (input)
CHARACTER*4 CDTYPE (input)
INTEGER LENVEC (input)
INTEGER ISIZE (input)
INTEGER JADRES (output)
CHARACTER*4 CRESLT (output)
```

This routine is identical to MAKDAT in every respect except that instead of creating a data area of length ISIZE stack words it creates a data area of ISIZE\*LENVEC stack words. The vector word length, LENVEC stack words, is stored in the MMS. This is particularly useful for character string arrays; LENVEC is then the string length in characters of the character array. Note this is important when using PEEKCA and POKECA.

#### 18.6.4.2.3. GRBSTK

```
SUBROUTINE GRBSTK (CDANAM, CDTYPE, CERACT, ISIZE, JADRES, CRESLT)
CHARACTER*(*) CDANAM, CERACT (input)
CHARACTER*4 CDTYPE (input)
INTEGER ISIZE (output)
INTEGER JADRES (output)
CHARACTER*4 CRESLT (output)
```

This routine is identical to MAKDAT except that it returns a pointer to the largest free data area of the required type that is available. ISIZE is returned with the data area size in words. If no free areas exist, then the largest vulnerable data area is used.

#### 18.6.4.2.4. SQZDAT

```
SUBROUTINE SQZDAT (CDANAM, CERACT, ISIZE, CRESLT)
CHARACTER*(*) CDANAM, CERACT (input)
```

```

INTEGER ISIZE (input)
CHARACTER*4 CRESLT (output)

```

This shrinks the data area CDANAM, reducing its length to ISIZE, which must be no larger than the original length of the data area.

#### 18.6.4.2.5. RESIZE

```

SUBROUTINE RESIZE (CDANAM, CERACT, ISIZE, CRESLT, CZ, DZ, IZ, LZ, RZ)
CHARACTER*(*) CDANAM, CERACT (input)
INTEGER ISIZE (input)
CHARACTER*4 CRESLT (output)
CHARACTER CZ(*) (input/output)
DOUBLE PRECISION DZ(*) (input/output)
INTEGER IZ(*) (input/output)
LOGICAL LZ(*) (input/output)
REAL RZ(*) (input/output)

```

This resizes the data area CDANAM, to the new size ISIZE, which may be larger or smaller than the original length of the data area.

**NOTE** that the address of CDANAM within the stack may be changed as a result of calling RESIZE.

#### 18.6.4.2.6. DELDAT

```

SUBROUTINE DELDAT (CDANAM, CERACT, CRESLT)
CHARACTER*(*) CDANAM, CERACT (input)
CHARACTER*4 CRESLT (output)

```

This deletes the data area CDANAM.

#### 18.6.4.2.7. LOCDAT

```

SUBROUTINE LOCDAT (CDANAM, CDTYPE, CERACT, ISIZE, JADRES, CRESLT)
CHARACTER*(*) CDANAM, CERACT (input)
INTEGER ISIZE, JADRES (output)
CHARACTER*4 CDTYPE, CRESLT (output)

```

This subroutine locates an existing data area CDANAM, and provides its type CDTYPE, size ISIZE, and address JADRES.

Note that if CDANAM is a vulnerable data area, then LOCDAT makes it safe again until the next call to VULDAT for CDANAM.

#### 18.6.4.2.8. INFDAT

```

SUBROUTINE INFDAT (CDANAM, CDTYPE, CERACT, LENVEC, ISIZE, JADRES, LEVVUL, CRESLT)
CHARACTER*(*) CDANAM, CERACT (input)
INTEGER LENVEC, ISIZE, JADRES, LEVVUL (output)
CHARACTER*4 CDTYPE, CRESLT (output)

```

This subroutine locates an existing data area CDANAM, and provides its type CDTYPE, vector word length, size ISIZE, in units of the vector word length, address JADRES and vulnerability level LEVVUL. If a character string array had been set up using MAKVEC with 20 strings of 10 character string length, then LENVEC would be returned with 10 and ISIZE with 20 a total length of 200 characters.

Note that unlike LOCDAT, this routine does NOT affect the vulnerability of a data area this is a pure inquiry routine.

### 18.6.4.3. Renaming And Linking

#### 18.6.4.3.1. RENAM

```
SUBROUTINE RENAM (COLDNM, CNEWNM, CERACT, CRESLT)
CHARACTER*(*) COLDNM, CNEWNM, CERACT (input)
CHARACTER*4 CRESLT (output)
```

The data area or directory COLDNM is given the new name CNEWNM. The subroutine will fail if CNEWNM already exists.

N.B. This routine was originally called RENAME. It has been renamed RENAM to avoid a clash with the UNIX system routine rename on some platforms.

#### 18.6.4.3.2. MAKLNK

```
SUBROUTINE MAKLNK (COLDNM, CNEWNM, CERACT, CRESLT)
CHARACTER*(*) COLDNM, CNEWNM, CERACT (input)
CHARACTER*4 CRESLT (output)
```

The data area or directory COLDNM is linked to a new data area or directory CNEWNM, that is, it is given the additional name CNEWNM. If CNEWNM is subsequently deleted (using DELLNK), then COLDNM still survives under its original name. However, if instead COLDNM is subsequently deleted (using DELDAT or DELDIR) then CNEWNM is also deleted automatically, so be careful with links! It is important to be aware of what may happen to the target of a linked data area.

Note that if COLDNM is actually a link, rather than a data area or directory, then MAKLNK operates as if COLDNM were replaced by the name of the data area or directory to which it is linked. Thus, there is never a link to another link; there are only links to data areas or directories.

Note that, as far as changing directories is concerned, linked directories behave as UNIX *hard links*, as explained in [CHGDIR](#) (p. 530).

#### 18.6.4.3.3. DELLNK

```
SUBROUTINE DELLNK (CLNNAM, CERACT, CRESLT)
CHARACTER*(*) CLNNAM, CERACT (input)
CHARACTER*4 CRESLT (output)
```

The data area or directory CLNNAM is assumed to have been created by a call to MAKLNK (with CNEWNM=CLNNAM), and this call to DELLNK will delete that link.

### 18.6.4.4. Copying

#### 18.6.4.4.1. COPDAT

```
SUBROUTINE COPDAT (CDFROM, CDTO, CERACT, CRESLT, CZ, DZ, IZ, LZ, RZ)
CHARACTER*(*) CDFROM, CDTO, CERACT (input)
CHARACTER CZ(*) (input/output)
DOUBLE PRECISION DZ(*) (input/output)
INTEGER IZ(*) (input/output)
LOGICAL LZ(*) (input/output)
REAL RZ(*) (input/output)
CHARACTER*4 CRESLT (output)
```

This subroutine copies one data area to another. CDFROM is the name of the original data area, and this must already exist. A new data area called CDTO is created, of the same size and type as CDFROM, and all data from CDFROM is copied to CDTO. If CDFROM is linked to another data area, then this is taken as the source for the data. The subroutine fails if CDTO already exists.

It is necessary to pass the global stacks CZ, DZ, IZ, LZ, RZ to this subroutine.

#### 18.6.4.4.2. COPDIR

```
SUBROUTINE COPDIR (CDFROM, CDTO, CERACT, CRESLT, CZ, DZ, IZ, LZ, RZ)
CHARACTER*(*) CDFROM, CDTO, CERACT (input)
CHARACTER CZ(*) (input/output)
DOUBLE PRECISION DZ(*) (input/output)
INTEGER IZ(*) (input/output)
LOGICAL LZ(*) (input/output)
REAL RZ(*) (input/output)
CHARACTER*4 CRESLT (output)
```

This subroutine copies a whole directory (CDFROM) and all its subdirectories to another, new, directory CDTO. The names of all subdirectories and data areas are recreated in the new directory. COPDIR will work if CDFROM is linked to another directory, but the subroutine will fail if CDTO already exists.

It is important to note that any data areas or subdirectories of CDFROM, which are links, will not be copied.

#### 18.6.4.5. Setting and Reading Individual Values

##### 18.6.4.5.1. POKECA

```
SUBROUTINE POKECA (CDANAM, JADRES, CVALUE, CERACT, CRESLT, CZ)
```

##### 18.6.4.5.2. POKECS

```
SUBROUTINE POKECS (CDANAM, CVALUE, CERACT, CRESLT, CZ)
```

##### 18.6.4.5.3. POKED

```
SUBROUTINE POKED (CDANAM, JADRES, DVALUE, CERACT, CRESLT,DZ)
```

##### 18.6.4.5.4. POKEI

```
SUBROUTINE POKEI (CDANAM, JADRES, IVALUE, CERACT, CRESLT,IZ)
```

##### 18.6.4.5.5. POKEL

```
SUBROUTINE POKEL (CDANAM, JADRES, LVALUE, CERACT, CRESLT,LZ)
```

##### 18.6.4.5.6. POKER

```
SUBROUTINE POKER (CDANAM, JADRES, RVALUE, CERACT, CRESLT, RZ)
CHARACTER*(*) CDANAM, CERACT (input)
CHARACTER*4 CRESLT (output)
CHARACTER*(*) CVALUE (input)
DOUBLE PRECISION DVALUE (input)
INTEGER JADRES, IVALUE (input)
LOGICAL LVALUE (input)
REAL RVALUE (input)
CHARACTER CZ(*) (output)
DOUBLE PRECISION DZ(*) (output)
INTEGER IZ(*) (output)
LOGICAL LZ(*) (output)
REAL RZ(*) (output)
```

These POKE subroutines are designed for setting a value at a single address, for a scalar or for one entry of an array, which is stored in the global stacks. This saves the programmer the job of locating the data area, and assigning a value. There is a separate subroutine for each Fortran variable type.

CDANAM is the name of the data area and JADRES is the position within the array (assuming CDANAM is an array) that is to be given a value. Note that if the data area CDANAM is a scalar, rather than an array, then JADRES is not used by the POKE subroutine.

CVALUE (or DVALUE, etc.) is the actual value that is to be assigned.

The relevant stack is passed (CZ, DZ, etc.) as an argument, along with the usual error handling flags CERACT and CRESLT.

In the case of character strings there are two subroutines, POKECA for arrays and POKECS for scalar (single string) data areas. When using POKECA, it is important to have the correct length for the string CVALUE, as one element of the character array. As with the other POKE subroutines, JADRES is simply the location within the character array where the value CVALUE will be set. For example, for an array CHARACTER\*2 CEXAMP(3) (total length 6 bytes), if you want to set the last entry CEXAMP(3) to be 'AB,' then you must set CDANAM to be CEXAMP, JADRES to be 3 and CVALUE to be 'AB.' If CVALUE is actually a local variable in the calling subroutine, then it must be declared as CHARACTER\*2.

For string arrays created with MAKVEC, the string length is stored in the MMS and POKECA uses that information. In this case, the restrictions on CVALUE are reduced, it can be any length less than equal to the length of a string in the string array. If CVALUE is shorter than the string length of the array, then padding with blanks is used. If CVALUE has a length greater than the array string length, then POKECA fails. Note that INFDAT can be used to determine the array size and string length.

Clearly there is no need for the argument JADRES in the POKECS subroutine, because CDANAM will be a single character string. If CDANAM has length greater than CVALUE, then the string is completed with blanks, while if CVALUE has length greater than CDANAM, then the POKECS fails. Note that calling POKECS for a character array CDANAM will have the effect of filling most of the array with blanks, so caution should be exercised.

#### 18.6.4.5.7. PEEKCA

```
SUBROUTINE PEEKCA (CDANAM, JADRES, CVALUE, CERACT, CRESLT, CZ)
```

#### 18.6.4.5.8. PEEKCS

```
SUBROUTINE PEEKCS (CDANAM, CVALUE, CERACT, CRESLT, CZ)
```

#### 18.6.4.5.9. PEEKD

```
SUBROUTINE PEEKD (CDANAM, JADRES, DVALUE, CERACT, CRESLT, DZ)
```

#### 18.6.4.5.10. PEEKI

```
SUBROUTINE PEEKI (CDANAM, JADRES, IVALUE, CERACT, CRESLT, IZ)
```

#### 18.6.4.5.11. PEEKL

```
SUBROUTINE PEEKL (CDANAM, JADRES, LVALUE, CERACT, CRESLT, LZ)
```

#### 18.6.4.5.12. PEEKR

```
SUBROUTINE PEEKR (CDANAM, JADRES, RVALUE, CERACT, CRESLT, RZ)
CHARACTER*(*) CDANAM, CERACT (input)
CHARACTER*4 CRESLT (output)
CHARACTER*(*) CVALUE (output)
DOUBLE PRECISION DVALUE (output)
INTEGER IVALUE (output)
INTEGER JADRES (input)
LOGICAL LVALUE (output)
```

```

REAL RVALUE (output)
CHARACTER CZ(*) (input)
DOUBLE PRECISION DZ(*) (input)
INTEGER IZ(*) (input)
LOGICAL LZ(*) (input)
REAL RZ(*) (input)

```

Corresponding to the POKE subroutines, there is this set of PEEK subroutines. These are designed for reading individual values from array data areas, or scalar data areas (that is, of length 1) from the global stacks. Again, there is a separate subroutine for each Fortran variable type, with two subroutines for characters. CDANAM is the name of the data area, with JADRES the array entry, hence, the actual value CVALUE (or DVALUE etc.) is to be obtained.

A programmer using PEEKCA must know the size of each string in the character array CDANAM, and must declare CVALUE to be of this length in the calling subroutine.

For string arrays created with MAKVEC, the string length is stored in the MMS and PEEKCA uses that information. In this case, the restrictions on CVALUE are reduced, it can be any length greater than equal to the length of a string in the string array. If CVALUE is longer than the string length of the array, then padding with blanks is used. If CVALUE has a length less than the array string length, then PEEKCA fails. Note that INFDAT can be used to determine the array size and string length.

When using PEEKCS the programmer may not necessarily know the length of CDANAM. In this case, CVALUE should be declared sufficiently large and LOCDAT must be used to obtain the actual length required for CVALUE. After the call to PEEKCS, CVALUE must be truncated to the correct length.

### 18.6.4.6. Name lists

#### 18.6.4.6.1. NAMLST

```

SUBROUTINE NAMLST (COM, CLIST, IENTRY, CVALUE, NCVAl, CERACT, RESLT, CZ, IZ)
CHARACTER COM*(*) (input)
CHARACTER CLIST*(*) (input)
INTEGER IENTRY (input/output)
CHARACTER CVALUE*(*) (input/output)
INTEGER NCVAl (output)
CHARACTER CERACT*(*) (input)
CHARACTER RESLT*(4) (output)
CHARACTER CZ(*)*(1) (input/output)
INTEGER IZ(*) (input/output)

```

A name list is simply a long character string consisting of a set of substrings. Each substring corresponds to a name and may be of arbitrary length. NAMLST enables you to treat the name list as if it were an array of strings, each string being of arbitrary length. The main advantage of using NAMLST is the potential for saving memory if the names in the list are of widely varying length. Note, however, that no space will be saved unless the mean length of a name is greater than 8 characters.

COM is a command string that takes the following possible values: COMPRESS, CREATE, DELETE, PEEK, POKE & SIZE. This string controls the operation of the routine in a, hopefully, self evident way.

CLIST is the name of the character data area to be used to hold the name list. Note that CLIST MUST be created using the CREATE command of NAMLST.

IENTRY is the array address to be used for COMPRESSing, PEEKing or POKEing an entry in the name list. In addition, IENTRY is used to set the maximum number of entries in the name list on creation and is returned with this number if the SIZE command is used.

CVALUE is used to hold string values for PEEKing and POKEing. For a PEEK CVALUE must be long enough to hold the entire entry. For a POKE, trailing spaces in CVALUE are ignored.

NCVAL is used to return the active length of CVALUE, which is the length after trailing spaces have been removed, when PEEKing.

If COM equals COMPRESS, then the IENTRY'th value in the list is removed and then the entries above have their entry number reduced by one; that is, entry IENTRY+n becomes IENTRY+n-1.

If COM equals CREATE, then a new name list, CLIST, is created with IENTRY possible entries.

If COM equals DELETE, then the name list, CLIST, is deleted.

If COM equals PEEK, then the IENTRY'th name in the list is returned in CVALUE(1:NCVAL) provided CVALUE is at least NCVAL characters long, where NCVAL is the active length in characters of the IENTRY'th name. If the IENTRY'th name has not yet been set, then CRESLT will be returned with NONE.

If COM equals POKE, then the IENTRY'th name in the list is overwritten with CVALUE(1:NACTIV), where NACTIV is the active length of CVALUE. Note that if the length of the new entry differs from the original, then CLIST has to be restructured incurring a CPU penalty. If an entire name list is to be filled, then the first entry should be POKed in first, the second second, and so on, for maximum efficiency.

If COM equals SIZE then IENTRY is returned with the maximum possible number of entries for the name list.

Note that NAMLST uses the vertical bar character, "|", as a separator in the CLIST array and so no entry should contain this character.

### 18.6.4.7. Memory Management Statistics

#### 18.6.4.7.1. GETMMS

```
SUBROUTINE GETMMS (CTYPE, CERACT, LENINF, INFO, CRESLT)
CHARACTER*(*) CTYPE, CERACT (input)
CHARACTER*4 CRESLT (output)
INTEGER LENINF (input)
INTEGER INFO (output)
```

This subroutine is used to obtain memory management statistics. You should set LENINF to be at least 25, and provide a local array INFO in the calling subroutine, which has dimension at least LENINF.

The character CTYPE should be set as one of 'CLCK,' 'FILE,' 'SYS,' 'REAL,' 'INTR,' 'DBLE,' 'LOGL' or 'CHAR' and this determines the information that will be returned in the INFO array.

If CTYPE = 'CLCK' then information is returned on the total number of memory management system calls so far:

$$\text{Number of calls} = J + 10^8 \times I *$$

where I=INFO(1) and J=INFO(2).

If CTYPE = 'FILE' then information is returned on the number of memory management system files (data areas, directories, etc.):

INFO(1) is the number of data areas present now.

INFO(2) is the peak number of data areas used so far.

INFO(3) = I and INFO(4) = J, giving the number of memory management calls made when this peak usage occurred (using the \* formula above).

INFO(5) is the number of directories present now.

INFO(6) is the peak number of directories used so far.

INFO(7) = I and INFO(8) = J, giving the number of memory management calls made when this peak usage occurred (using the \* formula above).

INFO(9) is the number of link files present now.

INFO(10) is the peak number of link files used so far.

INFO(11) = I and INFO(12) = J, giving the number of memory management calls made when this peak usage occurred (using the \* formula above).

INFO(13) is the total number of files (data areas + directories + link files) present now.

INFO(14) is the peak number of files used so far.

INFO(15) = I and INFO(16) = J, giving the number of memory management calls made when this peak usage occurred (using the \* formula above).

If CTYPE = 'SYS' then information is returned on the system limit statistics:

INFO(1) is the maximum number of files permitted at any one time.

INFO(2) is the maximum number of free data areas permitted at any one time.

INFO(3) is the maximum permitted length of a file name in characters.

INFO(4) is the maximum number of directories allowed in a full path name.

INFO(5) is the maximum vulnerability level allowed.

If CTYPE='CHAR,' 'DBLE,' 'INTR,' 'LOGL' or ' REAL' then statistics are returned just for data areas of that particular data type (namely character, double precision, integer, logical or real respectively):

INFO(1) is the number of data areas present now.

INFO(2) is the peak number of data areas used so far.

INFO(3) = I and INFO(4) = J, giving the number of memory management calls made when this peak usage occurred (using the \* formula above).

INFO(5) is the address space used by data.

INFO(6) is the peak address space used so far.

INFO(7) = I and INFO(8) = J, giving the number of memory management calls made when this peak usage occurred (using the \* formula above).

INFO(9) is the number of vulnerable data areas present now.

INFO(10) is the peak number of vulnerable data areas set so far.

INFO(11) = I and INFO(12) = J, giving the number of memory management calls made when this peak usage occurred (using the \* formula above).

INFO(13) is the address space used by vulnerable data.

INFO(14) is the peak vulnerable address space set so far.

INFO(15) = I and INFO(16) = J, giving the number of memory management calls made when this peak usage occurred (using the \* formula above).

INFO(17) is the number of free areas present now.

INFO(18) is the peak number of free areas created so far.

INFO(19) = I and INFO(20) = J, giving the number of memory management calls made when this peak usage occurred (using the \* formula above).

INFO(21) is the free address space available now.

INFO(22) is the minimum amount of free address space available so far.

INFO(23) = I and INFO(24) = J, giving the number of memory management calls made when this peak usage occurred (using the \* formula above).

INFO(25) is the number of vulnerable data areas deleted by the memory management system (to make space for new data) so far.

For all values of CTYPE, if MMSTAT is in an error condition no statistics are available, but if LENINF is at least 3, then the following will be returned:

INFO(1) = NUMERR, the error condition flag in MMSTAT.

INFO(2) = I and INFO(3) = J, giving the number of memory management calls made so far (using the \* formula above).

#### **18.6.4.7.2. WSTAT**

SUBROUTINE WSTAT

This subroutine prints long memory management system statistics to standard output. These consist of all data available from subroutine GETMMS, arranged in tabular form where appropriate.

### **18.7. User CEL Examples**


The following topics will be discussed:

- [User CEL Example 1: User Defined Momentum Source \(p. 543\)](#)
- [User CEL Example 2: Using Gradients for an Additional Variable Source \(p. 545\)](#)
- [User CEL Example 3: Integrated Quantity Boundary Conditions \(p. 549\)](#)

## 18.7.1. User CEL Example 1: User Defined Momentum Source

### 18.7.1.1. Problem Setup

A common application of user CEL functions is the specification of user defined source terms. In the following example, a constant source term for the y-component of the momentum equation has to be applied on two rectangular boxes characterized by their extension in the x and y coordinate direction.



### 18.7.1.2. Creating the User CEL Function

Additional information on creating user CEL functions in CFX-Pre is available in [User Functions in the CFX-Pre User's Guide](#).

First, you should first create a user routine with the following settings:

- Routine Name: `UserSourceRoutine`
- Option: User CEL Function
- Calling Name: `user_source`
- Library Name: `MomentumSource1`
- Library Path: `/home/cfxuser/shared_libraries`

Next, you should create a User Function with the following settings:

- Function Name: `UserSource`
- Option: User Function
- User Routine Name:
- Argument List: `[m], [m]`
- Result Units: `[kg m^-2 s^-2]`

In this example, the compiled code for the user subroutine `MomentumSource1.F` is stored in the shared library `libMomentumSource1.so` (the prefix and suffix may vary depending on your platform), which can be found under the `/home/cfxuser/shared_libraries/<architecture>` directory.

If there is a problem linking the shared library to the CFX-Solver, you can check that it has been created, but you will usually not need to know about this library.

The new user CEL function can now be used to set the momentum source components within the subdomain as follows:

- Momentum x-comp: 0 . 0
- Momentum y-comp: UserSource(X, Y)
- Momentum z-comp: 0 . 0

These values are set on the Subdomain Sources form. For details, see [Sources Tab in the CFX-Pre User's Guide](#).

### 18.7.1.3. User Fortran Routine

Source terms for the momentum equations can be specified in CEL for a given subdomain. Because the user CEL routine defined the extent of the source, the source subdomain can be defined to cover the entire flow domain. The subroutine was developed from the template routine `ucf_template.F` available in `<CFXROOT>/examples/`. Note that some commented sections of the routine have not been included here. The routine `MomentumSource1.F` has the following form:

```
#include "cfx5ext.h"
dllexport(user_source)
  SUBROUTINE USER_SOURCE (
    & NLOC,NRET,NARG,RET,ARGS,CRESLT,CZ,DZ,IZ,LZ,RZ)
  C
  C .....
  C
  C -----
  C      Argument list
  C -----
  C
  C      INTEGER NLOC, NRET, NARG
  C      CHARACTER CRESLT*(*)
  C      REAL      RET(1:NLOC,1:NRET), ARGS(1:NLOC,1:NARG)
  C
  C      INTEGER IZ(*)
  C      CHARACTER CZ(*)*(1)
  C      DOUBLE PRECISION DZ(*)
  C      LOGICAL LZ(*)
  C      REAL RZ(*)
  C
  C .....
  C
  C -----
  C      Executable statements
  C -----
  C
  C -----
  C      SOURCE = RET(1:NLOC,1)
  C      X      = ARGS(1:NLOC,1)
  C      Y      = ARGS(1:NLOC,2)
  C -----
  C
  C---- Low level user routine
  CALL USER_SOURCE_SUB (NLOC,RET(1,1),ARGS(1,1),ARGS(1,2))
  C
  CRESLT = 'GOOD'
  END
  SUBROUTINE USER_SOURCE_SUB (NLOC,SOURCE,X,Y)
  C
  C .....
  C
  C -----
  C      Local Variables
```

```

C -----
C      INTEGER NLOC, ILOC
C      REAL    SOURCE(NLOC), X(NLOC), Y(NLOC)
C -----
C      - 0.5<x<1.5 and 1.25<y<1.75 --> SOURCE = 1000.0
C      - 3.5<x<4.5 and 1.25<y<1.75 --> SOURCE = -1000.0
C -----
C      Executable Statements
C -----
C      DO ILOC=1,NLOC
C          SOURCE(ILOC) = 0.0
C          IF (X(ILOC).GE.0.5 .AND. X(ILOC).LE.1.5 .AND.
& Y(ILOC).GE.1.25 .AND. Y(ILOC).LE.1.75) THEN
C              SOURCE(ILOC) = 1000.0
C          ELSE IF (X(ILOC).GE.3.5 .AND. X(ILOC).LE.4.5 .AND.
& Y(ILOC).GE.1.25 .AND. Y(ILOC).LE.1.75) THEN
C              SOURCE(ILOC) = -1000.0
C          END IF
C      END DO
C
C      END

```

## 18.7.2. User CEL Example 2: Using Gradients for an Additional Variable Source

For some applications, the source terms for the transport equations might depend on local gradients. Gradients are currently not supported directly within CEL. However, gradients of most variables can still be accessed in CEL expressions through the use of user CEL functions. This is achieved by calling the utility USER\_GETVAR with the 'Gradient' operator attached to the variable name.

The following example shows the use of a source term depending on gradients of one Additional Variable,  $\phi_1$ , in the transport equation of another Additional Variable,  $\phi_2$ .

$$S_{\phi_2} = a \left[ \left( \frac{\partial \phi_1}{\partial x} \right)^2 + \left( \frac{\partial \phi_1}{\partial y} \right)^2 + \left( \frac{\partial \phi_1}{\partial z} \right)^2 \right] \quad (18-1)$$

$$\nabla \cdot (\rho \underline{U} \phi_2) = S_{\phi_2} \quad (18-2)$$

For this demonstration density is constant, the flow is uniform and  $\phi_1$  is a simple algebraic variable:

$$\phi_1 = x + 2y + 3z \quad (18-3)$$

so that the solution along a streamline can be trivially verified as:

$$\phi_2(l) = \phi_2(0) + 14 \frac{al}{\rho s} \quad (18-4)$$

where  $l$  is the distance from the inlet and  $s$  is the flow speed.

A user CEL function is given the coefficient  $a$  as an argument and computes the whole of the source term,  $S_{\phi_2}$ . The variables  $\phi_1$  and  $\phi_2$  have dimensions of length, so their gradients are therefore dimen-

sionless. The coefficient  $a$  has the same dimensions as the source term, which are those of density times velocity.

### 18.7.2.1. Problem Setup

#### 18.7.2.1.1. Creating the Additional Variables

Before creating a domain, define two Additional Variables:

- Create an Additional Variable called `phi1` of **Type Unspecified** with **Units** of [m]
- Create an Additional Variable called `phi2` of **Type Specific** with **Units** of [m]

#### 18.7.2.1.2. Creating the Domain

Create a domain that includes both Additional Variables `phi1` and `phi2`:

- Declare `phi1` of **Type Algebraic**, and type in the expression  $x + 2y + 3z$  to define it
- Declare `phi2` of **Type Transport Equation**. Do not set a Kinematic Diffusivity

Create a domain that includes both Additional Variables, solved using a transport equation. Do not set a kinematic diffusivity.

#### 18.7.2.1.3. Creating the User CEL Routine and Function

In CFX-Pre, you should create a User Routine and then a User Function. For details, see [User Routine Details View in the CFX-Pre User's Guide](#). Additional information on creating a User CEL Function in CFX-Pre is available; for details, see [User Functions in the CFX-Pre User's Guide](#).

The User Routine takes the following form:

- Routine Name: `UserSource2Routine`
- Option: `User CEL Function`
- Calling Name: `user_source2`
- Library Name: `AdVarSource`
- Library Path: `/home/cfxuser/shared_libraries`

and the User Function is set up as follows:

- Function Name: `UserSource2`
- Option: `User Function`
- User Routine Name: `UserSource2Routine`
- Argument List: `[kg m^-2 s^-1]`
- Result Units: `[kg m^-2 s^-1]`

In this example, the user subroutine `AdVarSource.F` is stored in the shared library `libAdVarSource.so` (the prefix and suffix may vary depending on your platform), which can be found under the `/home/cfxuser/shared_libraries/<architecture>` directory.

### 18.7.2.1.4. Defining the Source Term

The new User CEL Function can now be used to set the Additional Variable source within the subdomain as follows:

- Create a subdomain and set the Additional Variable Source Value as: `UserSource2(1000 [kg m-2 s-1])`.

This is accessed from the Subdomain Sources form. For details, see [Sources Tab in the CFX-Pre User's Guide](#).

The coefficient  $a$  in the nonlinear source term has been set to a constant value of 1000 [kg m<sup>-2</sup> s<sup>-1</sup>].

### 18.7.2.2. User Fortran Routine

The subroutine was developed from the template routine `ucf_template.F` available in `<CFX-ROOT>/examples/`. Note that some commented sections of the routine have not been included here. This routine contains a call to `USER_GETVAR` to access variable data. For details, see [Utility Routines for User Functions \(p. 497\)](#). Note that `USER_GETVAR` requires the fluid prefix for user-supplied variable names. For a one-off application it is possible simply to call `USER_GETVAR` with an assumed name for the working fluid, for example, for a single phase problem using 'Water':

```
CALL USER_GETVAR ('Water,phil.Gradient', CRESLT, pGRAD_PHI,
&                CZ,DZ,IZ,LZ,RZ)
```

However, to make it applicable in general, the example given here uses `USER_ASSEMBLE_INFO` to extract the equation and principal names, and `GET_PHASE_FROM_VAR` followed by `CONVERT_NAME_S2U` to extract the user's phase name. Hence, it works on any problem, independently of the choice of fluids.

- [USER\\_ASSEMBLE\\_INFO \(p. 516\)](#)
- [GET\\_PHASE\\_FROM\\_VAR \(p. 521\)](#)
- [CONVERT\\_NAME\\_S2U \(p. 520\)](#)

The routine `AdVarSource.F` has the following form:

```
#include "cfx5ext.h"
dllexport(user_source2)
      SUBROUTINE USER_SOURCE2 (
&      NLOC,NRET,NARG,RET,ARGS,CRESLT,CZ,DZ,IZ,LZ,RZ)
C-----
C      Details
C-----
C      ARGS(1:NLOC,1) holds parameter 'a' evaluated at all locations
C      RET(1:NLOC,1) will hold return result
C-----
C      Preprocessor includes
C-----
#include "MMS.h"
#include "stack_point.h"
C-----
C      Argument list
C-----
      INTEGER NLOC,NARG,NRET
      CHARACTER CRESLT*(*)
      REAL ARGS(NLOC,NARG), RET(NLOC,NRET)
      INTEGER IZ(*)
      CHARACTER CZ(*)*(1)
      DOUBLE PRECISION DZ(*)
      LOGICAL LZ(*)
      REAL RZ(*)
C-----
C      External routines
```

```

C -----
      INTEGER LENACT
      EXTERNAL LENACT
C -----
C      Local Variables
C -----
      CHARACTER*(MXDNAM) ACTION,CGROUP,CEQN,CTERM,CPVAR,
& CLVAR,CPATCH,CRESLOC,CPHASE
      CHARACTER*120 User_Phase_Name, User_Variable_Name
C -----
C      Stack pointers
C -----
      __stack_point__ pGRAD_PHI
C -----
C      Executable Statements
C -----
C      Initialise success flag.
      CRESLT = 'GOOD'
C      Initialise RET to zero.
      CALL SET_A_0 ( RET, NLOC*NRET )
C
C---- Determine user's phase name for use in USER_GETVAR
C
C      Use USER_ASSEMBLE_INFO to determine solver equation and principal
C      variable names CEQN, CPVAR.
      ACTION = 'GET'
      CALL USER_ASSEMBLE_INFO ( ACTION,CGROUP,CEQN,CTERM,CPVAR,
& CLVAR,CPATCH,CRESLOC,
& CZ,DZ,IZ,LZ,RZ)
      IF (CRESLOC.NE.'GOOD' .AND. CRESLOC.NE.'SOME') THEN
          CRESLT = 'FAIL'
          GO TO 999
      ENDIF
C      Extract phase name from principal variable
      CALL GET_PHASE_FROM_VAR (CPVAR, CPHASE)
C      Convert solver phase name to user phase name.
      CALL CONVERT_NAME_S2U('Phase',CPHASE,' ',User_Phase_Name,
& CRESLT, CZ,DZ,IZ,LZ,RZ)
      IF (CRESLT.NE.'GOOD') GO TO 999
C
C---- Obtain grad(phi)
C      in array shape GRAD_PHI(1:3,1:NLOC) located at RZ(pGRAD_PHI)
C
      User_Variable_Name = User_Phase_Name(1:LENACT(User_Phase_Name))
& // '.phi1.Gradient'
      CALL USER_GETVAR (User_Variable_Name, CRESLT, pGRAD_PHI,
& CZ,DZ,IZ,LZ,RZ)
      IF (CRESLT.NE.'GOOD') GO TO 999
C
C---- Calculate source expression in RET(1:NLOC,1)
C
      CALL USER_SOURCE_CAL( RET(1,1), ARGS(1,1), RZ(pGRAD_PHI), NLOC )
C
999 CONTINUE
C
C      Send any diagnostics or stop requests via master processor
      IF (CRESLT.NE.'GOOD') THEN
          CALL MESSAGE( 'BUFF', 'USER_SOURCE2 returned error:' )
          CALL MESSAGE( 'BUFF', CRESLT )
          CALL MESSAGE( 'BUFF-OUT', ' ' )
      END IF
C
C=====
      END
      SUBROUTINE USER_SOURCE_CAL (SOURCE, A, GRAD_PHI, NLOC)
C
C      Purpose: Source = a * grad(phi).grad(phi)
C
C      Inputs
          INTEGER NLOC
          REAL A(NLOC), GRAD_PHI(3,NLOC)
C      Outputs

```

```

      REAL SOURCE(NLOC)
C   Locals
      INTEGER ILOC
C
      DO ILOC = 1, NLOC
          SOURCE(ILOC) = A(ILOC) * ( GRAD_PHI(1,ILOC)**2
&      + GRAD_PHI(2,ILOC)**2
&      + GRAD_PHI(3,ILOC)**2 )
      END DO
C
      END

```

## 18.7.3. User CEL Example 3: Integrated Quantity Boundary Conditions

### 18.7.3.1. Problem Setup

One application of the integrated quantity functions would be to set a boundary inlet temperature based on some average outflow values from a domain. In this way, you could set up a boundary condition, which acts like a thermostat control for a room. This requires the use of a User CEL Function to set the inflow temperature, and one of the arguments, which is passed to the subroutine, is the average outflow temperature.

#### 18.7.3.1.1. Creating the User Function

Further information on creating a User CEL Function in CFX-Pre is available in [User Functions in the CFX-Pre User's Guide](#).

First, you should first create a User Routine with the following settings:

- Routine Name: INLET T
- Option: User CEL Function
- Calling Name: inlet\_t
- Library Name: InletTemperature
- Library Path: /home/cfxuser/shared\_libraries

Next, you should create a User Function with the following settings.

- Function Name: INLET T
- User Routine Name: INLET T
- Argument List: [K], [Pa]
- Result Units: [K]

In this example, the user subroutine `InletTemperature.F` is stored in the shared library `libInletTemperature.so` (the prefix and suffix may vary depending on your platform), which can be found under the `/home/cfxuser/shared_libraries/<architecture>` directory. The new User CEL Function can now be used to set the feedback loop for the inlet temperature as follows:

- On the **Inlet Boundary Condition Values** form set the **Heat Transfer** option to `Static Temperature` and enter the expression:

```
INLET_T( areaAve(T)@Outflow, areaAve(p)@Outflow )
```

Note that the integrated quantity is passed into the inlet temperature function as an argument. The CFX-Solver recalculates these values during the coefficient loop so that the value is always up to date. For details, see [Boundary Details: Inlet in the CFX-Pre User's Guide](#).

### 18.7.3.2. User Fortran Routine

The routine `InletTemperature.F` has the following form (note that this is not a complete routine, the purpose of this example is to demonstrate the quantities that can be passed to the subroutine).

```
#include "cfx5ext.h"
dllexport(inlet_t)
  SUBROUTINE INLET_T (NLOC,NRET,NARG,RET,ARGS,CRESLT,CZ,DZ,IZ,LZ,RZ)
C
C -----
C      Argument list
C -----
  INTEGER NLOC, NRET, NARG
  CHARACTER CRESLT*(*)
  REAL     RET(1:NLOC,1:NRET), ARGS(1:NLOC,1:NARG)
C
C -----
C `Static Temperature` is stored in RET(1:NLOC,1)
C `areaAve(T@Outflow)` is stored in ARGS(1:NLOC,1)
C `areaAve(p@Outflow)` is stored in ARGS(1:NLOC,2)
C -----
C
C -----
C      Executable statements
C -----
C
  ...
  END
```

## 18.8. User Junction Box Examples

The following topics will be discussed:


- [Junction Box Example 1: Profile Boundary Conditions](#) (p. 550)
- [Junction Box Example 2: Integrated Residence Time Distribution](#) (p. 558)
- [Junction Box Example 3: Timestep Control](#) (p. 562)
- [Junction Box Example 4: Solver Control](#) (p. 567)
- [Junction Box Example 5: Transient Information](#) (p. 568)

### 18.8.1. Junction Box Example 1: Profile Boundary Conditions

#### 18.8.1.1. Problem Setup

A common application of User Subroutines is the specification of a profile boundary condition. In this example, experimental data has been obtained for inflow boundary values at the inlet to a domain. The simulation is that of flow over a backward facing step; the inlet profile is given some step heights upstream of the step.

Inlet boundary condition with specified profile



The experimental data is provided in a two-dimensional table. The first column contains the wall-normal positions and the remaining five columns contain values for the  $u$ ,  $v$  and  $w$  velocity components, the turbulent kinetic energy and the turbulent eddy dissipation. The table has 29 wall-normal positions and appears as follows:

```

6    29
1.01724E-01 1.01665E-04 0.00000E+00 0.00000E+00 0.00000E+00 0.00000E+00
1.05172E-01 2.94293E-04 0.00000E+00 0.00000E+00 9.43200E+00 1.33962E+04
.....
1.94828E-01 2.94293E-04 0.00000E+00 0.00000E+00 8.94000E+00 8046000E+02
1.98276E-01 1.01665E-04 0.00000E+00 0.00000E+00 0.00000E+00 0.00000E+00

```

A Junction Box routine is required to read the data from the file and automatically pass it to the slave processors. The profile boundary is then set by a User CEL Function.

### 18.8.1.1.1. Creating the Junction Box Routine and User CEL Function

In CFX-Pre, you should create a Junction Box Routine, User CEL Routine and a User CEL Function. Further information on creating these objects in CFX-Pre is available in [User Functions in the CFX-Pre User's Guide](#).

User CEL Routine:

- Routine Name: U profile Routine
- Option: User CEL Function
- Calling Name: user\_uprofile
- Library Name: backstep
- Library Path: /home/user/Shared\_Libraries

User CEL Function:

- Function Name: U profile
- Option: User Function
- User Routine Name: U Profile Routine
- Argument List: [m]
- Result Units: [m/s]

Junction Box Routine:

- Routine Name: Load Inlet Profiles
- Option: Junction Box Routine

- Calling Name: `user_input`
- Library Name: `backstep`
- Library Path: `/home/user/Shared_Libraries`
- Junction Box Location: `User input`

As can be seen from this example, both routines are stored in the shared library `libbackstep.so` (the prefix and suffix may vary depending on your platform), which can be found in the `/home/user/Shared_Libraries/<architecture>` directory.

### 18.8.1.1.2. Setting the Boundary Condition

The new User CEL Function can now be used within a boundary condition in CFX-Pre. For example, create an inlet boundary condition using the **Cartesian Velocity Components** option and then set:

- `U = U_profile(y)`
- `V = 0.00 [m s^-1]`
- `W = 0.00 [m s^-1]`

### 18.8.1.1.3. Enabling the Junction Box Routine

In order to ensure that the solver calls the declared Junction Box routine, you should:

- Go to the **Solver Control** panel in CFX-Pre. For details, see [Basic Settings Tab in the CFX-Pre User's Guide](#).
- Select the Junction Box Routines box, and select the Junction Box Load Inlet Profile. For details, see [Basic Settings Tab in the CFX-Pre User's Guide](#).

The following CCL should be added to the CCL File. You can also enter this into the **Command Editor** dialog box (**Tools > Command Editor**) in CFX-Pre and click **Process**.

```
USER:
# Location of external inlet profiles.
Input File = /home/user/u_profile.dat
# Printing control. First character should be Y or N
User Printing = Yes
END
```

The CCL parameter `USER/Input File` automatically becomes the MMS parameter `USER/INPUT_FILE`. This is used in the Fortran subroutines to read in the user data. The `User Printing` parameter becomes the MMS parameter `USER/USER_PRINTING`. This is used in the following subroutines to control printing.

### 18.8.1.2. User Fortran Junction Box Routines

The data table is stored in an ASCII file in `/home/user/backstep.user.dat`. The user code to read the data from this file is implemented in a user routine shown below. The routine was developed from the template routine `jcb_template.F` available in `<CFXROOT>/examples/`.

```
#include "cfx5ext.h"
C=====
C
C Purpose: User Fortran for importing/interpolating external
C         velocity profile.
C
C Junction Box Routines:
C         USER_INPUT -> USER_INPUT_TABLE
C
```

```

C User CEL Functions:
C     USER_UPROFILE -> USER_UPROFILE_CAL -> USER_TABINT
C                                     -> USER_PRINT_PROFILE
C
C Command File data areas used:
C     /USER/INPUT_FILE
C     /USER/USER_PRINTING
C
C User Input data areas used:
C     /USER_DATA/NCOL
C     /USER_DATA/NLIN
C     /USER_DATA/TABLE(NCOL,NLIN)
C
C=====
dllexport(user_input)
      SUBROUTINE USER_INPUT ( CZ,DZ,IZ,LZ,RZ )
CC
CC -----
CC           Input
CC -----
CC     none
CC
CC -----
CC           Modified
CC -----
CC
CC     Stacks possibly.
CC
CC -----
CC           Output
CC -----
CC     none
CC
CC -----
CC           Details
CC -----
CC
CC     Load a velocity profile from filename given in /USER/INPUT_FILE.
CC
CC     This routine is defined with 'Junction Box Location = User Input'.
CC     It reads data into the directory /USER_DATA.
CC
CC     In a parallel run, this routine is only called from the master
CC     process, but any /USER_DATA data will then be automatically
CC     copied to the /USER_DATA directory on all slave processes.
CC=====
C -----
C     Preprocessor includes
C -----
#include "MMS.h"
#include "stack_point.h"
C
C -----
C           Argument list
C -----
      INTEGER IZ(*)
      CHARACTER CZ(*)*(1)
      DOUBLE PRECISION DZ(*)
      LOGICAL LZ(*)
      REAL RZ(*)
C
C -----
C           Local Parameters
C -----
C Fortran input channel
      INTEGER NCHANNEL
      PARAMETER (NCHANNEL=59)
C
C -----
C           Local Variables
C -----
C Result flag

```

```

      CHARACTER*4 CRESLT
C
C System info
      CHARACTER*(MXPNAM) WHICH_CALL
C
C Command file info
      CHARACTER*(MXPNAM) INPUT_FILE
      CHARACTER*(MXPNAM) USER_PRINTING
C
      INTEGER NCOL, NLIN
C
C -----
C      Stack pointers
C -----
C
      __stack_point__ pPOINT, pTABLE
C
C=====
C -----
C      Executable Statements
C -----
C
C Look up the system info for junction box calls: WHICH_CALL
      WHICH_CALL = 'Unknown'
      CALL PEEKCS( '/USER/WHICH_CALL', WHICH_CALL, 'SKIP', CRESLT, CZ )
C
C Look up command file info: INPUT_FILE, USER_PRINTING.
      INPUT_FILE = 'Unknown'
      CALL PEEKCS( '/USER/INPUT_FILE', INPUT_FILE, 'STOP', CRESLT, CZ )
C
      USER_PRINTING = 'No'
      CALL PEEKCS( '/USER/USER_PRINTING', USER_PRINTING, 'SKIP',
&                CRESLT, CZ )
C
C Send any diagnostic messages via master process.
      IF ( USER_PRINTING(1:1) .NE. 'N' ) THEN
          CALL MESSAGE( 'WRITE', 'Start USER_INPUT' )
          CALL MESSAGE( 'WRITE', 'WHICH_CALL= '//WHICH_CALL )
          CALL MESSAGE( 'WRITE', 'INPUT_FILE= '//INPUT_FILE )
      END IF
C
C Ensure that directory /USER_DATA exists and make this the current directory.
C
      CALL PSHDIR( '/', 'STOP', CRESLT )
      CALL CHGDIR( 'USER_DATA', 'STOP', CRESLT )
C
C Read data from file.
C
      OPEN( NCHANNEL, FILE=INPUT_FILE )
C
C Create space for array sizes NCOL and NLIN
      CALL MAKDAT( 'NCOL', 'INTR', 'STOP', 1, pPOINT, CRESLT )
      CALL MAKDAT( 'NLIN', 'INTR', 'STOP', 1, pPOINT, CRESLT )
C
C Read data in NCOL and NLIN
      READ ( NCHANNEL, * ) NCOL, NLIN
      CALL POKEI( 'NCOL', 1, NCOL, 'STOP', CRESLT, IZ )
      CALL POKEI( 'NLIN', 1, NLIN, 'STOP', CRESLT, IZ )
C
C Create space for array TABLE(NCOL,NLIN)
      CALL MAKDAT( 'TABLE', 'REAL', 'STOP', NCOL*NLIN, pTABLE, CRESLT )
C
C Read data into TABLE(NLIN,NCOL) located in RZ at pointer pTABLE
      CALL USER_INPUT_TABLE( NCHANNEL, RZ(pTABLE), NCOL, NLIN )
C
      CLOSE(NCHANNEL)
C
C Return to current directory on entry.
C
      CALL POPDIR( 'STOP', CRESLT )
C
C Send any diagnostic messages via master process.

```

```

        IF ( USER_PRINTING(1:1) .NE. 'N' ) THEN
            CALL MESSAGE( 'WRITE','End USER_INPUT' )
        END IF
C
        END
C
C=====
        SUBROUTINE USER_INPUT_TABLE( NCHANNEL, TABLE, NCOL, NLIN )
C -----
C Read data into TABLE(NLIN,NCOL)
C
C Input arguments
        INTEGER NCHANNEL, NCOL, NLIN
C
C Output arguments
        REAL TABLE(NCOL,NLIN)
C
        READ( NCHANNEL, *, END=900, ERR=900 ) TABLE
        RETURN
C
C Error Handling via master process.
    900 CONTINUE
        CALL MESSAGE( 'WRITE', 'Unexpected error/end on user file' )
        CALL CFXSTP( 'USER_INPUT_TABLE' )
        END

```

After the subroutine USER\_INPUT has been executed, the directory USER\_DATA exists and contains the following information:

- /USER\_DATA/NLIN: number of lines in the table.
- /USER\_DATA/NCOL: number of columns in the table.
- /USER\_DATA/TABLE: table containing the inflow boundary profiles.

The data specified in the profile table is used to specify the inlet values for the velocity components and the turbulence quantities. Therefore, each of these quantities requires a User CEL Routine to be created. The following routine is for the first velocity component, which refers to the second column of the inflow profile table:

```

C=====
dllexport(user_uprofile)
        SUBROUTINE USER_UPROFILE (
            & NLOC, NRET, NARG, RET, ARGS, CRESLT, CZ,DZ,IZ,LZ,RZ )
CC
CC User routine: interpolate U profile from imported data.
CC
CC -----
CC          Input
CC -----
CC NLOC   - size of current locale
CC NRET   - number of components in result
CC NARG   - number of arguments in call
CC ARGS() - (NLOC,NARG) argument values
CC
CC -----
CC          Modified
CC -----
CC Stacks possibly.
CC
CC -----
CC          Output
CC -----
CC RET()  - (NLOC,NRET) return values
CC CRESLT - 'GOOD' for success
CC
CC -----
CC          Details
CC -----
CC An array of profiles TABLE(NCOL,NLIN) has been read from file

```

```

CC by junction box routine USER_INPUT. This routine now uses
CC the table to return U values for each y value given in the
CC first argument.
CC
CC=====
C -----
C   Preprocessor includes
C -----
#include "MMS.h"
#include "stack_point.h"
C
C -----
C   Argument list
C -----
      INTEGER NLOC,NARG,NRET
C
      CHARACTER CRESLT*(*)
C
      REAL ARGS(NLOC,NARG), RET(NLOC,NRET)
C
      INTEGER IZ(*)
      CHARACTER CZ(*)*(1)
      DOUBLE PRECISION DZ(*)
      LOGICAL LZ(*)
      REAL RZ(*)
C
C -----
C   Local Variables
C -----
C Table info
      INTEGER NCOL, NLIN
C
C Command file info
      CHARACTER*(MXPNAM) USER_PRINTING
C
C Arguments for LOCDAT call
      CHARACTER*4 CDTYPE
      INTEGER ISIZE
C
C -----
C   Stack pointers
C -----
      __stack_point__ pTABLE
C
CC=====
C -----
C   Executable Statements
C -----
C Look up command file info: USER_PRINTING.
      USER_PRINTING = 'No'
      CALL PEEKCS( '/USER/USER_PRINTING', USER_PRINTING, 'SKIP',
& CRESLT, CZ )
C
C Send any diagnostic messages via master process.
      IF ( USER_PRINTING(1:1) .NE. 'N' ) THEN
          CALL MESSAGE( 'WRITE','Start USER_UPROFILE' )
      END IF
C
C Initialise RET() to zero.
      CALL SET_A_0( RET, NLOC*NRET )
C
C Find TABLE(NCOL,NLIN)
      CALL PEEKI( '/USER_DATA/NCOL', 1, NCOL, 'STOP', CRESLT, IZ )
      CALL PEEKI( '/USER_DATA/NLIN', 1, NLIN, 'STOP', CRESLT, IZ )
      CALL LOCDAT( '/USER_DATA/TABLE', CDTYPE, 'STOP', ISIZE,
& pTABLE, CRESLT )
C
C Compute profile U(N) for Y(N) using TABLE(NCOL,NLIN)
      CALL USER_UPROFILE_CAL(
& RET, ARGS, NLOC, RZ(pTABLE), NCOL, NLIN, USER_PRINTING )
C
C Send any diagnostic messages via master process.

```

```

        IF ( USER_PRINTING(1:1) .NE. 'N' ) THEN
            CALL MESSAGE( 'WRITE','End USER_UPROFILE' )
        END IF
C
C Set success flag.
        CRESLT = 'GOOD'
C
        END
C=====
        SUBROUTINE USER_UPROFILE_CAL(
            & U, Y, N, TABLE, NCOL, NLIN, USER_PRINTING )
C-----
C Compute profile U(N) for Y(N) using TABLE(NCOL,NLIN)
C-----
C Input arguments
C-----
C number of points
        INTEGER N
C
C y coordinate
        REAL Y(N)
C
C input table
C Y values are in the first column of the table.
C U values are in the second column of the table.
        INTEGER NCOL, NLIN
        REAL TABLE(NCOL,NLIN)
C
C printing control
        CHARACTER*(*) USER_PRINTING
C-----
C Output arguments
C-----
        REAL U(N)
C-----
C Locals
C-----
        INTEGER I
C
        DO I = 1, N
C
C interpolate U(I) for Y(I)
            CALL USER_TABINT( Y(I), U(I), 1, 2, TABLE, NCOL, NLIN )
C
C print I, U(I), Y(I)
C note that this data is unstructured, not ordered by Y value.
C
            IF ( USER_PRINTING(1:1) .NE. 'N' ) THEN
                CALL USER_PRINT_PROFILE( I, Y(I), U(I) )
            END IF
C
        END DO
C
        END
C=====
        SUBROUTINE USER_TABINT( X, Y, IX, IY, TABLE, NCOL, NLIN )
C-----
C Linear interpolation of table data Y in column IY of TABLE(),
C against an increasing co-ordinate X in column IX of TABLE().
C-----
C Inputs:
C-----
        REAL X
        INTEGER IX, IY
        INTEGER NCOL, NLIN
        REAL TABLE(NCOL,NLIN)
C-----
C Outputs:
C-----
        REAL Y
C-----
C Locals:

```

```

C-----
      INTEGER I, J
      REAL S
C
C Find J such that TABLE(IX,J) <= X < TABLE(IX,J+1)
      J = 0
      DO I = 1, NLIN
          IF ( TABLE(IX,I) .GT. X ) GO TO 100
          J = I
      END DO
100 CONTINUE
C
C Linearly interpolate Y
      IF( J .LE. 0 ) THEN
          Y = TABLE(IY,1)
      ELSE IF ( J .GE. NLIN ) THEN
          Y = TABLE(IY,NLIN)
      ELSE
          S = (X-TABLE(IX,J))/(TABLE(IX,J+1)-TABLE(IX,J))
          Y = TABLE(IY,J)*(1.0-S) + TABLE(IY,J+1)*S
      END IF
      END
C
C=====
      SUBROUTINE USER_PRINT_PROFILE( I, Y, U )
C-----
C Print (I, Y, U) via master process.
C
      INTEGER I
      REAL Y, U
C
      CHARACTER CFROMI*5, CFROMR*15
      EXTERNAL CFROMI, CFROMR
C
      CALL MESSAGE( 'BUFF-ASIS', CFROMI(I) )
      CALL MESSAGE( 'BUFF-ASIS', ' Y(I) = ' )
      CALL MESSAGE( 'BUFF-ASIS', CFROMR(Y) )
      CALL MESSAGE( 'BUFF-ASIS', ' U(I) = ' )
      CALL MESSAGE( 'BUFF-ASIS', CFROMR(U) )
      CALL MESSAGE( 'BUFF-OUT', ' ' )
      END

```

## 18.8.2. Junction Box Example 2: Integrated Residence Time Distribution

This example makes use of the facility in order to print out integrated values of a user-defined Additional Variable that measures the residence time distribution in the flow domain. It uses the facilities to loop over all domains and all boundary condition patches, and it prints out the integrated residence time distribution on each of these locales. For details, see:

- [USER\\_GET\\_GVAR](#) (p. 501)
- [USER\\_GET\\_MESH\\_INFO](#) (p. 507)
- [CONVERT\\_NAME\\_S2U](#) (p. 520).

It also uses the facilities to look up the fluid name on each domain. Hence, it should work generically for any single phase problem. For details, see

- [USER\\_GET\\_PHYS\\_INFO](#) (p. 513)
- [CONVERT\\_NAME\\_S2U](#) (p. 520).

## 18.8.2.1. Problem Setup

### 18.8.2.1.1. Creating the Additional Variables

Before creating the domains, define the Additional Variable representing Residence Time Distribution.

- Create an Additional Variable called `RTD` of **Type Volumetric**.
- Set **Units** of time [s].

### 18.8.2.1.2. Creating the Domains

Create one or more single phase domains. On each domain, include the Additional Variable `RTD`.

- Declare `RTD` of **Type Transport Equation**.
- Set its kinematic diffusivity equal to zero.

### 18.8.2.1.3. Creating the Subdomains and Additional Variable Sources

- On each domain, create a subdomain that encompass the entire domain.
- On each such subdomain, for the Additional Variable `RTD`, set **Option** to `Source`, and set the dimensionless source term identically equal to unity.

This ensure that the Additional Variable obeys the transport equation:

$$\frac{D}{Dt} (RTD) = 1 \quad (18-5)$$

Hence, integrated along stream lines `RTD`, measure the residence time of fluid particles along streamlines.

### 18.8.2.1.4. Creating the Junction Box Routine

In CFX-Pre, you should create a User Routine with the following settings:

- Routine Name: `User Output`
- Option: `Junction Box Routine`
- Calling Name: `user_output`
- Library Name: `user_output`
- Library Path: `/home/user/Shared_Libraries`
- Junction Box Location: `End of Run`

### 18.8.2.1.5. Enabling the Junction Box Routine

In order to ensure that the solver calls the declared Junction Box routine, you should:

- Go to the **Solver Control** panel in CFX-Pre. For details, see [Basic Settings Tab in the CFX-Pre User's Guide](#).
- Select the **Junction Box Routines** box, and select the Junction Box **User Output**.

### 18.8.2.2. User Fortran Junction Box Routine

This routine looks up the number of domains, and loops over them. On each domain, it computes and prints out the arithmetic average and maximum values of the Residence Time Distribution. Additionally, on each domain, it looks up the number of boundary condition patches, and loops over them. On each BCP, it also computes and prints the arithmetic average Residence Time Distribution. Some of the comment lines are omitted. This routine `user_output.F` is supplied in the `<CFXROOT>/examples/UserFortran/` directory of your CFX installation.

```
#include "cfx5ext.h"
dllexport(user_output)
      SUBROUTINE USER_OUTPUT (CZ, DZ, IZ, LZ, RZ)
C
C Routine called at end of run
C
C Preprocessor includes
#include "MMS.h"
#include "cfd_constants.h"
C
C Arguments
      CHARACTER*(1) CZ(*)
      DOUBLE PRECISION DZ(*)
      INTEGER IZ(*)
      LOGICAL LZ(*)
      REAL RZ(*)
C
C External routines
      CHARACTER*15 CFROMR
      INTEGER LENACT
      EXTERNAL CFROMR, LENACT
C
C Local parameters
      CHARACTER*(*) ROUTIN
      PARAMETER (ROUTIN = 'USER_OUTPUT')
C Local variables
      CHARACTER*4 CRESLT
      CHARACTER*(MXDNAM) CDIR_GLOB, CDIR_ZONE, CDIR_PHYS,
& CZONE, CBCP, CPHASE
      CHARACTER*120 User_Domain_Name, User_BCP_Name,
& User_Phase_Name, User_Var_Name
      INTEGER NZN, IZN, NBCP, IBCP
      REAL VAR
C
C Executable statements
      CALL MESSAGE( 'WRITE', ' ')
      CALL MESSAGE( 'WRITE', '-----')
      CALL MESSAGE( 'WRITE', 'Start USER_OUTPUT')
      CALL MESSAGE( 'WRITE', '-----')
      CALL MESSAGE( 'WRITE', ' ')
C
C---- Obtain global meshdata
      CDIR_GLOB = ' '
      CALL USER_GET_MESH_INFO (ROUTIN, 'GET', 'STOP', 'LATEST',
& ' ', ' ', CDIR_GLOB, CRESLT, CZ, DZ, IZ, LZ, RZ)
C---- Look up number of domains, and loop over domains
      CALL PEEKI ('/USER/'//CDIR_GLOB//'/NZN', IONE, NZN,
& 'STOP', CRESLT, IZ)
      IF (CRESLT.NE. 'GOOD') GOTO 999
      DO IZN = 1, NZN
C
C---- CZONE = solver domain name
      CALL PEEKCA ('/USER/'//CDIR_GLOB//'/CZONE', IZN, CZONE,
& 'STOP', CRESLT, CZ)
      IF (CRESLT.NE. 'GOOD') GOTO 999
C
C---- Convert to user domain name
      CALL CONVERT_NAME_S2U ('Domain', CZONE, ' ', User_Domain_Name,
& CRESLT, CZ, DZ, IZ, LZ, RZ)
      IF (CRESLT.NE. 'GOOD') GOTO 999
```

```

        CALL MESSAGE( 'WRITE', ' ')
        CALL MESSAGE( 'WRITE', '-----')
        CALL MESSAGE( 'WRITE', 'Domain: '//User_Domain_Name)
        CALL MESSAGE( 'WRITE', '-----')
        CALL MESSAGE( 'WRITE', ' ')
C
C---- Get physics info.
        CDIR_PHYS = ' '
        CALL USER_GET_PHYS_INFO (ROUTIN,'GET','STOP','LATEST',
&                                CZONE,' ',CDIR_PHYS,CRESLT, CZ,DZ,IZ,LZ,RZ)
C
C---- CPHASE = solver phase name (assumes single phase)
        CALL PEEKCA ('/USER//CDIR_PHYS//CPHASE', IONE, CPHASE,
&                    'STOP', CRESLT, CZ)
        IF (CRESLT .NE. 'GOOD') GOTO 999
C
C---- Convert to user phase name
        CALL CONVERT_NAME_S2U ('Phase', CPHASE, ' ', User_Phase_Name,
&                                CRESLT, CZ, DZ, IZ, LZ, RZ)
        IF (CRESLT .NE. 'GOOD') GOTO 999
C
C---- Set User Variable Name = User_Phase_Name.RTD
C---- (RTD = Residence Time Distribution).
        User_Var_Name = User_Phase_Name(1:LENACT(User_Phase_Name))
&                    // '.RTD'
        CALL MESSAGE( 'WRITE', ' ')
        CALL MESSAGE( 'WRITE', '-----')
        CALL MESSAGE( 'WRITE', 'Variable: '//User_Var_Name)
        CALL MESSAGE( 'WRITE', '-----')
        CALL MESSAGE( 'WRITE', ' ')
C
C---- Obtain global values on domain
        CALL USER_GET_GVAR (User_Var_Name, User_Domain_Name,
&                            'ave', CRESLT, VAR, CZ, DZ, IZ, LZ, RZ)
        IF (CRESLT .NE. 'GOOD') GOTO 999
        CALL MESSAGE( 'WRITE', 'RDT Mean Value = '//CFROMR(VAR))
C
        CALL USER_GET_GVAR (User_Var_Name, User_Domain_Name,
&                            'maxVal', CRESLT, VAR, CZ, DZ, IZ, LZ, RZ)
        IF (CRESLT .NE. 'GOOD') GOTO 999
        CALL MESSAGE( 'WRITE', 'RDT Max Value = '//CFROMR(VAR))
C
C---- Obtain zonal meshdata
        CDIR_ZONE = ' '
        CALL USER_GET_MESH_INFO (ROUTIN,'GET','STOP','LATEST',
&                                CZONE,' ',CDIR_ZONE,CRESLT,
&                                CZ,DZ,IZ,LZ,RZ)
C
C---- Look up number of Boundary Condition Patches (BCP's),
C---- and loop over BCP's.
        CALL PEEKI ('/USER//CDIR_ZONE//NBCP', IONE, NBCP,
&                    'STOP', CRESLT, IZ)
        IF (CRESLT .NE. 'GOOD') GOTO 999
        DO IBCP = 1, NBCP
C
C---- CBCP = solver BCP name
        CALL PEEKCA ('/USER//CDIR_ZONE//CBCP', IBCP, CBCP,
&                    'STOP', CRESLT, CZ)
        IF (CRESLT .NE. 'GOOD') GOTO 999
C
C---- Convert to user BCP name
        CALL CONVERT_NAME_S2U ('Bcp', CBCP, ' ', User_BCP_Name,
&                                CRESLT, CZ, DZ, IZ, LZ, RZ)
        IF (CRESLT .NE. 'GOOD') GOTO 999
        CALL MESSAGE( 'WRITE', ' ')
        CALL MESSAGE( 'WRITE', '-----')
        CALL MESSAGE( 'WRITE', 'Boundary: '//User_BCP_Name)
        CALL MESSAGE( 'WRITE', '-----')
        CALL MESSAGE( 'WRITE', ' ')
C
C---- Obtain global values on BCP
        CALL USER_GET_GVAR (User_Var_Name, User_BCP_Name,

```

```

&          'ave', CRESLT, VAR, CZ,DZ,IZ,LZ,RZ)
  IF (CRESLT .NE. 'GOOD') GOTO 999
  CALL MESSAGE( 'WRITE', 'RDT Mean Value = '//CFROMR(VAR))
C
  CALL USER_GET_GVAR (User_Var_Name,User_BCP_Name,
&          'maxVal',CRESLT, VAR, CZ,DZ,IZ,LZ,RZ)
  IF (CRESLT .NE. 'GOOD') GOTO 999
  CALL MESSAGE( 'WRITE', 'RDT Max Value = '//CFROMR(VAR))
C
C---- End Loop Over BCP's
      END DO
C
C---- End Loop Over Zones
      END DO
C
C---- Delete Mesh Data
  CALL USER_GET_MESH_INFO (ROUTIN,'DELETE','STOP','LATEST',
&          ' ',' ',CDIR_GLOB,CRESLT,
&          CZ,DZ,IZ,LZ,RZ)
C
999  CONTINUE
  IF (CRESLT .NE. 'GOOD') THEN
    CALL MESSAGE( 'WRITE', 'User abort, CRESLT = '//CRESLT)
    CALL CFXSTP (ROUTIN)
  ENDIF
C
  END

```

### 18.8.3. Junction Box Example 3: Timestep Control

This Junction Box subroutine should be called at the end of each timestep in a transient run. It is designed to dynamically control the timestep size during the transient run. The algorithm is similar to one of the adaptive timestepping algorithms available in the solver, but serves to illustrate how a junction box can be used to control the timestep size. The algorithm for modifying the timestep is as follows: if the previous timestep needed more iterations than MAXLOOPS, the next timestep size is decreased by a factor FACDEC. If the previous timestep needed fewer iterations than MINLOOPS, the next timestep size is increased by a factor FACINC. The junction box calls USER\_GET\_TRANS\_INFO to retrieve current timestep data and creates a data area called 'NEWDT' to store the next timestep size. The procedure requires a User CEL function called Retrieve\_deltat to use the timestep calculated by the junction box. Retrieve\_deltat requires an additional argument (passed in through the argument list) called 'Timesteps', which will be the initial timestep size. The routines t\_step\_control.F and Retrieve\_deltat.F are supplied in the <CFXROOT>/examples/UserFortran/ directory of your CFX installation.

The following is a listing of t\_step\_control.F:

```

#include "cfx5ext.h"
dllexport(tstepcontrol)
C=====
  SUBROUTINE tstepcontrol(CZ,DZ,IZ,LZ,RZ)
CC
CD Recalculates timestep size to fit into a maximum and minimum
CD coefficient loops.
CC
CC -----
CC          Modified
CC -----
CC
CV Stacks
CC
CC -----
CC          Modified
CC -----
CC
CC -----
CC          Output

```

```

CC -----
CC
CC -----
CC Modification History
CC -----
CC
CC
CC -----
CC Variable dictionary
CC -----
CC
CC -----
CC Local variables & parameters
CC -----
CC
CC CLOOP,LLOOP,NLOOP      : Coefficient loop name,length, and number
CC CSTEP,LTSTEP,NTSTEP   : Coefficient step name,length, and number
CC DT                    : Timestep size
CC MAXDT,MINDT           : Maximum and minimum timestep size
CC FACINC,FACDEC         : Increment and decrement factors
CC
CC=====
CC -----
C      Preprocessor includes
C -----
C
C #include "MMS.h"
C #include "stack_point.h"
C #include "cfd_constants.h"
C
C -----
C      Argument List
C -----
C
C      CHARACTER CZ(*)*(1)
C
C      DOUBLE PRECISION DZ(*)
C
C      INTEGER IZ(*)
C
C      LOGICAL LZ(*)
C
C      REAL RZ(*)
C
C -----
C      External routines
C -----
C
C      LOGICAL LFIL
C      EXTERNAL CFROMR,CFROMI,LFIL
C
C -----
C      Local Variables
C -----
C
C      CHARACTER*4 CRESLT
C      CHARACTER*(10) CFROMI
C      CHARACTER*(20) CLOOP,CTSTEP,CFROMR,FNAME
C
C      INTEGER LLOOP,NLOOP,LTSTEP,NTSTEP,MINLOOPS,MAXLOOPS,IUNIT,ICALL
C
C      REAL DT,MAXDT,MINDT,TIME,FACINC,FACDEC
C
C -----
C      Local Parameters
C -----
C
C      PARAMETER(IUNIT=91,FNAME='dt_nloop.dat')
C
C--Saved data.
C
C      SAVE ICALL,FACINC,FACDEC,MINDT,MAXDT,MINLOOPS,MAXLOOPS

```

```

C
C -----
C      Stack pointers
C -----
C
C      __stack_point__ pOINT
C
C -----
C      Executable Statements
C -----
C
C      IF (ICALL.EQ.0) THEN
C          ICALL=1
C
C----- Set defaults:
C      MINDT is used to enforce a positive timestep size
C
C          MINDT = 0.
C          MAXDT = 1.E10
C          MINLOOPS=3
C          MAXLOOPS=8
C
C----- Negative means: increase by 10/decrease by 0.1 each given
C      iteration number, positive means: factor itself
C
C          FACINC=-40.
C          FACDEC=-10.
C
C----- Get from USER area if there:
C
C          CALL USER_PEEKR('MINDT',1,MINDT,'SKIP',CRESLT,CZ)
C          CALL USER_PEEKR('MAXDT',1,MAXDT,'SKIP',CRESLT,CZ)
C          CALL USER_PEEKI('MINLOOPS',1,MINLOOPS,'SKIP',CRESLT,CZ)
C          CALL USER_PEEKI('MAXLOOPS',1,MAXLOOPS,'SKIP',CRESLT,CZ)
C          CALL USER_PEEKR('FACINC',1,FACINC,'SKIP',CRESLT,CZ)
C          CALL USER_PEEKR('FACDEC',1,FACDEC,'SKIP',CRESLT,CZ)
C
C----- Increment by factor 10 each ## time steps
C
C          IF (FACINC.LE.0) FACINC=10.*(1./ABS(FACINC))
C
C----- Decrement by factor 0.1 each ## time steps
C
C          IF (FACDEC.LE.0) FACDEC=0.1*(1./ABS(FACDEC))
C
C----- Output parameters
C
C          CALL MESSAGE('WRITE','MINDT is '//CFROMR(MINDT))
C          CALL MESSAGE('WRITE','MAXDT is '//CFROMR(MAXDT))
C          CALL MESSAGE('WRITE','MINLOOPS is '//CFROMI(MINLOOPS))
C          CALL MESSAGE('WRITE','MAXLOOPS is '//CFROMI(MAXLOOPS))
C          CALL MESSAGE('WRITE','FACINC is '//CFROMR(FACINC)//
&          ' ('//CFROMI(INT(1./LOG10(FACINC)+0.5))//')')
C          CALL MESSAGE('WRITE','FACDEC is '//CFROMR(FACDEC)//
&          ' ('//CFROMI(INT(-1./LOG10(FACDEC)+0.5))//')')
C          IF (IUNIT>0) OPEN(UNIT=IUNIT,FILE=FNAME)
C          END IF
C
C----- Get transient info
C
C          CALL USER_GET_TRANS_INFO('TSTEPCONTROL','GET',' ',
&          CZ,DZ,IZ,LZ,RZ)
C
C----- Get time step
C
C          CALL PEEKR('/USER/TRANS_INFO/DT',1,DT,'STOP',CRESLT,RZ)
C
C----- Write into file
C
C          IF (IUNIT>0) THEN
C
C----- Get time and current coefficient loop

```

```

C
  CALL PEEKR('/USER/TRANS_INFO/ATIME',1,TIME,'STOP',CRESLT,RZ)
  CALL PEEKI('/USER/TRANS_INFO/NCLOOP',1,NCLOOP,'STOP',CRESLT,IZ)
  WRITE(IUNIT,*) DT,NCLOOP,TIME
C
  END IF
C
C---- Control structure
C
  CALL MESSAGE('WRITE','Number of coeff loops was: '//CFROMI(NCLOOP))
C
  IF (NCLOOP.LT.MINLOOPS) THEN
    DT=MIN(FACINC*DT,MAXDT)
    CALL MESSAGE('WRITE','Time step increased to: '//CFROMR(DT))
  ELSE IF (NCLOOP.GT.MAXLOOPS) THEN
    DT=FACDEC*DT
    IF (MINDT.LE.0.AND.DT.LE.-MINDT) THEN
      IF (IUNIT.GT.0) CLOSE(IUNIT)
      CALL MESSAGE('WRITE','Stop program due to bad convergence.')
      OPEN(UNIT=91,FILE='stp')
      WRITE(91,*) ' '
      CLOSE(91)
    END IF
    DT=MAX(DT,MINDT)
    CALL MESSAGE('WRITE','Time step decreased to: '//CFROMR(DT))
  ELSE
    CALL MESSAGE('WRITE','Time step stayed at: '//CFROMR(DT))
  END IF
C
C---- Set new time step
C
  IF (.NOT.LFIL('/USER/NEWDT')) THEN
    CALL PSHDIR ('/USER','STOP',CRESLT)
    CALL MAKDAT('NEWDT','REAL','STOP',1,POINT,CRESLT)
    CALL POPDIR ('STOP',CRESLT)
  ENDIF
  CALL POKER('/USER/NEWDT',1,DT,'STOP',CRESLT,RZ)
C
C---- Release transient data
C
  CALL USER_GET_TRANS_INFO('TSTEPCONTROL','RELEASE',' ',
&                          CZ,DZ,IZ,LZ,RZ)
C
  END

```

The following is a listing of Retrieve\_deltat.F:

```

#include "cfx5ext.h"
dllexport(get_timestep)
  SUBROUTINE get_timestep (
&   NLOC,NRET,NARG,RET,ARGS,CRESLT,CZ,DZ,IZ,LZ,RZ)
CC
CD User routine: retrieves delta t stored in /USER directory
CC
CC -----
CC      Input
CC -----
CC
CC NLOC   - size of current locale
CC NRET   - number of components in result
CC NARG   - number of arguments in call
CC ARGS() - (NLOC,NARG) argument values
CC
CC -----
CC      Modified
CC -----
CC
CC Stacks possibly.
CC
CC -----
CC      Output
CC -----

```

```

CC
CC RET() - (NLOC,NRET) return values
CC CRESLT - 'GOOD' for success
CC
CC -----
CC      Details
CC -----
CC
CC=====
C
C -----
C      Preprocessor includes
C -----
C
#include "MMS.h"
#include "cfd_constants.h"
C
C -----
C      Global Parameters
C -----
C
C
C -----
C      Argument list
C -----
C
      CHARACTER CRESLT*(*)
      CHARACTER CZ(*)*(1)
C
      DOUBLE PRECISION DZ(*)
C
      INTEGER IZ(*)
      INTEGER NLOC,NARG,NRET
C
      LOGICAL LZ(*)
C
      REAL RZ(*)
      REAL ARGS(NLOC,NARG), RET(NLOC,NRET)
C
C
C -----
C      External routines
C -----
C
C
C -----
C      Local Parameters
C -----
C
C
C -----
C      Local Variables
C -----
C
      CHARACTER*(4) CRES
C
      REAL DT
C
C -----
C      Executable Statements
C -----
C
C
C Set success flag.
C
      CRES = 'GOOD'
C
C---- Retrieves DT value. If there is none, it uses default the value
C      passed as argument.
C
      CALL PEEKR('/USER/NEWDT', IONE,DT,'SKIP',CRES,RZ)
      IF (CRES .NE. 'GOOD') DT = ARGS(1,1)

```

```

      RET(1,1) = DT
C
      END

```

## 18.8.4. Junction Box Example 4: Solver Control

This example stops the Solver when either the max, min or mean value of a variable falls in a specified range. The user specifies the variable, its range and whether to use max, min or mean in the `USER` section of their `CCL`. This method can be useful for ventilation cases, where a transient simulation must be performed to determine when a flammable gas or contaminant falls below a certain limit. The routine should be called at the end of each timestep. It is a specialist routine, as it requires knowledge of solver data structures in order to issue the `STOP` instruction. This may require different operation depending on whether the simulation is transient or steady-state.

The following routine `solver_control.F` is supplied in the `<CFXROOT>/examples/UserFortran/` directory of your CFX installation. Some comment lines may be omitted below.

```

#include "cfx5ext.h"
dllexport(stopinteg)
      SUBROUTINE STOPINTEG (CZ,DZ,IZ,LZ,RZ)
C
C Stops solver when a variable integrated quantity falls in a range
C Junction box routine, to be called at the end of each timestep
C
C Include directives
#include "cfd_constants.h"
#include "MMS.h"
#include "stack_point.h"
C
C Arguments
      INTEGER IZ(*)
      CHARACTER CZ(*)*(1)
      DOUBLE PRECISION DZ(*)
      LOGICAL LZ(*)
      REAL RZ(*)
C External functions
      INTEGER LENACT
      EXTERNAL LENACT
C
      CHARACTER*15 CFROMR
      EXTERNAL CFROMR
C
C Local parameters
      CHARACTER*(*) ROUTIN
      PARAMETER (ROUTIN = 'STOPINTEG')
C
C Local Variables
      CHARACTER*4 CRESLT
      CHARACTER*(MXDNAM) CDIR_GLOB, CDIR_TEST, CZONE
      CHARACTER*80 USER_DOMAIN, USER_VAR, USER_OPER
C
      REAL USER_MIN, USER_MAX, VAR
C
C =====
C Executable Statements
C =====
C -----
C Obtain user domain name, assuming one domain only.
C -----
C
C---- Obtain global meshdata
C
      CDIR_GLOB = ' '
      CALL USER_GET_MESH_INFO (ROUTIN, 'GET', 'STOP', 'LATEST',
&
      ' ', ' ', CDIR_GLOB, CRESLT, CZ, DZ, IZ, LZ, RZ)
C
C---- CZONE = first solver domain name

```

```

C
  CALL PEEKCA ('/USER//CDIR_GLOB//CZONE', IONE, CZONE,
&            'STOP', CRESLT, CZ)
C
C---- Convert to user domain name
C
  CALL CONVERT_NAME_S2U ('Domain', CZONE, ' ', USER_DOMAIN,
&                      CRESLT, CZ, DZ, IZ, LZ, RZ)
C
C -----
C Get names and values from /USER
C -----
C
C Get names and values from /USER
C
  CALL USER_PEEKCS ('UserVarName', USER_VAR, 'STOP', CRESLT, CZ)
  CALL USER_PEEKCS ('UserVarOper', USER_OPER, 'STOP', CRESLT, CZ)
  CALL USER_PEEKR ('UserVarMin', IONE, USER_MIN, 'STOP', CRESLT, CZ)
  CALL USER_PEEKR ('UserVarMax', IONE, USER_MAX, 'STOP', CRESLT, CZ)
C
C -----
C Obtain the integrated quantity required
C -----
C
  CALL USER_GET_GVAR (USER_VAR, USER_DOMAIN, USER_OPER,
&                   CRESLT, VAR, CZ, DZ, IZ, LZ, RZ)
C
  CALL MESSAGE( 'WRITE', ' ')
  CALL MESSAGE( 'WRITE', '-----')
  CALL MESSAGE( 'WRITE', 'Entered subroutine //ROUTIN)
  CALL MESSAGE( 'WRITE', '-----0-----')
  CALL MESSAGE( 'WRITE', ' ')
  CALL MESSAGE( 'WRITE', 'Domain Name = //USER_DOMAIN)
  CALL MESSAGE( 'WRITE', 'User Variable = //USER_VAR)
  CALL MESSAGE( 'WRITE', 'User Operation = //USER_OPER)
  CALL MESSAGE( 'WRITE', 'Minimum Value = //CFROMR(USER_MIN))
  CALL MESSAGE( 'WRITE', 'Maximum Value = //CFROMR(USER_MAX))
  CALL MESSAGE( 'WRITE', 'Integrated Value = //CFROMR(VAR))
C
C -----
C If conditions are met, print a banner and stop after this timestep
C -----
C
C Stop achieved by setting /FLOW/ALGORITHM/CONTROL/NEXT_TSTEP to FALSE
  IF (VAR.GE.USER_MIN .AND. VAR.LE.USER_MAX) THEN
C
  CALL MESSAGE( 'WRITE', ' ')
  CALL MESSAGE( 'WRITE', '-----')
  CALL MESSAGE( 'WRITE', 'Stopping the solver in SOLVER_CONTROL ')
  CALL MESSAGE( 'WRITE', '-----')
  CALL MESSAGE( 'WRITE', ' ')
C
C Stop flag in case of transient simulation
C
  CALL POKEL ('/FLOW/ALGORITHM/CONTROL/NEXT_TSTEP', IONE, .FALSE.,
&          'STOP', CRESLT, LZ)
C
C Stop flag in case of steady-state simulation
C
  CALL POKEL ('/FLOW/ALGORITHM/CONTROL/STOP_TSL', IONE, .TRUE.,
&          'STOP', CRESLT, LZ)
CC
  END IF
C
  END

```

## 18.8.5. Junction Box Example 5: Transient Information

This is an example of how to obtain transient data from within a User Fortran junction box routine. In a junction box routine, it is necessary to loop over all zones (domains). For a single domain problem,

there will be only one zone, but the approach shown is more general, because it is possible to set a different timestep in each domain. The code shown first obtains and prints out non-zone-specific transient data, and then loops over all zones and obtains zone-specific transient data. Standard CFX memory management system routines, such as PSHDIR, POPDIR, PEEKI and PEEKR, are used to move around the data-structures and obtain the required data.

To use these files, it will first be necessary to modify the file run.ccl so that the shared library path is set to the correct location on your filesystem. The User Fortran will then need to be compiled as follows:

```
cfx5mkext -name transinfo transinfo.F
```

The case may be run once as follows:

```
cfx5solve -def transient.def -ccl run.ccl.
```

A restart may be carried out from the first run in order to complete additional time-steps and demonstrate how the accumulated timesteps count and value operates:

```
cfx5solve -def transient_001.res -ccl run.ccl
```

This routine transinfo.F is supplied in the <CFXROOT>/examples/UserFortran/ directory of your CFX installation.

```
#include "cfx5ext.h"
dllexport(get_tstep_info)
    SUBROUTINE GET_TSTEP_INFO (CZ, DZ, IZ, LZ, RZ)
    IMPLICIT NONE

C
C Example of obtaining transient info for all zones
C
C =====
C Include directives
C =====
C
#include "MMS.h"
#include "cfd_constants.h"
C
C =====
C Arguments
C =====
C
C Stacks
    CHARACTER*(1) CZ(*)
    DOUBLE PRECISION DZ(*)
    INTEGER IZ(*)
    LOGICAL LZ(*)
    REAL RZ(*)

C
C =====
C External functions
C =====
C
C Function to concatenate an integer on to the end of a string
    CHARACTER*(MXDNAM) CCATI
    EXTERNAL CCATI

C
C =====
C Local variables
C =====
C
C Result
    CHARACTER*4 CRESLT
C Zone (domain)
    CHARACTER*(MXDNAM) CZONE
C Path name
    CHARACTER*(MXPNAM) CDRNAM
C
C Number of zones & iterator
```

```

      INTEGER NZN, IZN
C Number of timesteps, accumulated timesteps, coefficient loops
      INTEGER NTSTEP, ATSTEP, NCLOOP
C
C Time, accumulated time, timestep value
      REAL DT, TIME_DTEND, RTIME_DTEND
C
C =====
C Executable statements
C =====
C
C -----
C Obtain and write non zone specific data
C -----
C
C Obtain number of timesteps, accumulated timesteps & coefficient loops
      CALL PSHDIR ('/FLOW/SOLUTION', 'STOP', CRESLT)
      CALL PEEKI ('NTSTEP', IONE, NTSTEP, 'STOP', CRESLT, IZ)
      CALL PEEKI ('ATSTEP', IONE, ATSTEP, 'STOP', CRESLT, IZ)
      CALL PSHDIR (CCATI('TSTEP',ATSTEP), 'STOP', CRESLT)
      CALL PEEKI ('NCLOOP', IONE, NCLOOP, 'STOP', CRESLT, IZ)
      CALL POPDIR ('STOP', CRESLT)
      CALL POPDIR ('STOP', CRESLT)
C
C Write to standard output
      WRITE(*,*)
      WRITE(*,*) '          Timestep:', NTSTEP
      WRITE(*,*) 'ACCUMULATED Timestep:', ATSTEP
      WRITE(*,*) '    COEFFICIENT LOOP:', NCLOOP
C
C -----
C Obtain and write zone specific data
C -----
C
C Determine the number of zones (domains)
      CALL PEEKI ('/FLOW/GEOMETRY/NZN', IONE, NZN, 'STOP', CRESLT, IZ)
C
C Loop over all zones
      DO IZN = 1,NZN
          CALL PEEKCA ('/FLOW/GEOMETRY/CZONE',
&      IZN, CZONE, 'STOP', CRESLT, CZ)
C
C Obtain time, accumulated time & timestep value for this zone
      CDRNAM = '/FLOW/SOLUTION/LATEST/' // CZONE
      CALL PSHDIR (CDRNAM, 'STOP', CRESLT)
      CALL PEEKR ('TIME_DTEND', IONE, TIME_DTEND, 'STOP', CRESLT, RZ)
      CALL PEEKR ('RTIME_DTEND', IONE, RTIME_DTEND, 'STOP', CRESLT, RZ)
      CALL PEEKR ('DT', IONE, DT, 'STOP', CRESLT, RZ)
      CALL POPDIR ('STOP', CRESLT)
C
C Write to standard output
      WRITE(*,*) '          ZONE:', IZN
      WRITE(*,*) '          TIME:', RTIME_DTEND
      WRITE(*,*) '    ACCUMULATED TIME:', TIME_DTEND
      WRITE(*,*) '    Timestep VALUE:', DT
      END DO
C
      END

```

## 18.9. Using CFX-4 Routines in CFX

With the availability of CFX Expression Language (CEL), many of the documented user routines presented in CFX can be set up using CEL in CFX. For details, see [CFX Expression Language \(CEL\) in the CFX Reference Guide](#). The following table lists some user routines from CFX-4, and how they can be set up in CFX.

CFX routine and description	How to set up in CFX
<p>USRBCS</p> <p>A routine that enables the specification of real information at inlets, mass flow boundaries, pressure boundaries, walls and conducting boundaries, both at the start of a run and on each timestep.</p>	<p>An inlet profile using User Fortran is described in Junction Box Example 1. For details, see <a href="#">Junction Box Example 1: Profile Boundary Conditions (p. 550)</a>. Time-varying boundary conditions can be set up using CEL, with an expression containing <b>t</b>.</p>
<p>USRBF</p> <p>To enable you to specify body forces in the momentum equations.</p>	<p>This routine has been replaced by both CEL and loss models. For details, see <a href="#">Sources (p. 31)</a>.</p>
<p>USRDEN</p> <p>Used to overwrite the default equation of state in a compressible flow, or to set a varying density in an incompressible flow.</p>	<p>There is no need to set <math>\partial \rho / \partial p</math> as this is calculated by the solver. Density can be specified using CEL.</p>
<p>USRDIF</p> <p>used to overwrite the default diffusion coefficients in each transport equation. The routine is called for each equation. The equation label enters through the argument list.</p>	<p>Can be specified using CEL, except for orthotropic diffusivity.</p>
<p>USRDMP</p> <p>Enables more complex control of output files.</p>	<p>Output control in CFX-Pre largely replaces the need for this routine. For details, see <a href="#">Output Control in the CFX-Pre User's Guide</a>.</p>
<p>USRDRG</p> <p>Enables you to overwrite the standard drag factor on particles in the particle transport model. This would normally involve setting the CD factor as a function of the relative speed of the particle and surrounding fluid.</p>	<p>Particle User Fortran can be used in CFX. For details, see <a href="#">Particle User Sources (p. 256)</a>.</p>
<p>USRGRD</p> <p>Enables you to define a grid and to specify movement of the grid with time.</p>	<p>This is covered by the explicit mesh movement feature of the moving mesh capability. For details, see <a href="#">Mesh Deformation in the CFX-Pre User's Guide</a>.</p>
<p>USRINT</p> <p>Used to overwrite the initial conditions, particularly on restarts.</p>	<p>CCL and/or CEL can be used here.</p>
<p>USRIPM</p> <p>Used to set complex interphase mass transfer terms.</p>	<p>CEL</p>
<p>USRIPT</p>	<p>CEL</p>

CFX routine and description	How to set up in CFX
Used to set complex interphase transfer terms.	
USRRAC To enable you to inspect or change reaction rate constants and their derivatives.	CEL and/or CCL
USRSLP To enable you to specify the slip velocity in the algebraic slip model.	CEL can be used.
USRSPH To enable you to specify specific heat as an arbitrary constitutive function.	CEL can be used.
USRSRC This routine enables you to intervene and change the equations; in particular, to add sources and sinks of momentum and energy.	This can be carried out using User CEL. An example is available in <i>User CEL Example 1: User Defined Momentum Source</i> (p. 543).
USRTRN The routine is called after the initial guess and at the end of each timestep. The routine can be used to monitor the calculation, or to produce special output for each timestep. It may also be used at the end of the job to calculate additional quantities from the basic solution variables.	The User Junction Box routines can handle this type of application.
USRVIS enables you to specify a variable viscosity as a function of any combination of the other variables for use in a laminar flow calculation.	CEL
USRWRK This routine enables you to reserve work space that may then be accessed in any of the user-defined routines.	This operation is implemented by making space available in the /USER data area. Space can be created using the MAKDAT routine. For details, see <i>MAKDAT</i> (p. 533).

## 18.10. State Point Evaluation

The user state point query function enables the evaluation of thermodynamic properties at a user specified state. This is accomplished by calling the following utility routine from within User Fortran sub-routines (User CEL functions or Junction Boxes):

```
CALL USER_STATEPT (VAR, CPROCALC, CPROPIND, RPROPIND, NPROPIND,
& CERACT, CRESLT, CZ, DZ, IZ, LZ, RZ)
```

The input arguments for this utility are:

- CHARACTER\*(\*) CPROPCALC - Name of requested output property variable.
- CHARACTER\*(\*) CPROPIND(NPROPIND) - Array of independent thermodynamic property names.
- REAL RPROPCALC(NPROPIND) - Array of independent thermodynamic property values.
- INTEGER NPROPIND - Number of independent thermodynamic properties.
- CHARACTER\*4 CERACT - Error action: STOP to stop on error, or SKIP to continue silently, with the result code returned in CRESLT.
- CHARACTER\*1(\*) CZ - CHARACTER data stack.
- DOUBLE DZ - DOUBLE PRECISION data stack.
- DOUBLE IZ - INTEGER data stack.
- DOUBLE LZ - LOGICAL data stack.
- DOUBLE RZ - REAL data stack.

The output arguments for this utility are:

- REAL VAR - Return value of CPROPCALC at the user-specified thermodynamic state.
- CHARACTER\*4 CRESLT - result code, which is GOOD if successful.

### 18.10.1. General Usage Notes

The following are guidelines on how to set the various input arguments:

- The function call to USER\_STATEPT must provide the input arguments in terms of thermodynamic properties and mixture composition, if applicable.
- User state point function calls do not support phases that use the "Saturation Temperature" or the "Small Droplet Temperature" heat transfer models.
- Each user state point function call must specify the material for which the output property is evaluated. The equation of state and constitutive relationship for the specified material are then used to evaluate the property.
- User state point function calls can accept an arbitrary number of single valued input arguments.
- Input arguments can be only thermodynamic properties and composition. Other variables are not supported.
- User state point function calls return a single valued result from the specified input arguments. The requested result must be a material property that is not one of the input arguments.
- In a simulation that involves disconnected domains, the specification of unique fluid names is required. Otherwise, the CFX-Solver may not be able to identify the corresponding materials.

### 18.10.2. Supported Independent Thermodynamic Input Properties

The following input properties are currently supported with USER\_STATEPT:

- Temperature
- Absolute Pressure
- Absolute Pressure and Temperature
- Absolute Pressure and Enthalpy

- Absolute Pressure and Entropy
- Pressure
- Pressure and Temperature
- Pressure and Enthalpy
- Pressure and Entropy
- Mixture Composition (if the material is a variable composition mixture)

The format of the input arguments is an array of property names. The names must be set to the valid short or long names.

### 18.10.3. Supported Thermodynamic Output Properties

The following output properties are currently supported with `USER_STATEPT`:

- Pressure and Absolute Pressure
- Temperature
- Static Enthalpy
- Static Entropy
- Specific Heat at Constant Pressure
- Specific Heat at Constant Volume
- Dynamic Viscosity
- Density
- Isentropic Compressibility
- Isothermal Compressibility
- Local Speed of Sound

### 18.10.4. Input and Output Property Name Format

The input and output arguments are specified using standard CFX Expression Language syntax. Both short and long names are supported. The syntax of the arguments is either `<fluid name>.<property>` or `<component>.<property>`, where `<fluid name>` is the name of the fluid, `<component>` is the mixture component name (if needed) and `<property>` is the name of the property in short or long form.

#### 18.10.4.1. Pure Substance Example

The following code section shows the use of short or long names for input and output properties for a simulation that involves a pure substance:

```

C
C---- Input thermodynamic properties:
C      ? Temperature and pressure
C
      CPROPIND(1) = 'T'
      CPROPIND(2) = 'pabs'
C
C---- Input values for temperature and pressure
C
      RPROPIND(1) = 498.15
      RPROPIND(2) = 101325.

```

```

C
C-----
C   Short names for input properties, long name for output property
C-----
C
C   CPROPCALC = 'Air Ideal Gas.Static Enthalpy'
CALL USER_STATEPT(H,CPROPCALC,CPROPIND,RPROPIND,
&                 NPROPIND,'SKIP',CRESLT, CZ,DZ,IZ,LZ,RZ)
C
C-----
C   Long names for input properties, short names for output property
C-----
C
C   CPROPIND(1) = 'Temperature'
C   CPROPIND(2) = 'Absolute Pressure'
C
C   CPROPCALC = 'Air Ideal Gas.Entropy'
CALL USER_STATEPT(S,CPROPCALC,CPROPIND,RPROPIND,
&                 NPROPIND,'SKIP',CRESLT, CZ,DZ,IZ,LZ,RZ)
C
C-----
C   Mixed long and short names for input/output properties
C-----
C
C   CPROPIND(1) = 'T'
C   CPROPIND(2) = 'Absolute Pressure'
C
C   CPROPCALC = 'Air Ideal Gas.Cp'
CALL USER_STATEPT(Cp,CPROPCALC,CPROPIND,RPROPIND,
&                 NPROPIND,'SKIP',CRESLT, CZ,DZ,IZ,LZ,RZ)
...

```

### 18.10.4.2. Mixture Example

The following code section shows the use of short or long names for input and output properties for a simulation that involves a mixture consisting of four different materials:

```

C
C---- Input thermodynamic properties:
C   ' Temperature and pressure
C
C   CPROPIND(1) = 'T'
C   CPROPIND(2) = 'pabs'
C
C---- Input values for temperature and pressure
C
C   RPROPIND(1) = 498.15
C   RPROPIND(2) = 101325.
C
C---- Specify mass fractions for each fluid component material (short
C   names)
C
C   CPROPIND(3) = 'N2 Ideal Gas.mf'
C   CPROPIND(4) = 'O2 Ideal Gas.mf'
C   CPROPIND(5) = 'CO2 Ideal Gas.mf'
C   CPROPIND(6) = 'CO2 Const Prop.mf'
C
C---- Fluid mixture mass fractions
C
C   RPROPIND(3) = 0.79
C   RPROPIND(4) = 0.18
C   RPROPIND(5) = 0.01
C   RPROPIND(6) = 0.01
C
C-----
C   Mixture enthalpy, short names for component mass fractions
C-----
C
C   CPROPCALC = 'MyMixture.Static Enthalpy'
CALL USER_STATEPT(H,CPROPCALC,CPROPIND,RPROPIND,
&                 NPROPIND,'SKIP',CRESLT, CZ,DZ,IZ,LZ,RZ)

```

```

C
C-----
C   Compute mixture specific heat capacity, long names for
C   component mass fractions
C-----
C
CPROPIND(3) = 'N2 Ideal Gas.Mass Fraction'
CPROPIND(4) = 'O2 Ideal Gas.Mass Fraction'
CPROPIND(5) = 'CO2 Ideal Gas.Mass Fraction'
CPROPIND(6) = 'CO2 Const Prop.Mass Fraction'
C
CPROPCALC = 'MyMixture.Cp'
CALL USER_STATEPT(CpM,CPROPCALC,CPROPIND,RPROPIND,
&                NPROPIND,'SKIP',CRESLT, CZ,DZ,IZ,LZ,RZ)
C
C-----
C   Compute specific heat capacity for one of the mixture components
C   use long names for component mass fractions
C-----
C
CPROPCALC = 'MyMixture.O2 Ideal Gas.Cp'
CALL USER_STATEPT(CpO2,CPROPCALC,CPROPIND,RPROPIND,
&                NPROPIND,'SKIP',CRESLT, CZ,DZ,IZ,LZ,RZ)
...

```

### 18.10.5. Supported Material Types

The state point utility function can evaluate thermodynamic properties of pure substances, mixtures of pure substances and specified components of a mixture.

### 18.10.6. Error Checks

The following error checking is performed for user state point functions:

- Validation of input and output thermodynamic properties.
- Check if output property can be computed from specified input data.
- For fluid mixtures, the following additional checks are performed:
  - Check if fluid is a mixture.
  - Check if specified components are valid mixture components.
  - Check if all mixture components have been specified.
  - Check if specified mass fractions sum up to unity. Mass fractions are assumed to be in the range between 0 and 1 and no clipping is performed if this is not the case. The user specified mass fractions are renormalized in case they do not sum up to unity with a tolerance of 2%.

### 18.10.7. USER\_STATEPT Example 1

The following example shows the usage of the user state point function to calculate the specific heat capacity for various materials. The heat capacity is calculated for a mixture (MyAir) as well as for each component of the mixture (MyAir.N2 Ideal Gas, MyAir.O2 Ideal Gas, MyAir.CO2 Ideal Gas and MyAir.CO2 Const Prop).

The CCL that is required to plot the efficiency in the CFX-Solver Manager is as follows:

```

LIBRARY:
CEL:
FUNCTION: Function 1
Argument Units = [[],[K],[Pa],[],[],[],[ ]]
Option = User Function
Result Units = [J kg^-1 K^-1]

```

```

User Routine Name = User Routine 1
END
EXPRESSIONS:
MyCp1 = Function 1(1,Tave,Pave,N2mf,O2mf,CO2mf,CO2lmf)
MyCp2 = Function 1(2,Tave,Pave,N2mf,O2mf,CO2mf,CO2lmf)
MyCp3 = Function 1(3,Tave,Pave,N2mf,O2mf,CO2mf,CO2lmf)
MyCp4 = Function 1(4,Tave,Pave,N2mf,O2mf,CO2mf,CO2lmf)
MyCp5 = Function 1(5,Tave,Pave,N2mf,O2mf,CO2mf,CO2lmf)
#
A = 0.1 [J kg^-1 K^-2]
MyCp = 1004 [J kg^-1 K^-1] + A*Temperature
CpCO2 = 851 [J kg^-1 K^-1] + A*Temperature
CpO2 = 920 [J kg^-1 K^-1] + A*Temperature
CpN2 = 1040 [J kg^-1 K^-1] + A*Temperature
#
Tave = massFlowAve(Temperature)@Outflow
Pave = massFlowAve(Absolute Pressure)@Outflow
N2mf = massFlowAve(N2 Ideal Gas.Mass Fraction)@Outflow
O2mf = massFlowAve(O2 Ideal Gas.Mass Fraction)@Outflow
CO2mf = massFlowAve(CO2 Ideal Gas.Mass Fraction)@Outflow
CO2lmf = massFlowAve(CO2 Const Prop.Mass Fraction)@Outflow
END
END
USER ROUTINE DEFINITIONS:
USER ROUTINE: User Routine 1
Calling Name = my_test
Library Name = mytest
Library Path = ..
Option = User CEL Function
END
END
FLOW: Flow Analysis 1
OUTPUT CONTROL:
MONITOR OBJECTS:
MONITOR POINT: Monitor Point 1
Expression Value = MyCp1
Option = Expression
END
MONITOR POINT: Monitor Point 2
Expression Value = MyCp2
Option = Expression
END
MONITOR POINT: Monitor Point 3
Expression Value = MyCp3
Option = Expression
END
MONITOR POINT: Monitor Point 4
Expression Value = MyCp4
Option = Expression
END
MONITOR POINT: Monitor Point 5
Expression Value = MyCp5
Option = Expression
END
MONITOR OBJECTS:
MONITOR BALANCES:
Option = Full
END
MONITOR FORCES:
Option = Full
END
MONITOR PARTICLES:
Option = Full
END
MONITOR RESIDUALS:
Option = Full
END
MONITOR TOTALS:
Option = Full
END

```

```

END
RESULTS:
  File Compression Level = Default
  Option = Standard
END
END
END

```

The Fortran source code for this example is given below:

```

#include "cfx5ext.h"
dllexport(my_test)
  SUBROUTINE MY_TEST (
    & NLOC, NRET, NARG, RET, ARGS, CRESLT, CZ,DZ,IZ,LZ,RZ )
CC
CC User routine: template for user CEL function
CC
CC -----
CC           Input
CC -----
CC
CC NLOC   - size of current locale
CC NRET   - number of components in result
CC NARG   - number of arguments in call
CC ARGS() - (NLOC,NARG) argument values
CC
CC -----
CC           Modified
CC -----
CC
CC Stacks possibly.
CC
CC -----
CC           Output
CC -----
CC
CC RET()  - (NLOC,NRET) return values
CC CRESLT - 'GOOD' for success
CC
CC -----
CC           Details
CC -----
CC
CC Template routine for user state point code
CC
CC=====
C
C -----
C           Argument list
C -----
C
C   INTEGER   NLOC,NARG,NRET
C
C   CHARACTER CRESLT*(*)
C
C   REAL      ARGS(NLOC,NARG), RET(NLOC,NRET)
C
C   INTEGER  IZ(*)
C   CHARACTER CZ(*)*(1)
C   DOUBLE PRECISION DZ(*)
C   LOGICAL  LZ(*)
C   REAL    RZ(*)
C
C -----
C           External routines
C -----
C
C   INTEGER  LENACT
C   EXTERNAL LENACT
C
C -----
C           Local Parameters

```

```

C -----
C
C -----
C      Local Variables
C -----
C
C      INTEGER      NPROPIND, NTESTPROP, IMAT, NMAT, IPROP
C      CHARACTER*(80) CPROPCALC, CPROPIND(6)
C
C      REAL          RPROPIND(6)
C
C      CHARACTER*(30) INDPROP(13)
C      CHARACTER*(30) MAT(5)
C
C      DATA INDPROP /'Static Enthalpy','Static Entropy','Cp','Cv',
&                   'Dynamic Viscosity','Density',
&                   'Pressure','Absolute Pressure',
&                   'Temperature','Absolute Temperature',
&                   'Isentropic Compressibility',
&                   'Isothermal Compressibility',
&                   'Local Speed of Sound'/
C
C      DATA MAT      /'MyAir','MyAir.N2 Ideal Gas',
&                   'MyAir.O2 Ideal Gas','MyAir.CO2 Ideal Gas',
&                   'MyAir.CO2 Const Prop'/
C
C -----
C      Stack pointers
C -----
C
C=====
C
C -----
C      Executable Statements
C -----
C
C---- Initialize RET(1:NLOC*NRET) to zero.
C
C      CALL SET_A_0(RET,NLOC*NRET)
C
C-----
C      Setup data required for state point calculation
C-----
C
C      NPROPIND      = 6
C
C      CPROPIND(1) = 'Temperature'
C      CPROPIND(2) = 'Absolute Pressure'
C
C      CPROPIND(3) = 'N2 Ideal Gas.mf'
C      CPROPIND(4) = 'O2 Ideal Gas.mf'
C      CPROPIND(5) = 'CO2 Ideal Gas.mf'
C      CPROPIND(6) = 'CO2 Const Prop.mf'
C
C---- 'Material' number:
C      --> '1': Mixture
C          '2': N2 Ideal Gas
C          '3': O2 Ideal Gas
C          '4': CO2 Ideal Gas
C          '5': CO2 Const Prop
C
C      IMAT = ARGS(NLOC,1)
C
C---- Input values of temperature and absolute pressure
C
C      RPROPIND(1) = ARGS(NLOC,2)
C      RPROPIND(2) = ARGS(NLOC,3)
C
C---- Input values of component mass fractions
C
C      RPROPIND(3) = ARGS(NLOC,4)
C      RPROPIND(4) = ARGS(NLOC,5)

```

```

      RPROPIND(5) = ARGS(NLOC,6)
      RPROPIND(6) = ARGS(NLOC,7)
C
C-----
C   Compute return variable value
C-----
C
C---- Compute Specific Heat capacity (= property '3' in above list)
C
      IPROP = 3
C
      IF (IMAT.GT.1) THEN
          NPROPIND = 2
      ENDIF
C
C---- Create output property name
C
      CPROPCALC = MAT(IMAT)(1:LENACT(MAT(IMAT)))/'. '//
&              INDPROP(IPROP)
      CALL USER_STATEPT(RVALUE,CPROPCALC,CPROPIND,RPROPIND,
&                      NPROPIND,'SKIP',CRESLT, CZ,DZ,IZ,LZ,RZ)
C
C---- Copy output property value to RET(1:NLOC,1).
C   --> NLOC = 1
C
      RET(1,1) = RVALUE
C
      END

```

### 18.10.8. USER\_STATEPT Example 2

Another application of the user state point function could be to calculate the isentropic expansion efficiency of a device. The following example code shows the usage of the `USER_STATEPT` function to accomplish this task. Input arguments for this routine are the mass flow averaged values of total enthalpy ( $H_1$ ) and entropy ( $S_1$ ) at a reference plane 1 as well as the mass flow averaged values of total enthalpy ( $H_2$ ) and total pressure ( $P_2$ ) at a second reference plane, such as an outlet. The isentropic expansion efficiency is defined as:

$$\eta_E = \frac{H_2 - H_1}{H_{S'} - H_1} \quad (18-6)$$

With the isentropic enthalpy,  $H_{S'}$ , being the enthalpy  $h = h(S_1, P_2)$ .

To calculate the isentropic efficiency, the following input data is provided to `USER_STATEPT`:

- Number of independent input properties: 2
- Input property names: `Static Entropy, Pressure`
- Input property values: `S1, P2`
- Output property name: `Air Ideal Gas.Static Enthalpy`

---

#### Note

Even though `P2` holds the value of total pressure, the input property name must be called `Pressure`.

The CCL that is required to plot the efficiency in the CFX-Solver Manager is as follows:

```

LIBRARY:
  USER ROUTINE DEFINITIONS:
    USER ROUTINE: User Routine 1
      Calling Name = my_eff
      Library Name = efficiency
      Library Path = ..
      Option = User CEL Function
    END
  END
  CEL:
    FUNCTION: Function 1
      Argument Units = [J/kg],[J/kg],[J/kg/K],[Pa]
      Option = User Function
      Result Units = []
      User Routine Name = User Routine 1
    END
    EXPRESSIONS:
      H1 = massFlowAve(Total Enthalpy in Stn Frame)@Inflow
      H2 = massFlowAve(Total Enthalpy in Stn Frame)@Outflow
      S1 = massFlowAve(Static Entropy)@Inflow
      P2 = massFlowAve(Total Pressure in Stn Frame)@Outflow
#
      Eff = Function 1(H1,H2,S1,P2)
    END
  END
  END
  FLOW: Flow Analysis 1
    OUTPUT CONTROL:
      MONITOR OBJECTS:
        MONITOR BALANCES:
          Option = Full
        END
        MONITOR FORCES:
          Option = Full
        END
        MONITOR PARTICLES:
          Option = Full
        END
        MONITOR RESIDUALS:
          Option = Full
        END
        MONITOR TOTALS:
          Option = Full
        END
        MONITOR POINT: Eff1
          Option = Expression
          Expression Value = Eff
        END
      END
    RESULTS:
      File Compression Level = Default
      Option = Standard
    END
  END
END

```

The Fortran source code for the expansion efficiency calculation is given below:

```

#include "cfx5ext.h"
dllexport(my_eff)
  SUBROUTINE MY_EFF (
    & NLOC,NRET,NARG,RET,ARGS,CRESLT, CZ,DZ,IZ,LZ,RZ)
  CC
  CD User routine: Compute isentropic efficiency
  CC
  CC -----
  CC      Input
  CC -----
  CC
  CC NLOC   - size of current locale
  CC NRET   - number of components in result
  CC NARG   - number of arguments in call

```

```

CC  ARGS() - (NLOC,NARG) argument values
CC
CC  -----
CC      Modified
CC  -----
CC
CC  Stacks possibly.
CC
CC  -----
CC      Output
CC  -----
CC
CC  RET() - (NLOC,NRET) return values
CC  CRESLT - 'GOOD' for success
CC
CC  -----
CC      Details
CC  -----
CC
CC  Template routine for user state point code
CC
CC=====
C
C  -----
C      Argument list
C  -----
C
C      INTEGER    NLOC,NARG,NRET
C      CHARACTER  CRESLT*(*)
C      REAL       ARGS(NLOC,NARG), RET(NLOC,NRET)
C
C      INTEGER  IZ(*)
C      CHARACTER CZ(*)*(1)
C      DOUBLE PRECISION DZ(*)
C      LOGICAL  LZ(*)
C      REAL    RZ(*)
C
C  -----
C      External routines
C  -----
C
C      Local Parameters
C  -----
C
C      Local Variables
C  -----
C
C      INTEGER      NPROPIND
C      CHARACTER*(80) CPROPCALC, CPROPIND(2)
C
C      REAL         RPROPIND(2), H1, H2, HIS, S1, SN, P2, DHIS, DHLOC,
C      &            ETA_E
C
C  -----
C      Stack pointers
C  -----
C
C=====
C
C  -----
C      Executable Statements
C  -----
C
C---- Initialize RET(1:NLOC*NRET) to zero.
C
C      CALL SET_A_0(RET,NLOC*NRET)
C
C-----
C      Averaged values of inlet total enthalpy, inlet entropy, outlet
C      total enthalpy and outlet total pressure are passed into his

```

```

C    routine.
C    Mass flow averaging is used.
C-----
C
C    H1 = ARGS(NLOC,1)
C    H2 = ARGS(NLOC,2)
C    S1 = ARGS(NLOC,3)
C    P2 = ARGS(NLOC,4)
C
C-----
C    Compute isentropic efficiency
C-----
C
C---- Number of input properties
C
C    NPROPIND    = 2
C
C---- Input properties are entropy and pressure
C
C    CPROPIND(1) = 'Static Entropy'
C    CPROPIND(2) = 'Pressure'
C
C---- Input values are s1 and p2
C
C    RPROPIND(1) = S1
C    RPROPIND(2) = P2
C
C---- Compute isentropic enthalpy, h = h(s1,p2)
C
C    CPROPCALC = 'Air Ideal Gas.Static Enthalpy'
C    CALL USER_STATEPT(HIS,CPROPCALC,CPROPIND,RPROPIND,
C    &                NPROPIND,'SKIP',CRESLT, CZ,DZ,IZ,LZ,RZ)
C
C---- Expansion efficiency
C
C    DHIS = HIS - H1
C    DHLOC = H2 - H1
C
C    IF (DHIS.LT.0.0 .AND.DHLOC.LT.0.0 .AND.DHIS.LT.DHLOC) THEN
C        ETA_E = (H2 - H1)/(HIS - H1 + SN)
C    ELSE
C        ETA_E = 1.0
C    ENDIF
C
C-----
C
C---- Copy output property value to RET(1:NLOC,1).
C    --> NLOC = 1
C
C    RET(1,1) = ETA_E
C
C---- Set success flag.
C
C    CRESLT = 'GOOD'
C
C-----
C    END

```

## 18.11. Calculating the Particle Drag Coefficient

The User Defined option enables you to use a User Fortran subroutine to calculate the particle drag coefficient. A particle user routine example is presented later in this section.

To use a particle user routine, you should first write the Fortran routine and create a shared library. Next, you should create a User Routine of type Particle User Routine in CFX-Pre. When defining the domain, particle user sources are enabled by selecting the **Particle User Source** check box for the appropriate quantity, then selecting the routine from the drop-down list. For details, see [Creating the Shared Libraries](#) (p. 491) and [Particle User Routines in the CFX-Pre User's Guide](#).

The Argument Variables list should contain the fluid and particle variables needed to calculate the source (help on how to use variable names in CFX, as well as a list of all variables, can be found in the VARIABLES file, in the /etc/ directory of your CFX installation). The Return Variables list allows you to return only the Particle Drag Coefficient.

# Index

## Symbols

1:1 domain interface type, 169

## A

abort, 488  
Additional Variables, 23  
  definition, 19  
  in multiphase flow, 210  
  kinematic diffusivity, 23  
  multiphase flow, 212  
  permeate walls, 81  
  sources, 32  
  specification - inlet, 69  
  specification - opening, 81  
  specification - outlet, 78  
  specification - wall, 88  
  tensor type, 26  
  turbulent flux closure, 24  
  units, 24  
  unspecified, 25  
advection scheme  
  CDS blending, 434  
  central difference, 435  
  first order, 434  
  second order high resolution, 434  
  selection, 434  
  specify blend factor, 435  
algebraic equation, 19  
algebraic slip, 21  
algebraic slip model, 235  
allow cbck for initcon, 474  
always output post processing, 472  
apply ic fluctuations for les, 476  
ARGS  
  in User Fortran, 485  
Arrhenius reactions  
  rate type, 301  
  with Temperature PDF reaction type, 301  
auto timescale, 425  
auto turnoff solve eq flag, 474  
autoignition model, 329  
automatic connections, 169  
automatic near-wall treatment, 150

## B

backup file at start, 472  
backup file at zero, 472  
blackbody temperature, 347

blend factor, 435  
  first order, 434  
  second order high resolution, 434  
boundary condition  
  mixed subsonic-supersonic inlet, 71  
boundary conditions, 59  
  degassing, 77  
  inlet, 64  
  opening, 78  
  outlet, 73  
  outlet - supersonic, 78  
  profile, 89  
  recommended types, 60  
  supersonic inlet, 70  
  symmetry plane, 88  
  wall, 81  
bounded bnd diffusion tets, 465  
BSL k-omega turbulence model, 127  
build artificial wall, 466  
buoyancy, 12  
  Boussinesq model, 13  
  full buoyancy model, 13  
  in multiphase flows, 197  
  reference temperature, 14

## C

case conversion of characters, 523  
catalogue size, 526, 528, 534  
cavitation  
  modeling information, 218  
  Rayleigh Plesset model, 219  
CEL  
  interaction with CFX-Solver, 446  
CEL (CFX expression language)  
  user functions, 484  
central difference advection scheme, 435  
CFX-RIF, 319  
CFX-Solver Manager  
  expert control parameters, 465  
  parallel processing, 449  
cfx5mkext, 491  
  -double option gives double precision, 492  
  Linux requires the Portland compiler, 492  
character strings  
  managing lists of, 539  
check isolated regions, 474  
chemistry post-processing , 333  
cht diffusion scheme, 466  
coal combustion, 289  
Coanda effect, 88  
coefficient of thermal expansion, 47  
collision

- of particles, 248
- combined eddy dissipation and finite rate chemistry model, 308
- combustion
  - autoignition model, 329
  - combined eddy dissipation and finite rate chemistry model, 308
  - ecfm, 314
  - eddy dissipation model, 304
  - extended coherent flame model, 314
  - finite rate chemistry model, 306
  - introduction to, 299
  - laminar flamelet model, 309
  - modelling, 299
  - modelling advice, 336
  - NO model, 330
  - premixed and partially premixed model, 311
  - reaction step specific, 309
  - residual material model, 317
  - soot model, 334
- component
  - definition, 18
  - sources, 32
- compressibility, 10
- compressible flow, 10
- conditional connection control
  - modeling, 171
- conditional connections
  - modeling, 171
- conjugate heat transfer, 10
- conservation target, 441
- constraint equation, 19
- contact angle, 233
- convergence
  - solving problems of, 441
- convergence control
  - maximum number of iterations, 424
- convergence criteria, 439
- convergence rate, 441
- coordinate frame
  - overview, 29
  - rotating frame of reference (RFR), 30
- counter-rotating, 83
- coupled partitioning
  - applies only to domains of the same physical type, 451
- coupled scalars, 476
- coupling
  - four-way, 248
- curvature correction, 128

## D

- data area names, 527
- degassing boundary condition, 77
- degeneracy check tolerance, 466
- delete backup files , 472
- dense gas-particle flows, 248
- density
  - dependencies, 43
- density difference buoyancy model, 13
- DES model, 142
- Detached Eddy Simulation (DES) model, 142
- diffusion at inlets, 466
- direct domain interface type, 169
- discrete transfer radiation model, 344
- discretization
  - see discretization, 232
- discretization options, 232
- disperse phase, 194
- domain
  - rotation and particle injection regions, 269
- domain interface modelling, 157
- domain interfaces
  - 1:1 connections, 169
  - automatic connections, 169
  - connection types, 168
  - defining as thin surfaces, 172
  - direct connections, 169
  - frame change, 161
  - GGI connections, 170
  - one-to-one connections, 169
  - overview, 157
  - periodic, 159
  - pitch change, 164
  - using multiple interfaces, 173
- domain temperature, 9
- domains
  - overview, 2
- drag
  - interphase (Gidaspow drag model), 199
  - interphase (Grace drag model), 200
  - interphase (Ishii-Zuber drag model), 199–200
  - interphase (mixture model), 201
  - interphase (Wen Yu drag model), 199
- dynamic viscosity, 44
- dynamical time, 427

## E

- ecfm, 314
- eddy dissipation and finite rate chemistry combined model, 308
- eddy dissipation model, 304
- efficiency calculation, 49

energy  
 sources, 32

energy equation  
 multiphase flow  
 multifluid model, 204

equations of state, 38

equilibrium phase change model, 369

erosion, 245

Euken  
 modified Euken model, 46

Eulerian-Eulerian model, 190

expert control parameters  
 CFX-Solver, 465  
 convergence control, 474  
 discretization, 465  
 I/O control, 472  
 linear solver, 470  
 modifying, 465  
 over-rides, 480  
 particle tracking, 478  
 physical models, 476  
 usage, 465

expert parameters, 465 (see expert control parameters)

explicit algebraic Reynolds Stress model, 130

expressions  
 using with initial conditions, 97

extended coherent flame model, 314

**F**

field char oxidation model, 290

field model, 290

finite rate chemistry and eddy dissipation combined model, 308

finite rate chemistry model, 306

finite slip, 83

Finnie erosion model, 245

first order backward Euler transient scheme, 433

flamelet libraries, 319

flow direction, 66

flow modeling  
 advice on, 419

fluid  
 definition, 19  
 properties - dynamic viscosity, 44  
 properties - molar mass, 40, 49  
 properties - thermal conductivity, 45  
 properties - thermal expansivity, 47

fluid properties  
 fluid type - ideal gas, 39  
 fluid type - ideal mixture, 19

force intersection, 477

Fortran  
 junction box routines, 486

four-way coupling, 248

frame  
 of reference - particle injection regions, 269

frame change interface, 161

free slip, 83

free stream damping, 467

free surface  
 flow, 230  
 modelling advice, 233

frozen rotor frame change model, 161

functions  
 user CEL - Fortran, 484

**G**

GGI, 157

GGI interface type, 170

ggi vertex weighting value, 477

Gibb model, 290

Gibb oxidation model, 290

Gidaspow drag model, 199

global coordinate frame, 29

global dynamic model control, 436

Grace drag model, 200

gray model, 351

**H**

heat transfer, 9  
 at walls, 84  
 coefficient, 211

heat transfer specification  
 inlet, 68  
 opening, 80  
 outlet, 78  
 wall - heat transfer, 85

high resolution transient scheme, 434

highres energy option, 469

homogeneous multiphase model, 196

**I**

ideal gas, 39

ideal mixture, 19

ignore solve flag on restart, 474

imbalance normalisation type, 474

imbalance normalization type, 474 (see imbalance normalisation type)

immersed solids, 14

include pref in forces, 472

inhomogeneous model, 195

initial conditions  
 automatic, 96

- automatic with value, 97
- reading from a file, 107
- setting, 96
- initial guess
  - reading from a file, 107
- initial time, 432
- initialization
  - parameters, 97
  - recommended, 97
- inlet, 64
  - boundary conditions, 64
  - heat transfer, 68
- inlet boundary condition
  - mixed subsonic-supersonic, 71
  - supersonic, 70
- interfluid transfer model, 195
- interp single phase treatment, 477
- interphase mass transfer, 212
- interphase species mass transfer, 220
- ipmt area density clip, 470
- Ishii-Zuber drag model, 199–200
- isothermal model, 9

**J**

- junction box location, 487
- junction box routines, 486

**K**

- k-epsilon turbulence model
  - turbulence model - k-epsilon, 127
- k-omega turbulence model, 127
- kinematic diffusivity, 23
- kinematic diffusivity and bulk viscosity, 22

**L**

- laminar flamelet model, 309
- laminar flow
  - turbulence model - laminar flow, 126
- laplacian stresses, 467
- Large Eddy Simulation (LES), 137
- length scale, 425
- LES, 137
- library materials, 47
- library path, 487
- lift force, 201
- linear solver failure, 445
- linearly exact numerics, 468
- liquid evaporation model, 254
- local coordinate frame, 29
- local timescale factor, 426

**M**

- Magnussen soot model, 334
- Marangoni effect, 232
- mass and momentum specification
  - inlet, 64
  - inlet - supersonic, 70
  - opening, 78
  - outlet, 73
- mass flow inlet
  - in multiphase, 228
  - multiphase, 228
- mass flow outlet
  - in multiphase, 228
  - multiphase, 228
- mass fraction
  - algebraic equation, 19
  - constraint equation, 19
  - definition, 306
  - sources, 32
- mass source
  - multiphase, 198
- mass transfer
  - user specified, 213
- master process, 449
- material properties, 38, 48
- max continuity loops, 475
- maximum number of iterations, 424
- maximum number of timesteps, 430
- maximum residual, 439
- maximum timescale, 426
- mcf concentrations output option, 472
- Memory Management System (MMS)
  - calling name, 487
  - catalogue size, 526
  - CERACT, 527
  - Character strings - managing lists, 539
  - CHDIR, 530
  - CHMDIR, 530
  - COPDAT, 536
  - COPDIR, 537
  - CRESLT, 527
  - data area names, 527
  - data areas - copying, 536
  - data areas - creating, 533
  - data areas - deleting, 535
  - data areas - deleting links, 536
  - data areas - linking, 536
  - data areas - listing, 531
  - data areas - locating, 535
  - data areas - reading values, 539
  - data areas - renaming, 536
  - data areas - resizing, 535

---

- data areas - setting values, 537
- data areas - shrinking, 535
- DELDAT, 535
- DELDIR, 530
- DELLNK, 536
- directories (memory management), 527
- directories (memory management) - copying, 537
- directories (memory management) - listing, 531
- error conventions, 527
- GETMMS, 540
- LISDAT, 531
- LOCDAT, 535
- MAKDAT, 533–534
- MAKDIR, 529
- MAKLNK, 536
- NAMLST, 539
- NARG, 485
- PEEKCA, 538
- PEEKCS, 538
- PEEKD, 538
- PEEKI, 538
- PEEKL, 538
- PEEKR, 538
- POKECS, 537
- POKEDA, 537
- POKEI, 537
- POKEL, 537
- POKER, 537
- Poking values, 537
- POPDIR, 531
- PSHDIR, 530
- PUTDIR, 531
- RENAME, 536
- RESIZE, 535
- routines, 526
- SKIP, 527
- SQZDAT, 534
- STOP, 527
- USER\_GETVAR, 498
- WARN, 527
- WSTAT, 542
- mesh aspect ratio, 423
- mesh connection recommendations, 171
- mesh deformation, 3
  - junction box routine, 8
  - regions of motion specified, 4
  - specified displacement, 7
  - specified location, 7
- mesh expansion, 422
- mesh generation
  - guidelines, 153
- mesh motion
  - boundary conditions, 87
  - mesh orthogonality, 420
  - mesh quality
    - measures of, 420
  - mesh resolution near the wall, 420
  - meshdisp diffusion scheme, 467
  - mfloip to trn files, 473
  - MFR, 157
  - mg solver option, 470
  - mixture drag model, 201
  - model coefficient relaxation, 475
  - modeling flow
    - advice on, 419
  - modelling
    - buoyant flow, 12
    - combustion, 299
    - flow near the wall, 148
    - Non-Newtonian flow, 26
  - molar mass, 40, 49
  - monitor digits, 473
  - monitor ftrans, 473
  - monitor ranges, 473
  - monitor scales, 473
  - Monte Carlo radiation model, 345
  - morphology, 194
  - mpf ggi force flow balance, 477
  - multiband model, 351
  - multicomponent flow, 18
    - boundary conditions, 22
    - example, 19
    - examples, 191
    - multiphase, 198
    - restrictions, 236
    - terminology, 18
  - multicomponent fluid
    - definition, 18
  - multigray model, 351
  - multigrid solver, 471
  - multiphase
    - convergence advice, 230
    - free surface, 230
    - initial conditions, 229
    - mass flow inlet, 228
    - mass flow outlet, 228
    - minimum volume fraction setting, 229
    - modelling advice, 229
    - timestep settings, 230
    - turbulence modelling tips, 229
  - multiphase flow, 189
    - boundary conditions, 225
    - buoyancy, 197
    - definition, 190

- examples, 191
- homogeneous Additional Variables, 212
- interfluid transfer model, 195
- interphase drag, 198
- interphase drag models - drag coefficient, 198
- interphase drag models - Gidaspow drag model, 199
- interphase drag models - Grace drag model, 200
- interphase drag models - Ishii-Zuber drag model, 199–200
- interphase drag models - mixture model, 201
- interphase drag models - Schiller-Naumann drag model, 199
- interphase drag models - Wen Yu drag model, 199
- interphase heat transfer models - heat transfer coefficient, 206, 211
- interphase heat transfer models - Hughmark Correlation, 205, 211
- interphase heat transfer models - Nusselt number, 206, 211
- interphase heat transfer models - Ranz-Marshall Correlation, 205, 211
- interphase transfer, 198
- lift force, 201
- mixture model, 198
- morphology, 194
- morphology - disperse phase, 194
- morphology - polydispersed, 194
- multicomponent multiphase flow, 198
- particle model, 198
- restrictions, 236
- terminology, 190
- turbulence, 209
- multiphase reactions, 289
- multiple size group (MUSIG) model, 207
- MUSIG model, 207

## N

- NO model, 330
- no slip, 82
- noise analysis, 407
- Non-Newtonian flow, 26
- non-wetting wall, 233
- normalized log residual, 441
- normalized residual, 439
- number of timesteps per run, 430

## O

- one-to-one domain interface type, 169
- outer loop relaxations default, 475
- outlet, 73
- overlap relaxation fluids, 471

## P

- P1 radiation model, 343
- parallel
  - visualizing mesh partitions, 463
- parallel processing
  - advice on running in parallel, 458
  - error correction, 459
  - introduction, 449
  - memory efficiency, 462
  - solver, 449
  - wall clock performance, 461
- Parallel Virtual Machine (PVM), 449
- part cvs weighting, 477
- particle
  - source control, 283
- particle collision model, 248
- particle collisions, 248
- particle diagnostics
  - penetration diagnostics, 273
  - transient particle diagnostics, 273
- particle drag coefficient
  - calculating with User Fortran, 583
- particle injection in rotating frames, 269
- particle injection regions, 268
  - in rotating frames, 269
- particle number rate, 263
- particle transport
  - boundary options, 260
  - creating materials, 239
  - domain options, 239
  - liquid evaporation model, 254
  - particle user sources, 256
  - solver control, 279
  - wall boundary settings, 264
- particle user sources, 256
- partitioning, 449
  - methods - recursive coordinate bisection, 451
- partitioning methods
  - circumferential, 454
  - directional recursive coordinate bisection, 453
  - MeTiS, 451
  - optimized recursive coordinate bisection, 452
  - radial, 453
  - user-specified direction, 452
- path names, 527
- PEEKing values, 539
- periodic domain interfaces, 159
- physical models, 2
  - Additional Variables, 23
  - Additional Variables - units, 24
  - heat transfer, 9
- physical timescale, 426

buoyant flows, 427  
 selection, 427  
**PIR**  
   see also particle injection regions, 268  
 pitch change in domain interfaces, 164  
 pointers  
   to stacks, 529  
 polydispersed, 194  
 polydispersed fluid model, 207  
 porosity  
   multiplying sources by, 38  
 porous cs discretisation option, 467  
 porous momentum losses  
   modeling, 33  
 positive and negative domain source totals, 440  
 premixed and partially premixed combustion model, 311  
 pressure diffusion scheme, 468  
 profile, 89  
 profile boundary conditions  
   extracting data from results files, 93  
   interpolation method, 93  
 pt distribute trans particles, 478  
 pt extrap vel for integ, 478  
 pt fluid var interpolation option, 480  
 pt linear src coef multiplier, 479  
 pt maximum particle temperature, 479  
 pt minimum diameter, 479  
 pt minimum eddy life time, 479  
 pt time interpolation, 479  
 pt tracks in absolute frame, 479  
 pt zone specific tracks, 479  
 PVM (Parallel Virtual Machine), 449

**R**  
 radiation  
   blackbody temperature, 347  
   comparison of models, 340  
   discrete transfer model, 344  
   general considerations, 346  
   introduction, 339  
   Monte Carlo model, 345  
   P1 model, 343  
   Rosseland model, 342  
   scattering model, 352  
   sources, 348  
   spectral model, 351  
   terminology, 341  
   theory, 339  
   thermal radiation control, 349  
 radiation properties, 46  
 Rayleigh Plesset model for cavitation, 219  
 reaction step specific combustion, 309  
 real fluids, 361  
   gas data tables, 375  
   real gas model parameters, 386  
   real gas property (RGP) file, 378  
   using a general setup, 373  
   using in ANSYS CFX, 362, 371  
 real gas model parameters, 386  
 real partition number, 463  
 Redlich Kwong equation of state, 362  
 reference  
   coordinate frame, 29  
   rotating frame and particle injection regions, 269  
 reference density  
   for multiphase flows, 197  
 reference pressure  
   setting, 11  
 relax mass, 475  
 require coefloop convergence, 475  
 residual  
   a measure of local imbalance, 439  
 residual material model, 317  
 residual target, 439  
 residual type, 439  
 Reynolds stress turbulence model, 128  
 RFR (rotating frame of reference), 30  
   particle injection regions, 269  
   see also rotating frame of reference, 269  
 RGP file, 378  
**RIF**  
   interaction tool, 322  
 rigid body  
   modeling, 355  
 rms residual, 439  
 Rosseland radiation model, 342  
 rotating, 83  
 rotating frame of reference (RFR), 30  
   for particle injection regions, 269  
 rough walls, 152

**S**  
**SAS**  
   SAS turbulence model, 146, 148  
 scalable wall functions, 148  
 scalar diffusion scheme, 468  
 Sear Stress Transport turbulence model, 127  
 second order backward Euler transient scheme, 433  
 second order high resolution, 434  
 separated flow, 424  
 shared libraries, 491  
 slave process  
   parallel solver , 449

- solid
    - side heat transfer coefficient, 85
  - solid domain, 59
  - solid timescale control, 428
  - solve emag, 480
  - solve energy, 480
  - solve fluids, 481
  - solve fsd, 481
  - solve masfrc, 481
  - solve mixture fraction, 481
  - solve particles, 480
  - solve postproc masfrc, 481
  - solve postproc tvariance, 481
  - solve radiation, 481
  - solve reaction progress, 482
  - solve scalar, 482
  - solve soot, 482
  - solve temperature variance, 482
  - solve turbulence, 482
  - solve volfrc, 482
  - solve wallscale, 482
  - Solver
    - accuracy, 445
    - issues with, 445
    - robustness, 445
  - solver relaxation fluids, 471
  - solver relaxation scalar, 471
  - solver target reduction fluids, 471
  - solver target reduction scalar, 471
  - Solver Yplus, 152
  - Sommerfeld collision model, 248
  - soot model, 334
  - source coefficient, 33
  - sources
    - locators for, 31
    - optional terms for equations, 31
    - radiation, 348
  - specific heat capacity
    - dependencies, 43
  - specified displacement, 7
  - specified location, 7
  - specified shear, 83
  - specify blend, 435
  - spectral model, 351
    - gray model, 351
    - multiband model, 351
    - multigray model, 351
  - SPMD model, 449
  - SST k-omega turbulence model, 127
  - SST turbulence model, 127
  - stack pointers, 529
  - stacks, 485, 526
    - utilization, 540, 542
  - stage frame change model, 162
  - standard temperature and pressure (STP), 47
  - steady state simulations, 3
  - stochastic model, 248
  - STP (standard temperature and pressure), 47
  - stress diffusion scheme, 468
  - subdomain
    - energy sources, 10
    - momentum sources, 34
  - subroutines
    - junction boxes, 486
    - user CEL functions, 484
  - subsonic flow, 10
  - supersonic flow, 10
    - compressible flow, 10
  - surface tension
    - in free surface flows, 231
  - symmetry plane, 88
- ## T
- Tabakoff erosion model, 246
  - tangential vector tolerance, 468
  - tbulk for htc, 469
  - tef numerics option, 478
  - tensor type
    - of Additional Variable, 26
  - thermal conductivity, 45
  - thermal energy model, 9
  - thermal expansivity, 47
  - thermal phase change model, 213
  - thermal radiation
    - modeling, 339
  - thin surfaces
    - allowed interface types, 172
    - defining domain interfaces as, 172
    - overview, 172
  - time per run, 429
  - timescale
    - advection flows, 427
    - steady state, 424
  - timescale control, 425
  - timestep
    - adaptive timestepping, 431
    - duration of transient problems, 429
    - size for transient problems, 430
    - transient, 429
  - timestep control, 429
  - timestep initialization, 434
  - topology estimate factor, 475
  - topology estimate factor zif, 476
  - total energy model, 9

total time, 429

transient blade row  
  modeling, 179

transient flow, 3

transient initialisation override, 473

transient initialization override, 473 (see transient initialisation override)

transient rotor-stator  
  frame change, 163

transient simulations  
  coefficient iterations, 430  
  timestep - adaptive, 431  
  timestep - duration, 429  
  timestep - size, 430

transonic flow, 10

transport equation  
  multicomponent fluid - definition, 19

turbo/mixing model, 161

turbulence, 126  
  sources, 32

turbulence model  
  BSL k-omega, 127  
  BSL Reynolds Stress, 130  
  curvature correction, 128  
  DES, 142  
  explicit algebraic Reynolds Stress model, 130  
  k-omega, 127  
  LES, 137  
  Reynolds Stress, 128  
  Reynolds stress - anisotropic turbulent diffusion, 129  
  rng k-epsilon turbulence model, 127  
  SAS, 146  
  SST k-omega, 127  
  transition, 130  
  w-Reynolds Stress, 130  
  zero equation, 126

turbulence models, 126  
  SAS, 148

turbulence specification  
  Inlet, 66  
  opening, 80  
  outlet, 78

turbulent flux closure, 10, 22, 24

turbulent wall functions, 148

**U**

use kolmogorov ts for extinction, 478

User Fortran  
  abort, 488  
  calculating the particle drag coefficient, 583  
  end of coefficient loop, 488  
  end of linear solution, 488  
  end of partitioning, 487  
  end of rigid body solution, 488  
  end of run, 487  
  end of time step, 487  
  first call, 487  
  first call partitioning, 487  
  junction box examples, 550  
  memory management system, 526  
  NLOC, 485  
  NRET, 485  
  RET, 485  
  start of coefficient loop, 487  
  start of linear solution, 488  
  start of partitioning, 487  
  start of rigid body solution, 488  
  start of run, 487  
  start of time step, 487  
  state point evaluation, 572  
  user CEL examples, 542  
  user input start of coefficient loop, 488  
  user input start of time step, 487  
  using CFX-4 routines in ANSYS CFX, 570  
  utility routines, 497

user functions  
  CEL, 484

user specified mass transfer, 213

user subroutines, 483  
  junction boxes, 486

**V**

variables  
  written to results file, 85

vector parallel tolerance, 469

viscosity  
  dynamic, 44

volfrc sumapp, 470

**W**

wall, 81  
  counter-rotating, 83  
  finite slip, 83  
  free slip, 83  
  heat transfer, 84  
  mass and momentum, 81  
  no slip, 82  
  rotating, 83  
  specified shear, 83

wall adhesion, 233

wall boiling model  
  using, 214

wall clock time, 473–474

wall functions, 148

wall roughness specification  
  wall, 84  
wallscale diffusion scheme, 470  
wallscale relaxation factor, 478  
Wen Yu drag model, 199  
wetting wall, 233

## **Y**

Yplus, 152

## **Z**

zero equation turbulence model, 126