

Case / Comp	Combination case name																		
			DL1	LL1	LL2	LL3	LL4	LL5	LL6	SHIP1_Up	SHIP1_DOWN	SEIs_X	SEIs_Y	SHIP2_DOWN	VANTRYKK				
			1	2	3	4	5	6	7	8	9	48	49	54	78				
Nominal loads	Type																		
100	ULS B1	ULS	1,35	1,05															1,05
101	ULS B1	ULS	1,35		1,05	1,05													1,05
102	ULS B1	ULS	1,35				1,05												1,05
103	ULS B1	ULS	1,35					1,05											1,05
104	ULS B1	ULS	1,35						1,05										1,05
105	ULS B1	ULS	1,35							1,05	1,05								1,05
106	ULS B1	ULS	1,35											1,05					1,05
107	ULS B2	ULS	1,20	1,50															1,05
108	ULS B2	ULS	1,20		1,5	1,5													1,05
109	ULS B2	ULS	1,20				1,5												1,05
110	ULS B2	ULS	1,20					1,5											1,05
111	ULS B2	ULS	1,20						1,5										1,05
112	ULS B2	ULS	1,20							1,5	1,5								1,05
113	ULS B2	ULS	1,20												1,5				1,05
114	ULS B2	ULS	1,20	1,05															1,50
115	ULS B2	ULS	1,20		1,05	1,05													1,50
116	ULS B2	ULS	1,20				1,05												1,50
117	ULS B2	ULS	1,20					1,05											1,50
118	ULS B2	ULS	1,20						1,05										1,50
119	ULS B2	ULS	1,20							1,05	1,05								1,50
120	ULS B2	ULS	1,20											1,05					1,50
121	SLS	SLS	1,00	1															1,00
122	SLS	SLS	1,00		1	1													1,00
123	SLS	SLS	1,00				1												1,00
124	SLS	SLS	1,00					1											1,00
125	SLS	SLS	1,00						1										1,00
126	SLS	SLS	1,00							1	1								1,00
127	SLS	SLS	1,00											1					1,00
128	ALS	ALS	1,00	0,5															0,00
129	ALS	ALS	1,00		0,7	0,7													0,00
130	ALS	ALS	1,00				0,5												0,00
131	ALS	ALS	1,00					0,5											0,00
132	ALS	ALS	1,00						0,5										0,00
133	ALS	ALS	1,00							0	0								0,00
134	ALS	ALS	1,00											0					0,00
135	ALS (tap av søyle)	ALS	1,00	0,3															0,00
136	ALS (tap av søyle)	ALS	1,00		0,6	0,6													0,00
137	ALS (tap av søyle)	ALS	1,00				0,3												0,00
138	ALS (tap av søyle)	ALS	1,00					0,3											0,00
139	ALS (tap av søyle)	ALS	1,00						0,3										0,00
140	ALS (tap av søyle)	ALS	1,00							0	0								0,00
141	ALS (tap av søyle)	ALS	1,00											0					0,00